



Uploading code to ESP8266

Uploading code to your ESP-8266 NodeMCU Kit is very simple, since it has a built-in programmer. You just plug your board to the computer and do not need to make any additional connections.

Look at the Tools menu, select Board "NodeMCU 1.0 (ESP-12E Module)" and all the configurations, by default, should look like this:



Important: Your COM port is very likely to be different from the preceding screenshot (Port: "COM6"). That's fine, because it doesn't interfere with anything. On the other hand, all the other configurations should look exactly the same.



After checking the configurations, click the “Upload Button” in the Arduino IDE and wait for a few seconds until you see the message “Done uploading.” in the bottom left corner.