Comprehensive Engineering Architecture for DC Fast Charger Controllers and Power Electronics

Electric vehicle (EV) charging infrastructure relies on a tightly integrated matrix of embedded hardware, real-time power electronics, and standardized digital communication stacks. In DC fast charging, classified under IEC 61851-1 as Mode 4 charging, the primary power conversion process is offloaded entirely from the vehicle's onboard charger to an external Electric Vehicle Supply Equipment (EVSE) station[1]. This architectural shift mandates continuous, high-speed coordination between the vehicle's Battery Management System (BMS) and the charger controller (Supply Equipment Communication Controller, or SECC)[1]. The controller must manage high-voltage DC delivery across wide operating ranges while maintaining galvanic isolation, supervising physical interlocks, and executing fault mitigations within strict timing windows[1].

1. Physical Layer Analog Signaling and Physical Interfaces

Before high-level digital data exchange can commence, the EVSE and EV establish physical connection integrity, verify cable current capacities, and confirm operational readiness using low-voltage analog signaling over the Control Pilot (CP) and Proximity Pilot (PP) contacts[4].

IEC 61851-1 Control Pilot Signaling Mechanics

The Control Pilot circuit functions as a low-voltage analog handshake and emergency interlock layer[8]. The EVSE generates a $1\ \text{kHz}$, $\pm 12\ \text{V}$ pulse-width modulated (PWM) square wave referenced to Protective Earth (PE)[9]. The signal driver inside the EVSE feeds the CP pin through a $1.00\ \text{k}\Omega$ ($\pm 1\%$ precision) series resistor (R_{EVSE})[5]. On the vehicle side, the Charge Control Unit modifies the positive peak voltage of the CP waveform by connecting defined resistive loads (R_2 and R_3) between the CP line and PE[5].

State	Nominal CP Voltage (VCP)	PWM Duty Cycle	EV Load Resistor (REV)	System Operational Condition
State A	$+12\ \text{V DC}$ (Static)	100% High	Open Circuit (∞)	Standby; EV disconnected; EVSE power output

				disabled[5].
State B	$+9\ \text{V}$ Peak / $-12\ \text{V}$ Low	3% _ 97% ($1\ \text{kHz}$)	$R_2 =$	EV connected; not ready for power; HLC stack initializing[5].
State C	$+6\ \text{V}$ Peak / $-12\ \text{V}$ Low	3% _ 97% ($1\ \text{kHz}$)	$R_2 \parallel R_3 =$ ($R_3 =$)	EV ready; power delivery permitted; standard non-ventilated area[5].
State D	$+3\ \text{V}$ Peak / $-12\ \text{V}$ Low	3% _ 97% ($1\ \text{kHz}$)	$R_2 \parallel R_3 =$ ($R_3 =$)	EV ready; power delivery permitted; enclosure ventilation required[5].
State E	$0\ \text{V}$	N/A	N/A	Error state; pilot short to PE or EVSE internal power loss[5].
State F	$-12\ \text{V}$ Static	N/A	N/A	Fault state; EVSE pilot driver hardware failure or broken PE line[11].

The nominal DC voltage levels are evaluated during the positive half-cycle of the PWM waveform with an allowable operational tolerance of $\pm 1.0\ \text{V}$ [11]. In DC fast charging configurations, the EVSE holds the PWM duty cycle at a fixed value between 3% and 7% (typically 5%)[5]. This specific duty cycle signals to the EV that standard AC PWM current encoding is bypassed, and High-Level Communication (HLC) via ISO 15118 or DIN SPEC

70121 is mandatory over the CP line before high-voltage output contactors are permitted to close[4].

Proximity Pilot Resistance Decoding and Ampacity Limits

The Proximity Pilot (PP) circuit serves as a localized hardware interlock within the cable assembly and connector plug[8]. It prevents cable overheating by encoding the thermal current capacity of the tethered assembly and provides a mechanism to prevent disconnects under load[8]. A pull-up voltage source inside the vehicle or charger feeds the PP contact, forming a voltage divider with a coding resistor (R_{PP}) embedded directly within the molded connector plug[8].

Cable Current Capacity	PP Resistor Value (RPP)	Resistor Tolerance	Mechanical Interlock & Thermal Function
13 A / 16 A	$680\ \Omega$	$\pm 3\%$	Caps current allocation; standard for uncooled light-duty cables[7].
20 A / 32 A	$220\ \Omega$	$\pm 3\%$	Standard threshold for uncooled medium-duty liquid/air cables[7].
63 A / 70 A	$100\ \Omega$	$\pm 3\%$	Heavy-duty liquid-cooled cable interface rating[7].
Unlatched / Open	$>$	N/A	Triggered when connector release latch is pressed; stops current flow[8].

When a user depresses the mechanical latch button on the charging handle to disconnect from the vehicle, an internal S3 switch opens or inserts an auxiliary resistance into the PP loop[8]. The vehicle's Analog-to-Digital Converter (ADC) senses this shift within milliseconds and commands the charger controller to ramp output current to zero[8]. This fast ramp-down occurs before the main power contacts physically separate, suppressing electrical arcing across the high-voltage pins[8].

Analog Front-End (AFE) Hardware Circuit Design

To translate the bipolar $\pm 12\ \mathrm{V}$ CP signal into voltage levels compatible with $3.3\ \mathrm{V}$ microcontrollers, the charger controller incorporates a dedicated Analog Front-End (AFE) circuit[5]. The driver stage employs a push-pull op-amp network powered from isolated $\pm 15\ \mathrm{V}$ auxiliary rails, outputting the $1\ \mathrm{kHz}$ square wave through a $1.00\ \mathrm{k\Omega}$ metal-film precision resistor[5].

The feedback path uses a precision resistor divider coupled with low-noise operational amplifiers configured as unity-gain buffers. This scales the $-12\ \mathrm{V}$ to $+12\ \mathrm{V}$ range into a unipolar $0\ \mathrm{V}$ to $3.3\ \mathrm{V}$ signal fed to a microcontroller ADC channel and window comparators. These hardware window comparators utilize precision reference voltages to monitor upper and lower voltage limits continuously. If the CP voltage drops into State E ($0\ \mathrm{V}$) or State F ($-12\ \mathrm{V}$), the comparators trigger high-priority hardware interrupts that bypass software polling loops to instantly disable the gate drivers[11]. Transient Voltage Suppression (TVS) diodes and gas discharge tubes are placed at the CP/PP input terminals to absorb electrostatic discharge ($\geq \pm 8\ \mathrm{kV}$ contact) and surge transients before they reach the control electronics.

2. High-Level Digital Communication Architecture and Protocol Stack

High-Level Communication (HLC) allows the EV and EVSE to negotiate dynamic charging profiles, transfer battery diagnostics, perform cryptographic authentication, and coordinate real-time voltage and current setpoints[1].

Power Line Communication (PLC) Hardware Stack

In Combined Charging System (CCS) architectures, HLC utilizes Power Line Communication (PLC) based on the HomePlug Green PHY (HPGP) specification[4]. The digital network layer is modulated directly onto the analog CP conductor using Orthogonal Frequency Division Multiplexing (OFDM) across the $2\ \mathrm{MHz}$ to $30\ \mathrm{MHz}$ frequency spectrum[13].

The physical interface relies on specialized PLC modems, such as the AEC-Q100 qualified Qualcomm QCA7006AQ or QCA7000[13]. The modem links to the central Supply Equipment Communication Controller (SECC) via a high-speed Serial Peripheral Interface (SPI) or Media Independent Interface (MII)[13]. To isolate the low-amplitude high-frequency PLC signal (roughly $1\ \mathrm{V}_{pp}$) from the $1\ \mathrm{kHz}, \pm 12\ \mathrm{V}$ PWM pilot signal and high-voltage transients, a passive coupling network is inserted between the modem and the CP pin.

This coupling network consists of a high-pass LC filter chain and an RF isolation transformer. High-voltage ceramic capacitors ($10\ \mathrm{nF}$ to $47\ \mathrm{nF}$, rated to $2\ \mathrm{kV}$) block the low-frequency $1\ \mathrm{kHz}$ PWM signal and DC offsets. The RF ferrite-core transformer provides galvanic

isolation and matches the $50\ \Omega$ unbalanced single-ended modem interface to the differential transmission impedance of the CP/PE line. Bandpass filtering attenuates frequencies below $1.8\ \mathrm{MHz}$ to reject PWM harmonics and suppresses frequencies above $30\ \mathrm{MHz}$ to prevent high-frequency switching noise generated by adjacent power conversion stages from degrading the communication link.

Signal Level Attenuation Characterization (SLAC) Protocol

Because PLC signals propagate across unshielded wiring, cross-talk can occur between adjacent charging cables at multi-port charging hubs[1]. The Signal Level Attenuation Characterization (SLAC) protocol resolves this ambiguity by measuring signal attenuation to ensure the logical link connects to the physically plugged vehicle[1].

The process begins when the EV sends a CM_SLAC_PARM.REQ packet to query the EVSE's network parameters[1]. The EVSE responds with CM_SLAC_PARM.CNF, containing its MAC address and run settings[1]. Next, the EV initiates the sounding phase by transmitting a CM_START_ATTEN_CHAR.IND frame, followed by a burst of 10 to 20 standard MAC sounding packets (M-CAV_SOUND.ATT) broadcast at a known power level[16].

The EVSE's PLC modem measures the Received Signal Strength Indicator (RSSI) across multiple OFDM sub-carrier tone groups[16]. The EVSE averages these measurements to calculate total signal attenuation in decibels (dB) and returns the result via CM_ATTEN_CHAR.IND[1]. If the calculated attenuation falls within expected limits—confirming a direct physical connection rather than a cross-talk path—the EV issues a CM_SLAC_MATCH.REQ message[1]. The EVSE then confirms logical binding with CM_SLAC_MATCH.CNF, establishing a point-to-point HomePlug Green PHY network link over the physical cable[1].

Protocol Evolution: DIN SPEC 70121 vs. ISO 15118

Two main standards define the messaging structure for CCS DC fast charging: DIN SPEC 70121 and ISO 15118[4]. DIN SPEC 70121 was established as an interim German specification to enable early DC fast charger rollouts, whereas ISO 15118 represents the international standard supporting advanced grid features, public key infrastructure, and bidirectional power flow[4].

Specification Parameter	DIN SPEC 70121:2014	ISO 15118-2 (Generation 1)	ISO 15118-20 (Generation 2)
Functional Scope	DC Fast Charging only[1]	AC & DC Charging, Plug & Charge[4]	Bidirectional Power Transfer (V2G), Smart Grid[4]

Transport Layer Security	Excluded (Plaintext XML over TCP)	TLS 1.2 mandatory for Plug & Charge[4]	TLS 1.3 mandatory across all sessions[4]
Authentication Methods	External Identification Means (EIM)[12]	EIM and Plug & Charge (PnC)[4]	EIM and Plug & Charge (PnC) with PKI[4]
Bidirectional Energy Flow	Unsupported[19]	Limited / Experimental	Native V2G, V2H, and V2B support[4]
Wireless / Pantograph	Unsupported	Unsupported	Conductive Pantographs & Wireless Transfer[4]
Data Encoding Format	EXI (Efficient XML Interchange)	EXI (Efficient XML Interchange)	EXI with optimized schema definitions

ISO 15118 High-Level Communication Sequence Execution

Once the SLAC process establishes the physical data link, the ISO 15118 state machine executes a structured message exchange sequence to manage the charging session[4]:



1. **Session Initialization**: The EV and EVSE exchange SupportedAppProtocolReq/Res messages to agree on standard versions (such as ISO 15118-2 vs. DIN SPEC 70121)[12]. Upon protocol selection, SessionSetupReq/Res assigns a unique Session ID to maintain context across potential connection pauses[12].
2. **Service Discovery and Authentication**: The EV requests station capabilities via ServiceDiscoveryReq/Res[12]. It selects the payment method using PaymentServiceSelectionReq/Res[12]. If Plug & Charge (PnC) is selected, contract certificates are presented via PaymentDetailsReq and validated using Transport Layer Security (TLS) and a Public Key Infrastructure (PKI)[4].
3. **Target Parameter Handshake**: During ChargeParameterDiscoveryReq/Res, the vehicle transmits its battery capacity, maximum voltage, maximum current limit, and current State of Charge (SoC)[4]. The EVSE compares these values against its power stage operating limits, grid capacity, and thermal boundaries to establish an agreed charging profile[4].
4. **Cable Check and Pre-Charge**: The EVSE executes an insulation resistance test

(CableCheckReq/Res) over the cable assembly while the vehicle's internal contactors remain open[4]. After verifying insulation integrity, the EVSE enters PreChargeReq/Res, adjusting its DC output voltage to match the EV's actual battery terminal voltage within $\Delta V < 20\ \mathrm{V}$ [4]. This matching step prevents high inrush currents and contactor arcing when the vehicle closes its main contactors[4].

5. **Active Current Demand Loop**: Once contactors close, the EV issues PowerDeliveryReq to start energy flow. The system enters a continuous control loop executing every $20\ \mathrm{ms}$ to $60\ \mathrm{ms}$, where the EV transmits CurrentDemandReq containing updated voltage and current setpoints[4]. The EVSE updates its DC-DC converter setpoints in real time to match these demands while returning status data in CurrentDemandRes[4].
6. **Session Termination**: When the battery reaches its target SoC or an operational fault occurs, the EV sends PowerDeliveryReq with a stop command. The EVSE ramps output current down to $0\ \mathrm{A}$, allowing both the EVSE and EV to open their high-voltage contactors under zero-load conditions. An active bleed circuit then discharges the residual cable voltage[6]. Finally, SessionStopReq/Res closes the logical session and releases the connector lock.

3. Charger Controller Hardware Architecture, Isolation, and Safety Subsystems

The Supply Equipment Communication Controller (SECC) is the central embedded hardware unit responsible for execution of low-voltage system logic, digital protocol handling, peripheral sensor acquisition, and real-time power module control[4].

Central Controller Board Architecture

The SECC hardware board is typically architected around a dual-core or heterogeneous processing engine, combining a real-time microcontroller (e.g., ARM Cortex-M7) for low-latency tasks with an application processor (e.g., ARM Cortex-A53 running embedded Linux) for network communications and stack management.

The application processor handles the ISO 15118 protocol engine, TLS encryption, OCPP (Open Charge Point Protocol) cloud communications, and user interfaces[4]. The real-time microcontroller directly controls hardware safety loops, reads CP/PP analog front-ends, monitors thermal sensors, drives contactor coils, and manages dual isolated CAN bus channels[5]. One CAN channel interfaces with power conversion modules to update voltage/current setpoints, while the second CAN channel handles auxiliary sensors and sub-system communication.

Isolation Monitoring Device (IMD) Integration

DC fast charging stations operate as ungrounded IT electrical power systems[6]. Neither the positive ($DC+$) nor negative ($DC-$) high-voltage rail is directly referenced to Protective Earth (PE)[6]. This floating configuration prevents single line-to-ground faults from causing

immediate short-circuit currents[6]. To maintain safety, an Isolation Monitoring Device (IMD) must continuously monitor system insulation resistance (R_{iso}) between both power rails and PE[6]. The IMD couples to the floating $DC+$ and $DC-$ rails through high-voltage current-limiting resistors and injects a low-frequency AC test signal or a pulsing DC bias voltage referenced to earth[6]. By measuring return currents through the PE path, the IMD computes the real-time isolation resistance (R_{iso}) normalized to the operating DC bus voltage[6].

Isolation Resistance Threshold (Riso)	System Status per IEC 61851-23	Controller Hardware Response
$>$	Normal Insulation Integrity[6]	Power transfer permitted; output contactors remain closed[6].
$100\ \Omega/\text{V}$ to $500\ \Omega/\text{V}$	Insulation Warning Level[6]	Controller logs warning; restricts operation or schedules service[6].
$<$	Critical Isolation Fault[6]	Immediate safety trip; inhibits contactors; ramps output to $0\ \text{A}$[6].

During the pre-charge phase, the controller commands the IMD to run an active insulation check on the cable assembly prior to the vehicle closing its contactors[4]. During active power transfer, the IMD continuously monitors R_{iso} [6]. If moisture ingress, insulation aging, or a cable breach causes R_{iso} to drop below $100\ \Omega/\text{V}$, the IMD asserts a hardware fault line connected to the microcontroller's Non-Maskable Interrupt (NMI) or Fault Input pin[5]. This hardware trip instantly disables gate drive signals to the power stage and opens the main DC contactors[5].

Active Discharge (Bleed Resistor) Subsystem Design

To meet safety requirements defined in IEC 61851-23, the voltage across the output terminals of the charging cable must discharge to a safe touch level ($V_{safe} < 60\ \text{V DC}$) within $t_{target} \leq 1.0\ \text{second}$ (and under $5.0\ \text{seconds}$ maximum for fault conditions) after charging terminates[6].

Because high-voltage output filter capacitor banks ($C_{bus} \approx 500\ \mu\text{F}$ to $2000\ \mu\text{F}$) store significant energy ($E = \frac{1}{2} C_{bus} V^2$), static passive discharge resistors would generate

excessive continuous thermal losses during normal operation. Therefore, fast chargers employ an active discharge circuit consisting of high-power thick-film bleed resistors connected in series with an isolated high-voltage semiconductor switch (such as a $1200\ \text{V}$ Silicon Carbide MOSFET or IGBT).

The decay of the DC bus voltage $V(t)$ over time during active discharge is modeled by the exponential RC decay equation:

$$V(t) = V_{initial} \cdot e^{-\frac{t}{R_{bleed} \cdot C_{bus}}}$$

Solving for the maximum allowable discharge resistance R_{bleed} yields:

$$R_{bleed} \leq \frac{-t_{target}}{C_{bus} \cdot \ln\left(\frac{V_{safe}}{V_{initial}}\right)}$$

For a $1000\ \text{V DC}$ maximum bus voltage with an output filter capacitance of $C_{bus} = 1000\ \mu\text{F}$, discharging to $V_{safe} = 60\ \text{V}$ within $t_{target} = 1.0\ \text{second}$ requires a total resistance of:

$$R_{bleed} \leq \frac{-1.0}{(1000 \times 10^{-6}) \cdot \ln\left(\frac{60}{1000}\right)} = \frac{-1.0}{10^{-3} \cdot (-2.813)} \approx 355.4\ \Omega$$

The active discharge switch and resistor array must handle a high peak power dissipation (P_{peak}) at the instant of turn-on:

$$P_{peak} = \frac{V_{initial}^2}{R_{bleed}} = \frac{(1000)^2}{355.4} \approx 2.81\ \text{kW}$$

The control logic driving the active discharge switch is designed to be fail-safe. Gate driver power for the discharge switch is held off during active power delivery. Upon session completion, emergency stop activation, or total control power loss, a relay or depletion-mode driver automatically engages the discharge circuit to bleed off residual charge.

Printed Circuit Board Design, EMC, and Safety Spacing

Layout design for charger control boards must manage the co-existence of low-voltage analog signals, high-speed digital processors, and high-voltage, high-current power switching nodes[5]. Compliance with safety standards such as IEC 60664-1 and UL 840 requires strict creepage

(distance along the PCB surface) and clearance (distance through air) spacing. Between $1000\ \mathrm{V}$ high-voltage circuits and Safety Extra-Low Voltage (SELV) control traces, a minimum clearance of $8.0\ \mathrm{mm}$ and a minimum creepage of $12.5\ \mathrm{mm}$ to $16.0\ \mathrm{mm}$ (depending on the substrate's Comparative Tracking Index, or CTI) must be maintained. Physical isolation slots are routed through the PCB substrate directly beneath optical or capacitive isolators to increase the effective creepage path length.

Grounding is partitioned into functional zones to prevent high-frequency noise coupling:

- **Protective Earth (PE)**: Tied directly to the metallic chassis enclosure and cable shield terminations.
- **Analog Ground (AGND)**: A quiet ground plane dedicated to precision CP/PP voltage dividers, current sense amplifiers, and temperature sensing nodes.
- **Digital Ground (DGND)**: Dedicated ground plane for microcontrollers, memory, Ethernet, and PLC transceivers.
- **Isolated High-Voltage Ground (HV-GND)**: Floating ground reference used for primary-side gate drivers and high-voltage sense circuits.

These planes are isolated across high-voltage barriers and joined at a single star-ground point using high-voltage Y2 safety capacitors and ferrite beads. Differential signal pairs—such as $120\ \Omega$ CAN bus lines and $100\ \Omega$ PLC signal tracks—are routed with length matching and kept isolated from high dV/dt switching nodes to maintain signal integrity and ensure electromagnetic compatibility (EMC) compliance under IEC 61851-21-2[3].

4. Power Conversion Topologies: Buck and Boost Converters

DC fast chargers utilize switched-mode DC-DC power converter topologies to adjust grid-rectified voltages to match variable vehicle battery voltages ranging from $200\ \mathrm{V}$ to $1000\ \mathrm{V}$ [4]. Buck (step-down) and Boost (step-up) topologies form the fundamental power conversion building blocks used across both auxiliary power supplies and primary power modules[18].

Buck Converter Analysis (Step-Down Topology)

A Buck converter lowers a higher DC input voltage (V_{in}) to a lower DC output voltage (V_{out}) by controlling the duty cycle (D) of a series switching switch[18].

Continuous Conduction Mode (CCM) Derivation

The circuit comprises a controlled switch (Q_1), a freewheel diode or synchronous switch (D_1), an inductor (L), and an output filter capacitor (C_{out}). Operating in Continuous Conduction Mode (CCM), the switching period is $T_s = 1/f_{sw}$, where f_{sw} is the switching frequency.

The switch is closed for duration $t_{on} = D \cdot T_s$ and open for $t_{off} = (1 - D) \cdot T_s$.

When Q_1 is ON, diode D_1 is reverse-biased. The voltage across inductor L is:

$$v_L(t) = V_{in} - V_{out}$$

When Q_1 turns OFF, inductor current freewheels through D_1. The voltage across inductor L becomes:

$$v_L(t) = -V_{out}$$

Under steady-state conditions, the net change in inductor current over one complete switching period must equal zero. Applying the Volt-Second Balance Principle ($\int_0^{T_s} v_L(t)dt = 0$):

$$(V_{in} - V_{out}) \cdot D \cdot T_s + (-V_{out}) \cdot (1 - D) \cdot T_s = 0$$

Dividing by T_s and expanding the terms:

$$V_{in} \cdot D - V_{out} \cdot D - V_{out} + V_{out} \cdot D = 0 \implies V_{out} = D \cdot V_{in}$$

Component Sizing Formulations

The peak-to-peak inductor ripple current (ΔI_L) during t_{on} is calculated as:

$$\Delta I_L = \frac{(V_{in} - V_{out}) \cdot D}{L \cdot f_{sw}} = \frac{V_{out} \cdot (1 - D)}{L \cdot f_{sw}}$$

To keep the converter operating in CCM at a specified minimum output load current ($I_{out,min}$), the inductance L must exceed the critical threshold (L_{min}):

$$L_{min} \geq \frac{(V_{in} - V_{out}) \cdot V_{out}}{2 \cdot I_{out,min} \cdot f_{sw} \cdot V_{in}}$$

The output capacitance (C_{out}) required to limit output voltage ripple to ΔV_{out} is calculated

by integrating the capacitor charge ripple:

$$C_{out} \geq \frac{\Delta I_L}{8 \cdot f_{sw} \cdot \Delta V_{out}}$$

Boost Converter Analysis (Step-Up Topology)

A Boost converter increases a lower DC input voltage (V_{in}) to a higher DC output voltage (V_{out})[18].

Continuous Conduction Mode (CCM) Derivation

The circuit places inductor L in series with input source V_{in}, while controlled switch Q_1 shunts the node after the inductor to ground. Diode D_1 connects this node to output capacitor C_{out} and the load.

When switch Q_1 is ON for duration $t_{on} = D \cdot T_s$, diode D_1 is reverse-biased, and energy builds up in inductor L:

$$v_L(t) = V_{in}$$

When switch Q_1 turns OFF for duration $t_{off} = (1 - D) \cdot T_s$, the inductor voltage reverses polarity, adding in series with V_{in} to conduct through diode D_1 into C_{out} and the load:

$$v_L(t) = V_{in} - V_{out}$$

Applying the Volt-Second Balance Principle ($\int_0^{T_s} v_L(t)dt = 0$):

$$V_{in} \cdot D \cdot T_s + (V_{in} - V_{out}) \cdot (1 - D) \cdot T_s = 0$$

Dividing by T_s and expanding the terms:

$$V_{in} \cdot D + V_{in} - V_{in} \cdot D - V_{out} \cdot (1 - D) = 0 \implies V_{out} = \frac{V_{in}}{1 - D}$$

Component Sizing Formulations

The peak-to-peak inductor ripple current (ΔI_L) is given by:

$$\Delta I_L = \frac{V_{in} \cdot D}{L \cdot f_{sw}}$$

To maintain CCM operation at minimum load resistance (R_{load}), the minimum critical inductance (L_{min}) must satisfy:

$$L_{min} \geq \frac{D \cdot (1 - D)^2 \cdot R_{load}}{2 \cdot f_{sw}}$$

Unlike the Buck converter, the output capacitor in a Boost topology must supply the total load current (I_{out}) during t_{on} when diode D_1 is reverse-biased. The required capacitance (C_{out}) to maintain ripple within ΔV_{out} is:

$$C_{out} \geq \frac{I_{out} \cdot D}{f_{sw} \cdot \Delta V_{out}}$$

Converter Topologies Comparison

Performance Characteristic	Buck Converter Topology	Boost Converter Topology
Voltage Ideal Transfer Function	$V_{out} = D \cdot$ ($V_{out} \leq$)[18]	$V_{out} =$ ($V_{out} \geq$)[18]
Input Current Waveform	Discontinuous / Pulsed (requires input filters)	Continuous (smooth input current; low EMI)
Output Current Waveform	Continuous (low output voltage ripple)	Discontinuous / Pulsed (requires low-ESR capacitors)

Switch Voltage Stress (V_{SW})	Equal to input voltage V_{in}	Equal to output voltage V_{out}
Primary Fast Charger Uses	Internal $12\ \text{V}/24\ \text{V}$ auxiliary rails[18]; step-down output stages	Active Power Factor Correction (PFC) stages[18]

Converter Integration in Fast Charging Systems

Industrial DC fast chargers combine these base converter topologies into multi-stage, isolated converter architectures[2].

Three-phase AC grid power ($400\ \text{V}$ to $480\ \text{V AC}$) is initially rectified by an Active Front-End (AFE) Power Factor Correction (PFC) stage—typically using a 3-phase Vienna Rectifier or a 6-switch active bridge topology[2]. This PFC stage functions as a Boost-derived converter, stepping up the rectified grid voltage to a stable intermediate DC link bus (typically $800\ \text{V DC}$) while enforcing sinusoidal input currents to maintain high power factor ($\text{PF} > 0.99$).

An isolated DC-DC conversion stage bridges the intermediate $800\ \text{V}$ DC bus to the vehicle output terminals. Resonant topologies, such as LLC or Phase-Shifted Full-Bridge (PSFB) converters, are used to provide galvanic isolation via high-frequency transformers. LLC resonant converters operate near their resonant frequency ($f_r = \frac{1}{2\pi\sqrt{L_r C_r}}$), enabling Zero Voltage Switching (ZVS) on primary switches and Zero Current Switching (ZCS) on secondary rectifiers. This minimizes switching losses and allows operating frequencies between $50\ \text{kHz}$ and $150\ \text{kHz}$.

To support wide battery voltage ranges ($200\ \text{V}$ to $1000\ \text{V}$), modern chargers use interleaved Buck or Boost cascades on the converter output[18]. Interleaving shifts the switching phases of multiple parallel power channels, reducing output current ripple, allowing smaller magnetic components, and improving thermal dissipation across the board.
Utilizing Silicon Carbide (SiC) MOSFET switches over legacy Silicon IGBTs significantly reduces combined conduction and switching losses:

$$P_{total} = P_{cond} + P_{sw} = \left(I_{RMS}^2 \cdot R_{DS(on)}\right) + \left((E_{on} + E_{off}) \cdot f_{sw}\right)$$

SiC MOSFETs feature extremely low $R_{DS(on)}$ values and reduced switching loss energies (

E_{on}, E_{off}), allowing fast chargers to achieve operational power conversion efficiencies exceeding 96% .

5. System Interoperability and Fault Diagnostic Matrix

The table below outlines common physical layer, communication, and hardware fault conditions, detailing their detection mechanisms, protocol-level flags, and safety actions executed by the charger controller:

Fault Condition	Primary Hardware Detection	Protocol / State Signal	Controller Executed Action	System Safety Outcome
Control Pilot Short to PE	AFE Hardware Window Comparators[11]	CP drops to $0\ \text{V}$ (State E)[5]	Hardware interrupt disables gate drivers	Inoperable state; opens contactors instantly[5].
PLC Signal Crosstalk / Coupling	Qualcomm PLC Modem / SLAC Engine[15]	Attenuation threshold check fails in CM_ATTEN_CHAR.IND [cite: 1, 16, 22]	Aborts matching; ignores CM_SLAC_MATCH.REQ [cite: 1, 22]	Prevents logical cross-connection to wrong vehicle[14].
Pre-Charge Voltage Deviation ($\Delta V >$)	Differential High-Voltage Sense ADC	Pre-charge target check fails in PreChargeReq	Halts state machine; sends error in PreChargeRes	Inhibits main contactor closure to avoid inrush[4].
Isolation Degradation ($<$)	Isolation Monitoring Device (IMD)[6]	IMD asserts fault line; HLC reports error[6]	Hardware trip opens gate drivers and AC/DC relays[6]	Isolates high-voltage bus; triggers active discharge[6].
Connector Latch Unlatch Event	Proximity Pilot (PP) Voltage Divider[8]	R_{PP} jumps from $150\ \Omega$ to $>$	Low-latency ADC interrupt triggers fast current	Ramps current to $0\ \text{A}$ before contacts separate[8].

		[cite: 8]	ramp-down	

6. Synthesis and Engineering Conclusions

The design of DC fast charger controllers requires a cohesive integration of analog signaling interfaces, digital communications, and power conversion stages[4]. Analog interfaces defined by IEC 61851-1 manage physical connection safety, while Power Line Communication superimposed on the Control Pilot line enables high-level digital negotiations via ISO 15118 and DIN SPEC 70121[4].

At the board level, isolating low-voltage processing electronics from high-voltage switching noise requires dedicated PCB layout techniques, including segmented ground domains, strict creepage and clearance distances, and differential signal routing[3]. Safety systems—specifically Isolation Monitoring Devices operating on floating IT power networks and active bleed discharge circuits—provide redundant protection against electrical shock hazards[6]. Finally, combining wide-bandgap SiC semiconductor devices with optimized Buck and Boost topologies yields high power density, precise voltage regulation across wide operating ranges, and efficient energy transfer for electric vehicle charging infrastructure[18].

Works cited

1. DIN SPEC 70121: V2G Communication Standards | PDF - Scribd, https://www.scribd.com/document/867829193/DIN70121
2. IEC 61851 - Wikipedia, https://en.wikipedia.org/wiki/IEC_61851
3. IEC 61851 standard for charging electric cars explained - ZERA GmbH, https://www.zera.de/en/znews/IEC-61851-a/
4. ISO 15118 Explained: Plug & Charge, V2G, and Smart ... - EV Range, https://www.evrange.com/ev-range-insights/what-is-iso-15118
5. IEC 61851 Explained: EV Charging Modes & Safety Guide - eInfochips, https://www.einfochips.com/blog/iec-61851-everything-you-need-to-know-about-the-ev-charging-standard/
6. Insulation Monitoring Device for EV Charger (IEC 61851-23), https://global-gongyuan.com/insulation-monitoring-device-for-ev-charger/
7. About: Type 2 AC EV Charging - Morek EVC, https://wiki.morek.eu/en/support/solutions/articles/204000046254-about-type-2-ac-ev-charging
8. CP and PP Signals in EV Charging - feyree EV Charger, https://www.feyree.com/blogs/news/ev-charging-cp-pp-signals-guide
9. Control Pilot (CP) Signal Explained: States, PWM & Faults - Klitv, https://klitv.com/glossary/control-pilot
10. Proximity Pilot and Control Pilot overview - PhilipMcGaw.com, https://philipmcgaw.com/proximity-pilot-and-control-pilot-overview/
11. IEC 61851 Inspection Form — EV Charging Safety | Geocadra, https://www.geocadra.com/en/standards/iec-61851-ev-charging
12. ISO 15118-2 Protocol - Typhoon HIL,

https://www.typhoon-hil.com/documentation/typhoon-hil-software-manual/References/iso15118_protocol.html
13. QCA7006AQ Connectivity Solution for EV Charging - Qualcomm, https://www.qualcomm.com/automotive/solutions/connectivity-positioning/products/qca7006aq
14. EV Charging Standards: CCS, ISO 15118 & Plug and Charge | renco, https://www.renco.de/resources/ev-charging-standards
15. ISO 15118 Details - WARP Dokumentation, https://docs.warp-charger.com/en/docs/tutorials/iso15118_details/
16. INTERNATIONAL STANDARD ISO 15118-3 - Regulations.gov, https://downloads.regulations.gov/FHWA-2022-0008-0405/attachment_1.pdf
17. ISO 15118 vs DIN SPEC 70121. What is the difference? - ADEV, https://adevcharge.com/blog/iso-15118-vs-din-spec-70121-what-is-the-difference/
18. ISO 15118 - Wikipedia, https://en.wikipedia.org/wiki/ISO_15118
19. Specification of ISO15118 Charging - AUTOSAR.org, https://www.autosar.org/fileadmin/standards/R24-11/CP/AUTOSAR_CP_SWS_ISO15118Charging.pdf
20. IEC 61851-23:2014 - Standard | IECEE, https://www.iecee.org/certification/iec-standards/iec-61851-232014
21. SLAC Protocol Vulnerability in EV Charging | CVE-2025-27071, https://plaxidityx.com/blog/blog-post/plaxidityx-discovers-critical-vulnerability-in-implementation-of-ev-charging-communication-protocol/
22. CVE-2025-12357: ISO 15118-2 SLAC Protocol MitM Vulnerability, https://www.sentinelone.com/vulnerability-database/cve-2025-12357/