# HDL Compiler<sup>™</sup> for VHDL User Guide

Version O-2018.06, June 2018

SYNOPSYS®

# **Copyright Notice and Proprietary Information**

©2018 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

#### **Destination Control Statement**

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

#### Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

#### **Trademarks**

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at http://www.synopsys.com/Company/Pages/Trademarks.aspx.

All other product or company names may be trademarks of their respective owners.

#### Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

#### **Third-Party Links**

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc. 690 E. Middlefield Road Mountain View, CA 94043 www.synopsys.com

#### **Copyright Notice for the Command-Line Editing Feature**

© 1992, 1993 The Regents of the University of California. All rights reserved. This code is derived from software contributed to Berkeley by Christos Zoulas of Cornell University.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2.Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3.All advertising materials mentioning features or use of this software must display the following acknowledgement:

This product includes software developed by the University of California, Berkeley and its contributors.

4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

#### Copyright Notice for the Line-Editing Library

© 1992 Simmule Turner and Rich Salz. All rights reserved.

This software is not subject to any license of the American Telephone and Telegraph Company or of the Regents of the University of California.

Permission is granted to anyone to use this software for any purpose on any computer system, and to alter it and redistribute it freely, subject to the following restrictions:

- 1. The authors are not responsible for the consequences of use of this software, no matter how awful, even if they arise from flaws in it.
- 2.The origin of this software must not be misrepresented, either by explicit claim or by omission. Since few users ever read sources, credits must appear in the documentation.
- 3.Altered versions must be plainly marked as such, and must not be misrepresented as being the original software. Since few users ever read sources, credits must appear in the documentation.
- 4. This notice may not be removed or altered.

	About This Manual
	Customer Support
1.	Introduction to HDL Compiler for VHDL
	Reading VHDL Designs
	Customizing Elaboration Reports
	Reporting Elaboration Errors
	Parameterized Models (Generics)
	Configuration Support.  Bind Entity to Architecture.  Architectures From the Same Library.  Architectures From Different Libraries  Component Inside a Concurrent Block.  Generic in a Configuration.

	Port Map in a Configuration	1-29
	Nested Configurations	1-30
	Indirectly Nested Configurations	1-31
	Embedded Configurations	1-32
	Multiple Architectures in Embedded Configurations	1-35
	Combinations of Embedded, Nested, and	
	Standalone Configurations	1-37
	Tool Behavior When Using Elaborate With the Entity Name	1-44
	Mixed Language Support	1-46
	Design Libraries	1-46
	Predefined Design Libraries	1-47
	Creating User-Defined Design Libraries	1-48
	User-Defined Design Library Example	1-48
	Using Design Units From Design Libraries	1-49
	Design Library Reports	1-50
	Package Support	1-50
	Array Naming Variables	1-50
	Licenses	1-51
2.	General Coding Considerations	
	Creating Relative Placement in Hardware Description Languages	2-2
	Scope of Support for Relative Placement	2-2
	Directives for Specifying Relative Placement	2-3
	Creating Groups Using rp_group and rp_endgroup	2-3
	Specifying Subgroups, Keepouts, and Instances Using rp_place	2-4
	Placing Cells Automatically Using rp_fill	2-5
	Specifying Placement for Array Elements Using rp_array_dir	2-6
	Relative Placement Example	2-6
	Declarative Region in generate Statements	2-8
	Design Units	2-9
	Direct Instantiation of Components	2-10
	Default Component Port Assignments	2-11
	Component Name Restrictions	2-11
	Component Sources	2-11
	Component Port Consistency	2-12

Component Architecture	
Package Names	
Procedures and Functions as Design Components	
·	
Data Types and Data Objects	
Globally Static Expressions in Port Maps	2-
Aliases	2-
Deferred Constants	2-2
Aggregates in Constant Record Declarations	2-2
Enumerated Types in the for and for-generate Constructs	2-2
Groups	2-2
Integer Data Types	2-2
Overloading an Enumeration Literal	2-2
Enumeration Encoding	2-:
Constant Floating-Point Support	
Syntax and Declarations	
Operators and Expressions	2-
Guidelines	2-:
math_real Package Support	2-
Unsupported Constructs and Operators	
Using the math_real Package	
Arithmetic Functions	
Usage Examples	2-
Operands	2-
Operand Bit-Width	2-
Array Slice Names	2-
Variable Array Slice Operations	2-
Computable and Noncomputable Operands	2-
Indexed Name Targets	2-
Modeling Considerations	2-
•	
Concatenation	
Unconstrained Type Ports	
Input Ports Associated With the Keyword open	
Multiple Events in a Single Process	
Multiple if Statements in a Process	
Keeping Signal Names	2-

	Controlling Structure	2-42
	Resolution Functions	2-42
	Asynchronous Designs	2-43
	Using Don't Care Values	2-43
	Finite State Machines	2-43
	Variables and Commands Specific to FSM Inference	2-44
	FSM Coding RequirementsFSM Example and Inference Report	2-44 2-45
	State Vector Attribute	2-47
	Multibit Inference	2-47
	Simulation/Synthesis Mismatch Issues	2-51
	Type Mismatches	2-51
	Set and Reset Signals	2-51
	Z Values in Expressions	2-51
	Don't Care Values in Comparisons	2-51
	Ordering of Enumerated Types Using the	
	ENUM_ENCODING attribute	2-52
	Sensitivity Lists	2-53
	Delay Specifications	2-53
3.	Modeling Combinational Logic	
	Synthetic Operators	3-2
	Logic and Arithmetic Operator Implementation	3-4
	Propagating Constants	3-5
	Bit-Truncation Coding for DC Ultra Datapath Extraction	3-5
	Multiplexing Logic	3-7
	SELECT_OP Inference	3-8
	MUX_OP Inference	3-9
	Variables That Control MUX_OP Inference	3-12
	MUX_OP Inference Examples	3-13
	MUX_OP Inference Limitations	3-16
	Unintended Latches and Feedback Paths in	
	Combinational Logic	3-17

# 4. Modeling Sequential Logic

Generic Sequential Cells (SEQGENs)	4-2
Inference Reports for Flip-Flops and Latches	4-4
Register Inference Variables	4-5
Register Inference Attributes	4-6
Inferring D and Set/Reset (SR) Latches Inferring SR Latches Overview—Latches Basic D Latch D Latch With Asynchronous Set D Latch With Asynchronous Reset D Latch With Asynchronous Set and Reset Limitations of D Latch Inference	4-7 4-8 4-9 4-10 4-11 4-12 4-13
Inferring D Flip-Flops Overview—Inferring D Flip-Flops Enabling Conditions in if Statements Rising-Edge-Triggered D Flip-Flop Falling-Edge-Triggered D Flip-Flop D Flip-Flop With Asynchronous Set D Flip-Flop With Asynchronous Reset D Flip-Flop With Asynchronous Set and Reset D Flip-Flop With Synchronous Set. D Flip-Flop With Synchronous Reset Signals D Flip-Flop With Synchronous and Asynchronous Load Multiple Flip-Flops: Asynchronous and Synchronous Controls	4-15 4-17 4-17 4-18 4-20 4-21 4-22 4-23 4-24 4-25 4-27 4-28
Inferring JK Flip-Flops	4-30 4-30 4-32
Inferring Master-Slave Latches	4-33 4-33 4-34 4-35

	Master-Slave Latch: Discrete Components	4-36
	Limitations of Register Inference	4-37
	Unloaded Sequential Cell Preservation	4-38
5.	Inferring Three-State Logic	
	Three-State Driver Inference Report	5-2
	Inferring a Basic Three-State Driver	5-2
	Inferring One Three-State Buffer From a Single Process	5-3
	Inferring Two Three-State Buffers	5-4
	Three-State Buffer With Registered Enable	5-5
	Three-State Buffer With Registered Data	5-7
	Understanding the Limitations of Three-State Inference	5-9
6.	Directives, Attributes, and Variables	
	Compiler Directives	6-2
	keep_signal_name	6-2
	template	6-3
	translate_off and translate_on	6-3
	resolution_method	6-3
	rp_group and rp_endgroup	6-3
	rp_place	6-4
	rp_fill	6-4
	rp_array_dir	6-5
	map_to_entity and return_port_name	6-5
	dc_tcl_script_begin and dc_tcl_script_end	6-5 6-7
	Directive Support by Pragma Prefix	
	Attributes	6-8
	Synopsys Defined Attributes	6-8
	IEEE Predefined Attributes	6-14
	Variables	6-14
7.	Writing Out Designs in VHDL Format	
	Netlist Writer Variables	7-2

	Writing Out VHDL Files	7-2
	VHDL Write Variables	7-3
	Bit and Bit-Vector Variables	7-5
	Resolution Function Variables	7-6
	Types and Type Conversion Variables	7-7
	Architecture and Configuration Variables	7-8
	Preserving Port Types	7-8
	VHDL Netlister Coding Considerations	7-11 7-11 7-12 7-13
8.	VHDL-2008 Language Support	
	VHDL-2008 Setting	8-2
	fixed_generic_pkg Package fixed_generic_pkg Data Type Conversion Functions Resize Functions Arithmetic Functions Comparison Functions Logical Operator Functions Shift and Rotate Functions	8-2 8-3 8-3 8-4 8-6 8-6 8-7
Αp	pendix A. Examples	
	Read-Only Memory	A-2
	Waveform Generator	A-4
	Definable-Width Adder-Subtracter	A-6
	Count Zeros—Combinational Version	A-7
	Count Zeros—Sequential Version	A-9
	Soft Drink Machine—State Machine Version	A-11
	Soft Drink Machine—Count Nickels Version	Δ-14

FSM Exar	mple: Moore Machine	A-16
FSM Exar	mple: Mealy Machine	A-18
Carry	kahead Adder	A-20 A-20 A-27
Input	Parallel Converter—Counting Bits	A-27 A-28 A-29
Serial-to-F	Parallel Converter—Shifting Bits	A-32
Programm	nable Logic Arrays	A-36
Appendix B.	Predefined Libraries	
_	_1164	B-2 B-2
std_lo Modif std_lo L S Convo Arithn Comp Shift I	arith Digic_arith Package Overview Digic_arith Package Digic_arith Data Types DINSIGNED DISIGNED DISIG	B-4 B-5 B-6 B-7 B-7 B-8 B-9 B-12 B-14 B-15
Unsup Using nume Conve Resiz Arithn Comp	pported Constructs and Operators g the numeric_std Package eric_std Data Types ersion Functions te Functions metic Functions to parison Functions	B-15 B-16 B-16 B-17 B-17 B-17 B-19 B-22

Shift and Rotate Functions	B-23
Shift and Rotate Operators	B-24
std_logic_misc	B-26
Standard Package	B-27
Data Type BOOLEAN	B-28
Data Type BIT	B-28
Data Type CHARACTER	B-28
Data Type INTEGER	B-29
Data Type NATURAL	B-29
Data Type POSITIVE	B-29
Data Type STRING	B-29
Data Type BIT_VECTOR	B-29
Synopsys Package—ATTRIBUTES	B-29
Appendix C. VHDL Constructs	
VHDL Construct Support	C-2
Configurations	C-2
Design Units	C-2
Data Types	C-3
Declarations	C-4
Specifications	C-6
Names	C-6
Operators	C-7
Operands and Expressions	C-9
Sequential Statements	C-10
Concurrent Statements	C-12
Lexical Elements	C-13
Specifics of Identifiers	C-13 C-13
Predefined Language Environment	C-14
VHDL Reserved Words	C-14

# Glossary

# Index

# Preface

This preface includes the following sections:

- About This Manual
- Customer Support

#### **About This Manual**

The HDL Compiler translates a VHDL hardware language description into a GTECH netlist that is used by the Design Compiler tool to create an optimized netlist. This manual describes the following:

- Modeling combinational logic, synchronous logic, three-state buffers, and multibit cells with HDL Compiler
- Using HDL Compiler Synthesis directives, attributes, and variables

#### **Audience**

The HDL Compiler for VHDL User Guide is written for logic designers and electronic engineers who are familiar with Design Compiler. Knowledge of the VHDL language is required, and knowledge of a high-level programming language is helpful.

#### **Related Publications**

For additional information about the HDL Compiler tool, see the documentation on the Synopsys SolvNet<sup>®</sup> online support site at the following address:

https://solvnet.synopsys.com/DocsOnWeb

You might also want to see the documentation for the following related Synopsys products:

- DC Explorer
- Design Compiler<sup>®</sup>
- DesignWare<sup>®</sup> components
- Library Compiler™
- VHDL System Simulator

#### **Release Notes**

Information about new features, enhancements, changes, known limitations, and resolved Synopsys Technical Action Requests (STARs) is available in the *HDL Compiler Release Notes* on the SolvNet site.

To see the HDL Compiler Release Notes,

1. Go to the SolvNet Download Center located at the following address:

# https://solvnet.synopsys.com/DownloadCenter

2. Select HDL Compiler, and then select a release in the list that appears.

# **Conventions**

The following conventions are used in Synopsys documentation.

Convention	Description
Courier	Indicates syntax, such as write_file.
Courier italic	Indicates a user-defined value in syntax, such as write_file design_list.
Courier bold	Indicates user input—text you type verbatim—in examples, such as
	<pre>prompt&gt; write_file top</pre>
[]	Denotes optional arguments in syntax, such as write_file [-format fmt]
	Indicates that arguments can be repeated as many times as needed, such as pin1 pin2 pinN
I	Indicates a choice among alternatives, such as low   medium   high
Ctrl+C	Indicates a keyboard combination, such as holding down the Ctrl key and pressing C.
\	Indicates a continuation of a command line.
1	Indicates levels of directory structure.
Edit > Copy	Indicates a path to a menu command, such as opening the Edit menu and choosing Copy.

# **Customer Support**

Customer support is available through SolvNet online customer support and through contacting the Synopsys Technical Support Center.

# **Accessing SolvNet**

The SolvNet site includes a knowledge base of technical articles and answers to frequently asked questions about Synopsys tools. The SolvNet site also gives you access to a wide range of Synopsys online services including software downloads, documentation, and technical support.

To access the SolvNet site, go to the following address:

https://solvnet.synopsys.com

If prompted, enter your user name and password. If you do not have a Synopsys user name and password, follow the instructions to sign up for an account.

If you need help using the SolvNet site, click HELP in the top-right menu bar.

## **Contacting the Synopsys Technical Support Center**

If you have problems, questions, or suggestions, you can contact the Synopsys Technical Support Center in the following ways:

- Open a support case to your local support center online by signing in to the SolvNet site at https://solvnet.synopsys.com, clicking Support, and then clicking "Open A Support Case."
- Send an e-mail message to your local support center.
  - E-mail support\_center@synopsys.com from within North America.
  - Find other local support center e-mail addresses at https://www.synopsys.com/support/global-support-centers.html
- Telephone your local support center.
  - o Call (800) 245-8005 from within North America.
  - Find other local support center telephone numbers at https://www.synopsys.com/support/global-support-centers.html

1

# Introduction to HDL Compiler for VHDL

The Synopsys Design Compiler tool uses the HDL Compiler tool to read designs written in the VHDL hardware description language.

This chapter contains the following sections:

- Reading VHDL Designs
- Customizing Elaboration Reports
- Reporting Elaboration Errors
- Parameterized Models (Generics)
- Configuration Support
- Design Libraries
- Package Support
- Array Naming Variables
- Licenses

# **Reading VHDL Designs**

When HDL Compiler reads a VHDL design, it checks the code for correct VHDL syntax and builds the generic technology (GTECH) netlist that Design Compiler uses to optimize the design. You can use the read command to do both functions automatically, or you can use the analyze and elaborate commands to do each function separately. It is recommended that you use the analyze and elaborate commands instead of the read command, because

- The elaborate command includes the functionality of the link command, which resolves design references.
- For parameterized designs, the read command builds a design only with the default generic value; if you want to build a new design with a nondefault value, you must use analyze and elaborate. See "Parameterized Models (Generics)" on page 1-16.
- The read command ignores standalone configurations.

HDL Compiler supports automatic linking of mixed language libraries. In Verilog, the default library is the one in the work directory, and you cannot have multiple libraries. In VHDL, however, you can have multiple design libraries.

If you want to read a VHDL netlist, use the specialized VHDL netlist reader instead of HDL Compiler. The VHDL netlist reader reads netlists faster and uses less memory.

#### Note:

To enable the VHDL netlist reader, you must set <code>enable\_vhdl\_netlist\_reader</code> to true (the default is <code>false</code>) and use the netlist reading commands shown in Table on page 1-3.

If the file is not a VHDL netlist or if <code>enable\_vhdl\_netlist\_reader</code> is set to <code>false</code>, HDL Compiler reads the design.

This section contains the following subsections:

- Summary of Reading Methods
- Using the analyze and elaborate Commands
- Using the read Command
- Automated Process of Reading Designs With Dependencies
- File Format Inference Based on File Extensions
- Specifying the VHDL Version

# **Summary of Reading Methods**

The recommended and alternative reading commands are shown in Table .

Type of input	Reading method
RTL	Recommended reading method  analyze -format vhdl { files } elaborate topdesign
	Alternative reading method read_vhdl { files } (Tcl) read_file -rtl vhdl { files } (Tcl)
Gate-level netlists	Recommended reading method read_vhdl -netlist { files } (Tcl) or read_file -rtl vhdl -netlist { files } (Tcl)
	Alternative reading method You can also use any RTL-reading command to read netlists, but it is slower and uses more memory than the specialized gate-level netlist reader.

# Using the analyze and elaborate Commands

When you are elaborating a design, the last analyzed architecture is used if you do not specify an architecture.

To understand how to use the analyze and elaborate commands, consider Example 1-1, which represents a single design with no user-defined libraries.

#### Example 1-1 Design dff\_pos

```
library IEEE;
use IEEE.std_logic_1164.all;
entity dff_pos is
  port (DATA, CLK : in std_logic;
       Q : out std_logic );
end dff_pos;

architecture rtl of dff_pos is
begin
process (CLK) begin
  if (rising_edge (CLK)) then
    Q <= DATA;
end if;</pre>
```

```
end process;
end rtl;
```

Example 1-2 through Example 1-4 show various reading methods.

#### Example 1-2

```
--The analyze and elaborate commands read design dff_pos which is --contained in a single file, dff_entity_arch.vhd.

dc_shell> analyze -format vhdl dff_entity_arch.vhd
dc_shell> elaborate dff_pos
```

#### Example 1-3

```
--Design dff_pos is contained in two files, dff_entity.vhd and --dff_arch.vhd. Each file is analyzed by a separate analyze command --and then the dff_pos design is elaborated.

dc_shell> analyze -format vhdl dff_entity.vhd dc_shell> analyze -format vhdl dff_arch.vhd dc_shell> elaborate dff_pos
```

#### Example 1-4

```
--Design dff_pos is contained in two files, dff_entity.vhd and --dff_arch.vhd. Both files are analyzed using a single analyze command, --and then elaborated.

dc_shell> analyze -format vhdl {dff_entity.vhd dff_arch.vhd} dc shell> elaborate dff pos
```

# **Using the read Command**

To use any read command, all your entity and architecture definitions must be contained in a single read. The entity and architecture definitions can be contained in separate files. Table 1-1 on page 1-4 shows various reading examples.

Table 1-1 read Command Examples

Example	Description
<pre>dc_shell-t&gt; read_file -format vhdl ALU.vhd</pre>	The read_file command reads the single design in the ALU.vhd file.
dc_shell-t> read_vhdl ALU.vhd	The read_vhdl command reads the single design in the ALU.vhd file.

Table 1-1 read Command Examples (Continued)

Example	Description		
<pre>dc_shell-t&gt; read_vhdl {ALU_subblock.vhd ALU_top.vhd}</pre>	The read_vhdl command reads a design consisting of two files: ALU_subblock.vhd and ALU_top.vhd.		
<pre>dc_shell-t&gt; read_vhdl ALU_subblock.vhd dc_shell-t&gt; read_vhdl ALU_top.vhd</pre>	Two read_vhdl commands read a design consisting of two files: ALU_subblock.vhd and ALU_top.vhd.		

When you use the read command, you must also use the current\_design command, to specify the working design, and the link command, to resolve design references, before optimizing the design. These operations are automatically done by the elaborate command. If you have configurations, you must use analyze. The read command ignores configurations and has limited supported for generics. See "Configuration Support" on page 1-18 and "Parameterized Models (Generics)" on page 1-16.

# **Automated Process of Reading Designs With Dependencies**

You can enable the tool to automatically read designs with dependencies in correct order by using the -autoread option with the read\_file or analyze command.

read\_file -autoread

This command reads files with dependencies automatically, analyzes the files, and elaborates the files starting at a specified top-level design. For example,

```
dc_shell> read_file -autoread file_list -top design_name
```

You must specify the file\_list argument to list the files, directories, or both to be analyzed. The <code>-autoread</code> option locates the source files by expanding each file or directory in the file\_list argument. You must specify the top design by using the <code>-top</code> option.

• analyze -autoread

This command reads files with dependencies automatically and analyzes the files without elaboration. For example,

```
dc_shell> analyze -autoread file_list -top design_name
```

You must specify the file\_list argument to list the files, directories, or both to be analyzed. The -autoread option locates the source files by expanding each file or directory in the file\_list argument. If you use the -top option, the tool analyzes only the source files needed to elaborate the top-level design. If you do not specify the -top option, the tool

analyzes all the files in the *file\_list* argument, grouping them in the order according to the dependencies that the <code>-autoread</code> option infers.

#### **Example**

The following example specifies the current directory as the source directory. The command reads the source files, analyzes them, and then elaborates the design starting at the top-level design.

```
dc_shell> read_file {.} -autoread -recursive -top E1
```

The following example specifies the file extensions for VHDL files other than the default (.vhd and .vhdl) and sets the file source lists. The read\_file -autoread command specifies the top-level design and includes only files with the specified VHDL file extensions.

```
dc_shell> set_app_var hdlin_autoread_sverilog_extensions {.vhdx .vhdlang}
dc_shell> set_app_var my_sources {entities/src archs/src}
dc_shell> set_app_var my_excludes {entities/src/no_hdl_* archs/src/docs/}
dc_shell> read_file $my_sources -recursive -exclude $my_excludes \
    -autoread -format vhdl -top TOP
```

Excluding directories is useful when you do not want the tool to use those files that have the same file extensions as the source files in the directories.

## The -autoread Option

When you use the <code>-autoread file\_list</code> option with the <code>read\_file</code> or <code>analyze</code> command, the resulting GTECH representation is retained in memory. Dependencies are determined by the files or directories specified in the file\_list argument. If the file\_list argument changes between consecutive calls of the <code>-autoread</code> option, the tool uses the latest set of files to determine the dependencies. You can use the <code>-autoread</code> option on designs written in any VHDL, Verilog, or SystemVerilog language version. If you do not specify this option, only the files specified in the <code>file\_list</code> argument are processed and the file list cannot include directories.

When you specify a directory as an argument, the command reads files from the directory. If you specify both the <code>-autoread</code> and <code>-recursive</code> options, the command also reads files in the subdirectories.

When the <code>-autoread</code> option is set, the command infers RTL source files based on the file extensions set by the variables listed in the following table. If you specify the <code>-format</code> option, only files with the specified file extensions are read.

Variable	Description	Default
hdlin_autoread_exclude_	Specifies the file extension to exclude files from	п п
extensions	the analyze process.	

Variable	Description	Default
hdlin_autoread_verilog_ extensions	Specifies the file extension to analyze files as Verilog files.	.v
hdlin_auto_autoread_vhdl_ extensions	Specifies the file extension to analyze files as VHDL files.	.vhd .vhdl
hdlin_autoread_sverilog_ extensions	Specifies the file extension to analyze files as SystemVerilog files.	.sv .sverilog

## **File Dependencies**

A file dependency occurs when a file requires language constructs that are defined in another file. When you specify the <code>-autoread</code> command, the tool automatically analyzes the files (and elaborates the files if you use the <code>read\_file</code> command) with the following dependencies in the correct order:

#### Analyze dependency

If file B defines entity E in SystemVerilog and file A defines the architecture of entity E, file A depends on file B and must be analyzed after file B. Language constructs that can cause analyze dependencies include VHDL package declarations, entity declarations, direct instantiations, and SystemVerilog package definitions and import.

#### Link dependency

If module X instantiates module Y in Verilog, you must analyze both of them before elaboration and linking to prevent the tool from inferring a black box for the missing module. Language constructs that can cause link dependencies include VHDL component instantiations and SystemVerilog interface instantiations.

#### Include dependency

When file X includes file Y using the <code>include</code> directive, this is known as an include dependency. The <code>-autoread</code> option analyzes the file where the <code>include</code> directive is when any of the included files are changed between consecutive calls of the <code>-autoread</code> option.

#### Verilog and SystemVerilog compilation-unit dependency

The dependency occurs when the tool detects files that must be analyzed together in one compilation unit. For example, Verilog or SystemVerilog macro usage and definition are located in different files but not linked by the `include directive, such as a macro defined several times in different files. The <code>-autoread</code> option cannot determine which file to use. Language constructs that can cause compilation-unit dependencies include SystemVerilog function types, local parameters, and enumerated values defined by the <code>\$unit scope</code>.

#### File Format Inference Based on File Extensions

You can specify a file format by using the <code>-format</code> option with the <code>read\_file</code> command. If you do not specify a format, the <code>read\_file</code> command infers the format based on the file extensions. If the file extension in unknown, the tool assumes the .ddc format. The file extensions in Table are supported for automatic inference:

Format	File extensions
ddc	.ddc
db	.db, .sldb, .sdb, .db.gz, .sldb.gz, .sdb.gz
SystemVerilog	.sv, .sverilog, .sv.gz, .sverilog.gz

The supported extensions are not case-sensitive. All formats except the .ddc format can be compressed in gzip (.gz) format.

If you use a file extension that is not supported and you omit the -format option, the synthesis tool generates an error message. For example, if you specify  $read_file$  test.vlog, the tool issues the following DDC-2 error message:

Error: Unable to open file 'test.vlog' for reading. (DDC-2)

# Specifying the VHDL Version

To specify which VHDL language version to use during the read process, set the hdlin\_vhdl\_std variable. The valid values for the hdlin\_vhdl\_std variable are 1987, 1993, and 2008, corresponding to the 1987, 1993, and 2008 VHDL LRM releases respectively. The default is 2008.

# **Customizing Elaboration Reports**

By default, the tool displays inferred sequential elements, MUX\_OPs, and inferred three-state elements in the elaboration reports using the basic setting, as shown in Table 1-2. You can choose to customize the report by setting the hdlin\_reporting\_level

variable to none, comprehensive, or verbose. A true, false, or verbose indicates that the corresponding information is included, excluded, or detailed respectively in the elaboration report.

Table 1-2 Basic hdlin\_reporting\_level Variable Settings

Information displayed (information keyword)	basic (default)	none	comprehensive	verbose
Floating net to ground connections (floating_net_to_ground)	false	false	true	true
Inferred state variables (fsm)	false	false	true	true
<pre>Inferred sequential elements (inferred_modules)</pre>	true	false	true	verbose
MUX_OPs (mux_op)	true	false	true	true
Synthetic cells (syn_cell)	false	false	true	true
<pre>Inferred three-state elements (tri_state)</pre>	true	false	true	true

In addition to the four settings, you can customize the report by specifying the add (+) or subtract (-) option. For example, to report floating-net-to-ground connections, synthetic cells, inferred state variables, and verbose information for inferred sequential elements, but not MUX OPs or inferred three-state elements, enter

```
dc_shell> set_app_var hdlin_reporting_level verbose-mux_op-tri_state
```

Setting the hdlin\_reporting\_level variable as follows is equivalent to the set\_app\_var hdlin\_reporting\_level comprehensive command, which reports comprehensive information.


```
dc_shell> set_app_var hdlin_reporting_level \
   basic+floating_net_to_ground+syn_cell+fsm
```

# **Reporting Elaboration Errors**

HDL Compiler elaborates designs in a top-down hierarchical order. The elaboration failure of a top-level module prohibits the elaboration of all associated submodules. The hdlin\_elab\_errors\_deep variable allows the elaboration of submodules even if the top-level module elaboration fails, enabling HDL Compiler to report more elaboration, link, and VER-37 errors and warnings in a hierarchical design during the first elaboration run.

To understand how the hdlin\_elab\_errors\_deep variable works, consider the four-level hierarchical design in Figure 1-1. This design has elaboration (ELAB) errors as noted in the figure.

Figure 1-1 Hierarchical Design



Under default conditions, when you elaborate the design, HDL Compiler reports only the errors in the first level (ELAB-368 and ELAB-298 in module A). To find the second-level error (ELAB-298 in submodule D), you need to fix the first-level errors and elaborate again.

When you use the hdlin\_elab\_errors\_deep variable, you only need to elaborate once to find the errors in module A and submodule D.

The next section describes the hdlin\_elab\_errors\_deep variable and provides methodology and examples.

## Methodology

Use the following methodology to enable HDL Compiler to report elaboration, link, and VER-37 errors across the hierarchy during a single elaboration run.

- 1. Identify and fix all syntax errors in the design.
- 2. Set hdlin\_elab\_errors\_deep to true.

When you set the hdlin\_elab\_errors\_deep variable to true, HDL Compiler reports the following:

```
"HDLC compilation run in rtl debug mode."
```

#### Important:

HDL Compiler does not create designs when you set hdlin\_elab\_errors\_deep to true. The tool reports warnings if you try to use commands that require a design. For example, if you run list\_designs, the tool reports the following:

```
"Warning: No designs to list. (UID-275)"
```

- 3. Elaborate your design using the elaborate command.
- 4. Fix any elaboration, link, and VER-37 errors. Review the warnings and fix errors as needed.
- 5. Set the hdlin\_elab\_errors\_deep variable to false.
- 6. Elaborate your error-free design.
- 7. Proceed with your normal synthesis flow.


The next section provides examples showing HDL Compiler reporting all errors across the hierarchy, reducing the need for multiple elaboration runs.

# **Examples**

To enable HDL Compiler to find errors down the hierarchy in one elaboration run, you can set the hdlin\_elab\_errors\_deep variable to true, changing it from its default of false. This variable is designed to speed up the time in finding design elaboration and linking errors.

This section uses the top design in Figure 1-2 as an example of reporting hierarchical errors. The error messages are shown in the figure. Example 1-5 lists the RTL code of the top design.

Figure 1-2 Hierarchical Design



#### Example 1-5 VHDL RTL for the top Design

```
-- entity top
entity top is
port (clk, a, b : in bit;
      c, o: out bit);
end entity top;
architecture Al of top is
component sub1 is
port ( a, b : in bit;
               : out bit);
       0
end component sub1;
component sub2 is
               : in bit;
port (a, b
               : out bit);
end component sub2;
begin
  subl_inst: subl port map (a, b, c);
  sub2_inst: sub2 port map (a, b, o);
end A1;
-- entity sub1
library IEEE;
use IEEE.std_logic_1164.all;
entity subl is
                : in bit;
port (a, b
       0
                : out bit);
end entity sub1;
```

```
architecture Al of subl is
component compl is
end component mysub;
 signal r : bit_vector(1 downto 0);
 signal temp, sig, sig1 : std_logic;
 constant icon : integer := 5;
begin
 temp <= TO_STDULOGIC(a or b);</pre>
 temp <= '1';
                -- ELAB-368 error
 temp <= sig and 'Z'; -- ELAB-306 error
 mysub_inst: mysub port map (a, b, o);
end Al;
-- entity mysub
library IEEE;
use IEEE.std_logic_1164.all;
entity mysub is
end entity mysub;
architecture Al of mysub is
component bar is
end component bar;
signal temp : bit;
begin
   temp <= a and b;
                  -- ELAB-368 error
   temp <= '1';
   bar_inst: bar port map(a, b, o);
end A1;
-- entity bar
    (a, b : in bit;
entity bar is
port (a, b
             : out bit);
end entity bar;
architecture Al of bar is
begin
   o <= not b;
end A1;
-- entity sub2
entity sub2 is
end entity sub2;
architecture A1 of sub2 is
begin
```

```
o <= a or b;
end A1;
```

When you elaborate the top design with the hdlin\_elab\_errors\_deep variable set to false, HDL Compiler reports the first-level ELAB-368 and ELAB-306 errors in the sub1 module but does not report the ELAB-368 error in the mysub submodule. Example 1-6 shows the session log.

#### Example 1-6 Session Log

```
analyze -f vhdl test.vhd
Running HDLC
Compiling Entity Declaration TOP
Compiling Architecture Al of TOP
Compiling Entity Declaration SUB1
Compiling Architecture Al of SUB1
Compiling Entity Declaration MYSUB
Compiling Architecture Al of MYSUB
Compiling Entity Declaration BAR
Compiling Architecture Al of BAR
Compiling Entity Declaration SUB2
Compiling Architecture Al of SUB2
HDLC compilation completed successfully.
Loading db file '/.../lsi_10k.db'
elaborate top
Loading db file '/.../gtech.db'
Loading db file '/.../standard.sldb'
  Loading link library 'lsi_10k'
  Loading link library 'gtech'
Running HDLC
HDLC compilation completed successfully.
Elaborated 1 design.
Current design is now 'top'.
Information: Building the design 'sub1'. (HDL-193)
Error: ./test.vhd:39: Net 'temp', or a directly connected net, is driven
more than one source, and at least one source is a constant net.
(ELAB-368)
Error: ./test.vhd:40: Illegal use of tristate value (HDL-140).
(ELAB-306)
*** HDLC compilation terminated with 2 errors. ***
Information: Building the design 'sub2'. (HDL-193)
HDLC compilation completed successfully.
Warning: Unable to resolve reference 'subl' in 'top'. (LINK-5)
1
current_design
Current design is 'top'.
{top}
list_designs
sub2 top (*)
```

When you set the hdlin\_elab\_errors\_deep variable to true, HDL Compiler reports errors down the hierarchy during elaboration. Example 1-7 shows the session log with all the error messages.

#### Example 1-7 Session Log With All the Error Messages

```
set hdlin_elab_errors_deep TRUE
TRUE
analyze -f vhdl test.vhd
Running HDLC
Compiling Entity Declaration TOP
Compiling Architecture Al of TOP
Compiling Entity Declaration SUB1
Compiling Architecture Al of SUB1
Compiling Entity Declaration MYSUB
Compiling Architecture Al of MYSUB
Compiling Entity Declaration BAR
Compiling Architecture Al of BAR
Compiling Entity Declaration SUB2
Compiling Architecture Al of SUB2
HDLC compilation completed successfully.
Loading db file '/.../lsi_10k.db'
1
elaborate top
Loading db file '/.../gtech.db'
Loading db file '/.../standard.sldb'
  Loading link library 'lsi_10k'
  Loading link library 'gtech'
Running HDLC
*** HDLC compilation run in rtl debug mode. ***
HDLC compilation completed successfully.
Elaborated 1 design.
Current design is now 'top'.
Information: Building the design 'sub1'. (HDL-193)
*** HDLC compilation run in rtl debug mode. ***
Error: ./test.vhd:39: Net 'temp', or a directly connected net, is driven
by more than one source, and at least one source is a constant net.
(ELAB-368)
Error: ./test.vhd:40: Illegal use of tristate value (HDL-140).
(ELAB-306)
*** HDLC compilation terminated with 2 errors. ***
*** HDLC compilation run with backup flow. ***
Information: Building the design 'sub2'. (HDL-193)
*** HDLC compilation run in rtl debug mode. ***
HDLC compilation completed successfully.
Information: Building the design 'mysub'. (HDL-193)
*** HDLC compilation run in rtl debug mode. ***
Error: ./test.vhd:60: Net 'temp', or a directly connected net, is driven
by more than one source, and at least one source is a constant net.
(ELAB-368)
*** HDLC compilation terminated with 1 errors. ***
*** HDLC compilation run with backup flow. ***
Information: Building the design 'bar'. (HDL-193)
```

```
*** HDLC compilation run in rtl debug mode. ***
HDLC compilation completed successfully.

1
current_design
Error: Current design is not defined. (UID-4)
list_designs
Warning: No designs to list. (UID-275)
```

By default, only the top-level errors are reported, that is, the ELAB-368 and ELAB-306 errors in the sub1 module. To report the child-level ELAB-368 error in the mysub submodule, you need to fix all the errors in the sub1 module and run the elaborate command again. However, when you set the hdlin\_elab\_errors\_deep variable to true, HDL Compiler reports all errors down the hierarchy in one elaboration run:

- ELAB-368 and ELAB-306 in the sub1 module
- ELAB-368 in the mysub submodule

When the hdlin\_elab\_errors\_deep variable to true, note the following guidelines:

- No designs are saved because the designs could be erroneous.
- The compile\_ultra and list\_designs commands do not work.
- You should use the analyze command rather than the read\_file command to read your design because the read\_file command has no link functionality and accepts no command-line parameter specifications.
- All syntax errors are reported when you run the analyze command, but HDL Compiler is not a linting tool. You should use the check\_design command in Design Compiler for linting.
- The runtime during elaboration might increase slightly.

#### Important:

HDL Compiler does not create designs when the  $hdlin_elab_errors_deep$  variable is set to true. If you run the  $list_designs$  command, HDL Compiler reports the following warning message:

```
Warning: No designs to list. (UID-275)
```

# **Parameterized Models (Generics)**

HDL Compiler fully supports generic declarations. Generics enable you to assign unique parameter values to each model instance when you elaborate your design.

The model in Example 1-8 uses a generic declaration to determine the bit-width of a register input; the default width is declared as 2.

#### Example 1-8 Generic Register Model

```
LIBRARY IEEE, SYNOPSYS;
USE IEEE.STD_LOGIC_1164.ALL;
USE IEEE.STD_LOGIC_ARITH.ALL;
USE IEEE.STD_LOGIC_MISC.ALL;
USE SYNOPSYS.ATTRIBUTES.ALL;
entity DFF is
 generic(N : INTEGER := 2); --flip flop is N bits wide
 port(input : in STD_LOGIC_VECTOR (N - 1 downto 0);
      clock : in STD_LOGIC;
      output : out STD_LOGIC_VECTOR (N - 1 downto 0) );
end DFF;
architecture RTL of DFF is
begin
entry : process (clock)
   variable tmp: STD_LOGIC_VECTOR (N - 1 downto 0);
begin
 if (clock = '0') then
  tmp := input;
   if (clock = '1') then
     output <= tmp;
   end if;
 end if;
end process;
end RTL;
```

Assuming that the file n-register.vhd contains the model in Example 1-8, you can analyze the model and store the results in the user-specified design library, mylib, with the following command:

```
dc_shell-t> analyze -format vhdl n-register.vhd -library mylib
```

To specify that an instance of the register model should have a bit-width of 3, use the elaborate command as follows:

```
dc shell-t> elaborate DFF -parameters N=3
```

The list designs command shows the design, as follows:

```
dc_shell-t> list_designs
  Design
----
* DFF_N3
```

Using the read command with generics is not recommended, because you can build only the default value of the generic. If you do not specify a default generic value, HDL Compiler reports the following:

```
Warning: filename:line: Generic N does not have default value. (ELAB-943).
```

In addition, you need to either set the variable hdlin\_auto\_save\_templates to true or insert the --synopsys template directive in the entity declaration, as follows:

```
entity DFF is
  generic(N : INTEGER := 2);   --flip flop is N bits wide
  port(input : in STD_LOGIC_VECTOR (N - 1 downto 0);
      clock : in STD_LOGIC;
      output : out STD_LOGIC_VECTOR (N - 1 downto 0) );
  -- synopsys template
end DFF;
```

The variables described in Table 1-3 control the naming of designs based on generic models. To list their current values, enter the following command:

```
dc shell-t> printvar template *
```

Table 1-3 Template Naming Variables

Variable	Description			
template_naming_style	Controls how templates (VHDL generics) are named. The default value is %s_%p, where %s is the name of the source design and %p is the parameter list. By default, the design name and the parameter list are separated by an underscore (_). The naming style for the parameter list is the value of the template_separator_style variable.			
template_separator_style	Provides a separator character for multiple parameters in a template name. The default value is an underscore (_).			
template_parameter_style	Controls how template parameters are named. The default value is %s%d, where %s is the name of a parameter and %d is the value of that parameter. By default, the parameter name and value are not separated. If there are two or more parameters, each parameter name or value pair is separated by the value of the template_separator_style variable.			

### **Configuration Support**

To enable configuration support, set the hdlin\_enable\_configurations variable to true. The default is false. When this variable is set to true, you cannot use the -autoread option with the analyze and read\_file commands. For more information about the -autoread option, see "Automated Process of Reading Designs With Dependencies" on page 1-5.

Configurations bind entity design units to architecture design units. To specify a configuration, you must use the analyze command. For example, if file.vhdl contains the configuration my\_configuration, read the design as follows:

```
analyze -f vhdl file.vhdl
elaborate my_configuration
```

Although VHDL allows different entities to have different architecture definitions of the same name, for example,

```
arch RTL1 of entity1 is
....
arch RTL1 of entity2 is
...
```

the same does not hold for configurations, for example,

```
configuration CNFG1 of entity1 is .... configuration CNFG1 of entity2 is
```

is not supported. HDL Compiler binds the last read definition of CNFG1 to both entities. Therefore, configuration names for different entities must be unique. There is no configuration/entity pair concept. If configurations for different entities have the same name and they are analyzed sequentially, only the last one remains, as shown:

```
entity conf_0_vhdl is
    port(x: in BIT; y: out BIT);
end conf_0_vhdl;

architecture design_0_vhdl of conf_0_vhdl is
    begin
    y <= x;
end design_0_vhdl;

configuration trivial_config of work.conf_0_vhdl is
    for design_0_vhdl
    end for;
end trivial_config;</pre>
```

#### Example 1-9 shows the dc\_shell log output.

#### Example 1-9 dc\_shell Log Output

```
dc_shell> elaborate trivial_config
Running HDLC
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/standard.sldb'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/gtech.db'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/lsi_10k.db'
format: vhdl
HDLC compilation completed successfully.
Current design is now 'conf_0_vhdl'
```

#### This following subsections describe HDL Compiler support for configurations:

- Bind Entity to Architecture
- Architectures From the Same Library
- Architectures From Different Libraries
- Component Inside a Concurrent Block
- Generic in a Configuration
- Port Map in a Configuration
- Nested Configurations
- Indirectly Nested Configurations
- Embedded Configurations
- Multiple Architectures in Embedded Configurations
- Combinations of Embedded, Nested, and Standalone Configurations
- Mixed Language Support

### **Bind Entity to Architecture**

Example 1-10 uses configurations to bind components C1 and C2 to specific entity/ architecture combinations.

#### Example 1-10 Binding Entities to Architectures

```
entity a bar b is
 port(a, b: in bit; c: out bit);
end a_bar_b;
architecture struct of a_bar_b is
  begin
    c <= not(a) and b;
end struct;
entity a_b_bar is
  port(a, b: in bit; c: out bit);
end a_b_bar;
architecture struct of a_b_bar is
  begin
      c <= a and not(b);
end struct;
entity conf_1_vhdl is
   port(a, b: in bit; c: out bit);
end conf_1_vhdl;
architecture struct of conf_1_vhdl is
     component a_bar_b port(a, b: in bit; c :out bit); end component;
     component a_b_bar port(a, b: in bit; c :out bit); end component;
     signal a_not_b, not_a_b: bit;
        begin
            C1: a_bar_b port map(a, b, not_a_b);
            C2: a_b_bar port map(a, b, a_not_b);
            c <= not_a_b or a_not_b;</pre>
end struct;
configuration config_example1 of conf_1_vhdl is
    for struct -- of conf_1_vhdl
      for C1: a_bar_b
          use entity work.a_bar_b(struct);
      end for;
      for C2: a_b_bar
         use entity work.a_b_bar(struct);
      end for;
   end for;
end config_example1;
```

#### Example 1-11 shows the dc shell log output.

#### Example 1-11 dc\_shell Log Output

```
dc_shell> elaborate config_example1
Running HDLC
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/standard.sldb'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/gtech.db'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/lsi_10k.db'
Component WORK.STRUCT/CONF_1_VHDL.STRUCT.Cl has been configured to use the following implementation:
    Work Library: WORK
    Design Name: A_BAR_B
```

```
Architecture Name: STRUCT

Component WORK.STRUCT/CONF_1_VHDL.STRUCT.C2 has been configured to use the following implementation:

Work Library: WORK

Design Name: A_B_BAR

Architecture Name: STRUCT

HDLC compilation completed successfully.

Information: Building the design 'A_BAR_B'. (HDL-193)

Running HDLC

HDLC compilation completed successfully.

Information: Building the design 'A_B_BAR'. (HDL-193)

Running HDLC

HDLC compilation completed successfully.

Current design is now 'conf_1_vhdl'
```

### **Architectures From the Same Library**

Example 1-12 uses configurations to bind two instances of the same component to different architectures of the same entity. The component C1 is implemented using architecture struct1, while C2 is implemented using architecture struct2.

#### Example 1-12 Using Architectures From the Same Library

```
entity a_bar_b is
    port(a, b: in bit; c: out bit);
end a bar b;
architecture struct1 of a_bar_b is
    c <= not(a) and b;
end struct1;
architecture struct2 of a_bar_b is
begin
    c <= a and not(b);
end struct2;
entity conf 2 vhdl is
    port(a, b: in bit; c: out bit);
end conf_2_vhdl;
architecture struct of conf_2_vhdl is
    component a_bar_b port(a, b: in bit; c :out bit); end component;
    signal a_not_b, not_a_b: bit;
begin
    C1: a_bar_b port map(a, b, not_a_b);
    C2: a_bar_b port map(a, b, a_not_b);
    c <= not_a_b or a_not_b;</pre>
end struct;
```

```
configuration config_example2 of conf_2_vhdl is
  for struct -- of conf_2_vhdl
     for C1: a_bar_b
         use entity work.a_bar_b(struct1);
  end for;
  for C2: a_bar_b
         use entity work.a_bar_b(struct2);
  end for;
  end for;
end config_example2;
```

#### Example 1-13 shows the dc shell log output.

#### Example 1-13 dc\_shell Log Output

```
dc shell> elaborate config example2
Running HDLC
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/standard.sldb'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/gtech.db'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/lsi_10k.db'
Component WORK.STRUCT/CONF_2_VHDL.STRUCT.C1 has been configured to use
the following implementation:
      Work Library: WORK
      Design Name: A_BAR_B
      Architecture Name: STRUCT1
Component WORK.STRUCT/CONF_2_VHDL.STRUCT.C2 has been configured to use
the following implementation:
      Work Library: WORK
     Design Name: A_BAR_B
      Architecture Name: STRUCT2
HDLC compilation completed successfully.
Information: Building the design 'A_BAR_B'. (HDL-193)
Running HDLC
HDLC compilation completed successfully.
Information: Building the design 'A_BAR_B'. (HDL-193)
Running HDLC
HDLC compilation completed successfully.
Current design is now 'conf_2_vhdl'
```

#### **Architectures From Different Libraries**

Example 1-14 uses configurations to bind two instances of the same component to different architectures in different libraries as follows:

- Bind architecture struct1 in library lib1 to an instantiation C1 of component a\_bar\_b
- Bind architecture struct2 in library lib2 to an instantiation C2 of component a\_bar\_b

#### Example 1-14 Using Architectures From Different Libraries

```
--File config3.1.vhdl
```

```
entity a bar b is
   port(a, b: in bit; c: out bit);
end a_bar_b;
architecture struct1 of a_bar_b is
   c <= not(a) and b;
end struct1;
--File config3.2.vhdl
entity a_bar_b is
    port(a, b: in bit; c: out bit);
end a_bar_b;
architecture struct2 of a_bar_b is
    c <= a and not(b);
end struct2;
--File config3.3.vhdl
library lib1, lib2;
use lib1.all;
use lib2.all;
entity conf_3_vhdl is
    port(a, b: in bit; c: out bit);
end conf_3_vhdl;
architecture struct of conf_3_vhdl is
    component a_bar_b port(a, b: in bit; c :out bit); end component;
    signal a_not_b, not_a_b: bit;
begin
    C1: a_bar_b port map(a, b, not_a_b);
    C2: a_bar_b port map(a, b, a_not_b);
    c <= not_a_b or a_not_b;</pre>
end struct;
configuration config_example3 of conf_3_vhdl is
    for struct -- of conf_3_vhdl
        for C1: a_bar_b
            use entity lib1.a_bar_b(struct1);
        end for;
        for C2: a_bar_b
            use entity lib2.a_bar_b(struct2);
        end for;
    end for;
end config_example3;
```

#### Example 1-15 shows the script file.

#### Example 1-15 Script File

```
sh mkdir ./lib1
sh mkdir ./lib2
define_design_lib lib1 -path ./lib1
define_design_lib lib2 -path ./lib2

analyze -f vhdl config3.1.vhdl -library lib1
analyze -f vhdl config3.2.vhdl -library lib2
analyze -f vhdl config3.3.vhdl
elaborate config_example3
```

#### Example 1-16 shows the dc\_shell log output.

#### Example 1-16 dc shell Log Output

```
dc shell> analyze -f vhdl config3.1.vhdl -library lib1
Running HDLC
Input files:
/TEST DIRECTORY/config3.1.vhdl
Compiling Entity Declaration A_BAR_B
Compiling Architecture STRUCT1 of A BAR B
HDLC compilation completed successfully.
dc_shell> analyze -f vhdl config3.2.vhdl -library lib2
Running HDLC
Input files:
config3.2.vhdl
Compiling Entity Declaration A_BAR_B
Compiling Architecture STRUCT2 of A_BAR_B
HDLC compilation completed successfully.
dc_shell> analyze -f vhdl config3.3.vhdl
Running HDLC
Input files:
config3.3.vhdl
Compiling Entity Declaration CONF_3_VHDL
Compiling Architecture STRUCT of CONF 3 VHDL
Compiling Configuration CONFIG EXAMPLE3 of CONF 3 VHDL
HDLC compilation completed successfully.
dc_shell> elaborate config_example3
Running HDLC
Loading db file '/SYNOPSYS ROOT DIRECTORY/libraries/syn/standard.sldb'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/gtech.db'
Loading db file '/SYNOPSYS_ROOT_DIRECTORY/libraries/syn/lsi_10k.db'
Component WORK.STRUCT/CONF_3_VHDL.STRUCT.C1 has been configured to use
the following implementation:
      Work Library: LIB1
     Design Name: A BAR B
      Architecture Name: STRUCT1
Component WORK.STRUCT/CONF_3_VHDL.STRUCT.C2 has been configured to use
```

```
the following implementation:
    Work Library: LIB2
    Design Name: A_BAR_B
    Architecture Name: STRUCT2

HDLC compilation completed successfully.

Information: Building the design 'A_BAR_B'. (HDL-193)

Running HDLC

HDLC compilation completed successfully.

Information: Building the design 'A_BAR_B'. (HDL-193)

Running HDLC

HDLC compilation completed successfully.

Current design is now 'conf_3_vhdl'
```

### **Component Inside a Concurrent Block**

Example 1-17 shows how to configure a component inside a concurrent block.

#### Example 1-17 Configuration With a Component Inside a Concurrent Block

```
entity my_or is
port (a, b: bit; z:out bit);
end entity my_or;
architecture beh of my_or is
begin
  z \ll a or b;
end;
entity conf_4_vhdl is
 port(A, B: BIT; Z: out BIT);
end;
architecture BEH of conf_4_vhdl is
  component MY AND
    port(A, B: BIT;
         Z: out BIT);
  end component;
begin
  Z <= A;
  L1: for I in 3 downto 0 generate
    L2: for J in I downto 0 generate
      L3: if J < I generate
        U1: MY_AND port map ( A, B, Z);
      end generate;
    end generate;
  end generate;
configuration config_example4 of conf_4_vhdl is
    for beh
        for L1
          for L2
```

Example 1-18 shows the dc\_shell log output.

#### Example 1-18 dc\_shell Log Output

### **Generic in a Configuration**

Example 1-19 shows a component configuration used with a generic. Notice that the MY\_AND component is configured to use the MY\_OR (width = 8) implementation.

#### Example 1-19 Generic in a Configuration

```
entity my_or is
generic (width : integer);
port (a, b: in bit_vector (width - 1 downto 0);
         z: out bit_vector (width - 1 downto 0));
end entity my_or;
architecture beh of my_or is
begin
  z \ll a \text{ or } b;
end;
entity conf_5_vhdl is
  port(A, B: in BIT_VECTOR (7 downto 0);
        z:
           out BIT_VECTOR (7 downto 0));
end;
architecture BEH of conf_5_vhdl is
  component MY_AND
    generic (width: integer := 5);
    port(A, B: in BIT_VECTOR (width - 1 downto 0);
         Z: out BIT_VECTOR (width - 1 downto 0));
  end component;
begin
  Z \leq A_i
  L1: for I in 3 downto 0 generate
        U1: MY_AND port map ( A, B, Z);
  end generate;
end;
configuration config example5 of conf 5 vhdl is
    for beh
        for L1
            for U1: MY AND
              use entity work.my_or (beh) generic map (width => 8);
        end for;
    end for;
end config_example5;
```

#### Example 1-20 shows the dc\_shell log output.

#### Example 1-20 dc\_shell Log Output

```
Design Name: MY_OR
    Architecture Name: BEH

HDLC compilation completed successfully.
    Information: Building the design 'MY_OR' instantiated from design
'conf_5_vhdl' with the parameters "width=8". (HDL-193)
    Running HDLC
    HDLC compilation completed successfully.
    Current design is now 'conf_5_vhdl'
```

### **Port Map in a Configuration**

Example 1-21 uses a port map in the configuration.

#### Example 1-21 Port Map in a Configuration

```
library ieee;
use ieee.std_logic_1164.all;
use std.standard.time;
entity INVERTER is
port (IN1 : in BIT; OUT1 : out BIT);
end INVERTER;
architecture STRUCT_I of INVERTER is
 begin
      out1 <= not in1;
  end STRUCT_I;
entity CONFIG_TEST1_VHDL is end CONFIG_TEST1_VHDL;
architecture STRUCT_T of CONFIG_TEST1_VHDL is
  signal S1, S2 : BIT := '1';
component INV_COMP is
  port (IN_A : in BIT; OUT_A : out BIT);
end component;
  begin
     lh : inv_comp port map (S1, S2);
end STRUCT_T;
configuration CONFIG_INV of CONFIG_TEST1_VHDL is
for STRUCT_T
  for LH : INV_COMP
    use entity WORK.INVERTER (STRUCT_I)
    generic map (PropTime => TimeH)
   port map (IN1 => IN A, OUT1 => OUT A);
  end for;
end for;
end CONFIG_INV;
```

### **Nested Configurations**

Example 1-22 uses a configuration inside a configuration.

#### Example 1-22 Nested Configurations

```
entity MY_AND is
port (A, B : in bit;
O : out bit);
end entity MY_AND;
architecture STRUCT1 of MY_AND is
begin
O \le A and B;
end STRUCT1;
entity MY XOR is
end entity MY_XOR;
architecture STRUCT1 of MY_XOR is
component MY_AND is
port (A, B : in bit;
     O: out bit);
end component;
begin
 U1: MY_AND port map (A, B, O);
end STRUCT1;
architecture STRUCT2 of MY_XOR is
signal S1, S2, S3, S4 : bit;
begin
S1 \le A and (not B);
S2 \le (not A) and B;
0 \le S1 \text{ or } S2;
end STRUCT2;
entity CONFIG_FLOW_VHDL is
port (A1, A2, A3, A4, A5, B1, B2, B3, B4, B5 : in bit;
     01, 02, 03, 04, 05
                                             : out bit);
end CONFIG_FLOW_VHDL;
architecture A1 of CONFIG_FLOW_VHDL is
component MY_XOR_COM is
end component;
component MY_AND is
port ( A, B : in bit;
              : out bit);
      0
end component ;
begin
```

```
U1 : MY XOR COM port map (A1, B1, O1);
U2 : MY_XOR_COM port map (A2, B2, O2);
U3 : MY_XOR_COM port map (A3, B3, O3);
U4 : MY_XOR_COM port map (A4, B4, O4);
V1 : MY_AND port map (A5, B5, O5);
end A1;
configuration TEST_CONFIG of MY_XOR is
  for STRUCT1
    for U1: MY_AND
     use entity WORK.MY_AND;
    end for;
  end for;
end TEST CONFIG;
configuration MY_CONFIG of CONFIG_FLOW_VHDL is
use WORK.all;
for Al
  for U1, U2 : MY XOR COM
     use entity WORK.MY_XOR (STRUCT1);
  end for;
  for U3 : MY_XOR_COM
    use entity WORK.MY_XOR (STRUCT2);
  end for;
  for U4 : MY XOR COM
     use configuration WORK.TEST_CONFIG;
  end for;
  for V1 : MY AND
      -- Use default
  end for;
end for;
end MY_CONFIG;
```

### **Indirectly Nested Configurations**

A directly nested configuration is a nested configuration that configures its subdesign by using a "use configuration subconfigure" clause, as shown in Example 1-23; an indirectly nested configuration is a nested configuration that configures its subdesign by using a "for" clause, as shown in Example 1-24.

#### Example 1-23 Directly Nested Configuration

```
configuration conf_in_conf_configuration of conf_in_conf is
   for test
      for all : conf_test
        use configuration WORK.TEST_CONFIG; -- nested configuration
      end for;
   end for;
end conf_in_conf_configuration;
```

#### Example 1-24 Indirectly Nested Configuration

### **Embedded Configurations**

The HDL Compiler tool supports embedded configurations. To enable this feature, set hdlin\_enable\_configurations to true. Example 1-25 shows an embedded configuration.

#### Example 1-25 Embedded Configuration

```
entity Buf is
   port (Input_pin: in Bit;Output_pin: out Bit);
end Buf;
architecture DataFlow of Buf is begin
   Output pin <= Input pin;
end DataFlow;
entity Test_Bench is
end Test_Bench;
  architecture Structure of Test_Bench is
  component Buf is
  port (Comp_I: in Bit; Comp_O: out Bit);
  end component;
  -- A binding indication; generic and port map aspects within a
  -- binding indication associate actuals (Comp_I, etc.) with
  -- formals of the entity declaration (Input_pin, etc.):
  for UUT: Buf
  use entity Work.Buf(DataFlow)
  port map (Input_pin => Comp_I,
  Output_pin=> Comp_O);
  signal S1,S2: Bit;
  begin
  -- A component instantiation statement; generic and portmap aspects
  -- within a component instantiation statement associate actuals
  -- (S1, etc.) with the formals of a component (Comp_I, etc.):
  UUT: Buf
  port map (Comp_I => S1, Comp_O => S2);
```

```
-- A block statement; generic and port map aspects within the
-- block header of a block statement associates actuals (in this
-- case, 4), with the formals defined in the block header:
B: block
begin
end block;
end Structure;
```

You can use an embedded configuration in only one for construct in one component, as shown in Example 1-26. However, as a standalone configuration, you can use embedded configurations in multi-nested configurations and in several for keywords, as shown in Example 1-27.

#### Example 1-26 Embedded Configuration

```
for u1: embed_shift use entity work.embed_shift;
```

#### Example 1-27 Standalone Configuration

To read designs with embedded configurations, use the standard VHDL reading methods of read\_vhld plus link or analyze and elaborate using the entity name. To help understand how the tool processes embedded configurations, consider the design in Example 1-28. When you read the RTL using read\_vhdl and link, the tool creates the log shown in Example 1-29; if you use analyze and elaborate, the tool creates the log shown in Example 1-30.

#### Note:

If you have multiple embedded architectures, you need to follow the usage guidelines described in "Multiple Architectures in Embedded Configurations" on page 1-35.

#### Example 1-28 Module config\_simple\_embed.vhd

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity embed_shift is
  generic (width: integer := 4);
  port (
   a : in bit_vector(0 to width - 1);
```

```
b : in integer;
        o : out bit_vector(0 to width - 1)
 );
end entity embed_shift;
architecture tmp1 of embed_shift is
begin
   o <= a sll b;
end architecture tmp1;
entity mix_embed_config is
port (
 a : in bit vector(0 to 7);
 b : in integer;
        o : out bit_vector(0 to 7)
 );
end entity mix_embed_config;
architecture tmp of mix_embed_config is
 component my shift is
 generic (width: integer := 8);
 port (
 a : in bit_vector(0 to width - 1);
 b : in integer;
 o : out bit_vector(0 to width - 1)
 );
 end component my shift;
for u1: my_shift use entity work.embed_shift;
-- use an embedded configuration because the component name is different
-- than the library name
begin
ul: my_shift
     port map (a, b, o);
end architecture tmp;
```

#### Example 1-29 HDL Compiler Report Log for read\_vhdl and link

```
dc shell> read vhdl config.support embedded.config 2.vhd
Loading db file '.../libraries/syn/lsi_10k.db'
Loading db file '.../libraries/syn/gtech.db'
Loading db file '.../libraries/syn/standard.sldb'
  Loading link library 'lsi_10k'
  Loading link library 'gtech'
Loading vhdl file './config_simple_embed.vhd'
Running HDLC
Compiling Entity Declaration EMBED_SHIFT
Compiling Architecture TMP1 of EMBED_SHIFT
Compiling Entity Declaration MIX_EMBED_CONFIG
Compiling Architecture TMP of MIX_EMBED_CONFIG
Component WORK.TMP/MIX_EMBED_CONFIG.TMP.U1 has been configured to use the
following implementation:
      Work Library: WORK
      Design Name: EMBED_SHIFT
HDLC compilation completed successfully.
```

#### Example 1-30 HDL Compiler Report Log for Analyze and Elaborate With Entity Name

```
analyze -f vhdl config_simple_embed.vhd
Running HDLC
Compiling Entity Declaration EMBED_SHIFT
Compiling Architecture TMP1 of EMBED SHIFT
Compiling Entity Declaration MIX_EMBED_CONFIG
Compiling Architecture TMP of MIX_EMBED_CONFIG
HDLC compilation completed successfully.
elaborate mix embed config
Loading db file '.../libraries/syn/gtech.db'
Loading db file '.../libraries/syn/standard.sldb'
  Loading link library 'gtech'
Running HDLC
Component WORK.TMP/MIX_EMBED_CONFIG.TMP.U1 has been configured to use the
following implementation:
      Work Library: WORK
      Design Name: EMBED_SHIFT
HDLC compilation completed successfully.
Elaborated 1 design.
Current design is now 'mix_embed_config'.
Information: Building the design 'EMBED SHIFT' instantiated from design
'mix embed config' with the parameters "width=8". (HDL-193)
HDLC compilation completed successfully.
1
```

### **Multiple Architectures in Embedded Configurations**

If you define multiple architectures for an entity and you instantiate that entity without a specific binding to a specific architecture, the tool chooses the last architecture that is read as the architecture for that entity. Consider Example 1-31 in which the MY\_AND entity is instantiated by the U2 component. The tool by default will associate the last architecture read, STRUCT4, with U2 and generate a warning shown in Example 1-32 on page 1-36.

To avoid this warning, you need to tell the tool which architecture to choose by specifying the binding in the embedded configuration. If you have several nested designs, you can

create a standalone configuration to connect the correct working libraries to the appropriate components and configurations. In HDL Compiler, you can select a configuration identifier and use it to elaborate. To ensure your design intent is correctly read, elaborate with the configuration identifier, as described in the next section.

#### Example 1-31 Default Architecture for U2 Component is STRUCT4

```
entity MY_AND is
  port (0 : out bit);
end entity MY_AND;
architecture STRUCT3 of MY_AND is
begin
  0 <= '1';
end STRUCT3;
architecture STRUCT4 of MY_AND is
begin
  0 <= '0';
end STRUCT4;
entity E1 is
 port (0 : out bit);
end E1;
architecture Al of El is
  component MY_AND is \,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\,\, same name as a previously found entity
    port(0 : out bit);
  end component;
begin
  U2 : MY_AND port map (0);
end A1;
```

#### Example 1-32 Tool Warns When Multiple Architectures Are Associated With an Entity

```
dc shell> read vhdl test.vhd
Loading db file '.../libraries/syn/gtech.db'
Loading db file '.../libraries/syn/standard.sldb'
 Loading link library 'gtech'
Loading vhdl file '.../test.vhd'
Running HDLC
Compiling Entity Declaration MY_AND
Compiling Architecture STRUCT3 of MY_AND
Compiling Architecture STRUCT4 of MY_AND
Compiling Entity Declaration El
Compiling Architecture Al of El
Warning: The entity 'MY_AND' has multiple architectures defined. The
last defined architecture 'STRUCT4' will be used to build the design
by default. (VHD-6)
HDLC compilation completed successfully.
Current design is now './MY_AND.db:MY_AND'
```

```
Loaded 2 designs.
Current design is 'MY_AND'.
MY AND E1
```

# **Combinations of Embedded, Nested, and Standalone Configurations**

In order for the tool to correctly read your design when it contains a combination of embedded, nested, and standalone configurations, you must elaborate with the configuration identifier instead of with the entity name. To help understand this requirement, consider the design in Example 1-34 through Example 1-38 on page 1-41. In this design, if you want the tool to select the "swap\_seq of swap\_exp" architecture, you must elaborate the design using the configuration identifier, as shown in Example 1-33.

Example 1-33 Correct Way to Read the Design With Embedded, Nested, and Standalone Configurations - Use the Configuration Identifier

```
manalyze -f vhdl config_nested_sync_async.vhd
analyze -f vhdl config_nested_swap_exp.vhd
analyze -f vhdl embed_nested_standalone_top.vhd
elaborate embed_top_config
write -f ddc -h -o t.ddc
...
```

If you elaborate with the entity name (or use <code>read\_vhd1</code>), the tool chooses the last defined architecture it sees, which is "comb\_seq of swap\_exp" for this design. The tool does not see the configuration defined in embed\_nest\_standalone\_top.vhd. When you use the configuration identifier (embed\_top\_config) to elaborate, the tool reads both the architecture and configuration code and will use the embedded and standalone configuration's declarations for its library and it will choose the correct components.

#### Example 1-34 Top Module in embed\_nest\_standalone\_top.vhd

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity embed_top is
         -- generic (width:integer:= 3);
         generic (width:integer:= 2);
         port (
                    : in std_logic;
               clk
               rst : in std_logic;
               din : in std_logic_vector(0 to width);
                   : in std_logic_vector(0 to width);
               dout : out std_logic_vector(0 to width)
         );
end entity embed_top;
architecture arch1 of embed_top is
```

```
signal tmp_data1, tmp_data2 : std_logic_vector(0 to width);
         for swap_exp2 : work.components.swap_exp use entity
work.swap_exp(swap_seq)
generic map (width1 => 3);
begin
         swap_exp1 : component work.components.swap_exp
            port map (clk => clk, rst => rst, din1 => din, din2 => d2, dout =>
tmp_data1);
         swap_exp2 : component work.components.swap_exp
            port map (clk => clk, rst => rst, din1 => tmp_data1, din2 => d2, dout =>
tmp_data2);
         swap_exp3 : component work.components.swap_exp
            port map (clk => clk, rst => rst, din1 => tmp_data2, din2 => d2, dout =>
dout);
end architecture arch1;
configuration embed_top_config of embed_top is
   for arch1
       for swap_exp1 : work.components.swap_exp
            use entity work.swap_exp(comb_seq) generic map (width1 => width + 1);
            for comb_seq
                for seq_gen
                    for all: work.components.sync_async
                  use entity work.sync_async(sync_logic) generic map (width2 => width1
+ 1);
                  for sync_logic
                     for next_level : work.components.and_or
                         use entity work.and_or(and_of_logic);
                       end for;
                  end for;
                  end for;
                end for;
            end for;
       end for;
-- for swap_exp2 : is simple so it embeds on architecture
       -- for swap_exp3 : work.components.sync_async
          -- use entity work.sync_async(comb_seq);
       for swap_exp3 : work.components.swap_exp
            use entity work.swap_exp(comb_seq);
            for comb_seq
                for sea gen
                    for all : work.components.sync_async
                      use entity work.sync_async(async_logic);
                    end for;
                end for;
            end for;
       end for;
   end for;
end configuration embed_top_config;
```

#### Example 1-35 Submodule in config\_nested\_swap\_exp.vhd

```
library ieee;
use ieee.std_logic_1164.all;
```

```
use ieee.std logic unsigned.all;
library work;
use work.components.all;
entity swap_exp is
     -- generic (width1 : integer := 4);
     generic (width1 : integer := 3);
     port (clk : in std_logic;
            rst : in std_logic;
            din1 : in std_logic_vector(0 to width1 - 1);
            din2 : in std_logic_vector(0 to width1 - 1);
            dout : out std logic vector(0 to width1 - 1));
end entity swap_exp;
architecture swap_seq of swap_exp is
signal int_data : std_logic_vector (0 to width1 - 1);
begin
     swap : process (din1) is
     begin
        int_data(2) <= din1(0);</pre>
        int_data(1) <= din1(1);</pre>
        int_data(0) <= din1(2);
     end process swap;
     seq : process (clk, rst) is
     begin
        if clk'event and clk = '1' then
           if (rst = '0') then
               -- dout <= 0;
               dout <= (others => '0');
           else
               dout <= int_data;</pre>
           end if;
        end if;
     end process seq;
end architecture swap_seq;
architecture comb_seq of swap_exp is
signal int_data : std_logic_vector (0 to 3);
begin
     comb : process (din1, din2) is
     begin
        int_data(2) <= not(din1(0) or din2(0));</pre>
        int_data(1) <= din1(2) xor din2(1);</pre>
        int_data(0) <= din1(1) and din2(2);</pre>
     end process comb;
     -- seq gen: for i in 0 to 3 generate
     seq_gen: for i in 0 to 2 generate
     begin
            reg : component work.components.sync_async
            port map (clk => clk, rst => rst, d1 => int_data(i), d2 =>
```

```
int_data(i),
q => dout(i));
    end generate seq_gen;
end architecture comb_seq;
```

#### Example 1-36 Submodule in config\_nested\_sync\_async.vhd

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity sync_async is
     generic (width2 : integer := 8);
     port (clk : in std_logic;
           rst : in std_logic;
           d1 : in std_logic;
           d2 : in std_logic;
           q : out std_logic);
end entity sync_async;
architecture sync_logic of sync_async is
    signal tmp_data1, tmp_data2 : std_logic_vector(0 to width2-1);
     next_level : component work.components.and_or
         port map (a => d1, b => d2, o => tmp_data1(0));
     reg: process (clk, rst) is
     begin
        if (clk'event and clk ='1') then
           if (rst = '0') then
              q <= '0';
           else
              q <= tmp_data1(0);</pre>
           end if;
        end if;
     report ("in SYNC");
     end process reg;
end architecture sync_logic;
architecture async_logic of sync_async is
    signal tmp_data1, tmp_data2 : std_logic_vector(0 to width2-1);
    begin
     process (clk, rst) is
     begin
        if rst = '0' then
           q <= '0';
        elseif clk'event and clk = '1' then
           q <= d1;
        end if;
     report ("in ASYNC");
```

```
end process;
end architecture async_logic;
```

#### Example 1-37 Submodule in config\_nested\_and\_or.vhd

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity and_or is
     port (a : in std_logic;
           b : in std_logic;
           o : out std_logic);
end entity and_or;
architecture and_of_logic of and_or is
     begin
        o \le a and b;
end architecture and_of_logic;
architecture or_of_logic of and_or is
     begin
        o <= a or b;
end architecture or_of_logic;
```

#### Example 1-38 Submodule in config\_nested\_pkg.vhd

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
package components is
   component and_or is
     port (a : in std logic;
           b : in std_logic;
           o : out std_logic);
   end component and_or;
   component sync_async is
     port (clk : in std_logic;
           rst : in std_logic;
            d1 : in std_logic;
            d2 : in std_logic;
             q : out std_logic);
   end component sync_async;
   component swap_exp is
     port (clk : in std_logic;
           rst : in std_logic;
           din1 : in std_logic_vector(0 to 2);
           din2 : in std_logic_vector(0 to 2);
           dout : out std_logic_vector(0 to 2));
```

end component swap\_exp;

end package components;

#### Example 1-39 HDL Compiler Log Report

```
analyze -f vhdl config_nested_and_or.vhd
Running HDLC
Compiling Entity Declaration AND_OR
Compiling Architecture AND_OF_LOGIC of AND_OR
Compiling Architecture OR_OF_LOGIC of AND_OR
Warning: The entity 'and_or' has multiple architectures defined. The
last defined
architecture 'or_of_logic' will be used to build the design by default.
(VHD-6)
HDLC compilation completed successfully.
analyze -f vhdl config_nested_pkg.vhd
Running HDLC
Compiling Package Declaration COMPONENTS
HDLC compilation completed successfully.
analyze -f vhdl config_nested_sync_async.vhd
Running HDLC
Compiling Entity Declaration SYNC_ASYNC
Compiling Architecture SYNC_LOGIC of SYNC_ASYNC
Compiling Architecture ASYNC_LOGIC of SYNC_ASYNC
Warning: The entity 'sync_async' has multiple architectures defined. The
last defined
architecture 'async_logic' will be used to build the design by default.
HDLC compilation completed successfully.
analyze -f vhdl config_nested_swap_exp.vhd
Running HDLC
Compiling Entity Declaration SWAP_EXP
Compiling Architecture SWAP_SEQ of SWAP_EXP
Compiling Architecture COMB_SEQ of SWAP_EXP
Warning: The entity 'swap_exp' has multiple architectures defined. The
last defined
architecture 'comb seq' will be used to build the design by default.
(VHD-6)
HDLC compilation completed successfully.
analyze -f vhdl embed_nest_standalone_top.vhd
Running HDLC
Compiling Entity Declaration EMBED_TOP
Compiling Architecture ARCH1 of EMBED_TOP
Compiling Configuration EMBED_TOP_CONFIG of EMBED_TOP
HDLC compilation completed successfully.
elaborate embed_top_config
Loading db file '.../libraries/syn/gtech.db'
Loading db file '.../libraries/syn/standard.sldb'
 Loading link library 'gtech'
Running HDLC
Component WORK.ARCH1/EMBED_TOP.ARCH1.SWAP_EXP1 has been configured to use
```

```
following
implementation:
     Work Library: WORK
     Design Name: SWAP_EXP
     Architecture Name: COMB_SEQ
Component WORK.ARCH1/EMBED_TOP.ARCH1.SWAP_EXP2 has been configured to use
the following implementation:
     Work Library: WORK
     Design Name: SWAP_EXP
     Architecture Name: SWAP_SEQ
Component WORK.ARCH1/EMBED_TOP.ARCH1.SWAP_EXP3 has been configured to use
the following implementation:
     Work Library: WORK
     Design Name: SWAP_EXP
     Architecture Name: COMB_SEQ
HDLC compilation completed successfully.
Elaborated 1 design.
Current design is now 'embed top'.
Information: Building the design 'SWAP_EXP' instantiated from design
'embed_top' with
the parameters "width1=3". (HDL-193)
Component WORK.COMB_SEQ/SWAP_EXP.COMB_SEQ.SEQ_GEN.REG has been configured
to use the following implementation:
     Work Library: WORK
     Design Name: SYNC_ASYNC
     Architecture Name: SYNC_LOGIC
     Configuration Name :
WORK.EMBED_TOP_CONFIG.ARCH1.SWAP_EXP1.COMB_SEQ.SEQ_GEN.REG
HDLC compilation completed successfully.
Information: Building the design 'SWAP_EXP' instantiated from design
'embed_top' with
the parameters "width1=3". (HDL-193)
Inferred memory devices in process
       in routine swap_exp_width13 line 28 in file
            '../vhdl_rtl/config_nested_swap_exp.vhd'.
______
Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
______
HDLC compilation completed successfully.
Warning: Design 'swap_exp_width13' was renamed to 'swap_exp_width13_1' to
a conflict with another design that has the same name but different
parameters.
(LINK-17)
Information: Building the design 'SWAP_EXP' instantiated from design
'embed_top' with
the parameters "width1=3". (HDL-193)
Component WORK.COMB_SEQ/SWAP_EXP.COMB_SEQ.SEQ_GEN.REG has been configured
to use the
following implementation:
    Work Library: WORK
     Design Name: SYNC_ASYNC
     Architecture Name: ASYNC_LOGIC
     Configuration Name :
```

```
HDLC compilation completed successfully.
Warning: Design 'swap_exp_width13' was renamed to 'swap_exp_width13_2' to
avoid a
conflict
with another design that has the same name but
different parameters. (LINK-17)
Information: Building the design 'SYNC_ASYNC' instantiated from design
'swap exp width13'
with the parameters "width2=4". (HDL-193)
Component WORK.SYNC_LOGIC/SYNC_ASYNC.SYNC_LOGIC.NEXT_LEVEL has been
configured to use
the following implementation:
    Work Library: WORK
    Design Name: AND_OR
    Architecture Name: AND_OF_LOGIC
    Configuration Name :
'report' output: in SYNC
Inferred memory devices in process
      in routine sync_async_width24 line 22 in file
         '../vhdl_rtl/config_nested_sync_async.vhd'.
______
Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
q_reg | Flip-flop | 1 | N | N | N | N | N | N | N |
______
HDLC compilation completed successfully.
Information: Building the design 'SYNC_ASYNC' instantiated from design
'swap_exp_width13_2' with the parameters "width2=8". (HDL-193)
'report' output: in ASYNC
Inferred memory devices in process
      in routine sync_async_width28 line 38 in file
          '../vhdl_rtl/config_nested_sync_async.vhd'.
______
Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
    ______
HDLC compilation completed successfully.
Information: Building the design 'AND_OR'. (HDL-193)
HDLC compilation completed successfully.
```

### **Tool Behavior When Using Elaborate With the Entity Name**

As noted in the previous sections, under certain conditions you need to elaborate using the configuration identifier. This section describes the problems that arise when you elaborate with the entity name.

Example 1-40 and Example 1-41 on page 1-45 show incorrect ways to read the design described in Example 1-34 on page 1-37 through Example 1-38 on page 1-41. Recall that for this design you want the tool to select the "swap\_seq of swap\_exp" architecture. An explanation of the tool behavior follows the examples.

# Example 1-40 Incorrect Way to Read When Using the Standalone Configuration: Elaborate With the Entity Name

```
analyze -f vhdl config_nested_sync_async.vhd
analyze -f vhdl config_nested_swap_exp.vhd
analyze -f vhdl embed_nested_standalone_top.vhd
elaborate embed_top
write -f ddc -h -o t.ddc
```

## Example 1-41 Incorrect Way to Read When Using Standalone Configurations: read\_vhdl and link

```
read_vhdl config_nested_sync_async.vhd
read_vhdl config_nested_swap_exp.vhd
read_vhdl embed_nested_standalone_top.vhd
link
write -f ddc -h -o t.ddc
```

If you use the reading style in Example 1-40 or Example 1-41, HDL Compiler only checks the contents from the architecture\_body in the embed\_nest\_standalone\_top.vhd file. It will ignore the rest of the RTL code in that module. In this case, it will ignore the entire configuration portion of the top module even if you declare the configuration in the RTL.

The design architecture contains three components: swap\_exp1, swap\_exp2, and swap\_exp3.

For the first component, swap\_exp1, HDL Compiler ignores whatever you code in the configuration declarative section. Instead, the tool picks up the last defined architecture (comb\_seq of swap\_exp) by default and will not select the "swap\_seq of swap\_exp" architecture in the config\_nested\_swap\_exp.vhd module, which is declared in the architecture statements part in the top module. Next, since the architecture "comb\_seq of swap\_exp" has its own library declared, the tool will search for the last defined architecture in the module of config\_nested\_sync\_async.vhd, which is the architecture "async\_logic of sync\_async", and will use it by default instead of other architectures in that module.

For the second component, swap\_exp2, the tool will be referred by the embedded configuration and will link to the architecture "swap\_seq of swap\_exp" in the config\_nested\_swap\_exp.vhd module, where it clearly states "use entity work.swap\_exp(swap\_seq)" as the embedded configuration in the architecture body.

For the swap\_exp3 component, HDL Compiler chooses the last defined architecture "async\_logic of sync\_async" by default for the same reasons described previously for the swap\_exp1 component.

### **Mixed Language Support**

VHDL Compiler supports Verilog and SystemVerilog subblock instantiations by using configured or direct methods. To enable this mixed language capability, set the hdlin\_vhdl\_mixed\_language\_instantiation and hdlin\_enable\_configurations variables to true. The default for both of these variables is false.

To illustrate mixed language support, consider a VHDL design A that contains two Verilog B designs from two different libraries. Example 1-42 shows the B instantiations. Example 1-43 shows a script that analyzes and elaborates the two Verilog subblocks into the VHDL top design.

#### Example 1-42 VHDL Subblocks Containing Verilog RTL

```
I1 : entity B_one.test
    port map(x => x1);
I2 : entity B_two.test
    port map(x => x2);
```

#### Example 1-43 Analyze and Elaborate Verilog Subblocks

```
define_design_lib work -path ./work define_design_lib B_one -path ./d_one define_design_lib B_two -path ./d_two set hdlin_vhdl_mixed_language_instantiation true analyze -format verilog -library B_one B_1.v analyze -format verilog -library B_two B_2.v analyze -format vhdl A.vhd elaborate A
```

When configuring Verilog blocks in VHDL, note the following guidelines:

- HDL Compiler checks ports for bit-width, not data type.
- All generics must be fully mapped.
- When a conflict occurs between a VHDL block and a Verilog block, HDL Compiler chooses the VHDL block.
- Default parameter values cannot be used.

### **Design Libraries**

This section contains the following subsections:

- Predefined Design Libraries
- Creating User-Defined Design Libraries

- User-Defined Design Library Example
- Using Design Units From Design Libraries
- Design Library Reports

### **Predefined Design Libraries**

The following packages are analyzed for you:

- std\_logic\_1164
- std\_logic\_arith
- numeric\_std
- std\_logic\_misc
- Standard package
- Synopsys ATTRIBUTES package

These packages are contained in the logical libraries IEEE, WORK, DEFAULT, and SYNOPSYS, which are defined during installation. Their default physical locations are defined in the .synopsys\_vss.setup file, located in the Synopsys synthesis root installation subdirectory. These packages are described in Appendix B, "Predefined Libraries."

Packages defined in these libraries can be used by your VHDL source code and are found automatically. Example 1-44 shows how to use the predefined std\_logic\_1164 package from the IEEE library.

#### Example 1-44 Using Predefined Libraries

```
library IEEE;
use IEEE.std_logic_1164.all;
```

Unlike all the other predefined packages, the Standard package does not require a use clause to enable your design to use the functions with the package.

#### Note:

These predefined packages are compatible only with the tool version they are released with; they are not compatible with other releases of the tool. A version number is stored in the intermediate format file, and the file can be read in only by the version in which it was created.

### **Creating User-Defined Design Libraries**

When designs or packages are analyzed, the analyzed results are stored in the WORK library by default. If you want to store the results in a user-defined library, for example, MYLIB, with a physical location of MYLIB\_LOC, you can use one of two methods. In the first method, you use the define\_design\_lib command; in the second, you use the .synopsys\_vss.setup file. These two methods are described in Table 1-4.

Table 1-4 Methods for Creating User-Defined Libraries

Method	Description		
define_design_lib	Use the define_design_lib command to specify the library name and location; for example,		
	define_design_lib MYLIB -path /MYLIB_LOC		
	Then analyze your design to MYLIB, for example,		
	analyze -library MYLIB -format vhdl $\{\{\dots.design\}\}$		
.synopsys_vss.setup	Add the user-specified library name and mapping to your .synopsys_vss.setup file; for example,		
	MYLIB: ./ MYLIB_LOC		
	Then, analyze your design to MYLIB, for example,		
	<pre>analyze -library MYLIB -format vhdl &lt;{design}&gt;</pre>		

### **User-Defined Design Library Example**

The following steps show you how to store the analysis of two packages in a user-defined library named COMMON-TLS and use these packages in the ALU design.

1. Define a logical library called "COMMON-TLS" and map it to a physical location, using the define\_design\_lib command; for example,

```
dc shell-t> define design lib COMMON-TLS -path ./COMMON
```

2. Store the analysis of the package files in the user-defined library COMMON-TLS (The packages reside in the files types.vhd and functions.vhd.)

```
dc_shell> analyze -format vhdl -library COMMON-TLS
{types.vhd functions.vhd}
```

The -library option indicates the library name where the analyzed file should be stored.

Declare the COMMON-TLS library in the ALU code:

```
library COMMON-TLS;
use COMMON-TLS.types.all;
use COMMON-TLS.functions.all;
```

Example 1-45 shows the complete flow using the analyze and elaborate commands. (Design ALU is defined in the files ALU\_entity.vhd and ALU\_arch.vhd.)

#### Example 1-45 Flow for User-Defined Library Using analyze

```
dc_shell> define_design_lib WORK -path ./work
dc_shell> define_design_lib COMMON-TLS -path ./COMMON
dc_shell> analyze -format vhdl \
    -library COMMON-TLS {types.vhdfunctions.vhd}
dc_shell> analyze -format vhdl {ALU_entity.vhd ALU_arch.vhd}
dc_shell> elaborate ALU_top
```

Example 1-46 shows the flow using the read command.

#### Example 1-46 Flow for User-Defined Library Using read

```
dc_shell> define_design_lib WORK -path ./work
dc_shell> define_design_lib COMMON-TLS -path ./COMMON
dc_shell> read_file -format vhdl \
    -library COMMON-TLS {types.vhd functions.vhd}
dc_shell> read_file -format vhdl {ALU_subblock.vhd ALU_top.vhd}
dc_shell> current_design ALU_top
dc_shell> link
```

### **Using Design Units From Design Libraries**

Design libraries contain analyzed designs and packages used when you

- Elaborate designs During elaboration, subdesigns are first linked by a search through
  designs in memory. HDL Compiler then searches the current design library for
  preexisting analyzed files of the subdesigns. The .db files in the search path are also
  automatically linked during elaboration of a top-level design. See the elaborate man
  page for syntax details.
- Instantiate design units Design units from design libraries can be instantiated into other designs. For example, you can instantiate the design adder by using

```
U1: entity adder (adder_arch)
   generic map (N => 16)
   port map (A,B,Z);
```

 Call a package in a library with the use clause – The use clause allows an entity to use a package from a library. Reference these packages in the declaration section of the entity description.

### **Design Library Reports**

To get a complete list of design libraries, use the <code>report\_design\_lib</code> -libraries command. To view the contents of an individual library, such as the IEEE library, use <code>report\_design\_lib</code> <code>IEEE</code>. To find out a library's physical location, use the <code>get\_design\_lib\_path</code> command.

For more information about these commands, see the man pages.

### **Package Support**

HDL Compiler supports the following packages:

- IEEE Package—std\_logic\_1164
- IEEE Package—std\_logic\_arith
- IEEE Package—numeric\_std (IEEE Standard 1076.3)
- IEEE Package—std\_logic\_misc
- Standard Package
- Synopsys Package—ATTRIBUTES

For more information on these packages, see Appendix B, "Predefined Libraries".

### **Array Naming Variables**

The three variables described in Table 1-5 affect how array elements are named. To list their current values, run the following command:

dc\_shell-t> printvar bus\*style

Table 1-5 Array Naming Variables

Variable	Description		
bus_naming_style	Describes how to name the bits in port, cell, and net arrays. When a multiple-bit array is read in, it is converted to a set of individual single-bit names. The value is a string containing the characters %s and %d, which are replaced by the array name and the bit (element) index, respectively. The default is "%s[%d]".		
	Example:		
	Array X_ARRAY is indexed from 0 to 7 and has bus_naming_style = "%s.%d"; HDL Compiler names the third element of X_ARRAY as X_ARRAY.2.		
	Note: It is recommended that you do not change this default value if the netlist will be written out in Verilog format.		
bus_dimension_separator_style	Specifies the style to use in separating multidimensional array indexes. The default is "][".		
bus_minus_style	Describes how to represent negative indexes in port, cell, and net names. The value is a string containing the characters %d (replaced by the absolute value of a negative index). The default is "-%d".		
	Example:		
	If bus_minus_style = "M%d", the index value of negative 3 is represented as "M3".		

### Licenses

The reading and writing license requirements are listed in Table .

Reader	Reading License required?		Writing License required?	
	RTL	Netlist	RTL	Netlist
HDL Compiler	Yes	Yes	Not applicable	Not applicable
VHDL netlist reader	Not applicable	No	No	No

# 2

## General Coding Considerations

This chapter discusses coding issues specific to HDL Compiler, in the following sections:

- Creating Relative Placement in Hardware Description Languages
- Declarative Region in generate Statements
- Design Units
- Data Types and Data Objects
- Operands
- Modeling Considerations
- Simulation/Synthesis Mismatch Issues

### **Creating Relative Placement in Hardware Description Languages**

Relative placement technology allows you to create structures in which you specify the relative column and row positions of instances. During placement and optimization, these structures are preserved and the cells in each structure are placed as a single entity.

You can use the relative placement capability to explore QoR benefits, such as shorter wire lengths, reduced congestion, better timing, skew control, fewer vias, better yield, and lower dynamic and leakage power.

Relative placement information embedded within the Verilog or VHDL description allows you to specify and modify relative placement information without updating the locations of many of the cells in the design. You can add relative placement constraints to an RTL design using embedded HDL compiler directives.

The following sections describe how to specify relative placement data for RTL designs.

Relative placement constraints can also be added inside the shell using Tcl commands. For more information, see the "Using Design Compiler Topographical Technology" chapter in the *Design Compiler User Guide*.

### **Scope of Support for Relative Placement**

Some restrictions apply when you specify relative placement.

The general restriction is that HDL Compiler for VHDL supports relative placement for RTL designs only; it does not support relative placement in a GTECH or mapped netlist.

For RTL designs, the following restrictions apply:

- You can specify relative placement directives only on register banks.
- When specifying relative placement directives for leaf-level registers, you must specify
  the directives inside an always block that infers registers and does not infer
  combinational logic.

If the always block does not infer registers, HDL Compiler generates the following error message:

Error: filename: line number: Relative placement register bank group 'rp group name does not contain a latch/FlipFlop. (ELAB-2)

### **Directives for Specifying Relative Placement**

You can specify relative placement information by using the following HDL compiler directives:

- rp\_group and rp\_endgroup
   See "Creating Groups Using rp\_group and rp\_endgroup" on page 2-3.
- rp\_place

See "Specifying Subgroups, Keepouts, and Instances Using rp\_place" on page 2-4.

rp\_fill
 See "Placing Cells Automatically Using rp\_fill" on page 2-5.

rp\_array\_dir

See "Specifying Placement for Array Elements Using rp\_array\_dir" on page 2-6.

#### Note:

For an example that shows relative placement directives in RTL code, see "Relative Placement Example" on page 2-6.

### Creating Groups Using rp\_group and rp\_endgroup

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

The rp\_group and rp\_endgroup directives allow you to specify a relative placement group. You must specify the directives inside a process block for leaf-level relative placement groups. Higher-level hierarchical groups must be specified within an architecture.

The VHDL syntax is as follows:

```
-- synopsys rp_group ( group_name {num_cols num_rows} )
-- synopsys rp_endgroup ( {group_name} )
```

You can determine the size of the group by using the <code>num\_cols</code> and <code>num\_rows</code> optional arguments to specify the number of rows and columns. If you specify the size, HDL Compiler checks the location of the instances that are placed in the group to verify that none of the instances are placed beyond the group's size limits; HDL Compiler generates an error message if a size violation occurs.

The following example shows that the inferred registers belong to a relative placement group named rp\_grp1:

```
-- synopsys rp_endgroup (rp_group1)
begin
if (CLK'event and CLK = '1') then
```

### Specifying Subgroups, Keepouts, and Instances Using rp\_place

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

The  $rp\_place$  directive allows you to specify a subgroup at a specific hierarchy, a keepout region, or an instance to be placed in the current relative placement group. When you use the  $rp\_place$  directive to specify a subgroup at a specific hierarchy, you must instantiate the subgroup's instances outside of any group declarations in the module.

The VHDL syntax is as follows:

```
-- synopsys rp_place ( hier group_name col row )
-- synopsys rp_place ( keep keepout_name col row width height )
-- synopsys rp_place ({leaf} [inst_name] col row )
```

You can use the *col* and *row* optional arguments to specify absolute row or column locations in the group's grid, or locations that are relative to the current pointer value (that is, the location of the current instance; for more information, see "Placing Cells Automatically Using rp\_fill" on page 2-5). To represent locations relative to the current pointer, enclose the column and row values in angle brackets (<>), as shown in the following example:

```
-- synopsys rp_place (my_group_1 0 0)
-- synopsys rp_place (my_group_2 0 <1>)
```

The example shows that group my\_group\_1 is placed at location (0,0) in the grid, and group my\_group\_2 is placed at the next row position (0,1).

If you do not specify the col and row arguments, objects are automatically placed in the current group's grid, filling empty slots. Each time a new instance is declared that is not explicitly placed, it is inserted into the grid at the location indicated by the current value of the pointer. After the instance is placed, the pointer is updated and the process is ready to be repeated.

The following example shows a relative placement group named my\_rpg that includes four subgroups that are placed at the following locations, respectively: (0,0), (0,1), (1, \*), and (1, \*). The wildcard character (\*) indicates that HDL Compiler can choose any value.

```
-- synopsys rp_group(my_rpg)
-- synopsys rp_place(hier rp_group1 0 0)
-- synopsys rp_place(hier rp_group2 0 1)
-- synopsys rp_place(hier rp_group3 1 *)
-- synopsys rp_place(hier rp_group4 1 *)
-- synopsys rp_endgroup(my_rpg)
```

### Placing Cells Automatically Using rp\_fill

The  $rp_fill$  directive automatically places the cells at the location specified by a pointer. You can think of this as an imaginary pointer that specifies where the current cell should be placed. Unless you explicitly set it, the pointer initially points to 0,0 (column zero, row zero) and the first cell is placed at that location. Each time a new instance is declared that is not explicitly placed, it is inserted into the grid at the location indicated by the current value of the pointer. After the instance is placed, the pointer is updated incrementally and the process is ready to be repeated. HDL Compiler for VHDL supports relative placement directives for RTL designs only.

The VHDL syntax is as follows:

```
-- synopsys rp_fill ( {col row} {pattern pat} )
```

The  $rp_fill$  arguments define how the pointer is updated. The col and row parameters specify the initial coordinates of the pointer. These parameters can represent absolute row or column locations in the group's grid or locations that are relative to the current pointer value. To represent locations relative to the current pointer, enclose the column and row values in angle brackets (<>). For example, assume the current pointer location is (3,4). In this case, specifying  $rp_fill$  <1> 0 initializes the pointer to (4,0) and that is where the next instance is placed. Absolute coordinates must be positive integers; relative coordinates can be any integer.

To specify how the pointer moves to the next placement location, use the pattern option with one of the following arguments:

Symbol	Definition
UX	up
DX	down
RX	right
LX	left

The pattern UX inserts cells one after another up a column; this is the default pattern. The pattern RX fills a row with instances.

If no pattern is specified, the incremental operation uses the last pattern string that is defined. If the row and column parameters are not specified, HDL Compiler does not initialize the fill pointer, and the pointer keeps the value it had before the  $rp_fill$  directive was read. If HDL Compiler encounters a group declaration, the fill pointer is initialized to (0,0) and the pattern is set to UX.

### Specifying Placement for Array Elements Using rp\_array\_dir

The rp\_array\_dir directive specifies whether the elements of an array are placed upward, from the least significant bit to the most significant bit, or downward, from the most significant bit to the least significant bit.

The VHDL syntax is as follows:

```
-- synopsys rp_array_dir ( up|down )
```

The following VHDL example shows array elements that are placed downward, from the most significant bit to the least significant bit:

```
process (CLK)
-- synopsys (rp_group1 )
-- synopsys rp_fill (0 0 UX)
-- synopsys rp_array_dir(down)
-- synopsys rp_endgroup (rp_group1)
begin
   if (CLK'event and CLK = '1') then
```

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

### **Relative Placement Example**

Example 2-1 shows VHDL relative placement directives applied to several register banks in a design.

Example 2-1 Relative Placement Using rp\_group, rp\_place, rp\_fill, and rp\_array\_dir Directives

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;


entity dff_sync_reset is
    port (DATA, CLK, RESET : in std_logic;
        DATA1, DATA2, DATA3, DATA4 : in std_logic_vector (7 downto 0);
        Q1, Q2, Q3, Q4 : out std_logic_vector (7 downto 0));
    attribute sync_set_reset of RESET : signal is "true";
end dff_sync_reset;

architecture rtl of dff_sync_reset is
-- synopsys rp_group(my_rpg)
-- synopsys rp_place(hier rp_group1 * 0)
-- synopsys rp_endgroup(my_rpg)
```

```
begin
  process (CLK)
                       -- synopsys rp_group (rp_group1 )
                       -- synopsys rp_fill (0 0 UX)
                       -- synopsys rp_array_dir(down)
                       -- synopsys rp_endgroup (rp_group1)
  begin
    if (CLK'event and CLK = '1') then
        if (RESET = '0') then
            Q1 <= (others => '0');
        else
            Q1 <= DATA1;
        end if;
    end if;
  end process;
  process (CLK)
                       -- synopsys rp_group (rp_group2 )
                       -- synopsys rp_fill (0 0 UX)
                       -- synopsys rp_array_dir(down)
                       -- synopsys rp_endgroup(rp_group2)
  begin
    if (CLK'event and CLK = '1') then
        if (RESET = '0') then
            Q2 <= (others => '0');
        else
            Q2 <= DATA2;
        end if;
    end if;
  end process;
  process (CLK) begin
    if (CLK') event and CLK = '1') then
        if (RESET = '0') then
            Q3 <= (others => '0');
        else
            O3 <= DATA3;
        end if;
    end if;
  end process;
  process (CLK) begin
    if (CLK') event and CLK = '1') then
        if (RESET = '0') then
            Q4 <= (others => '0');
        else
            Q4 <= DATA4;
        end if;
    end if;
  end process;
end rtl;
```

Figure 2-1 shows the layout of Example 2-1 after running Design Compiler topographical. Note that the register banks that were controlled with relative placement directives have a well structured layout, while the register banks that were not controlled with relative placement directives are not placed together.

Figure 2-1 Layout With Relative Placement Specified on Several Register Banks



### **Declarative Region in generate Statements**

HDL Compiler allows declarations within generate statements. Each iteration of the generate statement declares new copies of the objects in the declarative region. Consider Example 2-2, which describes four AND gates and four inverters. This code produces four independent signals named "S". HDL Compiler distinguishes these signals using a user-specified naming convention. This convention is determined by the hdlin\_generate\_naming\_style and hdlin\_generate\_separator\_style variables. See the man pages for information about these variables.

#### Example 2-2 Signal Declarations Within generate Statements

```
G: for I in 0 to 3 generate
  signal S: BIT;
begin
  S <= A(I) and B(I);
  Z(I) <= not S;
end generate;</pre>
```

Example 2-3 shows that you can declare objects other than signals in a generate statement.

#### Example 2-3 Function Declarations Within Generate Statements

```
G: for I in 0 to 3 generate
  function F (X: in BIT_VECTOR(0 to I)) return BIT is
  variable R: BIT := '1';
begin
  for J in X'RANGE loop
   R := R and x(j);
  end loop;
  return R;
  end function;
begin
  z(i) <= f (a(0 to i));
end generate;</pre>
```

Here, four versions of the function "f" are created, one for each iteration of the generate loop. Because the function is declared in the generate declarative region, it can only be called from the generate body.

### **Design Units**

Design unit requirements specific to HDL Compiler are discussed in the following subsections:

- Direct Instantiation of Components
- Default Component Port Assignments
- Component Name Restrictions
- Component Sources
- Component Port Consistency
- Instantiating Technology-Independent Components
- Component Architecture
- Package Names
- Procedures and Functions as Design Components

### **Direct Instantiation of Components**

HDL Compiler allows components to be directly instantiated in the design without a component declaration. This is a VHDL-93 feature that provides a more concise method of instantiating subdesigns. The following notation is used:

HDL Compiler always picks the last architecture analyzed for synthesis.

In the following examples, design1 (Example 2-4) is analyzed and saved in a library called DESIGN1\_LIB and design2 instantiates design1 (Example 2-5 on page 2-10).

#### Example 2-4 Design 1 Can Be Instantiated by Design 2

HDL Compiler supports the direct instantiation of design1 without a component declaration as shown in Example 2-5. Notice that design2 now requires fewer lines of code.

#### Example 2-5 Design 2 Instantiates Design 1

### **Default Component Port Assignments**

HDL Compiler supports the use of default assignments for component port declarations as shown in Example 2-6. This simplifies coding by allowing ports with default assignments to be omitted during component instantiation.

#### Note:

Default assignments for entity port declarations will be parsed but ignored by HDL Compiler.

#### Example 2-6 Default Port Assignments

```
component AND3 is
  port (A: in bit;
      B: in bit;
      C: in bit:= '1'; -- default assignment to component port
      Z : out bit
     );
end component;
.
.
.
.
U1 : AND3
  port map (A => A1,
      B => B1,
      Z => Z1
     );
```

### **Component Name Restrictions**

You cannot name components with keywords, identifiers from any Synopsys or IEEE package, or the GTECH\_ prefix.

### **Component Sources**

A declared component can come from

- The same VHDL source file
- A different VHDL source file
- Another format, such as EDIF, state table, or programmable logic arrays (PLAs)
- A component from a logic library
- A Verilog source file

A component that is not in one of the current VHDL source files must already have been compiled by Design Compiler and must reside either in memory or in a .db file in the search path. HDL Compiler searches for previously compiled components by name, in the following order:

- 1. In the current design in memory.
- 2. In the directories and files identified in the Design Compiler link path (link\_library variable). These files can include previously compiled designs or libraries of technology-specific components.
- 3. In the directories and files identified in the Design Compiler search path (search\_path variable).

### **Component Port Consistency**

HDL Compiler checks for consistent port mapping between all loaded designs. For RTL designs that are not VHDL or Verilog, the port names are taken from the original design description, as follows:

- For PLAs or state tables, the port names are the input and output names.
- For components in a logic library, the port names are the input and output pin names.
- For EDIF designs, the port names are the EDIF port names.
   The bit-widths of each port must match.
- For VHDL components, HDL Compiler verifies matching.
- For components from other sources, Design Compiler checks matching when linking the component to the VHDL description.

### **Instantiating Technology-Independent Components**

You can directly instantiate GTECH components in your RTL. The GTECH library contains the following technology-independent logical components:

- AND, OR, and NOR gates (2, 3, 4, 5, and 8)
- 1-bit adders and half adders
- 2-of-3 majority
- Multiplexers
- · Flip-flops and latches
- Multiple-level logic gates, such as AND-NOT, AND-OR, and AND-OR-INVERT

#### Note:

Instantiating GTECH components should be used with caution because it restricts the optimization of logic and might result in a degradation of design quality of results (QoR).

When you instantiate GTECH components, you can set the <code>map\_only</code> attribute to prevent Design Compiler from ungrouping the GTECH component and selecting a similar cell from the target library. When this attribute is applied, Design Compiler does not optimize the gates; instead, the gates are only mapped to the target technology. The <code>set\_map\_only</code> command in <code>Example 2-7</code> sets the <code>map\_only</code> attribute on each cell returned by the <code>find</code> command (all cells in the design RIPPLE\_CARRY that reference a GTECH\_ADD\_ABC cell). If you use your own library with attributes already set in that library, you do not have to set the <code>map\_only</code> attribute.

#### Example 2-7 GTECH Component Instantiation

```
library GTECH;
library ieee;
use IEEE.STD LOGIC 1164.all;
use gtech.gtech_components.all;
entity RIPPLE CARRY is
  generic(N: NATURAL);
  port(a, b : in std logic vector(n-1 downto 0);
      carry_in: in std_logic;
      sum : out std_logic_vector(n-1 downto 0);
      carry_out: out std_logic);
end RIPPLE_CARRY;
architecture TECH INDEP of RIPPLE CARRY is
  signal CARRY: std_logic_vector(N downto 0);
-- synopsys dc_tcl_script_begin
-- set_map_only [get_cells * -filter "ref_name==GTECH_ADD_ABC"]
-- synopsys dc tcl script end
begin
  CARRY(0) <= CARRY_IN;</pre>
  GEN: for I in 0 to N-1 generate
   U1: GTECH_ADD_ABC port map(
             Α
                           => A(I),
             B
                           => B(I),
                          => CARRY(I),
             C
             S
                          => SUM(I),
             COUT
                         => CARRY(I+1)
            );
  end generate GEN;
  CARRY OUT <= CARRY(N);
end TECH_INDEP;
```

To link this design in Design Compiler, you must have the GTECH.db library in your link\_library variable.

### **Component Architecture**

HDL Compiler uses the following two rules to select which entity and architecture to associate with a component instantiation:

- 1. Each component declaration must have an entity—a VHDL entity, a design entity from another source or format, or a library component—with the same name. This entity is used for each component instantiation associated with the component declaration.
- 2. If a VHDL entity has more than one architecture, HDL Compiler uses the last architecture analyzed. You can override this selection by using configurations. For more information on configuration, see "Configuration Support" on page 1-18.

### **Package Names**

Synopsys supports different packages with the same name if they exist in different libraries.

### **Procedures and Functions as Design Components**

Procedures and functions are represented by gates and cannot exist as entities (components) unless you use the directive <code>map\_to\_entity</code>, which causes HDL Compiler to implement a function or a procedure as a component instantiation. Procedures and functions that use <code>map\_to\_entity</code> are represented as components in designs where they are called.

When you add a map\_to\_entity directive to a subprogram definition, HDL Compiler assumes the existence of an entity with the identified name and the same interface.

HDL Compiler and Design Compiler do not check this assumption until they link the parent design. The matching entity must have the same input and output port names. If the subprogram is a function, you must also provide a return\_port\_name directive where the matching entity has an output port of the same name.

These two directives are called component implication directives:

```
-- synopsys map_to_entity entity_name
-- synopsys return_port_name port_name
```

Insert these directives after the function or procedure definition, as in the following example:

```
function MUX_FUNC(A,B: in TWO_BIT; C: in BIT)
    return TWO_BIT is

-- synopsys map_to_entity MUX_ENTITY
-- synopsys return_port_name Z
```

The behavioral description of the subprogram is not checked against the functionality of the entity overloading it. If there are differences in functionality between them, pre-synthesis and post-synthesis simulation results might not match.

Overloaded as used here refers to an entity that can have more than one function or definition. In this case, the MUX\_FUNC function is overloaded by the MUX\_ENTITY entity. The Synopsys map\_to\_entity directive causes HDL Compiler to ignore the contents of the MUX\_FUNC function and directly synthesize the contents of the MUX\_ENTITY entity. However, simulation uses the contents of the function. The function is overloaded because it has two definitions: function contents and the entity. These definitions should be the same to avoid a mismatch between synthesis and simulation results.

The matching entity (*entity\_name*) does not need to be written in VHDL. It can be in any format Design Compiler supports.

When HDL Compiler encounters the map\_to\_entity directive, it parses but ignores the contents of the subprogram definition.

Example 2-8 shows a function that uses component implication directives. Figure 2-2 on page 2-17 illustrates the corresponding design.


#### Example 2-8 Using Component Implication Directives on a Function

```
package MY_PACK is
         subtype TWO_BIT is BIT_VECTOR(1 to 2);
         function MUX_FUNC(A,B: in TWO_BIT; C: in BIT) return
               TWO_BIT;
end;
package body MY_PACK is
         function MUX_FUNC(A,B: in TWO_BIT; C: in BIT) return
               TWO_BIT is
         -- synopsys map_to_entity MUX_ENTITY
         -- synopsys return_port_name Z
         -- contents of this function are ignored but should match the
         -- functionality of the entity MUX_ENTITY, so pre- and post
         -- simulation will match
         begin
                if(C = '1') then
                      return(A);
                      return(B);
                end if;
         end;
end;
use WORK.MY_PACK.ALL;
entity TEST is
         port(A: in TWO_BIT; C: in BIT; TEST_OUT: out TWO_BIT);
end;
architecture ARCH of TEST is
begin
         cal_func: process (a, c)
         begin
                TEST_OUT <= MUX_FUNC(not A, A, C);</pre>
                                 -- Component implication call
         end process;
end;
use WORK.MY_PACK.ALL;
-- the following entity 'overloads' the function MUX_FUNC above
entity MUX_ENTITY is
         port(A, B: in TWO_BIT; C: in BIT; Z: out TWO_BIT);
end;
architecture ARCH of MUX_ENTITY is
begin
         process (a, b)
         begin
                case C is
                      when '1' => Z \le A;
                      when '0' \Rightarrow Z \Leftarrow B;
                end case;
```

end process;

end;

Figure 2-2 Schematic Design With Component Implication Directives




Example 2-9 shows the same design as Example 2-8, except that an entity is not created for the function. The component implication directives have been removed. Figure 2-3 on page 2-18 illustrates the corresponding design.

#### Example 2-9 Using Gates to Implement a Function

```
package MY_PACK is
         subtype TWO_BIT is BIT_VECTOR(1 to 2);
         function MUX_FUNC(A,B: in TWO_BIT; C: in BIT)
               return TWO_BIT;
end;
package body MY_PACK is
         function MUX_FUNC(A,B: in TWO_BIT; C: in BIT)
                return TWO_BIT is
         begin
                if(C = '1') then
                      return(A);
                else
                      return(B);
                end if;
         end;
end;
use WORK.MY_PACK.ALL;
entity TEST is
         port(A: in TWO_BIT; C: in BIT; Z: out TWO_BIT);
end;
architecture ARCH of TEST is
begin
         process (a, c)
         begin
                Z <= MUX_FUNC(not A, A, C);</pre>
         end process;
end;
```

Figure 2-3 Schematic Design Without Component Implication Directives



### **Data Types and Data Objects**

Data type and data object requirements specific to HDL Compiler are discussed in the following subsections:

- Globally Static Expressions in Port Maps
- Aliases
- Deferred Constants
- Aggregates in Constant Record Declarations
- Enumerated Types in the for and for-generate Constructs
- Groups
- Integer Data Types
- Overloading an Enumeration Literal
- Enumeration Encoding
- Constant Floating-Point Support
- math\_real Package Support

### **Globally Static Expressions in Port Maps**

HDL Compiler supports globally static expressions in port maps as shown in Example 2-10.

Example 2-10 HDL Compiler Supports Globally Static Expressions in Port Maps

```
component C is
  port (A, B: in BIT; Z: out BIT);
  end component;
    . . .
  signal X, Y: BIT
    . . .
Ul: C port map (X, '1', Y);
```

#### **Aliases**

HDL Compiler supports all alias types except labels, loop parameters, and generate parameters—these cannot be aliased per the VHDL language reference manual. Example 2-11 shows alias code that is supported in HDL Compiler.

#### Example 2-11 Support for Alias in HDL Compiler

```
entity e is
  port (a, c: in bit;
     z: out bit);
end;

architecture a of e is
  alias b is c;
begin
  z <= a and b;
end;</pre>
```

HDL Compiler supports the following alias types:

- Aliases without an explicit subtype indication as shown in Example 2-12
- Aliases with an explicit subtype indication
- Aliases to non-objects (that is, types) as shown in Example 2-13
- Aliases to subprograms as shown in Example 2-14

#### Example 2-12 Alias Without an Explicit Subtype Indication

```
signal S: BIT_VECTOR (0 to 7);
...
alias A is S;
```

In this case, A will have the same type as S.

#### Example 2-13 Alias to a Type

```
alias SLV is STD_LOGIC_VECTOR;
```

Example 2-14 shows an alias to a subprogram. This is a convenient way to refer to a specific subprogram in a package.

#### Example 2-14 Aliases to Subprograms

Subprogram aliases can also contain a signature. This makes it possible to distinguish among the various interpretations of an overloaded subprogram name as shown in Example 2-15.

#### Example 2-15 Subprogram Alias Containing a Signature

#### **Deferred Constants**

Constants defined in packages are useful for declaring a set of global design parameters that can be shared by multiple design entities. Example 2-16 shows how a constant declared in a global package DEFS is used to define the active edge for the clocks in the design. The value of "1" means that the flip-flops will be clocked on the rising edge of the clock.

Example 2-16 shows a deferred constant declaration in a package.

#### Example 2-16 Deferred Constants

```
-- defs pkg.vhd
-- ========
library ieee;
use ieee.std logic 1164.all;
package defs is
constant CLOCK ACTIVE EDGE: std logic := '1';
end;
design1.vhd
========
library ieee, mylib;
use ieee.std logic 1164.all;
use mylib.defs.all;
 process (clk) is
  begin
     if (clk'event and clk = CLOCK ACTIVE EDGE) then
       O <= D;
     end if;
  end process;
```

One of the limitations of normal constant declarations in packages is that if the constant value in the package is changed, then all the designs making use of that package must be reanalyzed to use the new constant value. In the previous example, this means that if you

want to change to a negative clock edge, you need to modify the CLOCK\_ACTIVE\_EDGE from "1" to "0" in defs\_pkg.vhd and reanalyze all the files that reference this package.

With deferred constants, the constant is declared in the package without initializing its value. The initialization of the constant is deferred to the package body declaration. Now if the constant value is changed in the package body, only the package body needs to be reanalyzed, followed by a re-elaboration of the top-level design. Example 2-17 shows how a deferred constant declaration can be used to define the active edge for the clocks in the design.

#### Example 2-17 Deferred Constant Declaration

```
defs_pkg.vhd
=========
package DEFS is
constant CLOCK_ACTIVE_EDGE: std_logic;
end DEFS;

defs_pkg_body.vhd
============
package body DEFS is
constant CLOCK_ACTIVE_EDGE: std_logic := '1';
end;
```

Now if you want to change from a falling-edge-triggered to a rising-edge-triggered behavior, you only need to modify and reanalyze the package body, in defs\_pkg\_body.vhd, and, re-elaborate the top-level design to implement the change. This allows for a more flexible and manageable design flow.

### **Aggregates in Constant Record Declarations**

HDL Compiler supports the use of aggregates in constant record declarations as shown in Example 2-18.

#### Example 2-18 Aggregates in Constant Record Declarations

### **Enumerated Types in the for and for-generate Constructs**

HDL Compiler supports the use of enumerated types as indexes in the for and for-generate constructs. Example 2-19 uses an enumerated type as an index in a for loop.

#### Example 2-19 Enumerated Types As Index in for Construct

```
package Defs is
type color is (RED, GREEN, BLUE);
subtype col_val is bit_vector (7 downto 0);
type pixel is array (color range RED to BLUE) of col_val;
function pix_fn (A1, A2: col_val) return col_val;
end Defs;
package body Defs is
  function pix_fn (A1, A2: col_val) return col_val is
   return (Al xor A2);
  end pix_fn;
end Defs;
use work.Defs.all;
entity pix is
 port (A, B: in pixel;
       Z: out pixel
       );
end pix;
architecture rtl of pix is
begin
  process (A, B)
  begin
    for I in RED to BLUE loop
                                 -- enumerated type used here
      Z(I) \le pix_fn(A(I),B(I));
    end loop;
  end process;
end rtl;
```

### Groups

HDL Compiler supports VHDL-93 group declarations as shown in Example 2-20. This feature allows you to create groups of named entities. One useful application of this feature is that you can apply attributes to the group as a whole instead of referencing individual signals.

#### Example 2-20 Group Declarations

```
package Defs is
group sig_grp is (signal<>);
end Defs;
library Synopsys;
use Synopsys.attributes.all;
use work.Defs.all;
entity top is
port (A, B: in bit;
      Z: out bit
end top;
architecture RTL of top is
group sig3_grp is (signal, signal, signal);
group inputs: sig_grp (A, B);
group all_ports: sig3_grp (A, B, Z);
-- input delay of 1.5 will be applied to A & B signals
attribute ARRIVAL of inputs: group is 1.5;
begin
  Z \ll A \text{ or } B;
end RTL;
```

### **Integer Data Types**

Multidigit numbers in VHDL can include underscores (\_) to make them easier to read.

HDL Compiler encodes an integer value as a bit vector whose length is the minimum necessary to hold the defined range and encodes integer ranges that include negative numbers as 2's-complement bit vectors.

### **Overloading an Enumeration Literal**

You can overload an enumeration literal by including it in the definition of two or more enumeration types. When you use such an overloaded enumeration literal, HDL Compiler is usually able to determine the literal's type. However, under certain circumstances, determination might be impossible. In such cases, you must qualify the literal by explicitly stating its type. Example 2-21 shows how you can qualify an overloaded enumeration literal.

#### Example 2-21 Enumeration Literal Overloading

```
type COLOR is (RED, GREEN, YELLOW, BLUE, VIOLET);
type PRIMARY_COLOR is (RED, YELLOW, BLUE);
signal A : COLOR;
...
A <= COLOR'(RED);</pre>
```

### **Enumeration Encoding**

Enumeration literals are synthesized into the binary equivalent of their positional value. By default, the first enumeration literal is assigned the value 0, the next enumeration literal is assigned the value 1, and so forth.

HDL Compiler automatically encodes enumeration values into bit vectors that are based on each value's position. The length of the encoding bit vector is the minimum number of bits required to encode the number of enumerated literals. For example, an enumeration type with five values would have a 3-bit encoding vector.

Example 2-22 shows the default encoding of an enumeration type with five values.

#### Example 2-22 Automatic Enumeration Encoding

```
type COLOR is (RED, GREEN, YELLOW, BLUE, VIOLET);
```

The enumeration values are encoded as follows:

```
RED = "000"
GREEN = "001"
YELLOW = "010"
BLUE = "011"
VIOLET = "100"
```

The colors can be compared according to their encoded values; the results of a comparison are

```
RED < GREEN < YELLOW < BLUE < VIOLET.
```

You can override the automatic enumeration encodings and specify your own enumeration encodings with the <code>ENUM\_ENCODING</code> attribute. This interpretation is specific to HDL Compiler, and overriding might result in a simulation/synthesis mismatch. See "ENUM\_ENCODING Attribute" on page 6-12.

### **Constant Floating-Point Support**

This section describes constant floating-point support, in the following subsections:

Syntax and Declarations

- Operators and Expressions
- Guidelines

### **Syntax and Declarations**

Floating-point syntax:

```
constant identifier_list : real_subtype [:= expression] ;
```

You can declare constant floating-point objects in

- Entities (except for generic maps)
- Architectures
- Processes
- Blocks
- Functions (as an argument, a return value, or a declarative part)
- Procedures (as an argument or a declarative part)

The following types can consist of constant floating-point objects:

- Scalar
- Array
- Record

Example 2-23 shows various constant floating-point declarations.

#### Example 2-23 Constant Floating-Point Declarations

### **Operators and Expressions**

The following operators are supported for constant floating-point type:

- Adding, signing, multiplying, and absolute value operators
- \*\* (power) operator ( <real\_data> \*\* <integer\_data> )
- Relational operators (>, <, =, /=, >=, <=)
- Subscript and vector operators (array)
- Field operator (record)

In the following example, my\_const1 and my\_const2 are constant floating-point types; my\_rec is a constant record type and rec1 is an element of my\_rec.

```
my_const1 + 3.14
my_const1/(-my_const2)
abs(-my_const1)
my_const1 ** 5
my_const1 >= my_const2
my_const1(3), my_const1(2 downto 0)
my_rec.rec1
```

Expressions can contain floating-point numbers and constants, but these expressions are only allowed at the following locations:

- Constant floating-point initialization
- Comparison (relational operation)

The value of an expression that contains a constant floating point must be resolvable at elaboration time.

In the following example, the floating-point constant, my\_const1 (3.14), is smaller than 5.6, so the condition in the if statement is true. This causes HDL Compiler to elaborate the first

clause of the if statement and ignore the second clause. HDL Compiler assigns bb to false, because my\_const1 (equaling 3.14) is known at elaboration time.

```
constant my_const1 : real :=3.14;
  if (my_const1 <= 5.6) then
    state <= a;
  else
    state <= b;
  endif;
  bb <= (my_const1/=3.14); -- bb is BOOLEAN type</pre>
```

#### **Guidelines**

- Floating-point objects are supported on Linux platforms, 32-bit SPARC and HP platforms, and 64-bit SPARC and HP platforms.
- Floating-point signal and variable objects are not supported, and cannot be synthesized; only constant floating point objects are supported.
- Floating-point objects in the generic map of an entity are not supported.
- The floating-point range is -1.0e38 to 1.0e38 inclusive, the same as the float type in C.
- The floating-point object initialization expression must be present and its value must be resolvable at the time of elaboration, or an error is reported.

### math\_real Package Support

This section describes HDL Compiler support for the IEEE standard VHDL math\_real package, which defines arithmetic functions using REAL type arguments.

This section contains the following:

- Unsupported Constructs and Operators
- Using the math real Package
- Arithmetic Functions
- Usage Examples

### **Unsupported Constructs and Operators**

HDL Compiler does not support the following components:

- Is\_X() function is a simulation rather than synthesis construct; it is ignored in synthesis
- REAL signals

REAL types with ranges

### Using the math\_real Package

The math\_real package is typically installed in the Synopsys root directory. Access it with the following statement in your VHDL code:

```
Library IEEE;
Use IEEE.math_real.all;
```

#### Note:

Operations on REAL type data are only supported for constant evaluation.

#### **Arithmetic Functions**

The math\_real package provides arithmetic functions for use with the REAL data type. These functions can be used in synthesis for constant calculations. Example 2-24 shows the declaration of these functions.

#### Example 2-24 Declarations of Arithmetic Functions

```
function "**" (X : in INTEGER; Y : in REAL) return REAL;
function "**" (X : in REAL; Y : in REAL) return REAL;
function "MOD" (X, Y : in REAL) return REAL;
function ARCCOS (X : in REAL) return REAL;
function ARCCOSH (X : in REAL) return REAL;
function ARCSIN (X : in REAL) return REAL;
function ARCSINH (X : in REAL) return REAL;
function ARCTAN (Y: in REAL) return REAL;
function ARCTAN (Y : in REAL; X : in REAL) return REAL;
function ARCTANH (X : in REAL) return REAL;
function CBRT (X : in REAL) return REAL;
function CEIL (X : in REAL) return REAL;
function COS (X : in REAL) return REAL;
function COSH (X : in REAL) return REAL;
function EXP (X : in REAL) return REAL;
function FLOOR (X : in REAL) return REAL;
function LOG (X : in REAL) return REAL;
function LOG (X : in REAL; BASE : in REAL) return REAL;
function LOG10 (X : in REAL) return REAL;
function LOG2 (X : in REAL) return REAL;
function REALMAX (X, Y : in REAL) return REAL;
function REALMIN (X, Y : in REAL) return REAL;
function ROUND (X : in REAL) return REAL;
function SIGN (X : in REAL) return REAL;
function SIN (X : in REAL) return REAL;
function SINH (X : in REAL) return REAL;
function SQRT (X : in REAL) return REAL;
function TAN (X : in REAL) return REAL;
function TANH (X : in REAL) return REAL;
function TRUNC (X : in REAL) return REAL;
```

```
procedure UNIFORM(variable SEED1, SEED2 : inout POSITIVE; variable X :
out REAL);
```

### **Usage Examples**

See Example 2-25 and Example 2-26.

#### Example 2-25 Constant Evaluation of Parameters

#### Example 2-26 User-Defined Functions

```
function realtodb(val : real ) return real is
begin
return 20.0*(log10(val));
end function;

CONSTANT Ar : real := 1.375;
CONSTANT Ar_db : real := realtodb(Ar);
```

### **Operands**

Operand requirements specific to HDL Compiler are discussed in the following subsections:

- Operand Bit-Width
- Array Slice Names
- Variable Array Slice Operations
- Computable and Noncomputable Operands
- Indexed Name Targets

### **Operand Bit-Width**

HDL Compiler uses the bit-width of the largest operand to determine the bit-width needed to implement an operator in a circuit. For example, an INTEGER operand is 32 bits wide by default. An addition of two INTEGER operands causes HDL Compiler to build a 32-bit adder.

To use hardware resources efficiently, always indicate the bit-width of numeric operands. For example, use a subrange of INTEGER when declaring types, variables, or signals.

```
type ENOUGH: INTEGER range 0 to 255;
variable WIDE: INTEGER range -1024 to 1023;
signal NARROW: INTEGER range 0 to 7;
```

### **Array Slice Names**

Slice names identify a sequence of consecutive elements of an array variable or signal. The syntax is

```
identifier (expression direction expression)
```

#### identifier

The identifier is the name of a signal or variable of an array type. Each *expression* must return a value within the array's index range and must be computable (see "Computable and Noncomputable Operands" on page 2-33).

#### direction

The *direction* must be either to or downto. The direction of a slice must be the same as the direction of an identifier's array type. If the left and right expressions are equal, they define a single element.

The value returned to an operator is a subarray containing the specified array elements.

### Variable Array Slice Operations

HDL Compiler supports *variable array slice* operations, which can perform assignment to (LHS) or selection of (RHS) a fixed-width group of bits at a variable base address of an expression.

Variable array slices must meet the following requirements:

- The slice width of the range must be constant.
- The upper and lower range expressions can use: \*, +, -, (), one noncomputable variable, and any computable constants (numeric or nonnumeric).

 If any nonnumeric constants are used, the upper and lower expressions must be identical in format except for a single integer difference.

### **Assignment and Selection**

Variable array slices on the LHS allow assignment to a variable group of bits:

```
myArray(i downto i - 3) <= data(3 downto 0);</pre>
```

For assignment, if the calculated range is partially out of the destination range, the out-of-range bit assignments have no effect.

Variable array slices on the RHS allow selection of a variable group of bits:

```
data(3 downto 0) <= myArray(i downto i - 3);</pre>
```

#### Note:

For simplicity, subsequent examples in this section show only bare variable array slice expressions instead of assignment (LHS) or selection (RHS) statements.

#### **Index Expression Variables**

Index expressions can use the index variable, which itself is noncomputable, within any computable expression:

```
-- i is an integer port
myArray(i downto i - 3)

-- v is a bit vector port
myArray(v downto v - 3)
myArray(v(4 downto 0) downto v(4 downto 0) - 3)
myArray(my_func(v) downto my_func(v) - 3)
```

#### **Index Expressions Using Only Numeric Constants**

When only numeric constants are used, the upper and lower expressions can use any format as long as the slice width remains constant.

```
-- upper and lower expressions can differ in format myArray(4 * (v - 1) downto 4 * v - 10) myArray((v - 2) * 3 to (3 - 1) * v + v - 2)
```

#### **Index Expressions Using Nonnumeric, Computable Constants**

When nonnumeric but computable constants are used, the upper and lower expressions must share the same format except for a single integer difference to indicate the range.

```
-- upper and lower expressions must be identical in format
```

### **Computable and Noncomputable Operands**

A computable operand is one whose value can be determined by HDL Compiler at compile time; that is, the operand value is constant and does not depend on any inputs. Noncomputable operand values depend on inputs that are known only at runtime. Because the operand value varies according to inputs, HDL Compiler needs to build additional logic to determine what the value is at runtime.

Following are examples of computable operands:

- Literal values
- for...loop parameters, when the loop's range is computable
- Variables assigned a computable expression
- Aggregates that contain only computable expressions
- Function calls whose return value is computable
- Expressions with computable operands
- Qualified expressions when the expression is computable
- Type conversions when the expression is computable
- The value of the and or nand operators when one of the operands is a computable '0'
- The value of the or operator or the nor operator when one of the operands is a computable '1'

Additionally, a variable is given a computable value if it is an OUT or INOUT parameter of a procedure that assigns it a computable value.

Typically, the following are noncomputable operands:

- Signals
- Ports

- Variables assigned different computable values that depend on a noncomputable condition
- Variables assigned noncomputable values

Example 2-27 shows some definitions and declarations, followed by several computable and noncomputable expressions.

#### Example 2-27 Computable and Noncomputable Expressions

```
signal S: BIT;
function MUX(A, B, C: BIT) return BIT is
 if (C = '1') then
   return(A);
  else
   return(B);
  end if;
end;
procedure COMP(A: BIT; B: out BIT) is
begin
  B := not A;
end;
process(S)
  variable V0, V1, V2: BIT;
  variable V_INT:
                      INTEGER;
  subtype MY_ARRAY is BIT_VECTOR(0 to 3);
  variable V_ARRAY:
                      MY_ARRAY;
begin
 V0 := '1'; -- Computable (value is '1')
 V1 := V0;
                        -- Computable (value is '1')
  V2 := not V1;
                        -- Computable (value is '0')
  for I in 0 to 3 loop
   V INT := I;
                         -- Computable (value depends on iteration)
  end loop;
  V_ARRAY := MY_ARRAY'(V1, V2, '0', '0');
                         -- Computable ("1000")
  V1 := MUX(V0, V1, V2); -- Computable (value is '1')
  COMP(V1, V2);
  V1 := V2;
                         -- Computable (value is '0')
 V1 := V2, -- Computable (value is '0')
V0 := S and '0'; -- Computable (value is '0')
  V1 := MUX(S, '1', '0'); -- Computable (value is '1')
  V1 := MUX('1', '1', S); -- Computable (value is '1')
  if (S = '1') then
   V2 := '0';
                        -- Computable (value is '0')
  else
```

### **Indexed Name Targets**

The syntax for an assignment to an indexed name (identifier) target is

```
identifier(index_expression) := expression; -- Variable assignment
identifier(index_expression) <= expression; -- Signal assignment</pre>
```

The identifier is the name of an array type signal or variable.

The index\_expression must evaluate to an index value for the identifier array's index type and bounds. It does not have to be computable, but more logic is synthesized if it is not. For more information, see "Computable and Noncomputable Operands" on page 2-33.

The assigned expression must have the array's element type.

### **Modeling Considerations**

Modeling requirements specific to HDL Compiler are discussed in the following subsections:

- Concatenation
- Unconstrained Type Ports
- Input Ports Associated With the Keyword open
- Multiple Events in a Single Process
- Multiple if Statements in a Process
- Keeping Signal Names
- Controlling Structure
- Resolution Functions
- Asynchronous Designs
- Using Don't Care Values
- Finite State Machines
- Multibit Inference

#### Concatenation

HDL Compiler supports both the 87 and 93 VHDL language reference manual (LRM) definitions of the concatenation operator. The default support is for the 93 LRM definition. To enable the 87 LRM definition, set the hdlin\_vhdl93\_concat variable to false, changing it from its default of true. To understand the difference between the two definitions, consider Example 2-28. In this example, the k3 and k4 constants are defined by using concatenation with the k1 and k2 constants. The values of k3 and k4 differ according to what VHDL language standard you use: VHDL-87 or VHDL-93.

If you use VHDL-93, the value of k3'left to k3'right is the same as k4'left to k4'right. To determine this value, the tool counts from 0 to 3 and the value does not depend on the k1 and k2 start positions.

If you use VHDL-87, the value of k3'left to k3'right, which is from 0 to 3, is different from k4'left to k4'right, which is from 1 down to -2. The difference is that concatenation in VHDL-87 defines the position count from the start position of the left operand k1 position (1) and the procedure (downto) instead of starting from the 0 position as is the case in the VHDL-93 language standard.

#### Example 2-28 Understanding Concatenation in VHDL-93 and VHDL-87

Example 2-29 shows the values of the k2, k3, and k5 constants interpreted by using VHDL-87 and VHDL-93 definitions.

#### Example 2-29 Another Example of Concatenation

```
type r1 is range 0 to 7;
type r2 is range 7 downto 0;
type t1 is array (r1 range <>) of bit;
type t2 is array (r2 range <>) of bit;
```

## **Unconstrained Type Ports**

HDL Compiler supports the usage of unconstrained type ports when the type of the ports can be deduced. In these cases, you must use the analyze and elaborate commands to read your design. The read command does not support type conversion on formal ports.

## Input Ports Associated With the Keyword open

If you associate an input port with the reserved keyword open, you must initialize it with a default expression, or the analyze command will report an error. HDL Compiler connects the open port with the default expression after elaboration.

## **Multiple Events in a Single Process**

HDL Compiler supports multiple events in a single process as shown in the following example:

```
process
begin
  wait until CLOCK'event and CLOCK = '1';
  if (CONDITION) then
    X <= A;
  else
    wait until CLOCK'event and CLOCK = '1';
  end if;
end process;</pre>
```

## Multiple if Statements in a Process

You can specify the same condition for multiple if statements in a process. The following examples show the supported, unsupported, and illegal coding styles:

## **Supported Coding Styles**

#### Example 2-30 Multiple if Statements With the Same Condition

```
process (clk)
begin
   if rising_edge(clk) then
      o1 <= i(1);
   end if;

   if rising_edge(clk) then
      o2 <= i(2);
   end if;
end process;</pre>
```

#### Example 2-31 Multiple if Statements With or Without a Set or Reset Condition

```
process (clk, rst)
begin
   if rst='1' then
      o1 <= '1';
   elsif rising_edge(clk) then
      o1 <= i(1); -- with reset
   end if;

if rising_edge(clk) then
      o2 <= i(2); -- without reset
   end if;
end process;</pre>
```

#### Example 2-32 Multiple Sequential and Combinational Blocks

```
process (clk) begin
  if rising_edge(clk) then -- sequential block
    o1 <= i(1);
  end if;

if rising_edge(clk) then -- sequential block
    o2 <= i(2);
  end if;

o3 <= i(1) and i(2); -- combinational block
end process;</pre>
```

You must specify sequential assignments before combinational assignments, as shown in Example 2-33.

#### Example 2-33 Sequential Assignments Before Combinational Assignments

```
process (clk, rst)
begin
  if rst='1' then
    o1 <= '1';
  elsif rising_edge(clk) then
    o1 <= i(1);
  end if;

if rising_edge(clk) then
    o2 <= i(2); -- o2, sequential
  end if;

o2 <= i(1); -- o2, combinational
end process;</pre>
```

#### Example 2-34 Multiple if Statements With the Same Variable

```
process (clk, rst)
variable t : std_logic;
begin
   if rst='1' then
     01 <= '1';
   elsif rising_edge(clk) then
                  -- variable t is assigned
      t := i(1);
     o1 <= i(1);
   end if;
   if rst = '1' then
      02 <= '0';
   elsif rising_edge(clk) then
     o2 <= t and i(2); -- variable t is used
   end if;
end process;
```

## **Unsupported Coding Style**

You must use the same clock edge as a condition for multiple if statements, that is, either a positive edge or negative edge. If you use both clock edges in multiple if statements, as shown in Example 2-35, the tool issues an ELAB-2040 error message.

#### Example 2-35 Different Clock Edges for Multiple if Statements

## **Illegal Coding Style**

If a combinational assignment comes before a sequential assignment, as shown in Example 2-36, the tool issues an ELAB-113 error message.

#### Example 2-36 Combinational Assignments Before Sequential Assignments

```
process (clk, rst)
begin
  if rst='1' then
    o1 <= '1';
  elsif rising_edge(clk) then
    o1 <= i(1);
  end if;
  o2 <= i(1);    -- o2, combinational
  if rising_edge(clk) then
    o2 <= i(2); -- o2, sequential
  end if;
end process;</pre>
```

In Example 2-37, the o2 signal has two different assignments under the same condition. The tool issues an ELAB-112 error message for this coding style.

### Example 2-37 Conflicting Assignments to a Signal

```
process (clk, rst)
begin
  if rst='1' then
    o1 <= '1';
  elsif rising_edge(clk) then
    o1 <= i(1);
  end if;

if rising_edge(clk) then
    o2 <= i(2); -- assignment to o2
  end if;

if rising_edge(clk) then
    o2 <= i(3); -- assignment to o2
  end if;

end process;</pre>
```

## **Keeping Signal Names**

When a signal is in a path to an output port, HDL Compiler usually keeps the signal's name if the signal is not removed during optimizations, such as removing redundant code. You can give HDL Compiler guideline information for keeping a signal name by using the hdlin\_keep\_signal\_name variable and the keep\_signal\_name directive. The default is all\_driving. Table 2-1 describes the variable options.

Table 2-1 hdlin keep signal name Variable Options

Option	Description
user	This option works with the keep_signal_name directive. HDL Compiler attempts to preserve a signal if the signal isn't removed by optimizations and that signal is labeled with the keep_signal_name directive. Both dangling and driving nets are considered. Although not guaranteed, HDL Compiler typically keeps the specified signal for this configuration.
all_driving (default)	HDL Compiler attempts to preserve a signal if the signal isn't removed by optimizations and the signal is in an output path. Only driving nets are considered. This option does not guarantee a signal is kept.

#### Note:

When a signal has no driver, the tool assumes logic 0 (ground) for the driver.

To prevent signals from being removed during optimizations, use the keep\_signal\_name directive, as shown in Example 2-38 and Example 2-39. This directive works together with the hdlin\_keep\_signal\_name variable. For the examples, this variable is set to user. Review the variable options and set this variable to your specific requirements before reading your design.

#### Example 2-38 Keep Signal tmp

```
entity bus_name is
   port (
        in1 : in bit_vector (1 downto 0);
        in2 : in bit_vector (1 downto 0);
        z : out bit_vector (1 downto 0));
end bus_name;

architecture imp of bus_name is
-- synopsys keep_signal_name "tmp"
   signal tmp : bit_vector (1 downto 0);
begin
   process(in1, in2)
begin
   tmp <= in1 and in2;
   z <= in1;</pre>
```

```
end process ;
end imp;
```

#### Example 2-39 Keep Signal tmp1 and tmp2

## **Controlling Structure**

You can use parentheses to force the synthesis of parallel hardware. For example, (A + B) + (C + D) builds an adder for A+B, an adder for C+D, and an adder to add the result. Design Compiler preserves the subexpressions dictated by the parentheses, but this restriction on Design Compiler optimizations might lead to less-than-optimum area and timing results.

Parentheses can also be helpful in coding for late-arriving signals. For example, if you are adding three signals—A, B, and C—and A is late arriving, then A+(B+C) can be useful in handling the late-arriving signal A. Design Compiler also tries to create a structure to allow the late-arriving signal to meet timing. Any restriction on Design Compiler optimizations might lead to less-than-optimum area and timing results.

#### **Resolution Functions**

The resolution function and the coding style determine the choice of wired logic. Synthesis neither checks for nor resolves possible data collisions on a synthesized three-state bus. You must ensure that the three-state enablers for a common bused line are not active at the same time.

## **Asynchronous Designs**

If you use asynchronous design techniques—that is, nonclocked designs—synthesis and simulation results might not agree. Because Design Compiler does not issue warning messages for asynchronous designs, you are responsible for verifying the correctness of your circuit. See the *Synopsys Timing Constraints and Optimization User Guide* for additional information.

## **Using Don't Care Values**

HDL Compiler always evaluates comparisons to don't care values to false. This behavior is different from simulation behavior. To prevent a synthesis/simulation mismatch, always use the IEEE 1076.3-1997 STD\_MATCH function when using don't care values in comparisons. See "Don't Care Values in Comparisons" on page 2-51.

## **Finite State Machines**

HDL Compiler automatically infers finite state machines (FSMs). For FSM optimization details, see the *Design Compiler Reference Manual: Optimization and Timing Analysis*.

This section includes the following subsections:

- Variables and Commands Specific to FSM Inference
- FSM Coding Requirements
- FSM Example and Inference Report
- State Vector Attribute

See Appendix A for additional FSM examples.

## **Variables and Commands Specific to FSM Inference**

The variables and commands listed in Table 2-2 are specific to FSM inference.

Table 2-2 Variables and Commands Specific to FSM Inference

Variables/Commands	Description
hdlin_reporting_level	Default is basic.  Variable enables and disables FSM inference reports. When set to comprehensive, FSM inference reports are generated when HDL Compiler reads the code. By default, FSM inference reports are not generated. For more information, including valid values, see "Customizing Elaboration Reports" on page 1-8.
fsm_auto_inferring	Default is false. Option determines whether or not Design Compiler automatically extracts the FSM during compile. This option controls Design Compiler extraction. In order to automatically infer and extract an FSM, fsm_auto_inferring must be true. See the Synopsys Timing Constraints and Optimization User Guide and the man page for additional information.

## **FSM Coding Requirements**

Follow the coding guidelines in Table 2-3 to enable HDL Compiler to infer an FSM.


Table 2-3 RTL Requirements for Automatic Detection of FSMs

Item	Description
Registers	To infer a register as an FSM state register, the register
	<ul> <li>Must never be assigned a value other than the defined state values.</li> </ul>
	<ul> <li>Must always be inferred as a flip-flop (not a latch).</li> </ul>
	<ul> <li>Must never be a design port, function port, or task port. This would make the encoding visible to the outside.</li> </ul>
	Inside expressions, FSM state registers can be used only as an operand of "==" or "/ =" comparisons or as the expression in a case statement that is an implicit comparison to the label expressions, such as "case (cur_state)". FSM state registers are not allowed to occur in other expressions—this would make the encoding explicit.
Function	Only one FSM design per entity is allowed. State variables cannot drive a port or be indexed. You cannot use record types as state variables.
Ports	All ports of the initial design must be either input ports or output ports. Inout ports are not supported.
Combinational feedback loops	Combinational feedback loops are not supported, although combinational logic that does not depend on the state vector is accurately represented.
Clocks	FSM designs can include only a single clock and an optional synchronous or asynchronous reset signal.

## **FSM Example and Inference Report**

When you set the hdlin\_reporting\_level variable to comprehensive, HDL Compiler creates an FSM inference report, as shown in Example 2-41 on page 2-47. The report describes the encoding of an FSM that HDL Compiler created from the RTL design. Example 2-40 on page 2-46 shows the FSM RTL code, and Figure 2-4 shows a diagram of an FSM based on that code. For more information about the hdlin\_reporting\_level variable, see "Customizing Elaboration Reports" on page 1-8.

Figure 2-4 FSM State Diagram



### Example 2-40 FSM RTL Code

```
library IEEE;
use IEEE.std_logic_1164.all;
entity FSM is
  port(CLK : in std_logic;
       X : in std_logic;
         : out std_logic);
       Y
end FSM;
architecture STATE_MACHINE_VIEW of FSM is
  -- Declare an enum type for the state
  type STATE_TYPE is (S0, S1, S2, S3);
  signal STATE : STATE_TYPE;
  signal NEXT_STATE : STATE_TYPE;
  begin
  -- This process sets the next state on the clock edge.
  SET_STATE: process(CLK, NEXT_STATE) begin
     if (CLK'event and CLK = '1') then
       STATE <= NEXT_STATE;</pre>
     end if;
  end process SET_STATE;
  -- This process determines the next state and output
  -- values based on the current state and input values.
  SET_NEXT_STATE: process(STATE,X) begin
    -- SET defaults for NEXT_STATE and all outputs.
    Y <= '0';
    NEXT_STATE <= S0;</pre>
    case STATE is
      when S0 =>
          Y <= '0';
          NEXT_STATE <= S1;</pre>
      when S1 =>
        if (X = '0') then
          Y <= '0';
          NEXT_STATE <= S1;</pre>
        else
          Y <= '1';
          NEXT_STATE <= S2;
        end if;
      when S2 =>
          Y <= '0';
          NEXT_STATE <= S3;</pre>
      when S3 =>
          Y <= '0';
          NEXT_STATE <= S0;</pre>
    end case;
  end process SET NEXT STATE;
end STATE_MACHINE_VIEW;
```

#### Example 2-41 Finite State Machine Inference Report

#### **State Vector Attribute**

When inferring FSMs, always check your FSM inference report to verify that HDL Compiler correctly inferred the FSM. To change a state encoding, use the STATE\_VECTOR attribute in the architecture to specify state vectors for your design in the RTL.

When writing a state machine in VHDL, you can use a STATE\_VECTOR attribute to provide information to Design Compiler. Use a STATE\_VECTOR attribute in the architecture; the attribute value is the name of the state signal. Use only one STATE\_VECTOR attribute for an architecture, as shown in Example 2-42.

#### Example 2-42 Using STATE VECTOR Attribute in Architecture

See the *Synopsys Timing Constraints and Optimization User Guide* for more information on specifying and encoding state machines.

#### **Multibit Inference**

The HDL Compiler tool can infer registers that have identical structures for each bit as multibit components. These components reduce area and power consumption in a design, but their primary benefits are the creation of a more uniform structure for layout during place and route.

To direct HDL Compiler to infer multibit components, do one of the following tasks:

• Embed the infer\_multibit attribute in the HDL source code.

The attribute gives you control over individual case statements. Set the infer\_multibit attribute to true on signals and variables to infer them as multibit components. See Example 2-43 on page 2-49.

• Use the hdlin infer multibit variable.

This variable controls multibit inference for all bused registers in the design. Valid values for this variable are:

o default none

Infers multibit components for signals that have the infer\_multibit attribute set to true in the VHDL RTL. This is the default.

o default all

Infers multibit components for all bused registers. To disable multibit mapping for specific signals, set the infer\_multibit attribute to false on those signals. See Example 2-45 on page 2-50.

o never

Does not infer multibit components regardless of the attributes or directives in the HDL source.

In Example 2-43, the infer multibit attribute is set on the q 0 signal.

Example 2-44 shows the inference report. In this report, the MB column indicates that the component is inferred as a flip-flop multibit component.

#### Example 2-43 Inferring a Multibit Flip-Flop With the infer\_multibit Attribute

```
-- This example is run under the default conditions, that is,
-- the hdlin_infer_multibit variable is set to the default_none value.
[RTL]
library IEEE, Synopsys;
use IEEE.std_logic_1164.all;
use Synopsys.attributes.all;
entity test_multibit is
 port (d0, d1, d2 : in std_logic_vector(7 downto 0);
        clk, rst : in std_logic;
        q0, q1, q2 : out std_logic_vector(7 downto 0) );
end test_multibit;
architecture rtl of test_multibit is
attribute infer_multibit of q0 : signal is "true";
begin
process (clk, rst) begin
  if (rst = '0') then
    q0 <= "00000000";
    q1 <= "00000000";
    q2 <= "00000000";
  elsif (clk'event and clk = '1') then
    q0 <= d0;
    q1 <= d1;
   q2 <= d2;
  end if;
end process;
end rtl;
```

#### Example 2-44 Inference Report Showing q0\_reg Inferred as a Multibit Flip-Flop

Register Name	========   Type 	=======   Width 	Bus	=====:   MB	=====   AR 	=====   AS 	=====   SR	=====   SS 	=====   ST
q2_reg   q0_reg   q1_reg	Flip-flop   Flip-flop   Flip-flop	8   8   8	Y Y Y Y	N   Y   N	Y   Y   Y	N   N   N	N   N   N	N   N   N	N     N     N

Presto compilation completed successfully.

Example 2-45 shows the same VHDL code but illustrates how to prevent multibit inference of the q\_0 signal when the hdlin\_infer\_multibit variable is set to the default\_all value. Example 2-46 shows the inference report. In this report, the MB column indicates that the component is not inferred as a multibit component.

#### Example 2-45 Inferring Multibit Flip-Flops With the hdlin\_infer\_multibit Variable

```
-- In this example, the hdlin_infer_multibit variable is set to the
-- default_all value.
[RTL]
library IEEE, Synopsys;
use IEEE.std_logic_1164.all;
use Synopsys.attributes.all;
entity test_multibit is
 port (d0, d1, d2 : in std_logic_vector(7 downto 0);
        clk, rst : in std_logic;
        q0, q1, q2 : out std_logic_vector(7 downto 0) );
end test_multibit;
architecture rtl of test_multibit is
attribute infer_multibit of q0 : signal is "false";
begin
process (clk, rst) begin
  if (rst = '0') then
   q0 <= "00000000";
    q1 <= "00000000";
    q2 <= "00000000";
  elsif (clk'event and clk = '1') then
    q0 <= d0;
    q1 <= d1;
    q2 <= d2;
  end if;
end process;
end rtl;
```

#### Example 2-46 Inference Report Showing q1\_reg and q2\_reg Inferred as Multibit Components

Register Name	Type	=======   Width   	Bus	=====   MB	=====   AR	=====   AS	=====   SR 	SS	=====   ST	=
q2_reg   q0_reg   q1_reg	Flip-flop   Flip-flop   Flip-flop	8     8     8	Y Y Y	Y   N   Y	Y   Y   Y	N   N   N	N   N   N	N   N   N	N   N   N	-     

Presto compilation completed successfully.

For information on how Design Compiler handles multibit components in a mapped design, see the *Design Compiler Optimization Reference Manual*.

## Simulation/Synthesis Mismatch Issues

This following sections describe simulation/synthesis mismatch issues:

- Type Mismatches
- Set and Reset Signals
- Z Values in Expressions
- Don't Care Values in Comparisons
- Ordering of Enumerated Types Using the ENUM\_ENCODING attribute
- Sensitivity Lists
- Delay Specifications

## **Type Mismatches**

The numeric\_std package and the std\_logic\_arith package have overlapping operations. Use of these two packages simultaneously during analysis could cause type mismatches.

## **Set and Reset Signals**

A simulation/synthesis mismatch can occur if the set/reset signal is masked by an X during initialization in simulation. Use of the <code>sync\_set\_reset</code> directive reduces mismatches. For examples, see "D Flip-Flop With Synchronous Set" on page 4-23 and "D Flip-Flop With Synchronous Reset" on page 4-24.

## **Z Values in Expressions**

The use of the  ${\tt z}$  value in an expression always evaluates to false and can cause a simulation/synthesis mismatch. For details, see "Understanding the Limitations of Three-State Inference" on page 5-9.

## **Don't Care Values in Comparisons**

To prevent simulation/synthesis mismatch, do not use don't care values in comparisons unless you use the IEEE 1076.3-1997 STD\_MATCH function.

Don't care types are treated differently in simulation than they are in synthesis. To a simulator, a don't care value is a distinct value, different from a 1 or a 0. In synthesis,

however, a don't care value becomes a 0 or a 1. When a don't care value is used in a comparison, HDL Compiler always evaluates the comparison to false. Because of this difference in treatment, there is the potential for a simulation/synthesis mismatch whenever a comparison is made with a don't care value.

For example, if X = '-' then is synthesized as if FALSE then.

The following case statement causes a synthesis/simulation mismatch because the simulator evaluates 1- to match 11 and 10 but the synthesis tool evaluates 1- to false; the same hold true for the 0- evaluation.

To fix this mismatch problem, always use the STD\_MATCH function; for example, rewrite the code above by using if statements, as follows:

```
if (STD_MATCH (A, "1,-"))
...
elseif (STD_MATCH (A, "0,-"))
...
else
```

HDL Compiler issues a warning similar to the following when it synthesizes such comparisons:

```
Warning: A partial don't-care value was read in routine test
line 24 in file 'test.vhd' This can cause simulation to
disagree with synthesis. (HDL-171)
```

## Ordering of Enumerated Types Using the ENUM ENCODING attribute

If you set the encoding of your enumerated types using the ENUM\_ENCODING attribute, the ordering operators compare your encoded value ordering, not the declaration ordering. Because this interpretation is specific to HDL Compiler, it might cause a mismatch with the VHDL simulator, which uses the declaration's order of enumerated types. See "Enumeration Encoding" on page 2-25 and "ENUM ENCODING Attribute" on page 6-12.

## **Sensitivity Lists**

HDL Compiler generates a warning if all the signals read by the process are not listed in the sensitivity list. The circuit HDL Compiler synthesizes is sensitive to all signals the process reads. To guarantee the same results from a VHDL simulator, follow these guidelines when developing the sensitivity list:

- For sequential logic, include the clock signal and all asynchronous control signals in the sensitivity list.
- For combinational logic, all inputs must be in the sensitivity list.

HDL Compiler checks sensitivity lists for completeness and issues a warning message for any signal that is read inside a process but is not in the sensitivity list. An error message is issued if a clock signal is read as data in a process.

#### Note:

The IEEE VHDL Standard does not allow a sensitivity list if the process has a wait statement. If your code has this condition, the HDL Compiler tool issues a warning and ignores the code.

## **Delay Specifications**

Delays are ignored for synthesis; their use can cause a synthesis/simulation mismatch.

# 3

## Modeling Combinational Logic

This chapter describes coding guidelines specific to HDL Compiler that are useful in combinational logic synthesis.

This chapter contains the following sections:

- Synthetic Operators
- Logic and Arithmetic Operator Implementation
- Propagating Constants
- Bit-Truncation Coding for DC Ultra Datapath Extraction
- Multiplexing Logic
- Unintended Latches and Feedback Paths in Combinational Logic

## **Synthetic Operators**


Synopsys provides a collection of IP, referred to as the DesignWare Basic IP Library, as part of the HDL Compiler products. Basic IP provide basic implementations of common arithmetic functions that can be referenced by HDL operators in your VHDL or Verilog source code.

The DesignWare paradigm is built on a hierarchy of abstractions. HDL operators (either built-in operators like + and \*, or HDL functions and procedures) are associated with synthetic operators, which are bound in turn to synthetic modules. Each synthetic module can have multiple architectural realizations, called implementations. When you use the HDL addition operator "+" in a design description, HDL Compiler infers the need for an adder resource, and puts an abstract representation of the addition operation into your circuit netlist. The same holds true when you instantiate a DesignWare component. For example, an instantiation of DW01\_add will be mapped to the synthetic operator associated with it. See Figure 3-1.

A synthetic library contains definitions for synthetic operators, synthetic modules, and bindings. It also contains declarations that associate synthetic modules with their implementations.

For more information about DesignWare synthetic operators, modules, and libraries, see the Synopsys DesignWare documentation.

Figure 3-1 DesignWare Hierarchy



## **Logic and Arithmetic Operator Implementation**

When HDL Compiler elaborates a design, it maps HDL operators to synthetic (DesignWare) operators that appear in the generic netlist. When Design Compiler optimizes the design, it maps these operators to DesignWare synthetic modules and chooses the best implementation, based on constraints, option settings, and wire-load models.

A Design Compiler license includes a DesignWare-Basic license that enables the DesignWare synthetic modules listed in Table 3-1. These modules support common logic and arithmetic HDL operators. By default, adders and subtracters must be more than 4 bits wide to be mapped to these modules. If they are smaller, the operators are mapped to combinational logic.

Table 3-1 Operators Supported by a DesignWare-Basic License

HDL operator	Linked to DesignWare synthetic module
Comparison (> or <)	DW01_cmp2
Absolute value (abs)	DW01_absval
Addition (+)	DW01_add
Subtraction (-)	DW01_sub
Addition or Subtraction (+ or -)	DW01_addsub
Incrementer (+)	DW01_inc
Decrementer (-)	DW01_dec
Incrementer or decrementer (+ or -)	DW01_incdec
Multiplier (*)	DW02_mult

Synopsys creates numerous DesignWare synthetic modules in addition to the basic modules. The DesignWare Building Block IP (formally called Foundation Library) is a collection of reusable intellectual property blocks that are integrated into the Synopsys synthesis environment. This library contains high-performance implementations of Basic Library IP plus many IP that implement more advanced arithmetic and sequential logic functions. For more information about DesignWare synthetic modules, see the DesignWare documentation.

## **Propagating Constants**

Constant propagation is the compile-time evaluation of expressions containing constants. HDL Compiler uses constant propagation to reduce the amount of hardware required to implement operators. For example, a "+" operator with a constant 1 as an input causes an incrementer, rather than a general adder, to be built. If both adder arguments are constants, no hardware is constructed, because the expression's value is calculated by HDL Compiler and inserted directly in the circuit.

Other operators that benefit from constant propagation include comparators and shifters. Shifting a vector by a constant amount requires no logic to implement; it requires only a reshuffling (rewiring) of bits.

## **Bit-Truncation Coding for DC Ultra Datapath Extraction**

Datapath design is commonly used in applications that contain extensive data manipulation, such as 3-D, multimedia, and digital signal processing (DSP). Datapath extraction transforms arithmetic operators, such as addition, subtraction, and multiplication, into datapath blocks to be implemented by a datapath generator.

The DC Ultra tool enables datapath extraction after timing-driven resource sharing and explores various datapath and resource-sharing options during compile.

DC Ultra datapath optimization supports datapath extraction of expressions containing truncated operands unless both of the following two conditions exist:

- The operands have upper bits truncated.
- The width of the resulting expression is greater than the width of the truncated operand.

Both conditions must be true to prevent extraction. For lower-bit truncations, the datapath is extracted in all cases.

Bit truncation can be either explicit or implicit. Table describes both types of truncation.

Truncation type	Description
Explicit bit truncation	An explicit upper-bit truncation is one in which you specify the bit range for truncation.
	The following code indicates explicit upper-bit truncation of operand A:
	signal A = std_logic_vector (i downto 0);
	$z \le A$ (j downto 0); where j < i

Truncation type	Description
Implicit bit truncation	An implicit upper-bit truncation is one that occurs through assignment. Unlike explicit upper-bit truncation, here you do not explicitly define the range for truncation.
	The following code indicates implicit upper-bit truncation of operand Y:
	signal A,B = std_logic_vector (7 downto 0);
	signal C,Y = std_logic_vector (8 downto 0);
	Y = A + B + C;
	Because A and B are each 8 bits wide, the return value of A+B will be 8 bits wide. However, because Y, which is 9 bits wide, is assigned to be the 9-bit wide addition (A+B)+C, the most significant bit (MSB) of the addition (A+B) is implicitly truncated. In this example, the MSB is the carryout.

To see how bit truncation affects datapath extraction, consider the code in Example 3-1.

In this example, d has the upper bit truncated, but e is only 8-bits so this code is extracted.

### Example 3-1 Design test1: Truncated Operand Is Extracted

In Example 3-2, d is truncated to 8-bits and in an expression assigned to e which is 9-bits. This code is not extracted.

#### Example 3-2 Design test2: Truncated Operand Is Not Extracted

```
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity test2 is
  port (a,b,c : in std_logic_vector(7 downto 0);
        e : out std_logic_vector(8 downto 0)); -- e is 9-bits wide
end test2;
architecture rtl of test2 is
  signal d : std_logic_vector(15 downto 0); -- d is 16-bit wide
begin
```

```
d <= a * b;
e <= '0'&c + d(7 downto 0); -- explicit upper bit truncation
end rtl;
```

In Example 3-3, the expression assigned to e contains implicit upper-bit truncation and the width of e is greater than the width of the implicitly truncated operand, so the code is not extracted.

### Example 3-3 Design test3: Truncated Operand Is Not Extracted

In Example 3-4, there is lower-bit truncation but no upper-bit truncation so this code is extracted.

#### Example 3-4 Design test4: Truncated Operand is Extracted

```
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity test4 is
  port (a,b : in std_logic_vector(7 downto 0);
        e : out std_logic_vector(7 downto 0));
end test4;
architecture rtl of test4 is
  signal d : std_logic_vector(15 downto 0); -- d is 16-bit wide
begin
  d <= a * b; -- no implicit upper bit truncation of d
  e <= d(15 downto 8); -- explicit lower bit truncation of d
end rtl;</pre>
```

## **Multiplexing Logic**

Multiplexers are commonly modeled with if and case statements. To implement this logic, HDL Compiler uses SELECT\_OP cells, which Design Compiler maps to combinational logic or multiplexers in the logic library. If you want Design Compiler to preferentially map multiplexing logic to multiplexers—or multiplexer trees—in your logic library, you must infer MUX OP cells.


The following sections describe multiplexer inference:

- SELECT OP Inference
- MUX\_OP Inference
- Variables That Control MUX OP Inference
- MUX\_OP Inference Examples
- MUX\_OP Inference Limitations

## **SELECT\_OP Inference**

By default, HDL Compiler uses SELECT\_OP components to implement conditional operations implied by if and case statements. An example SELECT\_OP cell implementation for an 8-bit data signal is shown in Figure 3-2.


Figure 3-2 SELECT OP Implementation for an 8-bit Data Signal



Note that for an 8-bit data signal, 8 selection bits are needed - this is called a one-hot implementation.

SELECT\_OPs behave like one-hot multiplexers; the control lines are mutually exclusive, and each control input allows the data on the corresponding data input to pass to the output. To determine which data signal is chosen, HDL Compiler generates selection logic, as shown in Figure 3-3.

Figure 3-3 HDL Compiler Output—SELECT\_OP and Selection Logic



Depending on the design constraints, Design Compiler implements the SELECT\_OP with either combinational logic or multiplexer cells from the logic library.

## **MUX\_OP Inference**

If you want Design Compiler to preferentially map multiplexing logic in your RTL to multiplexers—or multiplexer trees—in your logic library, you need to infer MUX\_OP cells. These cells are hierarchical generic cells optimized to use the minimum number of select signals. They are typically faster than the SELECT\_OP cell, which uses a one-hot implementation. Although MUX\_OP cells improve design speed, they also might increase area. During optimization, Design Compiler preferentially maps MUX\_OP cells to multiplexers—or multiplexer trees—from the logic library, unless the area costs are prohibitive, in which case combinational logic is used. See the *Synopsys Timing Constraints and Optimization User Guide* for information about how Design Compiler maps MUX\_OP cells to multiplexers in the target logic library.

Figure 3-4 shows a MUX\_OP cell for an 8-bit data signal. Notice that the MUX\_OP cell only needs three control lines to select an output; compare this with the SELECT\_OP which needed eight control lines.

data signals

DATA

DATA

DATA

DATA

DATA

DATA

DATA

DATA

DATA

S0

select signals


S2

Figure 3-4 MUX\_OP Generic Cell for an 8-bit Data Signal

Note that for an 8-bit word, only 3 selection bits are needed.

The MUX\_OP cell contains internal selection logic to determine which data signal is chosen; HDL Compiler does not need to generate any selection logic, as shown in Figure 3-5.

Figure 3-5 HDL Compiler Output—MUX\_OP Generic Cell for 8-Bit Data



Use the following methods to infer MUX\_OP cells:

- To infer MUX\_OP cells for a specific case or if statement, use the infer\_mux attribute or the -- synopsys infer\_mux directive in the VHDL description.
  - Attach the infer\_mux attribute to a case statement, by using the following syntax:
     case var is -- synopsys infer\_mux

o Attach the infer\_mux directive, as follows:

```
case SEL3 is -- synopsys infer_mux
when "00" => DOUT3 <= DIN3(0);
when "01" => DOUT3 <= DIN3(1);
when "10" => DOUT3 <= DIN3(2);
when "11" => DOUT3 <= DIN3(3);</pre>
```

• To infer MUX\_OP cells for a specific case or if statement regardless of the settings of the hdlin\_infer\_mux, hdlin\_mux\_oversize\_ratio, hdlin\_mux\_size\_limit, and hdlin mux size min variables, use the infer mux override directive.

#### For example,

The tool marks the MUX\_OP cells inferred by this directive with the size\_only attribute to prevent logic decomposition during optimization. Specifying this directive infers MUX\_OP cells even if the cells cause loss of resource sharing.

- To generate MUX\_OP cells for all case statements in a block, set the infer\_mux attribute on the block.
  - O Attach the infer\_mux attribute to a process, by using the following syntax: attribute infer\_mux of process\_label: label is "true";
- To generate MUX\_OP cells for all case and if statements, use the hdlin\_infer\_mux variable.

## **Variables That Control MUX\_OP Inference**

The variables that control MUX\_OP cell inference are listed in Table 3-2.

Table 3-2 MUX\_OP Inference Variables

Variable	Description
hdlin_infer_mux	Controls MUX_OP inference for all designs you input in the same Design Compiler session.
	Options:
	<ul> <li>default – Infers MUX_OPs for case and if statements in processes that have the infer_mux directive or attribute attached.</li> </ul>
	<ul> <li>none – Does not infer MUX_OPs, regardless of the directives set in the VHDL description. HDL Compiler generates a warning if hdlin_infer_mux = none and infer_mux are used in the RTL.</li> </ul>
	<ul> <li>all – Infers MUX_OPs for every case and if statement in your design for which one can be used. This can negatively affect the quality of results, because it might be more efficient to implement the MUX_OPs as random logic instead of using a specialized multiplexer structure.</li> </ul>
hdlin_mux_size_limit	Sets the maximum size of a MUX_OP that HDL Compiler can infer. The default is 32. If you set this variable to a value greater than 32, HDL Compiler might take an unusually long elaboration time.
	If the number of branches in a case statement exceeds the maximum size specified by this variable, HDL Compiler generates the following message:
	Warning: A mux was not inferred because case statement %s has a very large branching factor. (HDL-383)
hdlin_mux_size_min	Sets the minimum number of data inputs for a MUX_OP inference. The default is 2.
hdlin_mux_oversize_ ratio	Defines the ratio of the number of MUX_OP inputs to the unique number of data inputs. When this ratio is exceeded, a MUX_OP will not be inferred and the circuit will be generated with SELECT_OPs. The default is 100.

Table 3-2 MUX\_OP Inference Variables (Continued)

Variable	Description				
hdlin_mux_size_only	To ensure that MUX_OP cells are mapped to MUX technology cells, you must apply a size_only attribute to the cells to prevent logic decomposition in later optimization steps. You can set the size_only attribute on each MUX_OP manually or allow the tool to set it automatically. The automatic behavior can be controlled by the hdlin_mux_size_only variable.				
	Options:				
	• 0 – Specifies that no cells receive the size_only attribute.				
	<ul> <li>1 - Specifies that MUX_OP cells that are generated with the RTL infer_mux compiler directive and that are on set/reset signals receive the size_only attribute. This is the default.</li> </ul>				
	<ul> <li>2 – Specifies that all MUX_OP cells that are generated with the RTL infer_mux compiler directive receive the size_only attribute.</li> </ul>				
	<ul> <li>3 – Specifies that all MUX_OP cells on set/reset signals receive the size_only attribute: for example, MUX_OP cells that are generated by setting the hdlin_infer_mux variable to all.</li> </ul>				
	<ul> <li>4 - Specifies that all MUX_OP cells receive the size_only attribute: for example, MUX_OP cells that are generated by the hdlin_infer_mux variable set to all.</li> </ul>				
	By default, the hdlin_mux_size_only variable is set to 1, meaning that MUX_OP cells that are generated with the RTL infer_mux compiler directive and that are on set/reset signals receive the size_only attribute.				

## **MUX\_OP Inference Examples**

In Example 3-5, two MUX\_OPs and one SELECT\_OP are inferred, as follows:

- In the process proc1, a MUX\_OP is inferred for the case statement, because the infer\_mux attribute is placed on proc1.
- In the process proc2, there are two case statements.
  - For the first case statement, a SELECT\_OP is inferred. This is the default inference.
  - However, the second case statement in proc2 has the infer\_mux compiler directive set on it which causes HDL Compiler to infer the MUX\_OP cell.

Example 3-6 shows the inference report for the MUX\_OPs. Figure 3-6 shows a representation of the HDL Compiler implementation.

#### Example 3-5 Two MUX\_OPs and One SELECT\_OP Inferred

```
library ieee, synopsys;
use ieee.std_logic_1164.all;
use synopsys.attributes.all;
entity test is
  port (DIN1 : in std_logic_vector (7 downto 0);
        DIN2 : in std_logic_vector (7 downto 0);
        DIN3 : in std_logic_vector (3 downto 0);
        SEL1 : in std_logic_vector (2 downto 0);
        SEL2 : in std_logic_vector (2 downto 0);
        SEL3 : in std_logic_vector (1 downto 0);
        DOUT1 : out std logic;
        DOUT2 : out std_logic;
        DOUT3 : out std_logic
      );
end test;
architecture rtl of test is
attribute infer_mux of proc1 : label is "TRUE";
begin
  -- A MUX OP for DOUT1 will be inferred from the
  -- infer_mux attribute set on proc1
  proc1 : process (SEL1, DIN1)
  begin
     case SEL1 is
       when "000" => DOUT1 <= DIN1(0); when "001" => DOUT1 <= DIN1(1);
       when "010" \Rightarrow DOUT1 \Leftarrow DIN1(2);
       when "011" \Rightarrow DOUT1 \iff DIN1(3);
       when "100" => DOUT1 <= DIN1(4);
       when "101" => DOUT1 <= DIN1(5);
       when "110" => DOUT1 <= DIN1(6);
       when "111" => DOUT1 <= DIN1(7);
       when others => DOUT1 <= DIN1(0);
    end case;
  end process;
  proc2 : process (SEL2, SEL3, DIN2, DIN3)
  begin
  -- A SELECT_OP will be generated for DOUT2
  -- in the absence of an infer_mux attribute
     case SEL2 is
       when "000" => DOUT2 <= DIN2(0);
       when "001" => DOUT2 <= DIN2(1);
```

```
when "010" => DOUT2 <= DIN2(2);
       when "011" => DOUT2 <= DIN2(3);
       when "100" => DOUT2 <= DIN2(4);
       when "101" => DOUT2 <= DIN2(5);
       when "110" => DOUT2 <= DIN2(6);
       when "111" => DOUT2 <= DIN2(7);
       when others => DOUT2 <= DIN2(0);
    end case;
  -- A MUX_OP will be inferred for DOUT3 from the
  -- infer_mux pragma placed on this case statement
    case SEL3 is -- synopsys infer_mux
      when "00" => DOUT3 <= DIN3(0);
when "01" => DOUT3 <= DIN3(1);
      when "10" => DOUT3 <= DIN3(2);
when "11" => DOUT3 <= DIN3(3);
      when others => DOUT3 <= DIN3(0);
    end case;
  end process;
end rtl;
```

Example 3-6 shows the MUX\_OP inference report for the code in Example 3-5. The tool displays inference reports by default. If you do not want these reports displayed, you can turn them off using the hdlin\_reporting\_level variable. For more information about the hdlin\_reporting\_level variable, see "Customizing Elaboration Reports" on page 1-8.

#### Example 3-6 Inference Report for the Process in Example 3-5

block name/line	Inputs	Outputs	# sel inputs
proc1/24	8	1	3
proc2/55	4	1	2




Figure 3-6 HDL Compiler Implementation

## **MUX OP Inference Limitations**

HDL Compiler does not infer MUX OP cells for

- · Case statements in while loops
- Case statements embedded in if-then-else statements, unless the case statement appears in an if (CLK'event...) or in an elsif (CLK'event...) branch in the VHDL description

MUX\_OP cells are inferred for incompletely specified case statements, such as case statements that

- Contain an if statement or an others clause that covers more than one value
- Have a missing case statement branch or a missing assignment in a case statement branch
- Contain don't care values (X or "-")
- Are in an elsif (CLK'event...) branch

However, the logic might be nonoptimum, because other optimizations are disabled when you infer MUX\_OP cells under these conditions. For example, HDL Compiler optimizes default branches by default. If the <code>infer\_mux</code> attribute is on the case statement, this optimization is not done.

When inferring a MUX\_OP for an incompletely specified case statement, HDL Compiler generates the following ELAB-304 warning:

```
Warning: Case statement has an infer_mux attribute and a default branch or incomplete mapping. This can cause nonoptimal logic if a mux is inferred. (ELAB-304)
```

## **Unintended Latches and Feedback Paths in Combinational Logic**

HDL Compiler infers a latch when a signal or variable in a combinational process (one without a wait or if signal'event statement) is not fully specified in the VHDL description. A variable or signal is fully specified when it is assigned under all possible conditions. A variable or signal is not fully specified when a condition exists under which the variable is not assigned.

Example 3-7 shows several variables. A, B, and C are fully specified; X is not.

#### Example 3-7 Variable X Is Not Fully Specified

```
process (COND1)
 variable A, B, C, X : BIT;
begin
  A := '0' -- A is fully specified
  C := '0'
             -- C is fully specified
  if (COND1) then
   B := '1'; -- B is assigned when COND1 is TRUE
   C := '1'; -- C is already fully specified
   X := '1'; -- X is assigned when COND1 is TRUE
  else
   B := '0'; -- B is assigned when COND1 is FALSE
  end if;
  -- B is assigned under all branches of if (COND1),
  -- that is, both when COND1 is TRUE and when
  -- COND1 is FALSE, so B is fully specified.
  -- C is assigned regardless of COND1, so C is fully
  -- specified. (The second assignment to C does
  -- not change this.)
  -- X is not assigned under all branches of
  -- if (COND1), namely, when COND1 is FALSE,
      so X is not fully specified.
end process;
. . .
```

The conditions of each if and else statement are considered independent in Example 3-7.

In Example 3-8, variable A is not fully specified.

#### Example 3-8 Variable A Is Not Fully Specified

```
if (COND1) then
    A <= '1';
end if;

if (not COND1) then
    A <= '0';
end if;</pre>
```

A variable or signal that is not fully specified is considered conditionally specified, and HDL Compiler infers a latch to store the variable value. You can conditionally assign a variable, but you cannot read a conditionally specified variable. You can, however, both conditionally assign and read a signal.

If a fully specified variable is read before its assignment statements, combinational feedback might exist. For example, the following fragment synthesizes combinational feedback for VAL.

```
process(D, LOAD)
  variable VAL: BIT;
begin
  if (LOAD = '1') then
    VAL := D;
  else
    VAL := VAL;
  end if;
  VAL_OUT <= VAL;
end process;</pre>
```

In a combinational process, you can ensure that a variable or signal is fully specified, by providing an initial (default) assignment to the variable at the beginning of the process. This default assignment ensures that the variable is always assigned a value, regardless of conditions. Subsequent assignment statements can override the default. A default assignment is made to variables A and C in Example 3-7.

Another way to ensure that you do not imply combinational feedback is to use a sequential process (one with a wait or if signal'event statement). In such a case, variables and signals are registered. The registers break the combinational feedback loop.

HDL Compiler infers latches for incompletely specified case statements that use an others clause, where the others clause covers more than one value. To avoid latch inference, use a default statement before the case statements.

# 4

# Modeling Sequential Logic


This chapter contains the following sections, which describe how to infer latches and flip-flops:

- Generic Sequential Cells (SEQGENs)
- Inference Reports for Flip-Flops and Latches
- Register Inference Variables
- Register Inference Attributes
- Inferring D and Set/Reset (SR) Latches
- Inferring D Flip-Flops
- Inferring JK Flip-Flops
- Inferring Master-Slave Latches
- Limitations of Register Inference
- Unloaded Sequential Cell Preservation

### **Generic Sequential Cells (SEQGENs)**

When HDL Compiler reads a design, it uses generic sequential cells (SEQGENs), shown in Figure 4-1, to represent inferred flip-flops and latches.

Figure 4-1 SEQGEN Cell and Pin Assignments




To illustrate how HDL Compiler uses SEQGENs to implement a flip-flop, consider Example 4-1. This code infers a D flip-flop with an asynchronous reset.

#### Example 4-1 D Flip-Flop With Asynchronous Reset

```
library IEEE;
use IEEE.std_logic_1164.all;
entity dff async reset is
  port (DATA, CLK, RESET : in std_logic;
        Q : out std_logic );
end dff_async_reset;
architecture rtl of dff_async_reset is
begin
process ( CLK, RESET) begin
  if (RESET = '1') then
    Q <= '0';
  elsif (CLK'event and CLK = '1') then
    Q <= DATA;
  end if;
end process;
end rtl;
```


Figure 4-2 shows the SEQGEN implementation.

Figure 4-2 D Flip-flop With an Asynchronous Reset: HDL Compiler SEQGEN Implementation



After Design Compiler compiles the design, SEQGENs are mapped to the appropriate latch or flip-flop in the logic library. Figure 4-3 shows an example implementation after compile.

Figure 4-3 D Flip-flop With an Asynchronous Reset: Design Compiler Implementation



#### Note:

If the logic library does not contain the specific inferred flip-flop or latch, Design Compiler creates combinational logic for the missing function, if possible. For example, if you infer a D flip-flip with a synchronous set but your target logic library does not contain this type of flip-flop, Design Compiler creates combinational logic for the synchronous set function. Design Compiler cannot create logic to duplicate an asynchronous preset/reset. Your library must contain the sequential cell with the asynchronous control pins.

### Inference Reports for Flip-Flops and Latches

HDL Compiler provides inference reports that describe each inferred flip-flop or latch. You can enable or disable the generation of inference reports by using the hdlin\_reporting\_level variable. By default, hdlin\_reporting\_level is set to basic. When hdlin\_reporting\_level is set to basic or comprehensive, HDL Compiler generates a report similar to Example 4-2. This basic inference report shows only which type of register was inferred.

Example 4-2 Inference Report for a D Flip-Flop With Asynchronous Reset

Register Name	======================================		Width	= =   	Bus		MB		AR		AS		SR		SS		ST	
Q_reg	Flip-flop		1		N		N		Y	Ī	N		N		N		N	

In the report, the columns are abbreviated as follows:

- MB represents multibit cell
- AR represents asynchronous reset
- AS represents asynchronous set
- SR represents synchronous reset
- SS represents synchronous set
- ST represents synchronous toggle

A "Y" in a column indicates that the respective control pin was inferred for the register; an "N" indicates that the respective control pin was not inferred for the register. For a D flip-flop with an asynchronous reset, there should be a "Y" in the AR column. The report also indicates the type of register inferred, latch or flip-flop, and the name of the inferred cell.

When the hdlin\_reporting\_level variable is set to verbose, the report indicates how each pin of the SEQGEN cell is assigned, along with which type of register was inferred. Example 4-3 shows a verbose inference report.

Example 4-3 Verbose Inference Report for a D Flip-Flop With Asynchronous Reset

======================================	========   Type	Width	======   Bus	MB	====   AR	====   AS	=====   SR	SS	ST	
Q_reg	========   Flip-flop ========	1	======   N   ======	N =====	=====   Y =====	=====   N =====	N	N	N	

```
Sequential Cell (Q_reg)
Cell Type: Flip-Flop
Multibit Attribute: N
Clock: CLK
Async Clear: RESET
Async Set: 0
Async Load: 0
Sync Clear: 0
Sync Set: 0
Sync Toggle: 0
Sync Load: 1
```

If you do not want inference reports, set hdlin\_reporting\_level to none. For more information about the hdlin\_reporting\_level variable, see "Customizing Elaboration Reports" on page 1-8.

### **Register Inference Variables**

The variables in Table 4-1 control register inference. These are set before the design is read and apply to all applicable cells in the design. Use of these variables can have unintended consequences. For example, when the hdlin\_ff\_always\_sync\_set\_reset variable is set to true, HDL Compiler treats every signal in every process as though the sync\_set\_reset directive is attached to it. Therefore, it checks all processes for all constant (0 or 1) assignments for a register input. The control for these constant-assigned signals becomes part of the set/reset logic.

Table 4-1 Variables That Control Register Inference

Variable	Description
hdlin_keep_feedback (Default is false)	When this variable is true, HDL Compiler keeps all flip-flop feedback loops.
	When this variable is false, HDL Compiler removes all flip-flop feedback loops. For example, HDL Compiler removes feedback loops inferred from a statement such as Q=Q. Removing the state feedback from a simple D flip-flop creates a synchronous loaded flip-flop.
hdlin_ff_always_ sync_set_reset (Default is false)	When this variable is true, HDL Compiler attempts to infer synchronous set and reset conditions for all flip-flops.

Table 4-1 Variables That Control Register Inference (Continued)

Variable	Description
hdlin_ff_always_ async_set_reset (Default is true)	When this variable is true, HDL Compiler attempts to infer asynchronous set and reset conditions for all flip-flops.

# **Register Inference Attributes**

Use the attributes in Table 4-2 to direct HDL Compiler to the type of sequential device you want inferred. Attributes are added to the RTL on specific processes.

Table 4-2 Attributes for Controlling Register Inference

Attribute	Description
async_set_reset	When a single-bit signal has this attribute set to true, HDL Compiler searches for a branch that uses the signal as a condition and then checks whether the branch contains an assignment to a constant value. If the branch does, the signal becomes an asynchronous reset or set. See Example 4-4 on page 4-8, Example 4-11 on page 4-12, and Example 4-13 on page 4-13. Attach this attribute to 1-bit signals by using the following syntax:
	<pre>attribute async_set_reset of signal_name_list : signal is "true";</pre>
async_set_reset_local	VHDL Compiler treats listed signals in the specified process as if they have the async_set_reset attribute set to true.
	Attach this attribute to a process label by using the following syntax: attribute async_set_reset_local of process_label : label is "signal_name_list";
async_set_reset_local_a	VHDL Compiler treats all signals in the specified processes as if they have the async_set_reset attribute set to true.
	Attach this attribute to process labels by using the following syntax: attribute async_set_reset_local_all of process_label_list : label is "true";
sync_set_reset	When a single-bit signal has this attribute set to true, HDL Compiler checks the signal to determine whether it synchronously sets or resets a register in the design. See Example 4-33 on page 4-23 and Example 4-35 on page 4-25. Attach this attribute to 1-bit signals by using the following syntax:
	attribute sync_set_reset of signal_name_list: signal is "true";

Table 4-2 Attributes for Controlling Register Inference (Continued)

Attribute	Description
sync_set_reset_local	VHDL Compiler treats listed signals in the specified process as if they have the sync_set_reset attribute set to true.
	Attach this attribute to a process label by using the following syntax: attribute sync_set_reset_local of process_label : label is "signal_name_list";
<pre>sync_set_reset_local _all</pre>	VHDL Compiler treats all signals in the specified processes as if they have the <code>sync_set_reset</code> attribute set to <code>true</code> .
	Attach this attribute to process labels by using the following syntax: attribute sync_set_reset_local_all of process_label_list : label is "true";
one_cold one_hot	These attributes prevent HDL Compiler from implementing priority-encoding logic for the set and reset signals and are useful if you know your design has a one-hot or one-cold implementation. See Example 4-15 on page 4-14, Example 4-31 on page 4-22, and Example 4-43 on page 4-32. Attach the attributes to set or reset signals on sequential devices by using the following syntax:
	attribute one_cold signal_name_list: signal is "true"; or attribute one_hot signal_name_list: signal is "true";
	You might want to add an assertion to the VHDL code to ensure that the group of signals has a one-cold or one-hot implementation. HDL Compiler does not produce any logic to check this assertion.
clocked_on_also	This attribute is set in an embedded Design Compiler script and used for master-slave inference. For more information, see "Inferring Master-Slave Latches" on page 4-33.

# Inferring D and Set/Reset (SR) Latches

This section describes how to infer SR and D latches, in the following subsections:

- Inferring SR Latches
- Inferring D Latches
- · Limitations of D Latch Inference

### **Inferring SR Latches**

Use SR latches with caution, because they are difficult to test. Design Compiler does not ensure that the logic driving the inputs is hazard-free, so you must verify that the inputs are hazard-free and do not glitch. Example 4-4 provides the VHDL code that implements the SR latch described in the truth table in Table 4-3. Example 4-5 shows the inference report generated by HDL Compiler.

Table 4-3 SR Latch Truth Table (NAND Type)

Set	Reset	у
0	0	Not stable
0	1	1
1	0	0
1	1	у

#### Example 4-4 SR Latch

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity sr_latch is
 port (SET, RESET : in std_logic;
        Q : out std_logic );
  attribute async_set_reset of SET, RESET :
    signal is "true";
end sr_latch;
architecture rtl of sr_latch is
process (SET, RESET) begin
  if (SET = '0') then
    Q <= '1';
  elsif (RESET = '0') then
   Q <= '0';
  end if;
end process;
end rtl;
```

#### Example 4-5 Inference Report for an SR Latch

### Inferring D Latches

The following sections provide code examples and inference reports for D latches:

- Overview—Latch Inference
- Basic D Latch
- D Latch With Asynchronous Set
- D Latch With Asynchronous Reset
- D Latch With Asynchronous Set and Reset

#### Overview—Latch Inference

When you do not specify a variables value under all conditions, such as an incompletely specified if statement, HDL Compiler infers a D latch.

For example, the if statement in Example 4-6 infers a D latch, because there is no else clause. The resulting value for output Q is specified only when input enable has a logic 1 value. As a result, output Q becomes a latched value.

#### Example 4-6 Latch Inference

```
process(DATA, GATE) begin
  if (GATE = '1') then
   Q <= DATA;
  end if;
end process;</pre>
```

To avoid latch inference, assign a value to the signal under all conditions, as shown in Example 4-7.

#### Example 4-7 Fully Specified Signal: No Latch Inference

```
process(DATA, GATE) begin
  if (GATE = '1') then
   Q <= DATA;
  else
   Q <= '0';
  end if;
end process;</pre>
```

Variables declared locally within a subprogram do not hold their value over time, because each time a subprogram is called, its variables are reinitialized. Therefore, HDL Compiler does not infer latches for variables declared in subprograms. In Example 4-8, HDL Compiler does not infer a latch for output Q.

#### Example 4-8 Function: No Latch Inference

```
function MY_FUNC(DATA, GATE : std_logic) return std_logic is
    variable STATE: std_logic;
begin
  if (GATE = '1') then
    STATE := DATA;
  end if;
  return STATE;
end;
. . .
Q <= MY_FUNC(DATA, GATE);</pre>
```

#### **Basic D Latch**

When you infer a D latch, make sure you can control the gate and data signals from the top-level design ports or through combinational logic. Controllable gate and data signals ensure that simulation can initialize the design.

Example 4-9 provides the VHDL template for a D latch. HDL Compiler generates the verbose inference report shown in Example 4-10.

#### Example 4-9 Basic D Latch

```
library IEEE;
use IEEE.std_logic_1164.all;
entity d_latch is
  port (GATE, DATA: in std_logic;
       Q: out std_logic);
end d_latch;

architecture rtl of d_latch is
begin
process (GATE, DATA) begin
  if (GATE = '1') then
    Q <= DATA;
  end if;
end process;
end rtl;</pre>
```

#### Example 4-10 Verbose Inference Report for a D Latch

```
Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |

| Q_reg | Latch | 1 | N | N | N | N | - | - | - |

Sequential Cell (Q_reg)
Cell Type: Latch
Multibit Attribute: N
Clock: 0
Async Clear: 0
Async Set: 0
Async Load: GATE
```

### **D Latch With Asynchronous Set**

Use the async\_set\_reset attribute to specify the asynchronous set or reset controls. HDL Compiler examines the polarity of the constants assigned to the signals with the async\_set\_reset attribute to determine if the signal is an AR ('0') or an AS ('1').

Example 4-11 provides the VHDL template for a D latch with an asynchronous set. HDL Compiler generates the verbose inference report shown in Example 4-12.

#### Example 4-11 D Latch With Asynchronous Set

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity d_latch_async_set is
  port (GATE, DATA, SET : in std_logic;
        Q : out std_logic );
  attribute async_set_reset of SET :
    signal is "true";
end d_latch_async_set;
architecture rtl of d_latch_async_set is
process (GATE, DATA, SET) begin
  if (SET = '0') then
   Q <= '1';
  elsif (GATE = '1') then
   Q <= DATA;
  end if;
end process;
end rtl;
```

#### Example 4-12 Verbose Inference Report for a D Latch With Asynchronous Set

### **D Latch With Asynchronous Reset**

Use the async\_set\_reset attribute to specify asynchronous set or reset controls.

Example 4-13 provides the VHDL template for a D latch with an asynchronous reset. HDL Compiler generates the verbose inference report shown in Example 4-14.

#### Example 4-13 D Latch With Asynchronous Reset

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity d_latch_async_reset is
 port (GATE, DATA, RESET : in std_logic;
        Q : out std_logic );
  attribute async_set_reset of RESET :
    signal is "true";
end d_latch_async_reset;
architecture rtl of d_latch_async_reset is
process (GATE, DATA, RESET) begin
  if (RESET = '0') then
   Q <= '0';
  elsif (GATE = '1') then
   Q <= DATA;
  end if;
end process;
end rtl;
```

#### Example 4-14 Inference Report for D Latch With Asynchronous Reset

### **D Latch With Asynchronous Set and Reset**

Example 4-15 provides the VHDL template for a D latch with an active-low asynchronous set and reset. This template uses the async\_set\_reset attribute to direct HDL Compiler to the asynchronous signals in the process.

The template in Example 4-15 uses the <code>one\_cold</code> attribute to prevent priority encoding of the set and reset signals. If you do not specify the <code>one\_cold</code> attribute, the set signal has priority, because it is used as the condition for the if clause. Use <code>one\_cold</code> for active-low signals and <code>one\_hot</code> for active-high signals. Example 4-16 shows the verbose inference report.

#### Example 4-15 D Latch With Asynchronous Set and Reset

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity d_latch_async is
  port (GATE, DATA, SET, RESET :in std_logic;
        Q : out std_logic );
  attribute one_cold of SET, RESET :
    signal is "true";
end d_latch_async;
architecture rtl of d_latch_async is
  attribute async_set_reset of SET, RESET :
    signal is "true";
begin
process (GATE, DATA, SET, RESET) begin
  if (SET = '0') then
   Q <= '1';
  elsif (RESET = '0') then
    Q <= '0';
  elsif (GATE = '1') then
    Q <= DATA;
  end if;
end process;
end rtl;
```

#### Example 4-16 Inference Report for D Latch With Asynchronous Set and Reset

```
Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |

| Q_reg | Latch | 1 | N | N | Y | Y | - | - | - |

Sequential Cell (Q_reg)
Cell Type: Latch
Multibit Attribute: N
Clock: 0
Async Clear: RESET'
Async Set: SET'
Async Load: GATE
```

#### **Limitations of D Latch Inference**

A variable must always have a value before it is read. As a result, you cannot read a conditionally assigned variable after the if statement in which it is assigned. A conditionally assigned variable is assigned a new value under some, but not all, conditions.

Example 4-17 shows an invalid use of the conditionally assigned variable VALUE.

#### Example 4-17 Invalid Use of a Conditionally Assigned Variable

```
signal X, Y : std_logic;
. . . .
process
  variable VALUE : std_logic;
begin

if (condition) then
   VALUE := X;
end if;

Y <= VALUE; -- Invalid read of variable VALUE
end;</pre>
```

### **Inferring D Flip-Flops**

The following subsections describe various types of D flip-flop inference:

- Overview—Inferring D Flip-Flops
- Enabling Conditions in if Statements
- Rising-Edge-Triggered D Flip-Flop
- Falling-Edge-Triggered D Flip-Flop
- D Flip-Flop With Asynchronous Set
- D Flip-Flop With Asynchronous Reset
- D Flip-Flop With Asynchronous Set and Reset
- D Flip-Flop With Synchronous Set
- D Flip-Flop With Synchronous Reset
- D Flip-Flop With Complex Set/Reset Signals
- D Flip-Flop With Synchronous and Asynchronous Load
- Multiple Flip-Flops: Asynchronous and Synchronous Controls

### **Overview—Inferring D Flip-Flops**

HDL Compiler infers a D flip-flop whenever the condition of a wait or if statement uses an edge expression. Use the following syntax to describe a rising edge:

```
SIGNAL' event and SIGNAL = '1'
```

Use the following syntax to describe a falling edge:

```
SIGNAL'event and SIGNAL = '0'
```

If you are using the IEEE std\_logic\_1164 package, you can use the following syntax to describe a rising edge and a falling edge:

```
if (rising_edge (CLK)) then
if (falling_edge (CLK)) then
```

You can use the following syntax for a bused clock. You can also use a member of a bus as a signal.

```
sig(3)'event and sig(3) = '1'
rising_edge (sig(3))
```

If possible, use the if statement, because it provides greater control over the inferred registers. Only one wait statement per process is allowed.

In a process that models sequential logic, HDL Compiler allows statements to precede or to follow the if statement as long as no statement following the if statement tries to write a value that is assigned within the if statement. See Example 4-18.

#### Example 4-18 HDL Compiler Supports Statements Preceding and Following if ck'EVENT

```
P: process (ck)
  variable X, Y: BIT;
begin
  Y := not D; -- assignment before the if statement
  if ck'EVENT and ck = '1' then
   X := D;
  end if;
  Q <= X and Y; -- assignment after the if statement
  end process;</pre>
```

There are cases in which statements appearing before the if statement would make the code cannot be synthesized. Specifically, when the statements preceding the if statement writes to a variable that was also written to within the if body, as shown in Example 4-19, the code would not be synthesizable.

# Example 4-19 Code Cannot Be Synthesized—if ck'EVENT Statement Writes to a Variable Written to in Body

```
P: process (ck)
  variable X: BIT;
begin
  X := D1;
  if ck'EVENT and CK = '1' then
    X := D2; -- conflicts with previous assignment
  end if;
  Q <= X;
end process;</pre>
```

### **Enabling Conditions in if Statements**

HDL Compiler allows conditions in the test of the if statement that are not part of the clock edge test. When other conditions appear in the test, HDL Compiler synthesizes them by assuming they are enable conditions. HDL Compiler also recognizes permutations of the conditions in the if statement. Example 4-20 shows the coding style supported by HDL Compiler.

#### Example 4-20 HDL Compiler Supports Enabling Expressions in if Statements

```
process (ck)
begin
  if (ck = '1' and en = '1' and ck'EVENT) then
    --sequential_statements
  end if;
end process;
```

### Rising-Edge-Triggered D Flip-Flop

When you infer a D flip-flop, make sure you can control the clock and data signals from the top-level design ports or through combinational logic. Controllable clock and data signals ensure that simulation can initialize the design. If you cannot control the clock and data signals, infer a D flip-flop with asynchronous reset or set, or with synchronous reset or set.

Example 4-21 uses the 'event attribute and Example 4-22 uses the rising\_edge function to code a rising-edge-triggered D flip-flop. Example 4-23 shows the verbose inference report.

#### Example 4-21 Rising-Edge-Triggered D Flip-Flop Using 'event Attribute

```
library IEEE;
use IEEE.std_logic_1164.all;
entity dff_pos is
   port (DATA, CLK : in std_logic;
        Q : out std_logic );
end dff_pos;
```

```
architecture rtl of dff_pos is
begin
process (CLK) begin
  if (CLK'event and CLK = '1') then
    Q <= DATA;
  end if;
end process;
end rtl;</pre>
```

#### Example 4-22 Rising-Edge-Triggered D Flip-Flop Using rising\_edge

```
library IEEE ;
use IEEE.std_logic_1164.all;
entity dff_pos is
  port (DATA, CLK : in std_logic;
       Q : out std_logic );
end dff_pos;
architecture rtl of dff_pos is
begin
process (CLK) begin
  if (rising_edge (CLK)) then
       Q <= DATA;
  end if;
end process;
end rtl;</pre>
```

#### Example 4-23 Inference Report for Rising-Edge-Triggered D Flip-Flop

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
  ______
Sequential Cell (Q_reg)
    Cell Type: Flip-Flop
    Multibit Attribute: N
    Clock: CLK
    Async Clear: 0
    Async Set: 0
    Async Load: 0
    Sync Clear: 0
    Sync Set: 0
    Sync Toggle: 0
    Sync Load: 1
```

### Falling-Edge-Triggered D Flip-Flop

Example 4-24 uses the 'event attribute and Example 4-25 uses the falling\_edge function to code a falling-edge-triggered D flip-flop.

HDL Compiler generates the verbose inference report shown in Example 4-26.

#### Example 4-24 Falling-Edge-Triggered D Flip-Flop Using 'event

```
library IEEE;
use IEEE.std_logic_1164.all;

entity dff_neg is
   port (DATA, CLK : in std_logic;
        Q : out std_logic );
end dff_neg;

architecture rtl of dff_neg is
begin
process (CLK) begin
   if (CLK'event and CLK = '0') then
        Q <= DATA;
   end if;
end process;
end rtl;</pre>
```

#### Example 4-25 Falling-Edge-Triggered D Flip-Flop Using falling\_edge

```
library IEEE;
use IEEE.std_logic_1164.all;
entity dff_neg is
  port (DATA, CLK : in std_logic;
       Q : out std_logic );
end dff_neg;

architecture rtl of dff_neg is
begin
process (CLK) begin
  if (falling_edge (CLK)) then
    Q <= DATA;
  end if;
end process;
end rtl;</pre>
```

Example 4-26 Inference Report for Falling-Edge-Triggered D Flip-Flop

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
Q_reg | Flip-flop | 1 | N | N | N | N | N | N | N |
Sequential Cell (Q_reg)
     Cell Type: Flip-Flop
     Multibit Attribute: N
     Clock: CLK'
     Async Clear: 0
     Async Set: 0
     Async Load: 0
     Sync Clear: 0
     Sync Set: 0
     Sync Toggle: 0
     Sync Load: 1
```

### D Flip-Flop With Asynchronous Set

Example 4-27 provides the VHDL template for a D flip-flop with an asynchronous set. HDL Compiler generates the verbose inference report shown in Example 4-28.

#### Example 4-27 D Flip-Flop With Asynchronous Set

```
library IEEE;
use IEEE.std_logic_1164.all;
entity dff_async_set is
  port (DATA, CLK, SET : in std_logic;
       Q : out std_logic );
end dff_async_set;

architecture rtl of dff_async_set is
begin
process (CLK, SET) begin
  if (SET = '0') then
    Q <= '1';
  elsif (CLK'event and CLK = '1') then
    Q <= DATA;
  end if;
end process;
end rtl;</pre>
```

Example 4-28 Inference Report for a D Flip-Flop With Asynchronous Set

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
 Sequential Cell (Q_reg)
    Cell Type: Flip-Flop
    Multibit Attribute: N
    Clock: CLK
    Async Clear: 0
    Async Set: SET'
    Async Load: 0
    Sync Clear: 0
    Sync Set: 0
    Sync Toggle: 0
    Sync Load: 1
```

### **D Flip-Flop With Asynchronous Reset**

Example 4-29 provides the VHDL template for a D flip-flop with an asynchronous reset. HDL Compiler generates the verbose inference report shown in Example 4-30.

#### Example 4-29 D Flip-Flop With Asynchronous Reset

```
library IEEE;
use IEEE.std_logic_1164.all;

entity dff_async_reset is
  port (DATA, CLK, RESET : in std_logic;
        Q : out std_logic );
end dff_async_reset;

architecture rtl of dff_async_reset is
begin
process ( CLK, RESET) begin
  if (RESET = '1') then
        Q <= '0';
  elsif (CLK'event and CLK = '1') then
        Q <= DATA;
  end if;
end process;
end rtl;</pre>
```

Example 4-30 Inference Report for a D Flip-Flop With Asynchronous Reset

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
Q_reg | Flip-flop | 1 | N | N | Y | N | N | N | N |
______
Sequential Cell (Q_reg)
     Cell Type: Flip-Flop
     Multibit Attribute: N
     Clock: CLK
     Async Clear: RESET
     Async Set: 0
     Async Load: 0
     Sync Clear: 0
     Sync Set: 0
     Sync Toggle: 0
     Sync Load: 1
```

### D Flip-Flop With Asynchronous Set and Reset

Example 4-31 provides the VHDL template for a D flip-flop with active-high asynchronous set and reset pins.

The template in Example 4-31 uses the <code>one\_hot</code> attribute to prevent priority encoding of the set and reset signals. If you do not specify the <code>one\_hot</code> attribute, the reset signal has priority, because it is used as the condition for the if clause. The <code>one\_cold</code> attribute would be used instead of the <code>one\_hot</code> if you had active-low signals. HDL Compiler generates the verbose inference report shown in Example 4-32.

#### Example 4-31 D Flip-Flop With Asynchronous Set and Reset

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity dff_async is
 port (DATA, CLK, SET, RESET : in std_logic;
        Q : out std_logic );
  attribute one_hot of SET, RESET : signal is "true";
end dff_async;
architecture rtl of dff_async is
begin
process (CLK, SET, RESET) begin
  if (RESET = '1') then
    Q <= '0';
  elsif (SET = '1') then
    Q <= '1';
  elsif (CLK'event and CLK = '1') then
    Q <= DATA;
  end if;
end process;
end rtl;
```

Example 4-32 Inference Report for a D Flip-Flop With Asynchronous Set and Reset

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
  ______
Sequential Cell (Q_reg)
    Cell Type: Flip-Flop
    Multibit Attribute: N
    Clock: CLK
    Async Clear: RESET
    Async Set: SET
    Async Load: 0
    Sync Clear: 0
    Sync Set: 0
    Sync Toggle: 0
    Sync Load: 1
```

### **D Flip-Flop With Synchronous Set**

Use the <code>sync\_set\_reset</code> compiler directive to infer a D flip-flop with a synchronous set/reset. When you compile your design, the SEQGEN inferred by HDL Compiler will be either

- Mapped to a flip-flop in the logic library with a synchronous set/reset pin or
- Mapped to a regular D flip-flop. In this case, Design Compiler builds synchronous set/ reset logic in front of the D pin.

The choice depends on which method provides a better optimization result.

It is important to use the <code>sync\_set\_reset</code> compiler directive to label the set/reset signal. This compiler directive tells Design Compiler that the signal should be kept as close to the register as possible during mapping, preventing a simulation/synthesis mismatch which can occur if the set/reset signal is masked by an X during initialization in simulation.

Example 4-33 shows the recommended coding style for a synchronous set/reset flip-flop, using the sync\_set\_reset compiler directive. HDL Compiler generates the verbose inference report shown in Example 4-34

#### Example 4-33 D Flip-Flop With Synchronous Set

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity dff_sync_set is
   port (DATA, CLK, SET : in std_logic;
        Q : out std_logic );
   attribute sync_set_reset of SET : signal is "true";
end dff_sync_set;
```

```
architecture rtl of dff_sync_set is
begin
process (CLK) begin
  if (CLK'event and CLK = '1') then
    if (SET = '1') then
      Q <= '1';
    else
      Q <= DATA;
    end if;
end if;
end process;
end rtl;</pre>
```

Example 4-34 Inference Report for a D Flip-Flop With Synchronous Set

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
   Q_reg | Flip-flop | 1 | N | N | N | N | Y | N |
______
Sequential Cell (O reg)
     Cell Type: Flip-Flop
     Multibit Attribute: N
     Clock: CLK
     Async Clear: 0
     Async Set: 0
     Async Load: 0
     Sync Clear: 0
     Sync Set: SET
     Sync Toggle: 0
     Sync Load: 1
```

### **D Flip-Flop With Synchronous Reset**

Use the <code>sync\_set\_reset</code> compiler directive to infer a D flip-flop with a synchronous set/reset. When you compile your design, the SEQGEN inferred by HDL Compiler will be mapped to a flip-flop in the logic library with a synchronous set/reset pin or Design Compiler will use a regular D flip-flop and build synchronous set/reset logic in front of the D pin. The choice depends on which method provides a better optimization result.

It is important to use the <code>sync\_set\_reset</code> compiler directive to label the set/reset signal. This compiler directive tells Design Compiler that the signal should be kept as close to the register as possible during mapping, preventing a simulation/synthesis mismatch which can occur if the set/reset signal is masked by an X during initialization in simulation.

Example 4-35 shows the recommended coding style for a synchronous set/reset flip-flop using the sync\_set\_reset compiler directive. HDL Compiler generates the verbose inference report shown in Example 4-36.

#### Example 4-35 D Flip-Flop With Synchronous Reset

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity dff_sync_reset is
  port (DATA, CLK, RESET : in std_logic;
        Q : out std_logic );
  attribute sync_set_reset of RESET :
    signal is "true";
end dff_sync_reset;
architecture rtl of dff_sync_reset is
begin
process (CLK) begin
  if (CLK'event and CLK = '1') then
    if (RESET = '0') then
      0 <= '0';
    else
      Q <= DATA;
    end if;
  end if;
end process;
end rtl;
```

#### Example 4-36 Inference Report for a D Flip-Flop With Synchronous Reset

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
   Q_reg | Flip-flop | 1 | N | N | N | N | Y | N | N |
______
Sequential Cell (Q_reg)
     Cell Type: Flip-Flop
     Multibit Attribute: N
     Clock: CLK
     Async Clear: 0
     Async Set: 0
     Async Load: 0
     Sync Clear: RESET'
     Sync Set: 0
     Sync Toggle: 0
     Sync Load: 1
```

### D Flip-Flop With Complex Set/Reset Signals

While many set/reset signals are simple signals, some include complex logic. To enable HDL Compiler to generate a clean set/reset (that is, one attached to only the appropriate set/reset pin), use the following coding guidelines:

• Apply the appropriate set/reset attribute (sync\_set\_reset or async\_set\_reset) to the set/reset signal. For example,

- Use no more than two operands in the set/reset logic expression conditional.
- Use the set/reset signal as the first operand in the set/reset logic expression conditional.

This coding style supports usage of the negation operator on the set/reset signal and the logic expression. The logic expression can be a simple expression or any expression contained inside parentheses. However, any deviation from these coding guidelines will not be supported. For example, the following coding styles are not supported: using a subscripted value as reset, using a more complex expression other than the OR of two expressions, or using a rst (or ~rst) that does not appear as the first argument in the expression.

#### Examples:

```
process(...)
  if (rst='1' OR logic_expression)
    q \ll 0;
  else ...
  else ...
. . .
a <= rst OR NOT( a | b & c);
process(...)
if (a)
q = 0;
else ...;
else ...;
process(...)
if ( NOT rst OR NOT (a OR b OR c))
q = 0;
else ...
else ...
```

### D Flip-Flop With Synchronous and Asynchronous Load

To infer a component with both synchronous and asynchronous controls, you must check the asynchronous conditions before you check the synchronous conditions.

Example 4-37 provides the VHDL template for a D flip-flop with a synchronous load (called SLOAD) and an asynchronous load (called ALOAD). HDL Compiler generates the verbose inference report shown in Example 4-38.

#### Example 4-37 D Flip-Flop With Synchronous and Asynchronous Load

```
library IEEE;
use IEEE.std_logic_1164.all;
entity dff a s load is
port(SLOAD, ALOAD, ADATA, SDATA,CLK : in std_logic; Q : out std_logic );
end dff a s load;
architecture rtl of dff_a_s_load is
signal asyn rst, asyn set :std logic ;
asyn_set <= ALOAD AND (ADATA);</pre>
asyn rst <= ALOAD AND NOT(ADATA);</pre>
process (CLK,asyn_set, asyn_rst)
begin
if (asyn_set ='1') then
0 <= '1';
elsif (asyn_rst ='1') then
q <= '0';
elsif (clk'event and clk ='1' and SLOAD = '1') then Q <= SDATA; end if;
end process;
end rtl;
```

Example 4-38 Inference Report for a D Flip-Flop With Synchronous and Asynchronous Load

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
  ______
Sequential Cell (Q_reg)
    Cell Type: Flip-Flop
    Multibit Attribute: N
    Clock: CLK
    Async Clear: ADATA' ALOAD
    Async Set: ADATA ALOAD
    Async Load: 0
    Sync Clear: 0
    Sync Set: 0
    Sync Toggle: 0
    Sync Load: SLOAD
```

### Multiple Flip-Flops: Asynchronous and Synchronous Controls

If a signal is synchronous in one process but asynchronous in another, set both the sync\_set\_reset and async\_set\_reset attributes on the signal.

In Example 4-39, the <code>infer\_sync</code> process uses the reset signal as a synchronous reset and the <code>infer\_async</code> process uses the reset signal as an asynchronous reset. Example 4-40 shows the verbose inference report.

#### Example 4-39 Multiple Flip-Flops: Asynchronous and Synchronous Controls

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity multi_attr is
  port (DATA1, DATA2, CLK, RESET, SLOAD : in std_logic;
        Q1, Q2 : out std_logic );
end multi_attr;
architecture rtl of multi attr is
  attribute async_set_reset of RESET :
    signal is "true";
  attribute sync_set_reset of RESET :
    signal is "true";
begin
infer_sync: process (CLK) begin
  if (CLK') event and CLK = '1') then
    if (RESET = '0') then
      01 <= '0';
    elsif (SLOAD = '1') then
      Q1 <= DATA1;
```

end if;
end if;

end process infer\_sync;

```
infer_async: process (CLK, RESET) begin
    if (RESET = '0') then
      Q2 <= '0';
    elsif (CLK'event and CLK = '1' and SLOAD = '1') then
      O2 <= DATA2;
    end if;
   end process infer_async;
   end rtl;
Example 4-40 Inference Reports for Example 4-39
Inferred memory devices in process
      in routine multi_attr line 17 in file
      '/remote/vhdl_example/multi_attr.vhd'.
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
| Q1_reg | Flip-flop | 1 | N | N | N | N | N | N | N |
______
Inferred memory devices in process
      in routine multi_attr line 27 in file
      '/remote/vhdl_example/multi_attr.vhd'.
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
Sequential Cell (Q1_reg)
      Cell Type: Flip-Flop
      Multibit Attribute: N
      Clock: CLK
      Async Clear: 0
      Async Set: 0
      Async Load: 0
      Sync Clear: RESET'
      Sync Set: 0
      Sync Toggle: 0
      Sync Load: SLOAD
Sequential Cell (Q2_reg)
      Cell Type: Flip-Flop
      Multibit Attribute: N
      Clock: CLK
      Async Clear: RESET'
      Async Set: 0
      Async Load: 0
      Sync Clear: 0
      Sync Set: 0
      Sync Toggle: 0
      Sync Load: SLOAD
```

### **Inferring JK Flip-Flops**

This section contains code examples and inference reports for the following types of JK flip-flops:

- Basic JK Flip-Flop
- JK Flip-Flop With Asynchronous Set and Reset

### **Basic JK Flip-Flop**

When you infer a JK flip-flop, make sure you can control the J, K, and clock signals from the top-level design ports to ensure that simulation can initialize the design.

Example 4-41 provides the VHDL code that implements the JK flip-flop described in the truth table in Table 4-4.

In the JK flip-flop, the J and K signals act as active-high synchronous set and reset. Use the sync\_set\_reset attribute to indicate that the J and K signals are the synchronous set and reset for the design.

Example 4-42 on page 4-31 shows the verbose inference report generated by HDL Compiler.

Table 4-4 Truth Table for JK Flip-Flop

J	K	CLK	Qn+1
0	0	Rising	Qn
0	1	Rising	0
1	0	Rising	1
1	1	Rising	not (Qn)
Χ	Χ	Falling	Qn

#### Example 4-41 JK Flip-Flop

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity jk is
  port(J, K, CLK : in std_logic;
       Q_out : out std_logic );
  attribute sync_set_reset of J, K :
    signal is "true";
end jk;
architecture rtl of jk is
  signal Q : std_logic;
begin
process
  variable JK : std_logic_vector ( 1 downto 0);
  wait until (CLK'event and CLK = '1');
  JK := (J \& K);
  case JK is
    when "01" \Rightarrow Q \iff '0';
    when "10" \Rightarrow Q \iff '1';
    when "11" => Q \le not(Q);
    when "00" => Q <= Q;
    when others => Q <= 'X';
  end case;
end process;
Q out <= Q;
end rtl;
```

#### Example 4-42 Inference Report for a JK Flip-Flop

```
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
Q_reg | Flip-flop | 1 | N | N | N | Y | Y | N |
_______
Sequential Cell (Q_reg)
     Cell Type: Flip-Flop
     Multibit Attribute: N
     Clock: CLK
     Async Clear: 0
     Async Set: 0
     Async Load: 0
     Sync Clear: J' K
     Sync Set: J K'
     Sync Toggle: 0
     Sync Load: K
```

### JK Flip-Flop With Asynchronous Set and Reset

Example 4-43 provides the VHDL template for a JK flip-flop with asynchronous set and reset. Use the sync\_set\_reset attribute to indicate the JK function. Use the one\_hot attribute to prevent priority encoding of the set and reset signals. HDL Compiler generates the verbose inference report shown in Example 4-44.

#### Example 4-43 JK Flip-Flop With Asynchronous Set and Reset

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
use synopsys.attributes.all;
entity jk_async_sr is
 port (SET, RESET, J, K, CLK : in std_logic;
        Q_out : out std_logic );
  attribute sync_set_reset of J, K :
   signal is "true";
  attribute one_hot of SET, RESET : signal is "true";
end jk_async_sr;
architecture rtl of jk_async_sr is
  signal Q : std_logic;
process (CLK, SET, RESET)
  variable JK : std_logic_vector (1 downto 0);
begin
  if (RESET = '1') then
    Q <= '0';
  elsif (SET = '1') then
    Q <= '1';
  elsif (CLK'event and CLK = '1') then
    JK := (J \& K);
    case JK is
      when "01" \Rightarrow Q \iff '0';
      when "10" => Q <= '1';
      when "11" => Q \le not(Q);
      when "00" => Q <= Q;
      when others => Q <= 'X';
    end case;
  end if;
end process;
Q_out <= Q;
end rtl;
```

Example 4-44 Inference Report for a JK Flip-Flop With Asynchronous Set and Reset

Register Name	 Туре	width	======   Bus	MB	=====   AR	=====   AS	=====   SR	=====   SS	=====   ST
Q_reg	Flip-flop	1   1	N	====   N =====	=====   Y =====	Y	Y	=====   Y =====	N

```
Sequential Cell (Q_reg)
Cell Type: Flip-Flop
Multibit Attribute: N
Clock: CLK
Async Clear: RESET
Async Set: SET
Async Load: 0
Sync Clear: J' K
Sync Set: J K'
Sync Toggle: 0
Sync Load: K
```

### **Inferring Master-Slave Latches**

This section contains the following subsections:

- Master-Slave Latch Overview
- Master-Slave Latch: Single Master-Slave Clock Pair
- Master-Slave Latch: Multiple Master-Slave Clock Pairs
- Master-Slave Latch: Discrete Components

#### **Master-Slave Latch Overview**

Design Compiler infers master-slave latches by using the clocked\_on\_also attribute.

In your VHDL description, describe the master-slave latch as a flip-flop, using only the slave clock. Specify the master clock as an input port, but do not connect it. In addition, set the clocked\_on\_also attribute on the master clock port (called MCK in these examples).

This coding style requires that cells in the target logic library contain slave clocks defined with the <code>clocked\_on\_also</code> attribute. The <code>clocked\_on\_also</code> attribute defines the slave clocks in the cell's state declaration. For more information about defining slave clocks in the target logic library, see the *Library Compiler User Guide*.

If Design Compiler does not find any master-slave latches in the target logic library, the tool leaves the master-slave generic cell (MSGEN) unmapped. Design Compiler does not use D flip-flops to implement the equivalent functionality of the cell.

#### Note:

Although the vendor's component behaves as a master-slave latch, Library Compiler supports only the description of a master-slave flip-flop.

### Master-Slave Latch: Single Master-Slave Clock Pair

Example 4-45 provides the VHDL template for a master-slave latch.

See "dc\_tcl\_script\_begin and dc\_tcl\_script\_end" on page 6-5 for more information on the dc\_tcl\_script\_begin and dc\_tcl\_script\_end compiler directives. HDL Compiler generates the verbose inference report shown in Example 4-46.

#### Example 4-45 Master-Slave Latch

```
library IEEE;
use IEEE.std_Logic_1164.all;
entity mslatch is
  port(MCK, SCK, DATA : in std_logic;
       Q : out std_logic );
end mslatch;
architecture rtl of mslatch is
begin
-- synopsys dc_tcl_script_begin
-- set_attribute -type string MCK signal_type clocked_on_also
-- set_attribute -type boolean MCK level_sensitive true
-- synopsys dc_tcl_script_end
process(SCK, DATA) begin
  if (SCK'event and SCK= '1') then
   Q <= DATA;
  end if;
end process;
end rtl;
```

#### Example 4-46 Inference Report for a Master-Slave Latch

==========	=	========	=	======	==	====	==	====	==	====	=	====	==	====	==	====	=	====	==
Register Name		Type		Width		Bus		MB		AR		AS		SR		SS		ST	
Q_reg		Flip-flop		1	Ī	N		N		N		N		N		N		N	Ī
==========	=		=	======	-	====:	==	====	==	====	=	===:	==	===:	==	====	=	====	==

### Master-Slave Latch: Multiple Master-Slave Clock Pairs

If the design requires more than one master-slave clock pair, you must specify the associated slave clock in addition to the clocked\_on\_also attribute. Example 4-47 illustrates the use of clocked\_on\_also with the associated\_clock option. Example 4-48 shows the verbose inference reports.

#### Example 4-47 Inferring Master-Slave Latches With Two Pairs of Clocks

```
library IEEE;
use IEEE.std_Logic_1164.all;
entity mslatch2 is
 port(SCK1, MCK1, DATA1, SCK2, MCK2, DATA2 : in std_logic;
 Q1, Q2 : out std_logic );
end mslatch2;
architecture rtl of mslatch2 is
begin
-- synopsys dc_tcl_script_begin
-- set_attribute -type string MCK1 signal_type clocked_on_also
-- set_attribute -type boolean MCK1 level_sensitive true
-- set_attribute -type string MCK1 associated_clock SCK1
-- set_attribute -type string MCK2 signal_type clocked_on_also
-- set_attribute -type boolean MCK2 level_sensitive true
-- set_attribute -type string MCK2 associated_clock SCK2
-- synopsys dc_tcl_script_end
process (SCK1, DATA1) begin
 if (SCK1'event and SCK1 = '1') then
   O1 <= DATA1;
 end if;
end process;
process (SCK2, DATA2) begin
 if (SCK2'event and SCK2 = '1') then
   Q2 <= DATA2;
  end if;
end process;
end rtl;
```

#### Example 4-48 Inference Reports for Master-Slave Latch: Multiple Clock Pairs

===========	=	========	=	======	==	====	==	====	==	====	==	====	==	====	=	====	==:	====	:=
Register Name		Type		Width		Bus		MB		AR		AS		SR		SS		ST	
Q2_req	-	======= Flip-flop	_	 1	- <del>-</del> -	 N	 	N	 	N	 	N	 	 N	 	 N	·=·	 N	1
	:=	========	=	======	==:	====	==	===:	==	===:	==	====	==	===:	:=	====	==:	====	:=

### **Master-Slave Latch: Discrete Components**

If your target logic library does not contain master-slave latch components, you can infer two-phase systems using two D latches. Example 4-49 shows a simple two-phase system with clocks MCK and SCK. Example 4-50 shows the verbose inference reports.

#### Example 4-49 Two-Phase Clocks

```
library IEEE;
use IEEE.std_Logic_1164.all;
entity LATCH_VHDL is
 port(MCK, SCK, DATA: in std_logic;
       Q : out std_logic );
end LATCH_VHDL;
architecture rtl of LATCH_VHDL is
  signal TEMP : std_logic;
process (MCK, DATA) begin
  if (MCK = '1') then
   TEMP <= DATA;
  end if;
end process;
process (SCK, TEMP) begin
  if (SCK = '1') then
   Q <= TEMP;
  end if;
end process;
end rtl;
```

### Example 4-50 Inference Reports for Two-Phase Clocks

```
Inferred memory devices in process
    in routine LATCH_VHDL line 10 in file
        '/remote/vhdl_example/latch_vhdl.vhd'.
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
TEMP_reg | Latch | 1 | N | N | N | - | - | - |
______
Inferred memory devices in process
    in routine LATCH_VHDL line 15 in file
        '/remote/vhdl_example/latch_vhdl.vhd'.
______
| Register Name | Type | Width | Bus | MB | AR | AS | SR | SS | ST |
______
Q_reg | Latch | 1 | N | N | N | - | - | - |
______
Sequential Cell (TEMP reg)
    Cell Type: Latch
    Multibit Attribute: N
    Clock: 0
    Async Clear: 0
    Async Set: 0
    Async Load: MCK
Sequential Cell (Q_reg)
    Cell Type: Latch
    Multibit Attribute: N
    Clock: 0
    Async Clear: 0
    Async Set: 0
    Async Load: SCK
```

# **Limitations of Register Inference**

For best results when inferring registers, restrict each process to inferring a single type of memory cell, use the templates provided in this chapter, and understand the following inference limitations.

HDL Compiler cannot infer the following components. You must instantiate them in your VHDL description.

- Flip-flops and latches with three-state outputs
- Flip-flops with bidirectional pins
- Flip-flops with multiple clock inputs
- Multiport latches
- Register banks

#### Note:

Although you can instantiate flip-flops with bidirectional pins, Design Compiler interprets these cells as black boxes.

If you use an if statement to infer D flip-flops, your design must meet the following requirements:

• The edge expression, such as CLK'event rising\_edge (CLK), must be the only condition of an if or an elsif clause.

The following if statement is invalid, because it has multiple conditions in the if clause:

```
if (edge \text{ and RST} = '1')
```

 You can have only one edge expression in an if clause, and the if clause must not have an else clause.

The following if statement is invalid, because you cannot include an else clause when using an edge expression as the if or elsif condition:

```
if X > 5 then
   sequential_statement;
elsif edge then
   sequential_statement;
else
   sequential_statement;
end if;
```

 An edge expression cannot be part of another logical expression or be used as an argument.

The following function call is invalid, because you cannot use the edge expression as an argument:

```
any_function(edge);
```

• If you are using only wait statements for sequential inferencing, only one wait statement is allowed in a process. Coding styles using multiple wait statements, such as FSMs using multiple wait statements, are not supported. The tool generates the following error message if you use multiple wait statements in a process:

```
HDLC does not support processes with multiple event statements. (ELAB-336)
```

# **Unloaded Sequential Cell Preservation**

HDL Compiler does not automatically keep unloaded or undriven flip-flops or latches in a design. These cells are determined to be unnecessary and are removed during optimization. You can use the hdlin\_preserve\_sequential variable to control which cells to preserve:

- To preserve unloaded/undriven flip-flops and latches in your GTECH netlist, set hdlin\_preserve\_sequential to all.
- To preserve all unloaded flip-flops only, set hdlin\_preserve\_sequential to ff.
- To preserve all unloaded latches only, set hdlin\_preserve\_sequential to latch.
- To preserve all unloaded sequential cells, including unloaded sequential cells that are used solely as loop variables, set hdlin\_preserve\_sequential to all+loop variables.
- To preserve flip-flop cells only, including unloaded sequential cells that are used solely as loop variables, set hdlin\_preserve\_sequential to ff+loop\_variables.
- To preserve unloaded latch cells only, including unloaded sequential cells that are used solely as loop variables, set hdlin\_preserve\_sequential to latch+loop\_variables.

Example 4-51 and Example 4-52 indicate which components are saved when hdlin\_preserve\_sequential is set to all (the default is none). For more details about hdlin\_preserve\_sequential, see the man page.

### Important:

To preserve unloaded cells through compile, you also need to set compile\_delete\_unloaded\_sequential\_cells to false (the default is true); otherwise, Design Compiler will optimize them away.

Example 4-51 has hdlin\_preserve\_sequential set to all to save the unloaded cell sum2 and the combinational logic preceding it; note that the combinational logic after it is not saved. If you also want to save the combinational logic after sum2, you need to recode the design as shown in Example 4-52.

### Example 4-51 Preserves an Unloaded Cell (sum2) and Two Adders

```
signal save : std_logic_vector(1 downto 0);
begin
process (clk) begin
  if (clk'event and clk = '1') then
    sum1 <= in1 + in2;
    sum2 <= in1 + in2 + in3; -- sum2 reg is saved
  end if;
end process;

out_z <= not sum1;
end rtl;</pre>
```

Example 4-52 preserves the sum2 register and all combinational logic before it.

### Example 4-52 Preserves an Unloaded Cell (save) and Three Adders

```
set hdlin_preserve_sequential = all
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity seq_cell_ex3 is
 port(
      clk
                   : in std_logic);
end seq_cell_ex3;
architecture rtl of seq_cell_ex3 is
signal sum1, sum2 : std_logic_vector(1 downto 0);
signal save : std_logic_vector(1 downto 0);
begin
process (clk) begin
 if (clk'event and clk = '1') then
   sum1 <= in1 + in2;
   sum2 <= in1 + in2 + in3; -- this combinational logic</pre>
                            -- is saved
 end if;
end process;
out_z <= not sum1;</pre>
```

```
process (clk) begin
  if (clk'event and clk = '1') then
    save <= sum1 + sum2; -- this combinational logic is saved
  end if;
end process;
end rtl;</pre>
```

By default, the hdlin\_preserve\_sequential variable does not preserve variables used in for loops as unloaded registers. To preserve these variables, you must set the hdlin preserve sequential variable to ff+loop variables.

#### Note:

The tool does not distinguish between unloaded cells (those not connected to any output port) and feedthroughs. See Example 4-53 for an example of a feedthrough.

### Example 4-53 Feedthrough Example

```
entity regl is
 port (
    d0, clk: in bit;
    q0: out bit);
end entity regl;
architecture behave of regl is
begin -- behave
  storage: process (clk)
    variable temp1, temp2 : bit;
        if clk'event and clk = '1' then
          temp1 := d0;
          temp2 := temp1;
        end if;
        q0 <= temp2;
      end process storage;
end behave;
```

With hdlin\_preserve\_sequential set to ff, HDL Compiler builds two registers: one for the feedthrough cell temp1 and the other for the loaded cell temp2, as shown in the following memory inference report:

### Example 4-54 Feedthrough Register temp1

Register Name	======================================		Width		==== Bus		==== MB ====		==== AR		AS		SR		SS		==== ST	=
temp1_reg temp2_reg	Flip-flop   Flip-flop		1 1		N N	- !		- !	N N			- :	N N		N N		N N	

# 5

# Inferring Three-State Logic

HDL Compiler infers a three-state buffer when you assign the value of Z to a signal or variable. The Z value represents the high-impedance state. HDL Compiler infers one three-state buffer per process. You can assign high-impedance values to single-bit or bused signals (or variables). HDL Compiler does not provide any variables, attributes, or directives to control the inference.

This chapter includes the following sections:

- Three-State Driver Inference Report
- Inferring a Basic Three-State Driver
- Inferring One Three-State Buffer From a Single Process
- Inferring Two Three-State Buffers
- Three-State Buffer With Registered Enable
- Three-State Buffer With Registered Data
- Understanding the Limitations of Three-State Inference

# **Three-State Driver Inference Report**

The hdlin\_reporting\_level variable determines whether HDL Compiler generates a three-state inference report. If you do not want inference reports, set the hdlin\_reporting\_level variable to none. The default is basic, meaning that a report will be generated. Example 5-1 shows a three-state inference report:

### Example 5-1 Three-State Inference Report

The first column of the report indicates the name of the inferred three-state device. The second column indicates the type of inferred device. The third column indicates the width of the inferred device. HDL Compiler generates the same report for the default and verbose reports for three-state inference. For more information about the hdlin\_reporting\_level variable, see "Customizing Elaboration Reports" on page 1-8.

# Inferring a Basic Three-State Driver

Example 5-2 provides the VHDL template for a basic three-state buffer. HDL Compiler generates the inference report shown in Example 5-3. Figure 5-1 shows the compiled output.

### Example 5-2 Basic Three-State Buffer

```
library IEEE, synopsys;
use IEEE.std_logic_1164.all;
entity three_state_basic is
port(IN1, ENABLE : in std_logic;
        OUT1 : out std_logic );
end;


architecture rtl of three_state_basic is
begin

process (IN1, ENABLE) begin
  if (ENABLE = '1') then
    OUT1 <= IN1;
  else
    OUT1 <= 'Z'; -- assigns high-impedance state
  end if;
end process;
end rtl;</pre>
```

Example 5-3 Inference Report for a Basic Three-State Buffer

Register Name	==========	===========	=======
OUT1_tri   Tri-State Buffer   1	Register Name	Туре	Width
	OUT1_tri	Tri-State Buffer	1

Figure 5-1 A Basic Three-State Buffer



# Inferring One Three-State Buffer From a Single Process

Example 5-4 provides an example of placing all high-impedance assignments in a single process. In this case, the data is gated and HDL Compiler infers a single three-state buffer. Example 5-5 shows the inference report.

### Example 5-4 Inferring One Three-State Buffer From a Single Process

```
library IEEE;
use IEEE.std logic 1164.all;
entity three_state is
 port ( A, B, SELA, SELB : in std_logic ;
         T : out std_logic );
end three_state;
architecture rtl of three_state is
begin
infer : process (SELA, A, SELB, B) begin
  T <= 'Z';
  if (SELA = '1') then
    T <= A;
  elsif (SELB = '1') then
    T <= B;
  end if;
end process infer;
end rtl;
```

### Example 5-5 Single Process Inference Report

Register Name	Type	======   Width	=
T_tri	Tri-State Buffer	1	_

# **Inferring Two Three-State Buffers**

Example 5-6 provides an example of placing each high-impedance assignment in a separate process. In this case, HDL Compiler infers multiple three-state buffers. Example 5-7 shows the inference report. Figure 5-2 shows the design.


### Example 5-6 Inferring Two Three-State Buffers

```
library IEEE;
use IEEE.std_logic_1164.all;
entity three_state is
 port ( A, B, SELA, SELB : in std_logic ;
        T : out std_logic );
end three_state;
architecture rtl of three state is
infer1 : process (SELA, A) begin
  if (SELA = '1') then
   T <= A;
  else
    T <= 'Z';
  end if;
end process infer1;
infer2 : process (SELB, B) begin
  if (SELB = '1') then
   T <= B;
  else
   T <= 'Z';
  end if;
end process infer2;
end rtl;
```

Example 5-7 Inference Report for Two Three-State Buffers

Register	Name	Type	Width
T_tri		Tri-State Buffer	1
Register	Name	Туре	Width
T_tri2		Tri-State Buffer	1 1
========	======		=======

Figure 5-2 Two Three-State Buffers



# **Three-State Buffer With Registered Enable**

When a variable, such as THREE\_STATE in Example 5-8, is assigned to a register and defined as a three-state buffer within the same process, HDL Compiler also registers the enable pin of the three-state gate. Example 5-8 shows an example of this type of code, and Example 5-9 shows the inference report. Figure 5-3 shows the schematic generated by the code, a three-state buffer with a register on its enable pin.

### Example 5-8 Inferring a Three-State Buffer With Registered Enable

```
library IEEE;
use IEEE.std_logic_1164.all;
entity three_state is
   port ( DATA, CLK, THREE_STATE : in std_logic ;
          OUT1 : out std_logic );
end three_state;
architecture rtl of three_state is
begin
infer : process (THREE_STATE, CLK) begin
   if (THREE_STATE = '0') then
      OUT1 <= 'Z';
   elsif (CLK' event and CLK = '1') then
     OUT1 <= DATA;
   end if;
end process infer;
end rtl;
```

### Example 5-9 Inference Report for a Three-State Buffer With Registered Enable

Register Name	======= Type 	======================================	======   Bus	=====   AR	=====   AS	=====   SR	=====   SS	=====   ST	=   
OUT1_reg   OUT1_tri_enable_reg	Flip-flop Flip-flop	1   1	:	N   N	:	:	N   N	:	   




Figure 5-3 Three-State Buffer With Registered Enable

# **Three-State Buffer With Registered Data**

Example 5-10 uses two processes to instantiate a three-state buffer, with a flip-flop on the input pin. Example 5-11 shows the inference report. Figure 5-4 shows the schematic generated by the code.

### Example 5-10 Three-State Buffer With Registered Data


```
TEMP <= DATA;
end if;
end process;

process (THREE_STATE, TEMP) begin
  if (THREE_STATE = '0') then
    OUT1 <= 'Z';
  else
    OUT1 <= TEMP;
  end if;
end process;
end rtl;</pre>
```

Example 5-11 Inference Report for a Three-State Buffer With Registered Data

Register Name	Type	   	Width	= =    -	Bus		AR		AS		SR		SS		ST	
TEMP_reg	Flip-flop	Ī	1	 	N	Ī	N	Ī	N	Ī	N	Ī	N		N	_
				==	-===		====		====		====	==:	====	==:	====	:=
Register Name	Type	_ [	Width													
OUT1_tri   Tri-	State Buffer		1		_ 											

Figure 5-4 Three-State Buffer With Registered Data



# **Understanding the Limitations of Three-State Inference**

You can use the Z value as

- A signal assignment
- A variable assignment
- A function call argument
- A return value
- An aggregate definition

You cannot use the  ${\tt z}$  value in an expression, except for concatenation and comparison with  ${\tt z}$ , such as in

```
if (IN_VAL = 'Z') then y<=0 endif;
```

This is an example of permissible use of the  ${\tt z}$  value in an expression, but it always evaluates to false. Therefore, it is also a simulation and synthesis mismatch.

### This code

```
OUT_VAL <= ('Z' and IN_VAL);
```

is an example of an incorrect use of the z value in an expression. It is incorrect because it is not a comparison expression. This code generates an error because HDL Compiler cannot compute any expressions that use 'Z' as an input.

Be careful when using expressions that compare with the  ${\rm z}$  value. Design Compiler always evaluates these expressions to false, and the pre-synthesis and post-synthesis simulation results might differ. For this reason, HDL Compiler issues a warning when it synthesizes such comparisons.

# 6

# Directives, Attributes, and Variables

This chapter describes the compiler directives, attributes, and HDL read variables supported by HDL Compiler in the following sections:

- Compiler Directives
- Attributes
- Variables

# **Compiler Directives**

HDL Compiler synthesis directives are special comments that affect the actions of the Synopsys HDL Compiler and Design Compiler tools. These comments are ignored by other VHDL tools.

These directives begin as a VHDL comment (--) followed by a *pragma* prefix (pragma, synopsys, or synthesis) and then the directive. Whitespace is permitted (but not required) before and after the two hyphens.

#### Note:

Not all directives support all pragma prefixes; see "Directive Support by Pragma Prefix" on page 6-7 for details.

The following topics describe the supported directives:

- keep\_signal\_name
- template
- translate\_off and translate\_on
- · resolution method
- rp\_group and rp\_endgroup
- rp place
- rp fill
- rp\_array\_dir
- map\_to\_entity and return\_port\_name
- dc\_tcl\_script\_begin and dc\_tcl\_script\_end
- Directive Support by Pragma Prefix

# keep\_signal\_name

You can give HDL Compiler guideline information for keeping a signal name by using the hdlin\_keep\_signal\_name variable (default is all\_driving) and the keep\_signal\_name directive. For details, see "Keeping Signal Names" on page 2-41.

### template

The template directive is used to read a design with a generic given that the generic default is specified. For more information, see "Parameterized Models (Generics)" on page 1-16.

### translate\_off and translate\_on

The code contained within these directives is ignored and treated as comments.

### resolution\_method

Resolution directives determine the resolution function associated with resolved signals. HDL Compiler does not support arbitrary resolution functions. It only supports the following three resolution methods:

```
-- synopsys resolution_method wired_and
-- synopsys resolution_method wired_or
-- synopsys resolution_method three_state
```

For more information, see "Resolution Functions" on page 2-42.

### rp\_group and rp\_endgroup

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

The rp\_group and rp\_endgroup directives allow you to specify a relative placement group. All cell instances declared between the rp\_group and rp\_endgroup directives are members of the specified group. These directives are available for RTL designs and netlist designs.

The VHDL syntax for RTL and netlist designs is as follows:

```
-- synopsys rp_group ( group_name {num_cols num_rows} )
-- synopsys rp_endgroup ( {group_name} )
```

For more information and an example, see "Creating Groups Using rp\_group and rp\_endgroup" on page 2-3.

### rp\_place

The rp\_place directive allows you to specify a subgroup at a specific hierarchy, a keepout region, or an instance to be placed in the current relative placement group. When you use the rp\_place directive to specify a subgroup at a specific hierarchy, you must instantiate the subgroup's instances outside of any group declarations in the module. This directive is available for RTL designs and netlist designs.

The VHDL syntax for RTL and netlist designs is as follows:

```
-- synopsys rp_place ( hier group_name col row )
-- synopsys rp_place ( keep keepout_name col row width height )
-- synopsys rp_place ({leaf} [inst_name] col row )
```

For more information and an example, see "Specifying Subgroups, Keepouts, and Instances Using rp\_place" on page 2-4.

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

### rp\_fill

The  $rp_fill$  directive automatically places the cells at the location specified by a pointer. Each time a new instance is declared that is not explicitly placed, it is inserted into the grid at the location indicated by the current value of the pointer. After the instance is placed, the pointer is updated incrementally and the process is ready to be repeated. This directive is available for RTL designs and netlist designs.

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

The  $rp_fill$  arguments define how the pointer is updated. The col and row parameters specify the initial coordinates of the pointer. These parameters can represent absolute row or column locations in the group's grid or locations that are relative to the current pointer value. To represent locations relative to the current pointer, enclose the column and row values in angle brackets (<>). For example, assume the current pointer location is (3,4). In this case, specifying  $rp_fill$  <1> 0 initializes the pointer to (4,0) and that is where the next instance is placed. Absolute coordinates must be nonnegative integers; relative coordinates can be any integer.

The VHDL syntax for RTL designs is as follows:

```
-- synopsys rp_fill ( {col row} {pattern pat} )
```

For more information, see "Placing Cells Automatically Using rp\_fill" on page 2-5.

### rp\_array\_dir

The rp\_array\_dir directive specifies whether the elements of an array are placed upward, from the least significant bit to the most significant bit, or downward, from the most significant bit to the least significant bit.

The VHDL syntax for RTL designs is as follows:

```
-- synopsys rp_array_dir ( up|down )
```

For more information and an example, see "Specifying Placement for Array Elements Using rp\_array\_dir" on page 2-6.

Note:

HDL Compiler for VHDL supports relative placement directives for RTL designs only.

### map\_to\_entity and return\_port\_name

Component implication directives map VHDL subprograms onto existing components or VHDL entities.

Synopsys supports the following component implication directives:

```
-- synopsys map_to_entity entity_name
-- synopsys return_port_name port_name
```

For more information, see "Procedures and Functions as Design Components" on page 2-14. Other directives, such as map\_to\_operator, are used to drive inference of HDL operators such as \*, +, and -. See the *DesignWare Developer Guide* for more information about synthetic comments.

# dc\_tcl\_script\_begin and dc\_tcl\_script\_end

You can embed Tcl commands that set design constraints and attributes within the RTL by using the dc\_tcl\_script\_begin and dc\_tcl\_script\_end directives, as shown in Example 6-1.

Example 6-1 Using the dc tcl script begin and dc tcl script end Directives

```
-- synopsys dc_tcl_script_begin

-- set_max_area 0.0

-- set_drive -rise 1 port_b

-- set_max_delay 0.0 port_z

-- synopsys dc_tcl_script_end
```

Design Compiler interprets the statements embedded between the dc\_tcl\_script\_begin and the dc\_tcl\_script\_end directives. If you want to comment out part of your script, use the # comment character.

The following items are not supported in embedded Tcl scripts:

- Hierarchical constraints
- Wildcards
- List commands
- Multiple-line commands

Following are guidelines for using embedded Tcl scripts:

- You cannot embed Tcl scripts outside an entity or architecture; they must be embedded inside an entity or architecture.
- Constraints and attributes declared inside an entity or architecture apply only to the enclosing entity or architecture.
- Any dc\_shell scripts embedded in functions apply to the whole module.
- Include only commands that set constraints and attributes. Do not use action commands such as compile, gen, and report. The tool ignores these commands and issues a warning or error.
- The constraints or attributes set in the embedded script go into effect after the read command is executed. Therefore, variables that affect the read process itself are not in effect before the read.
- Design Compiler performs error checking after the read command finishes. Syntactic and semantic errors in dc shell strings are reported at this time.
- You can have more than one dc\_tcl\_script\_begin / dc\_tcl\_script\_end pair per file or entity/architecture. The compiler does not issue an error or warning when it sees more than one pair. Each pair is evaluated and set on the applicable code.
- An embedded dc\_shell script does not produce any information or status messages unless there is an error in the script.
- If you use embedded Tcl scripts while running in dcsh mode, Design Compiler issues the following error message:
  - Error: Design 'MID' has embedded Tcl commands which are ignored in EQN mode. (UIO-162)
- Usage of built-in Tcl commands is not recommended.
- Usage of output redirection commands is not recommended.

# **Directive Support by Pragma Prefix**

Not all pragma prefixes support all directives:

- The synopsys prefix is intended for directives specific to HDL Compiler. The tool issues an error message if an unknown directive is encountered.
- The pragma and synthesis prefixes are intended for industry-standard directives. The tool ignores any unsupported directives to allow for directives intended for other tools. Directives specific to HDL Compiler are not supported.

Table 6-1 shows how each directive is handled by each pragma prefix.

Table 6-1 Directive Support by Pragma Prefix

Directive	synopsys	pragma	synthesis
translate_off translate_on	Used	Used	Used
<pre>dc_tcl_script_begin dc_tcl_script_end</pre>	Used	Used	Used
<pre>dc_script_begin dc_script_end</pre>			
keep_signal_name	Used	Ignored	Ignored
template	Used	Ignored	Ignored
resolution_method	Used	Ignored	Ignored
rp_group rp_endgroup	Used	Ignored	Ignored
rp_place			
rp_fill			
rp_array_dir			
<pre>map_to_entity return_port_name</pre>	Used	Ignored	Ignored
Any unknown directive	Error	Ignored	Ignored

## **Attributes**

This section describes the following:

- Synopsys Defined Attributes
- IEEE Predefined Attributes

# **Synopsys Defined Attributes**

The Synopsys defined attributes are listed in Table 6-2. When you use these attributes, insert the following line in your VHDL description, just before the entity declaration.

```
use SYNOPSYS.ATTRIBUTES.all;
```

These attributes are included in the ATTRIBUTES package.

Table 6-2 Attributes Supported by HDL Compiler

Attribute	Description
arrival	See Table 6-3 on page 6-10.
async_set_reset	See Table 4-2 on page 4-6.
async_set_reset_local	See Table 4-2 on page 4-6.
async_set_reset_local_all	See Table 4-2 on page 4-6.
dont_touch	See Table 6-3 on page 6-10.
dont_touch_network	See Table 6-3 on page 6-10.
drive_strength	See Table 6-3 on page 6-10.
enum_encoding	See "Synopsys Defined Attributes" on page 6-8.
equal	See Table 6-3 on page 6-10.
fall_arrival	See Table 6-3 on page 6-10.
fall_drive	See Table 6-3 on page 6-10.
infer_multibit	See "Multibit Inference" on page 2-47.
infer_mux	See "MUX_OP Inference" on page 3-9.

Table 6-2 Attributes Supported by HDL Compiler (Continued)

Attribute	Description
load	See Table 6-3 on page 6-10.
logic_one	See Table 6-3 on page 6-10.
logic_zero	See Table 6-3 on page 6-10.
max_area	See Table 6-3 on page 6-10.
max_delay	See Table 6-3 on page 6-10.
max_fall_delay	See Table 6-3 on page 6-10.
max_rise_delay	See Table 6-3 on page 6-10.
max_transition	See Table 6-3 on page 6-10.
min_delay	See Table 6-3 on page 6-10.
min_fall_delay	See Table 6-3 on page 6-10.
min_rise_delay	See Table 6-3 on page 6-10.
one_cold	See Table 4-2 on page 4-6.
one_hot	See Table 4-2 on page 4-6.
opposite	See Table 6-3 on page 6-10.
rise_arrival	See Table 6-3 on page 6-10.
rise_drive	See Table 6-3 on page 6-10.
sync_set_reset	See Table 4-2 on page 4-6.
sync_set_reset_local	See Table 4-2 on page 4-6.
sync_set_reset_local_all	See Table 4-2 on page 4-6.
unconnected	See "Synopsys Defined Attributes" on page 6-8.

The design attributes are described in Table 6-3.

Table 6-3 Design Attributes

Attribute	Туре	Description
Input port Attributes		
MAX_AREA	real	Maximum desired area, in logic library area units. attribute MAX_AREA of EXAMPLE : entity is 500.0;
MAX_TRANSITION	real	Maximum allowable transition time for any network in the design, in logic library time units. attribute MAX_TRANSITION of EXAMPLE : entity is 3.0;
ARRIVAL	real	Expected signal arrival time, in technology library time units. Sets both RISE_ARRIVAL and FALL_ARRIVAL. attribute ARRIVAL of A: signal is 1.5;
DRIVE_STRENGTH	real	Input signal's drive strength, in technology library load units. Sets both RISE_DRIVE and FALL_DRIVE. attribute DRIVE_STRENGTH of A, B: signal is 0.01;
RISE_ARRIVAL	real	Input signal's rise time. attribute RISE_ARRIVAL of C : signal is 1.5;
FALL_ARRIVAL	real	Input signal's fall time. attribute FALL_ARRIVAL of A, B : signal is 1.5;
FALL_DRIVE	real	Input signal's drive strength while falling. attribute FALL_DRIVE of B : signal is 0.01;
RISE_DRIVE	real	Input signal's drive strength while rising. attribute RISE_DRIVE of A : signal is 0.01;

Table 6-3 Design Attributes (Continued)

Attribute	Туре	Description
EQUAL	Boolean	Applied to pairs of input ports; true
		if both ports are logically equal.
		attribute EQUAL of A, B: signal is TRUE;
		The attributes EQUAL and OPPOSITE are used only for pairs of single-bit ports (signals).
OPPOSITE	Boolean	Applied to pairs of input ports; true
		if the two ports are logically opposite.
		attribute OPPOSITE of A, B: signal is TRUE;
LOGIC_ONE	Boolean	True if the input port is always at logic 1.
		attribute LOGIC_ONE of A : signal is TRUE;
LOGIC_ZERO	Boolean	True if the input port is always at logic 0
		attribute LOGIC_ZERO of A, B: signal is TRUE;
DONT_TOUCH_NETWORK	Boolean	True if the network connected to the input
		port is to be excluded from optimization
		attribute DONT_TOUCH_NETWORK of A : signal is TRUE;
Output Port Attributes		
LOAD	real	Loading on output port, in library load units.
		attribute LOAD of Y, Z : signal is 5.0;
UNCONNECTED	Boolean	Can be set to true if the output port is not
		connected to external circuitry.
		attribute UNCONNECTED of X : signal is TRUE;
MIN_RISE_DELAY	real	Minimum allowable delay time before
		the output port's signal rises.attribute MIN_RISE_DELAY of X : signal is 5.0;
MIN_FALL_DELAY	real	Minimum allowable delay time before
		the output port's signal falls.
		attribute MIN_FALL_DELAY of Y: signal is 5.0;

Table 6-3 Design Attributes (Continued)

Attribute	Туре	Description
MAX_DELAY	real	Maximum allowable delay time, from any input signal connected to the output port, in logic library time units Sets both MAX_RISE_DELAY and MAX_FALL_DELAY. attribute MAX_DELAY of X : signal is 20.0;
MAX_RISE_DELAY	real	Maximum allowable delay time before the output port's signal rises. attribute MAX_RISE_DELAY of Z : signal is 20.0;
MAX_FALL_DELAY	real	Maximum allowable delay time before the output port's signal falls. attribute MAX_FALL_DELAY of X, Y: signal is 20.0;
MIN_DELAY	real	Minimum allowable delay time, from any input signal connected to the output port, in logic library time units Sets both MIN_RISE_DELAY and MIN_FALL_DELAY attribute MIN_DELAY of X, Z : signal is 5.0;
Cell attributes		
DONT_TOUCH	Boolean	True if the instance is not to be optimized. attribute DONT_TOUCH of INSTANCE: label is TRUE; A dont_touch attribute cannot be set to false.

### **ENUM\_ENCODING Attribute**

You can override the automatic enumeration encodings and specify your own enumeration encodings with the <code>ENUM\_ENCODING</code> attribute. This interpretation is specific to HDL Compiler. This attribute allows HDL Compiler to interpret your logic correctly. Place the synthesis attribute <code>ENUM\_ENCODING</code> on your primary logic type.

The ENUM\_ENCODING attribute must be a string containing a series of vectors, one for each enumeration literal in the associated type. The encoding vector is specified by '0's, '1's, 'D's, 'U's, and 'Z's, separated by blank spaces.

The possible encoding values for the ENUM\_ENCODING attribute are '0', '1', 'D', 'U', and 'Z' and are described in Table 6-4.

Table 6-4 Encoding Values for the ENUM\_ENCODING Attribute

Encoding value	Description
'0'	Bit value '0'.
'1'	Bit value '1'.
'D'	Don't care (can be either '0' or '1').
'U'	Unknown. If 'U' appears in the encoding vector for an enumeration, you cannot use that enumeration literal except as an operand to the = and /= operators. You can read an enumeration literal encoded with a 'U' from a variable or signal, but you cannot assign it.
	For synthesis, the = operator returns false and /= returns true when either of the operands is an enumeration literal whose encoding contains 'U'.
'Z'	High impedance.

The first vector in the attribute string specifies the encoding for the first enumeration literal, the second vector specifies the encoding for the second enumeration literal, and so on. The ENUM ENCODING attribute must immediately follow the type declaration.

Example 6-2 illustrates how the default encodings from Example 2-22 on page 2-25 can be changed with the ENUM\_ENCODING attribute.

### Example 6-2 Using the ENUM\_ENCODING Attribute

```
attribute ENUM_ENCODING: STRING;
   -- Attribute definition

type COLOR is (RED, GREEN, YELLOW, BLUE, VIOLET);
attribute ENUM_ENCODING of
   COLOR: type is "010 000 011 100 001";
   -- Attribute declaration
```

The enumeration values are encoded as follows:

```
RED = "010"
GREEN = "000"
YELLOW = "011"
BLUE = "100"
VIOLET = "001"
```

The result is GREEN < VIOLET < RED < YELLOW < BLUE.

### Note:

The interpretation of the ENUM\_ENCODING attribute is specific to HDL Compiler. Other VHDL tools, such as simulators, use the standard encoding (ordering).

### **IEEE Predefined Attributes**

See "Names" on page C-6 for the IEEE predefined attributes supported by HDL Compiler.

## **Variables**

HDL Compiler read variables are described in Table 6-5.

Table 6-5 Variables

Name	Default	Description	
hdlin_elab_errors_deep	false	Allows the elaboration of submodules even if the top-level module elaboration fails, enabling HDL Compiler to report more elaboration, link, and VER-37 errors and warnings in a hierarchical design during the first elaboration run. See "Reporting Elaboration Errors" on page 1-10.	
hdlin_enable_configurations	False	Enables configuration support.	
hdlin_generate_separator_style	-	Specifies the separator string for instances generated in multiple-nested loops. This is a VHDL only supported variable. Verilog generate naming follows the Verilog LRM standard, so this variable is not required.	
hdlin_infer_enumerated_types	False	Infers enumerated types.	
hdlin_infer_function_local_latches	False	Allows latches to be inferred for functionand procedure-scope variables.	
hdlin_keep_signal_name	all_driving	Attempts to keep a signal name if there is path from the signal to an output port. This includes preserving cells between the signal and the output port.	

Table 6-5 Variables (Continued)

Name	Default	Description
hdlin_mux_oversize_ratio	100	Defined as the ratio of the number of MUX inputs to the unique number of data inputs. When this ratio is exceeded, a MUX will not be inferred and the circuit will be generated with SELECT_OPs.
hdlin_mux_size_min	2	Sets the minimum number of data inputs for MUX inference.
hdlin_mux_size_only	1	Controls which MUX_OP cells receive the size_only attribute. By default, MUX_OP cells that are generated with the RTL infer_mux compiler directive and that are on set/reset signals receive the size_only attribute. For more information and a complete list of options, see Table 3-2 on page 3-12.
hdlin_no_sequential_mapping	false	Prevents sequential mapping.
hdlin_one_hot_one_cold_on	true	Optimizes according to one_hot and one_cold attributes.
hdlin_optimize_array_references	true	Optimizes constant offsets in array references.
hdlin_optimize_enum_types	false	Simplifies comparisons based on enumerated type information.

Table 6-5 Variables (Continued)

Name	Default	Description
hdlin_preserve_sequential	none	Preserves unloaded sequential cells (latches or flip-flops) that would otherwise be removed during optimization by HDL Compiler. The following options are supported:
		<ul> <li>none or false-No unloaded sequential cells are preserved. This is the default behavior.</li> </ul>
		<ul> <li>all or true-All unloaded sequential cells are preserved, excluding unloaded sequential cells that are used solely as loop variables.</li> </ul>
		<ul> <li>all+loop_variables or true+loop_variables—All unloaded sequential cells are preserved, including unloaded sequential cells that are used solely as loop variables.</li> </ul>
		<ul> <li>ff-Only flip-flop cells are preserved, excluding unloaded sequential cells that are used solely as loop variables.</li> </ul>
		<ul> <li>ff+loop_variables-Only flip-flop cells are preserved, including unloaded sequential cells that are used solely as loop variables.</li> </ul>
		<ul> <li>latch-Only unloaded latch cells are preserved, excluding unloaded sequential cells that are used solely as loop variables.</li> </ul>
		<ul> <li>latch+loop_variables—Only unloaded latch cells are preserved, including unloaded sequential cells that are used solely as loop variables.</li> </ul>
		Important: To preserve unloaded cells through compile, you must set
		compile_delete_unloaded_sequential_cells to false.
		See "Unloaded Sequential Cell Preservation" on page 4-38.
hdlin_prohibit_nontri_multiple_drivers	true	Issues an error when a non-tri net is driven by more than one process or continuous assignment.

Table 6-5 Variables (Continued)

Name	Default	Description	
hdlin_support_subprogram_var_init	true	Controls whether or not HDL Compiler honors the initial value given to a variable. When this variable is set to false, the default, HDL Compiler issues a warning that the initial value given to a variable is ignored.	
hdlin_vhdl_std	2008	Specifies the VHDL standard to enforce: 1987, 1993, or 2008.	
hdlin_vhdl_syntax_extensions	false	<ul> <li>Enables the following features:</li> <li>Deferred constant definition</li> <li>Arrays of base type Boolean</li> <li>Impure functions</li> <li>When you use these constructs, make sure you perform a thorough verification.</li> </ul>	

# 7

# Writing Out Designs in VHDL Format

While using Design Compiler, you can write out any design in a variety of formats, including VHDL. Existing gate-level netlists, sets of logic equations, or technology-specific circuits can be automatically converted to a VHDL description. The resulting VHDL description can serve as documentation of the original design, and you can use it as a starting point for reimplementation in a new technology. In addition, you can give the VHDL description to a VHDL simulator to provide circuit timing information.

The following sections discuss how to write out designs in VHDL format.

- Netlist Writer Variables
- Writing Out VHDL Files
- VHDL Write Variables
- Bit and Bit-Vector Variables
- Resolution Function Variables
- Types and Type Conversion Variables
- Architecture and Configuration Variables
- Preserving Port Types
- VHDL Netlister Coding Considerations

### **Netlist Writer Variables**

The netlist writer variables discussed in this chapter are listed in Table 7-1.

Table 7-1 Variable Summary

Group	Attributes/Directives/Variables
Write variables	<pre>vhdlout_dont_create_dummy_nets, vhdlout_equations, vhdlout_follow_vector_direction, vhdlout_separate_scan_in vhdlout_local_attributes, vhdlout_upcase, vhdlout_use_packages, vhdlout_write_architecture, vhdlout_write_components, vhdlout_write_entity, vhdlout_write_top_configuration</pre>
Bit and bit-vector variables	<pre>vhdlout_three_state_name, vhdlout_unknown_name, vhdlout_zero_name, vhdlout_bit_type, vhdlout_bit_vector_type, vhdlout_one_name</pre>
Resolution function variables	<pre>vhdlout_three_state_res_func, vhdlout_wired_and_res_func, vhdlout_wired_or_res_func</pre>
Types and type conversion variables	<pre>vhdlout_package_naming_style, vhdlout_preserve_hierarchical_types, vhdlout_single_bit</pre>
Architecture and configuration variables	<pre>vhdlout_top_configuration_arch_name, vhdlout_top_configuration_entity_name, vhdlout_top_configuration_name</pre>

# **Writing Out VHDL Files**

To write out VHDL design files, use the write command.

```
dc_shell> write -format vhdl -output my_file.vhdl
```

The write -format vhdl command is valid whether or not the current design originated as a VHDL source file. You can write out any design, regardless of initial format (equation, netlist, and so on), as a VHDL design.

For more information about the write command, see Using Tcl With Synopsys Tools.

#### **VHDL Write Variables**

Several dc\_shell variables affect how designs are written out as VHDL files. These variables must be set before you write out the design. They can be set interactively or in your .synopsys dc.setup file.

The following variables affect writing out VHDL (vhdlout variables). To list them, enter

```
dc_shell> man vhdlio_variables
```

```
vhdlout_dont_create_dummy_nets
```

Controls whether the VHDL writer creates dummy nets for connecting unused pins or ports.

By default, this variable is set to false and the VHDL writer creates dummy nets.

Set this variable to true to disable dummy net creation.

```
vhdlout_equations
```

When set to true, this variable determines that combinational logic is written with technology-independent Boolean equations, sequential logic is written with technology-independent wait and if statements, and three-state drivers are written with technology-independent code.

By default, this variable is set to false and all mapped logic is written with technology-specific netlists.

Set this variable to true to force the VHDL writer to write technology-independent logic.

```
vhdlout_follow_vector_direction
```

Controls how the VHDL writer determines the array range direction.

By default, this variable is false and the VHDL writer uses ascending array range values, regardless of the original array range direction.

Set this variable to true to force the VHDL writer to determine the array range direction from the original design.

```
vhdlout local attributes
```

This variable is obsolete. Use the write\_script command instead (see the write\_script man page).

```
vhdlout_separate_scan_in
```

Controls how the scan chain is written out in VHDL.

By default, this variable is false and the VHDL writer writes the scan chain in the same file as the design. In this case, the scan chain is not visible in the testbench and parallel-load simulation is not possible.

Set this variable to true to force the VHDL writer to write the scan chain as a separate package to enable parallel-load simulation.

```
vhdlout_upcase
```

Determines, when set to true, that identifiers are written out in uppercase to the VHDL file.

When this variable is set to false, identifiers are written out with their Design Compiler names. The default is false.

```
vhdlout_use_packages
```

This variable is a list of package names. A use clause is written into the VHDL file for each of these packages for all entities; library clauses are also written out as needed.

If this variable is not set or is set to an empty list ({ }), it has no effect on the write command.

To use packages from specific libraries, you can prefix the library to the package name. For example,

#### becomes

```
use IEEE.std_logic_1164.all;
use IEEE.std_logic_arith.all;
use VENDOR.PARTS.FFD;

vhdlout write architecture
```

When this variable is set to true (the default), an architecture definition is written out to the VHDL file.

```
vhdlout_write_components
```

This variable controls whether component declarations for cells mapped to a logic library are written out (if set to true) or not (false).

Component declarations are required by VHDL. If you set this variable to false, make sure a package containing the necessary component declarations is listed in vhdlout use packages.

The default is true. See also the <code>vhdlout\_use\_packages</code> variable.

```
vhdlout_write_entity
```

When this variable is set to true (the default), an entity definition is written out to the VHDL file and to any conversion packages as necessary.

```
vhdlout_write_top_configuration
```

When this variable is set to true, a top-level configuration definition is written out to the VHDL file. The default is false.

#### **Bit and Bit-Vector Variables**

Bit and bit-vector variables, whose descriptions follow, define the names of bits, bit vectors, and the associated types.

```
vhdlout_bit_type
```

The name of the bit type used for writing out single-bit values, used with the following variables:

```
vhdlout_one_name
vhdlout_three_state_name
vhdlout_zero_name
vhdlout_bit_vector_type
```

The default is std\_logic. For example, a simulator uses a bit type of t\_logic, defined as

```
type t_logic is (U, D, Z, ..., F0, F1, ...);
```

and a bit vector type of t\_logic\_vector, defined as

```
type t_logic_vector is array (integer range <>) of
t_logic;
```

The following dc\_shell commands define the appropriate bit and bit vector types and values to write.

When writing a generic three-state model, Design Compiler displays an error if vhdlout\_bit\_type is set to its default value of a bit. Set vhdlout\_bit\_type to a bit type that includes a high-impedance value ('Z'). For more information about inferred three-state devices, see Chapter 5, "Inferring Three-State Logic."

```
vhdlout_bit_vector_type
```

The name of the bit vector type used for writing multiple-bit values, used with the vhdlout\_bit\_type, vhdlout\_one\_name, and vhdlout\_zero\_name variables.

The default is std\_logic\_vector. For an example, see the description of vhdlout\_bit\_type.

```
vhdlout_one_name
```

The name of the enumeration literal that represents a logic 1.

The default is '1'. For an example, see the description of vhdlout\_bit\_type.

```
vhdlout three state name
```

The name of the high-impedance bit value used for three-state device values.

The default is 'Z'.

```
vhdlout_unknown_name
```

The value used to drive a signal to the unknown state, usually a character literal or an enumeration name.

The default is 'X'.

```
vhdlout_zero_name
```

The name of the enumeration literal that represents a logic 0.

The default is '0'. For an example, see the description of vhdlout\_bit\_type.

#### **Resolution Function Variables**

The resolution function variables, whose descriptions follow, name resolution functions that are written out.

```
vhdlout_three_state_res_func
```

Names a three-state resolution function to use instead of the default function. You must supply this function in a package listed in vhdlout\_use\_packages.

If the variable is set to " " (the default), a resolution function is written out if needed.

```
vhdlout_wired_and_res_func
```

Names a wired AND resolution function to use instead of the default function. You must supply this function in a package listed in vhdlout\_use\_packages.

If the variable is set to " " (the default), a resolution function is written out if needed.

```
vhdlout_wired_or_res_func
```

Names a wired OR resolution function to use instead of the default. You must supply this function in a package listed in vhdlout\_use\_packages.

If the variable is set to " " (the default), a resolution function is written out if needed.

## **Types and Type Conversion Variables**

The following types and type conversion variables define type conversion functions and how the VHDL writer writes out types.

```
vhdlout_package_naming_style
```

This variable controls how packages of conversion functions are named. The default is "CONV\_PACK\_%d", where %d is a number that is incremented as necessary to produce a unique name. By default, the package name and the number are separated by underscores ( ).

```
vhdlout_preserve_hierarchical_types
```

This variable affects how ports on lower-level designs are written out. Top-level design ports are controlled by <code>vhdlout\_single\_bit</code>. (A design is considered lower-level if it is instantiated by any of the designs being written out.)

When this variable is set to USER, all ports on lower-level designs are written with their original data types. This option affects only designs that are read in VHDL format.

When set to VECTOR, all ports on lower-level designs are written with their ports bused; ports keep their names. These bused ports contrast to ports that are bit-blasted. Bit-blasting is the term for breaking down a bus to its individual bus members. The port types are defined by <code>vhdlout\_bit\_vector\_type</code> or by <code>vhdlout\_bit\_type</code>, in the case of single-bit ports. This setting is likely to give the most efficient description for simulation. The default is VECTOR. You must ensure that <code>vhdlout\_bit\_vector\_type</code> is an array type whose elements are of <code>vhdlout\_bit\_type</code>.

When this variable is set to BIT, typed ports are bit-blasted. If the type of a port is N bits wide, it is written to the VHDL file as N separate ports. Each port is given the type defined by <code>vhdlout\_bit\_type</code>. This variable has no effect if you set <code>vhdlout\_single\_bit to BIT</code>. <code>vhdlout\_preserve\_hierarchical\_types</code> is then ignored, and the whole design hierarchy is written out bit-blasted.

This variable cannot take on a higher value than the current setting of vhdlout\_single\_bit. The descending order is {USER, VECTOR, BIT}. Thus, the combination of vhdlout\_single\_bit set to VECTOR and vhdlout\_preserve\_hierarchical\_types set to USER is not possible.

```
vhdlout_single_bit
```

This variable affects how ports on the top-level design are written out. Lower-level design ports are controlled by <code>vhdlout\_preserve\_hierarchical\_types</code>. A design is considered lower-level if it is instantiated by any of the designs being written out.

When this variable is set to USER, all ports on the top-level design are written with their original data types. This option affects only designs that are read in VHDL format. The default is USER.

When this variable is set to VECTOR, all ports on the top-level design are written with their ports bused. Ports keep their names (in contrast to bit-blasted ports). Port types are defined by <code>vhdlout\_bit\_vector\_type</code> or by <code>vhdlout\_bit\_type</code>, in the case of single-bit ports. For buses, the range always starts with 0 and goes in ascending order, regardless of what the range definition was in the HDL source. Ensure that <code>vhdlout\_bit\_vector\_type</code> is an array type whose elements are of <code>vhdlout\_bit\_type</code>.

When this variable is set to BIT, typed ports are bit-blasted. If the type of a port is N bits wide, it is written to the VHDL file as N separate ports. Each port is given the type defined by <code>vhdlout\_bit\_type</code>.

To determine the current value of this variable, use the list vhdlout\_single\_bit command.

## **Architecture and Configuration Variables**

The following architecture and configuration variables control the names of the architectures, configurations, and entities written to the VHDL file.

```
vhdlout_top_configuration_arch_name
```

Determines the architecture name that is written out in a configuration definition. The default is "A".

```
vhdlout_top_configuration_entity_name
```

Determines the entity name that is written out in a configuration definition. The default is "E".

```
vhdlout_top_configuration_name
```

Determines the configuration name that is written out in a configuration definition. The default is "CFG\_TB\_E".

## **Preserving Port Types**

Example 7-1 shows how to write out the current design in VHDL format with port types (vector or record types) preserved.

#### Example 7-1 Preserving Port Types When Writing VHDL

Example 7-2 shows a VHDL input file. Example 7-3 and Example 7-4 shows the corresponding output files.

#### Example 7-2 Original VHDL Input File

The dc\_shell commands in Example 7-3 use the default values of the vhdlout\_variables (described in "VHDL Write Variables" on page 7-3) to generate the test\_vhdl output file.

#### Example 7-3 TEST\_VHDL Written Out in Default VHDL Format

```
library IEEE;
use IEEE.std_logic_1164.all;
package CONV_PACK_test_vhdl is
-- define attributes
attribute ENUM_ENCODING : STRING;
end CONV_PACK_test_vhdl;
library IEEE;
use IEEE.std_logic_1164.all;
use work.CONV_PACK_test_vhdl.all;
entity test vhdl is
   port( a : in std_logic_vector (3 downto 0); b : out std_logic_vector
(3 downto 0));
end test_vhdl;
architecture SYN_structural of test_vhdl is
   component GTECH_NOT
     port( A : in std_logic; Z : out std_logic);
   end component;
begin
   I_0 : GTECH_NOT port map(A => a(3), Z => b(3));
   I_1 : GTECH_NOT port map(A => a(2), Z => b(2));
   I_2 : GTECH_NOT port map(A => a(1), Z => b(1));
   I_3 : GTECH_NOT port map(A => a(0), Z => b(0));
end SYN_structural;
```

If you set vhdlout\_single\_bit to bit, the output file generated is shown in Example 7-4.

#### Example 7-4 TEST\_VHDL Written Out With Port Types in VHDL Format

```
library IEEE;
use IEEE.std_logic_1164.all;
entity test_vhdl is
   port( a_3_port, a_2_port, a_1_port, a_0_port : in std_logic;
b_3_port,
         b_2_port, b_1_port, b_0_port : out std_logic);
end test_vhdl;
architecture SYN_structural of test_vhdl is
   component GTECH NOT
     port( A : in std_logic; Z : out std_logic);
   end component;
begin
   I_0 : GTECH_NOT port map( A => a_3_port, Z => b_3_port);
   I_1 : GTECH_NOT port map( A => a_2_port, Z => b_2_port);
   I_2 : GTECH_NOT port map( A => a_1_port, Z => b_1_port);
   I_3 : GTECH_NOT port map( A => a_0_port, Z => b_0_port);
end SYN_structural;
```

## **VHDL Netlister Coding Considerations**

To understand how the VHDL netlister writes out designs, you need to be familiar with the following coding considerations:

- Built-In Type Conversion Function
- How the Netlister Handles Custom Types
- Case Sensitivity

These issues are discussed in the nest sections.

## **Built-In Type Conversion Function**

The VHDL netlister does not use packages and does not check for type equivalence. If you do not provide your own type conversion functions, the VHDL netlister translates only the logic values 0 and 1. Example 7-5 shows the VHDL netlister's built-in type conversion function that converts from type std logic vector to type my bit.

#### Example 7-5 Type Conversion Function

```
-- User-defined type declaration
attribute ENUM_ENCODING : STRING;
type my_bit is (A, B, C);
attribute ENUM_ENCODING of my_bit : type is "00 01 11";
-- std_logic_vector to enum type function
function std_logic_vector_to_my_bit(arg : in std_logic_vector ( 1 to 2 ))
return my_bit is
-- synopsys built_in SYN_FEED_THRU;
begin
         case arg is
               when "00" => return A;
               when "01" => return B;
               when "11" => return C;
               when others => assert FALSE -- this should not happen.
                     report "un-convertible value"
                     severity warning;
                     return A;
         end case;
end;
```

## **How the Netlister Handles Custom Types**

All types you use should be resolved. If types are not resolved, the VHDL netlister uses built-in resolution functions to resolve conflicts between multiple drivers on the same signal. Use the following functions to specify your own resolution function to the VHDL netlister:

```
vhdlout_three_state_res_func
vhdlout_wired_and_res_func
vhdlout_wired_or_res_func
```

Example 7-6 shows the resolution function the VHDL netlister writes out. This resolution function is used to resolve the value for multiple sources driving a signal, port, or pin.

#### Example 7-6 VHDL Resolution Function

```
function X( inputs : in vhdlout_bit_vector_type ) return vhdlout_bit_type is
-- synopsys resolution method three state
variable retval: vhdlout_bit_type;
begin
 retval := vhdlout_three_state_name;
         for i in inputs'range loop
          if inputs(i) /= vhdlout_three_state_name then
                  if ( retval = vhdlout_three_state_name ) then
                           retval := inputs(i);
                     else
                          retval := vhdlout_unknown_name
                           exit;
                     end if;
               end if;
         end loop;
return retval;
end X;
```

Example 7-7 shows a simplified description of the process flow for the resolution function in Example 7-6.

In this example, the <code>vhdlout\_three\_state\_name</code> and <code>vhdlout\_unknown\_name</code> variables use the default values z and x, respectively, for brevity. You can set the values for both of these variables.

#### Example 7-7 Pseudocode of VHDL Resolution Function

```
if the only logic values are 'z'
    return 'z'
if there are 'z's and another logic value
    return the other logic value
if there are non-'z' logic values that are different
    return 'x'
else
    return the common logic value
```

## **Case Sensitivity**

The VHDL netlist writer is case insensitive. For example, \A and \a are considered to be unique identifiers; however, the VHDL netlist writer considers them to be the same identifier.

#### Note:

The VHDL netlist reader is case-sensitive and supports the VHDL 93 standard.

# 8

## VHDL-2008 Language Support

The following topics describe the VHDL-2008 Language support in the HDL Compiler tool:

- VHDL-2008 Setting
- fixed\_generic\_pkg Package

## VHDL-2008 Setting

By default, the HDL Compiler tool is set to read VHDL-2008 language constructs. To change the VHDL language version that is used when reading the RTL files, set the hdlin\_vhdl\_std variable. The valid values for this variable are 1987, 1993, and 2008, corresponding to the 1987, 1993, and 2008 VHDL LRM releases. The default is 2008.

#### **Simplified Sensitivity List**

When the VHDL version is set to 2008, you can use the all keyword in the sensitivity list. Instead of listing all inputs to a combinational logic process, use the all keyword to make the process sensitive to all the input signals. This simplifies the sensitivity list, reducing mismatches between simulation and synthesis.

## fixed\_generic\_pkg Package

The HDL Compiler tool supports the VHDL-2008 fixed\_generic\_pkg package, which is used to implement fixed-point arithmetic.

The HDL Compiler tool supports a compatible version of the VHDL-2008 fixed-point package. The VHDL-2008 fixed-point package declares generics to control the rounding and overflow behaviors, while the compatible version, fixed\_generic\_pkg package, defines these elements as constants with the following constant values:

```
package fixed_generic_pkg is
   constant fixed_round_style : FIXED_ROUND_STYLE_TYPE := fixed_round;
   constant fixed_overflow_style : FIXED_OVERFLOW_STYLE_TYPE :=
fixed_saturate;
   constant fixed_guard_bits: NATURAL := 3;
   constant no_warning : BOOLEAN := false
```

Because the compatible fixed-point package uses constants rather than generics, you do not need to instantiate it. This package is installed in the Synopsys root directory. To access it, include the following statement in your VHDL code:

```
library IEEE;
use IEEE.fixed_generic_pkg.all
```

To learn the fixed-point package and the functions it provides, see

- fixed generic pkg Data Type
- Conversion Functions
- Resize Functions
- Arithmetic Functions

- Comparison Functions
- Logical Operator Functions
- Shift and Rotate Functions

## fixed\_generic\_pkg Data Type

The fixed\_generic\_pkg package defines the UNRESOLVED\_UFIXED and UNRESOLVED\_SFIXED data types for unsigned and signed representations respectively.

```
type UNRESOLVED_UFIXED is array (INTEGER range <>) of STD_ULOGIC;
type UNRESOLVED_SFIXED is array (INTEGER range <>) of STD_ULOGIC;
```

To be compatible with the VHDL-2008 data types, the fixed\_generic\_pkg package defines the next subtypes:

```
subtype U_UFIXED is UNRESOLVED_ufixed;
subtype U_SFIXED is UNRESOLVED_sfixed;
subtype UFIXED is UNRESOLVED_ufixed;
subtype SFIXED is UNRESOLVED_sfixed;
```

#### Note:

Synthesis neither checks for nor resolves possible data collisions on a synthesized three-state bus. You should ensure that the three-state enablers for a common bus are not active at the same time.

The fixed-point data types define the location of the binary point using a negative index, and the binary point resides between index 0 and -1. In the following example, Y represents a signed fixed-point number, where bits 7 through 0 are designated to the integer part of the number and bits -1 through -6 are designated to the fractional part.

```
signal Y : SFIXED (7 downto -6)
```

You must declare fixed-point data types with an index range in descending order; an index range in ascending order is not allowed. For example, if a number is declares as SFIXED (-5 to 6), the tool issues an error message. For more information, see the IEEE Std 1076-2008.

#### **Conversion Functions**

The fixed-point package provides functions to convert INTEGER, REAL, SIGNED, UNSIGNED, and literals. To call a conversion function, you can specify the upper and lower index bounds or pass a parameter that uses the upper and lower index bounds. In the same way, the package provides functions to convert fixed-point values to UNSIGNED, SIGNED, INTEGER, and REAL. For example,

```
signal r : SFIXED (7 downto -6);
signal i : INTEGER;
signal s : SIGNED (13 downto 0);

i <= to_integer (r);    -- Directly specify the index bounds
s <= to_signed (r, s); -- s pass a reference to set the output length</pre>
```

You can optionally specify the overflow\_style, round\_style, and guard\_bits arguments for the conversion functions. If you do not specify an argument, the tool uses the default.

The following example shows how to use the to\_sfixed conversion function:

#### **Resize Functions**

The fixed-point package data widths are designed to prevent overflows. The index range of each operation result is defined in Table .

Operation	Result range
A + B	Max(A'left, B'left) + 1 downto Min(A'right, B'right)
A – B	Max(A'left, B'left) + 1 downto Min(A'right, B'right)
A * B	A'left + B'left + 1 downto A'right + B'right
A rem B	Min(A'left, B'left) downto Min(A'right, B'right)
Signed A/B	A'left – B'right + 1 downto A'right – B'left
Signed A mod B	Min(A'left, B'left) downto Min(A'right, B'right)
Signed reciprocal(A)	–A'right downto –A'left – 1
abs A	A'left + 1 downto A'right
– A	A'left + 1 downto A'right

Operation	Result range
Unsigned A/B	A'left – B'right downto A'right – B'left – 1
Unsigned A mod B	B'left downto Min(A'right, B'right)
Unsigned reciprocal(A	-A'right + 1 downto -A'lef

The package provides the sfixed\_high, ufixed\_high, sfixed\_low, and ufixed\_low functions to calculate index ranges and to resize output results. You specify the operands and operator for each function to calculate the index range for each operation. For example,

The valid operators include +, -, \*, /, r or R (rem), m or M (mod), 1 (reciprocal), a or A (abs), and n or N (unary). You can also pass the operands as a parameter to obtain the upper and lower bounds of the index range automatically. For example,

You can use the resize functions to fix an output size following the rounding and saturation rules. For example,

Alternatively, you can resize an output by passing the resulting variable as a reference to calculate the index bounds. For example,

To use the round\_style and overflow\_style values, you need to include the fixed\_float\_types package in your VHDL code, as shown in the following statement:

```
library IEEE;
use IEEE.fixed_generic_pkg.all
use IEEE.fixed_float_types.all
```

The fixed\_float\_types package defines the round\_style\_type and overflow\_style\_type data types.

```
type FIXED_ROUND_STYLE_TYPE is (fixed_round, fixed_truncate);
type FIXED_OVERFLOW_STYLE_TYPE is (fixed_saturate, fixed_wrap);
```

If you do not specify the round\_style and overflow\_style values, the fixed\_round and fixed\_saturate values are used by default.

#### **Arithmetic Functions**

You can use the following arithmetic functions defined in the fixed-point package with the UFIXED, SFIXED, NATURAL, and INTEGER data types and literals (including REAL):

- Binary arithmetic functions: +, -, \*, /, rem, mod, divide, remainder, and modulo
- Unary arithmetic functions: -, abs, and reciprocal

As shown in the following example, the fixed-point package supports the scalb function:

```
constant half: UFIXED (2 downto -2) := "00010"; --000.10
signal two UFIXED (5 downto 0);
two <= scalb (half, 2); -- "00010."</pre>
```

The fixed-point package also supports the IS\_NEGATIVE function, which returns true when the SFIXED argument is negative.

## **Comparison Functions**

You can use the comparison functions (>, <, <=, >=, =, /=, and std\_match) to compare the SFIXED (or UFIXED) data type with the SFIXED (or UFIXED), NATURAL, INTEGER, and REAL data types. The returned data type is BOOLEAN for these functions.

You can use the matching operators (?=,?/=,?>, and ?<) to compare the SFIXED (or UFIXED) data type with the SFIXED (or UFIXED), NATURAL, INTEGER, and REAL data types. The returned data type is STD\_ULOGIC.

The maximum and minimum functions perform a comparison operation and return the appropriate values.

## **Logical Operator Functions**

The fixed-point package provides functions to define all the logical operators, including NOT, AND, NAND, OR, NOR, XOR, and XNOR. These logical operator functions can operate on the UFIXED (or SFIXED) and STD\_ULOGIC data types and return the UFIXED (or SFIXED) data type.

Operator	L	R	Return type
nor	UFIXED		UFIXED
nor	SFIXED		SFIXED
and, nand, or, nor, xor, xnor	UFIXED	UFIXED	UFIXED
and, nand, or, nor, xor, xnor	SFIXED	SFIXED	SFIXED
and, nand, or, nor, xor, xnor	STD_ULOGIC	SFIXED	SFIXED
and, nand, or, nor, xor, xnor	SFIXED	STD_ULOGIC	SFIXED
and, nand, or, nor, xor, xnor	STD_ULOGIC	UFIXED	UFIXED
and, nand, or, nor, xor, xnor	UFIXED	STD_ULOGIC	UFIXED

The fixed-point package provides reduction functions to perform reduction operations on all bits of a vector (UFIXED or SFIXED), returning an STD\_ULOGIC data type (and\_reduce, nand reduce, or reduce, nor reduce, xor reduce, and xnor reduce).

#### Note:

As a compatibility version of VHDL-2008, the fixed-point package adds a postfix of \_reduce to all reduction functions. For example, and\_reduce and nand\_reduce.

#### **Shift and Rotate Functions**

The fixed-point package provides functions to shift bits for UFIXED and SFIXED data types. Table shows the shift function declarations.

Operator	Arg	Count	Return type
sll	UFIXED	INTEGER	UFIXED
srl	UFIXED	INTEGER	UFIXED
rol	UFIXED	INTEGER	UFIXED

Operator	Arg	Count	Return type
ror	UFIXED	INTEGER	UFIXED
sla	UFIXED	INTEGER	UFIXED
sra	UFIXED	INTEGER	UFIXED
sll	SFIXED	INTEGER	SFIXED
srl	SFIXED	INTEGER	SFIXED
rol	SFIXED	INTEGER	SFIXED
ror	SFIXED	INTEGER	SFIXED
sla	SFIXED	INTEGER	SFIXED
sra	SFIXED	INTEGER	SFIXED
shift_left	UFIXED	NATURAL	UFIXED
shift_right	UFIXED	NATURAL	UFIXED
shift_left	SFIXED	NATURAL	SFIXED
shift_right	SFIXED	NATURAL	SFIXED



## Examples

Source files for examples demonstrating the use of VHDL are typically in the /synopsys/syn/examples/vhdl directory. These examples are included in the following sections:

- Read-Only Memory
- Waveform Generator
- Definable-Width Adder-Subtracter
- Count Zeros—Combinational Version
- Count Zeros—Sequential Version
- Soft Drink Machine—State Machine Version
- Soft Drink Machine—Count Nickels Version
- FSM Example: Moore Machine
- FSM Example: Mealy Machine
- Carry-Lookahead Adder
- Serial-to-Parallel Converter—Counting Bits
- Serial-to-Parallel Converter—Shifting Bits
- Programmable Logic Arrays

## **Read-Only Memory**

Example A-1 on page A-3 shows how you can define a read-only memory in VHDL. The ROM is defined as an array constant, ROM. Each line of the constant array specification defines the contents of one ROM address. To read from the ROM, index into the array.

The number of ROM storage locations and bit-width is easy to change. The subtype ROM\_RANGE specifies that the ROM contains storage locations 0 to 7. The constant ROM\_WIDTH specifies that the ROM is 5 bits wide.

After you define a ROM constant, you can index into that constant many times to read many values from the ROM. If the ROM address is computable, no logic is built and the appropriate data value is inserted. If the ROM address is not computable, logic is built for each index into the value. For this reason, consider resource sharing when using a ROM. In Example A-1 on page A-3, ADDR is not computable, so logic is synthesized to compute the value.


HDL Compiler does not actually instantiate a typical array-logic ROM, such as those available from ASIC vendors. Instead, it creates the ROM from random logic gates (AND, OR, NOT, and so on). This type of implementation is preferable for small ROMs and for ROMs that are regular. For very large ROMs, consider using an array-logic implementation supplied by your ASIC vendor.

Example A-1 shows the VHDL source code, and Figure A-1shows the synthesized circuit schematic.

#### Example A-1 Implementation of a ROM in Random Logic

```
package ROMS is
  -- declare a 5x8 ROM called ROM
  constant ROM_WIDTH: INTEGER := 5;
  subtype ROM_WORD is BIT_VECTOR (1 to ROM_WIDTH);
  subtype ROM_RANGE is INTEGER range 0 to 7;
  type ROM_TABLE is array (0 to 7) of ROM_WORD;
  constant ROM: ROM_TABLE := ROM_TABLE'(
      ROM_WORD'("10101"),
                                        -- ROM contents
      ROM_WORD'("10000"),
      ROM_WORD'("11111"),
      ROM_WORD'("11111"),
      ROM_WORD'("10000"),
      ROM_WORD'("10101"),
      ROM_WORD'("11111"),
      ROM_WORD'("11111"));
end ROMS;
use work.ROMS.all;
                   -- Entity that uses ROM
entity ROM_5x8 is
  port(ADDR: in ROM_RANGE;
       DATA: out ROM_WORD);
end;
architecture BEHAVIOR of ROM_5x8 is
  DATA <= ROM(ADDR);</pre>
                          -- Read from the ROM
end BEHAVIOR;
```

Figure A-1 Synthesized Circuit of the ROM




#### **Waveform Generator**

The waveform generator example shows how to use the previous ROM example to implement a waveform generator.

Assume that you want to produce the waveform output shown in Figure A-2.

- 1. First, declare a ROM wide enough to hold the output signals (4 bits) and deep enough to hold all time steps (0 to 12, for a total of 13).
- 2. Next, define the ROM so that each time step is represented by an entry in the ROM.
- 3. Finally, create a counter that cycles through the time steps (ROM addresses), generating the waveform at each time step.

Figure A-2 Waveform Example



Example A-2 shows an implementation for the waveform generator. It consists of a ROM, a counter, and some simple reset logic.

#### Example A-2 Implementation of a Waveform Generator

```
package ROMS is
  -- a 4x13 ROM called ROM that contains the waveform
  constant ROM_WIDTH: INTEGER := 4;
  subtype ROM_WORD is BIT_VECTOR (1 to ROM_WIDTH);
  subtype ROM_RANGE is INTEGER range 0 to 12;
  type ROM_TABLE is array (0 to 12) of ROM_WORD;
  constant ROM: ROM_TABLE := ROM_TABLE'(
      "1100", -- time step 0
      "1100",
              -- time step 1
      "0100", -- time step 2
      "0000",
              -- time step 3
      "0110",
               -- time step 4
      "0101",
               -- time step 5
      "0111",
               -- time step 6
               -- time step 7
      "1100",
      "0100",
               -- time step 8
      "0000",
               -- time step 9
      "0110", -- time step 10
      "0101",
               -- time step 11
      "0111"); -- time step 12
end ROMS;
use work.ROMS.all;
entity WAVEFORM is
                              -- Waveform generator
 port(CLOCK: in BIT;
      RESET: in BOOLEAN;
       WAVES: out ROM WORD);
end;
architecture BEHAVIOR of WAVEFORM is
  signal STEP: ROM_RANGE;
begin
  TIMESTEP_COUNTER: process -- Time stepping process
    wait until CLOCK'event and CLOCK = '1';
    if RESET then -- Detect reset
     STEP <= ROM_RANGE'low; -- Restart</pre>
    elsif STEP = ROM_RANGE'high then -- Finished?
   STEP <= ROM_RANGE'high; -- Hold at last value -- STEP <= ROM_RANGE'low; -- Continuous wave
    else
      STEP <= STEP + 1; -- Continue stepping
    end if;
  end process TIMESTEP_COUNTER;
  WAVES <= ROM(STEP);
end BEHAVIOR;
```

When the counter STEP reaches the end of the ROM, STEP stops, generates the last value, then waits until a reset. To make the sequence automatically repeat, remove the following statement:

```
STEP <= ROM_RANGE'high; -- Hold at last value

Use the following statement instead (commented out in Example A-2 on page A-5):
STEP <= ROM_RANGE'low; -- Continuous wave</pre>
```

#### **Definable-Width Adder-Subtracter**

VHDL lets you create functions for use with array operands of any size. This example shows an adder-subtracter circuit that, when called, is adjusted to fit the size of its operands.

Example A-3 shows an adder-subtracter defined for two unconstrained arrays of bits (type BIT\_VECTOR) in a package named MATH. When an unconstrained array type is used for an argument to a subprogram, the actual constraints of the array are taken from the actual parameter values in a subprogram call.

#### Example A-3 MATH Package for Example A-4 on page A-7

```
package MATH is
  function ADD_SUB(L, R: BIT_VECTOR; ADD: BOOLEAN)
     return BIT VECTOR;
    -- Add or subtract two BIT VECTORs of equal length
end MATH;
package body MATH is
    function ADD_SUB(L, R: BIT_VECTOR; ADD: BOOLEAN)
        return BIT VECTOR is
      variable CARRY: BIT;
      variable A, B, SUM:
          BIT_VECTOR(L'length-1 downto 0);
    begin
      if ADD then
          -- Prepare for an "add" operation
          A := L;
          B := R;
          CARRY := '0';
      else
          -- Prepare for a "subtract" operation
          A := L;
          B := not R;
          CARRY := '1';
      end if;
      -- Create a ripple carry chain; sum up bits
      for i in 0 to A'left loop
        SUM(i) := A(i) xor B(i) xor CARRY;
        CARRY := (A(i) \text{ and } B(i)) or
                 (A(i) and CARRY) or
                 (CARRY and B(i));
      end loop;
```

```
return SUM; -- Result end; end MATH;
```

Within the function ADD\_SUB, two temporary variables, A and B, are declared. These variables are declared to be the same length as L (and necessarily, R) but have their index constraints normalized to L'length-1 downto 0. After the arguments are normalized, you can create a ripple carry adder by using a for loop.

No explicit references to a fixed array length are in the function ADD\_SUB. Instead, the VHDL array attributes 'left and 'length are used. These attributes allow the function to work on arrays of any length.

Example A-4 shows how to use the adder-subtracter defined in the MATH package. In this example, the vector arguments to functions ARG1 and ARG2 are declared as BIT\_VECTOR(1 to 6). This declaration causes ADD\_SUB to work with 6-bit arrays.

#### Example A-4 Implementation of a 6-Bit Adder-Subtracter

```
use work.MATH.all;
entity EXAMPLE is
    port(ARG1, ARG2: in BIT_VECTOR(1 to 6);
        ADD: in BOOLEAN;
        RESULT : out BIT_VECTOR(1 to 6));
end EXAMPLE;

architecture BEHAVIOR of EXAMPLE is
begin
    RESULT <= ADD_SUB(ARG1, ARG2, ADD);
end BEHAVIOR;</pre>
```

### Count Zeros—Combinational Version

The count zeros—combinational example, Example A-5 on page A-8, illustrates a design problem in which an 8-bit-wide value is given and the circuit determines two things:

- That no more than one sequence of zeros is in the value.
- The number of zeros in that sequence (if any). This computation must be completed in a single clock cycle.

The circuit produces two outputs: the number of zeros found and an error indication.

A valid input value can have at most one consecutive series of zeros. A value consisting entirely of ones is defined as a valid value. If a value is invalid, the zero counter resets to 0. For example, the value 00000000 is valid and has eight zeros; value 11000111 is valid and has three zeros; value 00111100 is invalid.

Example A-5 shows the VHDL description for the circuit. It consists of a single process with a for loop that iterates across each bit in the given value. At each iteration, a temporary INTEGER variable (TEMP\_COUNT) counts the number of zeros encountered. Two temporary Boolean variables (SEEN\_ZERO and SEEN\_TRAILING), initially false, are set to true when the beginning and end of the first sequence of zeros are detected.

If a zero is detected after the end of the first sequence of zeros (after SEEN\_TRAILING is true), the zero count is reset (to 0), ERROR is set to true, and the for loop is exited.

Example A-5 shows a combinational (parallel) approach to counting the zeros. The next example shows a sequential (serial) approach.

#### Example A-5 Count Zeros—Combinational

```
entity COUNT_COMB_VHDL is
  port(DATA: in BIT VECTOR(7 downto 0);
       COUNT: out INTEGER range 0 to 8;
       ERROR: out BOOLEAN);
end;
architecture BEHAVIOR of COUNT_COMB_VHDL is
begin
  process(DATA)
    variable TEMP_COUNT : INTEGER range 0 to 8;
    variable SEEN_ZERO, SEEN_TRAILING : BOOLEAN;
  begin
    ERROR <= FALSE;</pre>
    SEEN ZERO := FALSE;
    SEEN TRAILING := FALSE;
    TEMP COUNT := 0;
    for I in 0 to 7 loop
      if (SEEN TRAILING and DATA(I) = '0') then
        TEMP COUNT := 0;
        ERROR <= TRUE;</pre>
        exit;
      elsif (SEEN_ZERO and DATA(I) = '1') then
        SEEN_TRAILING := TRUE;
      elsif (DATA(I) = '0') then
        SEEN_ZERO := TRUE;
        TEMP COUNT := TEMP COUNT + 1;
      end if;
    end loop;
    COUNT <= TEMP COUNT;
  end process;
end BEHAVIOR;
```

## **Count Zeros—Sequential Version**

The count zeros—sequential example, Example A-6, shows a sequential (clocked) variant of the preceding design (Count Zeros—Combinational Version).

The circuit now accepts the 8-bit data value serially, 1 bit per clock cycle, by using the DATA and CLK inputs. The other two inputs are

- RESET, which resets the circuit
- READ, which causes the circuit to begin accepting data bits

The circuit's three outputs are

- IS LEGAL, which is true if the data was a valid value
- COUNT\_READY, which is true at the first invalid bit or when all 8 bits have been processed
- COUNT, the number of zeros (if IS\_LEGAL is true)

#### Note:

The output port COUNT is declared with mode BUFFER so that it can be read inside the process. OUT ports can only be written to, not read in.

#### Example A-6 Count Zeros—Sequential

```
entity COUNT_SEQ_VHDL is
 port(DATA, CLK: in BIT;
      RESET, READ: in BOOLEAN;
       COUNT: buffer INTEGER range 0 to 8;
       IS_LEGAL: out BOOLEAN;
      COUNT_READY: out BOOLEAN);
end;
architecture BEHAVIOR of COUNT_SEQ_VHDL is
begin
 process
   variable SEEN_ZERO, SEEN_TRAILING: BOOLEAN;
   variable BITS_SEEN: INTEGER range 0 to 7;
   wait until CLK'event and CLK = '1';
    if(RESET) then
     COUNT_READY <= FALSE;
                    IS_LEGAL <= TRUE;
SEEN_ZERO := FALSE;
     SEEN_TRAILING := FALSE;
     COUNT <= 0;
     BITS_SEEN
                   := 0;
    else
      if (READ) then
        if (SEEN_TRAILING and DATA = '0') then
          IS_LEGAL <= FALSE;</pre>
         COUNT <= 0;
         COUNT_READY <= TRUE;
        elsif (SEEN_ZERO and DATA = '1') then
         SEEN_TRAILING := TRUE;
        elsif (DATA = '0') then
         SEEN_ZERO := TRUE;
         COUNT <= COUNT + 1;
        end if;
        if (BITS SEEN = 7) then
         COUNT_READY <= TRUE;</pre>
        else
         BITS_SEEN := BITS_SEEN + 1;
        end if;
     end if; -- if (READ)
                -- if (RESET)
    end if;
 end process;
end BEHAVIOR;
```

#### **Soft Drink Machine—State Machine Version**

The soft drink machine—state machine example, Example A-7, is a control unit for a soft drink vending machine.

The circuit reads signals from a coin input unit and sends outputs to a change dispensing unit and a drink dispensing unit.

Here are the design parameters for Example A-7 and Example A-8 on page A-15:

- This example assumes that only one kind of soft drink is dispensed.
- This is a clocked design with CLK and RESET input signals.
- The price of the drink is 35 cents.
- The input signals from the coin input unit are NICKEL\_IN (nickel deposited), DIME\_IN (dime deposited), and QUARTER\_IN (quarter deposited).
- The output signals to the change dispensing unit are NICKEL\_OUT and DIME\_OUT.
- The output signal to the drink dispensing unit is DISPENSE (dispense drink).

The first VHDL description for this design uses a state machine description style. The second VHDL description is in Example A-8 on page A-15.

#### Example A-7 Soft Drink Machine—State Machine

```
library synopsys; use synopsys.attributes.all;
entity DRINK_STATE_VHDL is
  port(NICKEL_IN, DIME_IN, QUARTER_IN, RESET: BOOLEAN;
       CLK: BIT;
       NICKEL OUT, DIME OUT, DISPENSE: out BOOLEAN);
end;
architecture BEHAVIOR of DRINK_STATE_VHDL is
  type STATE_TYPE is (IDLE, FIVE, TEN, FIFTEEN,
                  TWENTY, TWENTY FIVE, THIRTY, OWE DIME);
  signal CURRENT STATE, NEXT STATE: STATE TYPE;
  attribute STATE VECTOR : STRING;
  attribute STATE VECTOR of BEHAVIOR : architecture is
                           "CURRENT STATE";
attribute sync set reset of reset : signal is "true";
begin
  process(NICKEL_IN, DIME_IN, QUARTER_IN,
          CURRENT STATE, RESET, CLK)
    -- Default assignments
   NEXT STATE <= CURRENT STATE;
   NICKEL OUT <= FALSE;
   DIME OUT <= FALSE;
```

```
DISPENSE <= FALSE;</pre>
-- Synchronous reset
if(RESET) then
 NEXT_STATE <= IDLE;</pre>
else
  -- State transitions and output logic
  case CURRENT_STATE is
    when IDLE =>
      if(NICKEL_IN) then
        NEXT_STATE <= FIVE;</pre>
      elsif(DIME_IN) then
        NEXT STATE <= TEN;
      elsif(QUARTER_IN) then
        NEXT_STATE <= TWENTY_FIVE;</pre>
      end if;
    when FIVE =>
      if(NICKEL IN) then
        NEXT_STATE <= TEN;</pre>
      elsif(DIME_IN) then
        NEXT_STATE <= FIFTEEN;</pre>
      elsif(QUARTER_IN) then
        NEXT_STATE <= THIRTY;</pre>
      end if;
    when TEN =>
      if(NICKEL_IN) then
        NEXT_STATE <= FIFTEEN;</pre>
      elsif(DIME_IN) then
        NEXT_STATE <= TWENTY;</pre>
      elsif(QUARTER_IN) then
        NEXT_STATE <= IDLE;</pre>
         DISPENSE <= TRUE;
      end if;
    when FIFTEEN =>
      if(NICKEL_IN) then
        NEXT_STATE <= TWENTY;</pre>
      elsif(DIME_IN) then
        NEXT_STATE <= TWENTY_FIVE;</pre>
      elsif(QUARTER_IN) then
         NEXT_STATE <= IDLE;</pre>
         DISPENSE <= TRUE;
        NICKEL_OUT <= TRUE;
      end if;
    when TWENTY =>
      if(NICKEL IN) then
        NEXT_STATE <= TWENTY_FIVE;</pre>
      elsif(DIME_IN) then
        NEXT_STATE <= THIRTY;</pre>
      elsif(QUARTER_IN) then
```

```
NEXT STATE <= IDLE;
           DISPENSE <= TRUE;
           DIME_OUT <= TRUE;</pre>
         end if;
      when TWENTY_FIVE =>
         if(NICKEL IN) then
           NEXT_STATE <= THIRTY;</pre>
         elsif(DIME_IN) then
           NEXT_STATE <= IDLE;</pre>
           DISPENSE <= TRUE;
         elsif(QUARTER_IN) then
           NEXT STATE <= IDLE;
           DISPENSE <= TRUE;
           DIME_OUT <= TRUE;</pre>
           NICKEL_OUT <= TRUE;</pre>
         end if;
      when THIRTY =>
         if(NICKEL_IN) then
           NEXT_STATE <= IDLE;</pre>
           DISPENSE <= TRUE;
         elsif(DIME_IN) then
           NEXT_STATE <= IDLE;</pre>
           DISPENSE <= TRUE;
           NICKEL_OUT <= TRUE;</pre>
         elsif(QUARTER_IN) then
           NEXT_STATE <= OWE_DIME;</pre>
           DISPENSE <= TRUE;</pre>
           DIME_OUT <= TRUE;</pre>
         end if;
      when OWE_DIME =>
        NEXT_STATE <= IDLE;</pre>
        DIME_OUT <= TRUE;</pre>
    end case;
  end if;
end process;
-- Synchronize state value with clock
-- This causes it to be stored in flip-flops
process
begin
  wait until CLK'event and CLK = '1';
  CURRENT_STATE <= NEXT_STATE;</pre>
end process;
```

end BEHAVIOR;

## Soft Drink Machine—Count Nickels Version

The soft drink machine—count nickels example, Example A-8, uses the same design parameters as the preceding Example A-7 on page A-11 (Soft Drink Machine—State Machine Version), with the same input and output signals. In this version, a counter counts the number of nickels deposited. This counter is incremented by 1 if the deposit is a nickel, by 2 if it is a dime, and by 5 if it is a quarter.

#### Example A-8 Soft Drink Machine—Count Nickels

```
entity DRINK COUNT VHDL is
  port(NICKEL_IN, DIME_IN, QUARTER_IN, RESET: BOOLEAN;
       CLK: BIT;
       NICKEL_OUT, DIME_OUT, DISPENSE: out BOOLEAN);
end;
architecture BEHAVIOR of DRINK_COUNT_VHDL is
  signal CURRENT_NICKEL_COUNT,
        NEXT_NICKEL_COUNT: INTEGER range 0 to 7;
  signal CURRENT_RETURN_CHANGE, NEXT_RETURN_CHANGE : BOOLEAN;
begin
  process(NICKEL_IN, DIME_IN, QUARTER_IN, RESET, CLK,
          CURRENT_NICKEL_COUNT, CURRENT_RETURN_CHANGE)
    variable TEMP_NICKEL_COUNT: INTEGER range 0 to 12;
    -- Default assignments
   NICKEL_OUT <= FALSE;
   DIME OUT <= FALSE;
   DISPENSE <= FALSE;
   NEXT_NICKEL_COUNT <= 0;</pre>
   NEXT_RETURN_CHANGE <= FALSE;</pre>
    -- Synchronous reset
    if (not RESET) then
      TEMP_NICKEL_COUNT := CURRENT_NICKEL_COUNT;
      -- Check whether money has come in
      if (NICKEL_IN) then
        -- NOTE: This design will be flattened, so
        -- these multiple adders will be optimized
        TEMP_NICKEL_COUNT := TEMP_NICKEL_COUNT + 1;
      elsif(DIME_IN) then
        TEMP_NICKEL_COUNT := TEMP_NICKEL_COUNT + 2;
      elsif(QUARTER_IN) then
        TEMP_NICKEL_COUNT := TEMP_NICKEL_COUNT + 5;
      end if;
      -- Enough deposited so far?
      if(TEMP_NICKEL_COUNT >= 7) then
        TEMP_NICKEL_COUNT := TEMP_NICKEL_COUNT - 7;
        DISPENSE <= TRUE;
      end if;
      -- Return change
      if(TEMP_NICKEL_COUNT >= 1 or
         CURRENT_RETURN_CHANGE) then
        if(TEMP_NICKEL_COUNT >= 2) then
          DIME_OUT <= TRUE;</pre>
          TEMP_NICKEL_COUNT := TEMP_NICKEL_COUNT - 2;
          NEXT_RETURN_CHANGE <= TRUE;</pre>
        end if;
        if(TEMP_NICKEL_COUNT = 1) then
          NICKEL_OUT <= TRUE;</pre>
          TEMP_NICKEL_COUNT := TEMP_NICKEL_COUNT - 1;
        end if;
```

```
end if;


NEXT_NICKEL_COUNT <= TEMP_NICKEL_COUNT;
end if;
end process;

-- Remember the return-change flag and
-- the nickel count for the next cycle
process
begin
   wait until CLK'event and CLK = '1';
   CURRENT_RETURN_CHANGE <= NEXT_RETURN_CHANGE;
   CURRENT_NICKEL_COUNT <= NEXT_NICKEL_COUNT;
end process;</pre>
```

## **FSM Example: Moore Machine**

Figure A-3 is a diagram of a simple Moore finite state machine. It has one input (X), four internal states (S0 to S3), and one output (Z).

Figure A-3 Moore Machine Specification



The VHDL code implementing this finite state machine is shown in Example A-9.

The machine description includes two processes. One process defines the synchronous elements of the design (state registers); the other process defines the combinational part of the design (state assignment case statement).

## Example A-9 Implementation of a Moore Machine


```
entity MOORE is
                                -- Moore machine
  port(X, CLOCK: in BIT;
       Z: out BIT);
end;
architecture BEHAVIOR of MOORE is
  type STATE_TYPE is (S0, S1, S2, S3);
  signal CURRENT_STATE, NEXT_STATE: STATE_TYPE;
begin
  -- Process to hold combinational logic
  COMBIN: process(CURRENT_STATE, X)
  begin
    case CURRENT_STATE is
      when S0 =>
        Z <= '0';
        if X = '0' then
          NEXT_STATE <= S0;</pre>
        else
          NEXT_STATE <= S2;</pre>
        end if;
      when S1 =>
        Z <= '1';
        if X = '0' then
          NEXT_STATE <= S0;</pre>
        else
          NEXT_STATE <= S2;</pre>
        end if;
      when S2 =>
        Z <= '1';
        if X = '0' then
          NEXT_STATE <= S2;</pre>
        else
          NEXT_STATE <= S3;</pre>
        end if;
      when S3 =>
        Z <= '0';
        if X = '0' then
          NEXT_STATE <= S3;
          NEXT_STATE <= S1;</pre>
        end if;
    end case;
  end process;
  -- Process to hold synchronous elements (flip-flops)
  SYNCH: process
  begin
    wait until CLOCK'event and CLOCK = '1';
    CURRENT_STATE <= NEXT_STATE;
  end process;
```

end BEHAVIOR;

## **FSM Example: Mealy Machine**

Figure A-4 is a diagram of a simple Mealy finite state machine. The VHDL code for implementing this finite state machine is shown in Example A-10. The machine description includes two processes, as in the previous Moore machine example.

Figure A-4 Mealy Machine Specification




## Example A-10 Implementation of a Mealy Machine

```
entity MEALY is
                            -- Mealy machine
  port(X, CLOCK: in BIT;
       Z: out BIT);
end;
architecture BEHAVIOR of MEALY is
  type STATE_TYPE is (S0, S1, S2, S3);
  signal CURRENT_STATE, NEXT_STATE: STATE_TYPE;
begin
  -- Process to hold combinational logic.
  COMBIN: process(CURRENT_STATE, X)
  begin
    case CURRENT_STATE is
      when S0 =>
        if X = '0' then
          Z <= '0';
```

```
NEXT_STATE <= S0;</pre>
      else
         Z <= '1';
        NEXT_STATE <= S2;</pre>
      end if;
    when S1 =>
      if X = '0' then
        Z <= '0';
        NEXT_STATE <= S0;</pre>
      else
        Z <= '0';
        NEXT_STATE <= S2;</pre>
      end if;
    when S2 =>
      if X = '0' then
        Z <= '1';
        NEXT_STATE <= S2;</pre>
      else
         Z <= '0';
        NEXT_STATE <= S3;</pre>
      end if;
    when S3 =>
      if X = '0' then
        Z <= '0';
        NEXT_STATE <= S3;</pre>
      else
         Z <= '1';
        NEXT_STATE <= S1;</pre>
      end if;
  end case;
end process;
-- Process to hold synchronous elements (flip-flops)
SYNCH: process
begin
 wait until CLOCK'event and CLOCK = '1';
  CURRENT_STATE <= NEXT_STATE;</pre>
end process;
```

end BEHAVIOR;



## **Carry-Lookahead Adder**

This example uses concurrent procedure calls to build a 32-bit carry-lookahead adder. The adder is built by partitioning of the 32-bit input into eight slices of 4 bits each. Each of the eight slices computes propagate and generate values by using the PG procedure.

Propagate (output P from PG) is '1' for a bit position if that position propagates a carry from the next-lower position to the next-higher position. Generate (output G) is '1' for a bit position if that position generates a carry to the next-higher position, regardless of the carry-in from the next lower position. The carry-lookahead logic reads the carry-in, propagate, and generate information computed from the inputs. The logic computes the carry value for each bit position and makes the addition operation an XOR of the inputs and the carry values.

## **Carry Value Computations**

The carry values are computed by a three-level tree of 4-bit carry-lookahead blocks.

- The first level of the tree computes the 32 carry values and the eight group-propagate
  and generate values. Each of the first-level group-propagate and generate values tells if
  that 4-bit slice propagates and generates carry values from the next-lower group to the
  next-higher group. The first-level lookahead blocks read the group carry computed at the
  second level.
- The second-level lookahead blocks read the group-propagate and generate information from the four first-level blocks and then compute their own group-propagate and generate information. The second-level lookahead blocks also read group carry information computed at the third level to compute the carries for each of the third-level blocks.

• The third-level block reads the propagate and generate information of the second level to compute a propagate and generate value for the entire adder. It also reads the external carry to compute each second-level carry. The carry-out for the adder is '1' if the third-level generate is '1' or if the third-level propagate is '1' and the external carry is '1'.

The third-level carry-lookahead block is capable of processing four second-level blocks. But because there are only two second-level blocks, the high-order 2 bits of the computed carry are ignored; the high-order 2 bits of the generate input to the third-level are set to 0, "00", and the propagate high-order bits are set to "11". These settings cause the unused portion to propagate carries but not to generate them. Figure A-5 shows the overall structure for the carry-lookahead adder.




Figure A-5 Carry-Lookahead Adder Block Diagram

The VHDL implementation of the design in Figure A-5 is accomplished with the following procedures:

## CLA

Names a 4-bit carry-lookahead block.

## PG

Computes first-level propagate and generate information.

## SUM

Computes the sum by adding the XOR values to the inputs with the carry values computed by CLA.

## **BITSLICE**

Collects the first-level CLA blocks, the PG computations, and the SUM. This procedure performs all the work for a 4-bit value except for the second- and third-level lookaheads.

Example A-11 shows a VHDL description of the adder.

## Example A-11 Carry-Lookahead Adder

```
package LOCAL is
 constant N: INTEGER := 4;
 procedure BITSLICE(
     A, B: in BIT_VECTOR(3 downto 0);
     CIN: in BIT;
     signal S: out BIT_VECTOR(3 downto 0);
     signal GP, GG: out BIT);
 procedure PG(
     A, B: in BIT_VECTOR(3 downto 0);
     P, G: out BIT_VECTOR(3 downto 0));
 function SUM(A, B, C: BIT_VECTOR(3 downto 0))
     return BIT_VECTOR;
 procedure CLA(
     P, G: in BIT_VECTOR(3 downto 0);
     CIN: in BIT;
     C: out BIT_VECTOR(3 downto 0);
     signal GP, GG: out BIT);
end LOCAL;
package body LOCAL is
     ______
 -- Compute sum and group outputs from a, b, cin
 _____
 procedure BITSLICE(
     A, B: in BIT_VECTOR(3 downto 0);
     CIN: in BIT;
     signal S: out BIT_VECTOR(3 downto 0);
     signal GP, GG: out BIT) is
   variable P, G, C: BIT_VECTOR(3 downto 0);
 begin
   PG(A, B, P, G);
   CLA(P, G, CIN, C, GP, GG);
   S \le SUM(A, B, C);
 end;
 -- Compute propagate and generate from input bits
 procedure PG(A, B: in BIT_VECTOR(3 downto 0);
             P, G: out BIT_VECTOR(3 downto 0)) is
 begin
   P := A or B;
   G := A \text{ and } B;
 _____
 -- Compute sum from the input bits and the carries
 function SUM(A, B, C: BIT_VECTOR(3 downto 0))
     return BIT_VECTOR is
```

```
begin
   return(A xor B xor C);
  -- 4-bit carry-lookahead block
  procedure CLA(
      P, G: in BIT_VECTOR(3 downto 0);
      CIN: in BIT;
      C: out BIT_VECTOR(3 downto 0);
      signal GP, GG: out BIT) is
    variable TEMP_GP, TEMP_GG, LAST_C: BIT;
  begin
    TEMP\_GP := P(0);
    TEMP GG := G(0);
   LAST_C := CIN;
   C(0) := CIN;
    for I in 1 to N-1 loop
      TEMP_GP := TEMP_GP and P(I);
      TEMP\_GG := (TEMP\_GG \text{ and } P(I)) \text{ or } G(I);
     LAST_C := (LAST_C and P(I-1)) or G(I-1);
     C(I) := LAST_C;
    end loop;
    GP <= TEMP_GP;
   GG <= TEMP_GG;
  end;
end LOCAL;
use WORK.LOCAL.ALL;
-- A 32-bit carry-lookahead adder
______
entity ADDER is
 port(A, B: in BIT_VECTOR(31 downto 0);
       CIN: in BIT;
       S: out BIT_VECTOR(31 downto 0);
       COUT: out BIT);
end ADDER;
architecture BEHAVIOR of ADDER is
  signal GG,GP,GC: BIT_VECTOR(7 downto 0);
    -- First-level generate, propagate, carry
  signal GGG, GGP, GGC: BIT_VECTOR(3 downto 0);
    -- Second-level gen, prop, carry
  signal GGGG, GGGP: BIT;
    -- Third-level gen, prop
begin
  -- Compute Sum and 1st-level Generate and Propagate
  -- Use input data and the 1st-level Carries computed
  -- later.
```

```
BITSLICE(A( 3 downto 0),B( 3 downto 0),GC(0),
 BITSLICE(A( 3 downto 0), B( 3 downto 0), GC(0),

S( 3 downto 0), GP(0), GG(0));

BITSLICE(A( 7 downto 4), B( 7 downto 4), GC(1),

S( 7 downto 4), GP(1), GG(1));

BITSLICE(A(11 downto 8), B(11 downto 8), GC(2),

S(11 downto 8), GP(2), GG(2));
  BITSLICE(A(15 downto 12),B(15 downto 12),GC(3),
            S(15 downto 12), GP(3), GG(3));
  BITSLICE(A(19 downto 16),B(19 downto 16),GC(4),
            S(19 \text{ downto } 16), GP(4), GG(4));
  BITSLICE(A(23 downto 20),B(23 downto 20),GC(5),
            S(23 downto 20), GP(5), GG(5));
  BITSLICE(A(27 downto 24),B(27 downto 24),GC(6),
            S(27 downto 24), GP(6), GG(6));
  BITSLICE(A(31 downto 28),B(31 downto 28),GC(7),
            S(31 \text{ downto } 28), GP(7), GG(7));
  -- Compute first-level Carries and second-level
  -- generate and propagate.
  -- Use first-level Generate, Propagate, and
  -- second-level carry.
  process(GP, GG, GGC)
    variable TEMP: BIT VECTOR(3 downto 0);
    CLA(GP(3 downto 0), GG(3 downto 0), GGC(0), TEMP,
         GGP(0), GGG(0));
    GC(3 downto 0) <= TEMP;
  end process;
  process(GP, GG, GGC)
    variable TEMP: BIT_VECTOR(3 downto 0);
    CLA(GP(7 downto 4), GG(7 downto 4), GGC(1), TEMP,
         GGP(1), GGG(1));
    GC(7 downto 4) <= TEMP;
  end process;
  -- Compute second-level Carry and third-level
  -- Generate and Propagate
  -- Use second-level Generate, Propagate and Carry-in
  -- (CIN)
  process(GGP, GGG, CIN)
    variable TEMP: BIT_VECTOR(3 downto 0);
    CLA(GGP, GGG, CIN, TEMP, GGGP, GGGG);
    GGC <= TEMP;
  end process;
  -- Assign unused bits of second-level Generate and
  -- Propagate
  GGP(3 downto 2) <= "11";
  GGG(3 downto 2) <= "00";
  -- Compute Carry-out (COUT)
  -- Use third-level Generate and Propagate and
  -- Carry-in (CIN).
  COUT <= GGGG or (GGGP and CIN);
end BEHAVIOR;
```

## **Implementation**

In the carry-lookahead adder implementation, procedures perform the computation of the design. The procedures can also be in the form of separate entities and used by component instantiation, producing a hierarchical design. HDL Compiler does not collapse a hierarchy of entities, but it does collapse the procedure call hierarchy into one design.

The keyword *signal* is included before some of the interface parameter declarations. This keyword is required for the out formal parameters when the actual parameters must be signals.

The output parameter C from the CLA procedure is not declared as a signal; thus, it is not allowed in a concurrent procedure call. Only signals can be used in such calls. To overcome this problem, subprocesses are used, declaring a temporary variable TEMP. TEMP receives the value of the C parameter and assigns it to the appropriate signal (a generally useful technique).

## Serial-to-Parallel Converter—Counting Bits

This example shows the design of a serial-to-parallel converter that reads a serial, bit-stream input and produces an 8-bit output.

The design reads the following inputs:

SERIAL IN

The serial input data.

#### RESET

The input that, when it is '1', causes the converter to reset. All outputs are set to 0, and the converter is prepared to read the next serial word.

## **CLOCK**

The value of RESET and SERIAL\_IN, which is read on the positive transition of this clock. Outputs of the converter are also valid only on positive transitions.

The design produces the following outputs:

PARALLEL\_OUT

The 8-bit value read from the SERIAL\_IN port.

## READ\_ENABLE

The output that, when it is '1' on the positive transition of CLOCK, causes the data on PARALLEL OUT to be read.

#### PARITY\_ERROR

The output that, when it is '1' on the positive transition of CLOCK, indicates that a parity error has been detected on the SERIAL\_IN port. When a parity error is detected, the converter halts until restarted by the RESET port.

## **Input Format**


When no data is being transmitted to the serial port, keep it at a value of '0'. Each 8-bit value requires 10 clock cycles to read it. On the 11th clock cycle, the parallel output value can be read.

In the first cycle, a '1' is placed on the serial input. This assignment indicates that an 8-bit value follows. The next 8 cycles transmit each bit of the value. The most significant bit is transmitted first. The 10th cycle transmits the parity of the 8-bit value. It must be '0' if an even number of '1' values are in the 8-bit data, and '1' otherwise. If the converter detects a parity error, it sets the PARITY\_ERROR output to '1' and waits until the value is reset.

On the 11th cycle, the READ\_ENABLE output is set to '1' and the 8-bit value can be read from the PARALLEL\_OUT port. If the SERIAL\_IN port has a '1' on the 11th cycle, another 8-bit value is read immediately; otherwise, the converter waits until SERIAL IN goes to '1'.

Figure A-6 shows the timing of this design.

Figure A-6 An Example of Waveform Through the Converter



## **Implementation Details**

The implementation of the converter is as a four-state finite-state machine with synchronous reset. When a reset is detected, the converter enters a WAIT\_FOR\_START state. Description of the states follow.

#### WAIT FOR START

Stay in this state until a '1' is detected on the serial input. When a '1' is detected, clear the PARALLEL OUT registers and go to the READ BITS state.

## **READ\_BITS**

If the value of the current\_bit\_position counter is 8, all 8 bits have been read. Check the computed parity with the transmitted parity. If it is correct, go to the ALLOW\_READ state; otherwise, go to the PARITY ERROR state.

If all 8 bits have not yet been read, set the appropriate bit in the PARALLEL\_OUT buffer to the SERIAL\_IN value, compute the parity of the bits read so far, and increment the current\_bit\_position.

## ALLOW READ

This is the state where the outside world reads the PARALLEL\_OUT value. When that value is read, the design returns to the WAIT\_FOR\_START state.

#### PARITY ERROR DETECTED

In this state, the PARITY ERROR output is set to '1' and nothing else is done.

This design has four values stored in registers:

## **CURRENT STATE**

Remembers the state as of the last clock edge.

## CURRENT BIT POSITION

Remembers how many bits have been read so far.

## **CURRENT\_PARITY**

Keeps a running XOR of the bits read.

#### CURRENT PARALLEL OUT

Stores each parallel bit as it is found.

The design has two processes: the combinational NEXT\_ST containing the combinational logic and the sequential SYNCH that is clocked.

NEXT\_ST performs all the computations and state assignments. The NEXT\_ST process starts by assigning default values to all the signals it drives. This assignment guarantees that all signals are driven under all conditions. Next, the RESET input is processed. If RESET is not active, a case statement determines the current state and its computations. State transitions are performed by assignment of the next state's value you want to the NEXT\_STATE signal.

The serial-to-parallel conversion itself is performed by these two statements in the NEXT ST process:

```
NEXT_PARALLEL_OUT(CURRENT_BIT_POSITION) <= SERIAL_IN;
NEXT_BIT_POSITION <= CURRENT_BIT_POSITION + 1;</pre>
```

The first statement assigns the current serial input bit to a particular bit of the parallel output. The second statement increments the next bit position to be assigned.

SYNCH registers and updates the stored values previously described. Each registered signal has two parts, NEXT\_... and CURRENT\_...:

NEXT ...

Signals hold values computed by the NEXT\_ST process.

CURRENT\_...

Signals hold the values driven by the SYNCH process. The CURRENT\_... signals hold the values of the NEXT\_... signals as of the last clock edge.

Example A-12 shows a VHDL description of the converter.

#### Example A-12 Serial-to-Parallel Converter—Counting Bits

```
-- Serial-to-Parallel Converter, counting bits
package TYPES is
  -- Declares types used in the rest of the design
  type STATE_TYPE is (WAIT_FOR_START,
                      READ BITS,
                      PARITY_ERROR_DETECTED,
                      ALLOW_READ);
  constant PARALLEL_BIT_COUNT: INTEGER := 8;
  subtype PARALLEL_RANGE is INTEGER
      range 0 to (PARALLEL_BIT_COUNT-1);
  subtype PARALLEL_TYPE is BIT_VECTOR(PARALLEL_RANGE);
end TYPES;
use WORK.TYPES.ALL; -- Use the TYPES package
entity SER_PAR is
                     -- Declare the interface
  port(SERIAL_IN, CLOCK, RESET: in BIT;
       PARALLEL_OUT: out PARALLEL_TYPE;
       PARITY_ERROR, READ_ENABLE: out BIT);
end;
architecture BEHAVIOR of SER_PAR is
  -- Signals for stored values
  signal CURRENT_STATE, NEXT_STATE: STATE_TYPE;
  signal CURRENT_PARITY, NEXT_PARITY: BIT;
  signal CURRENT_BIT_POSITION, NEXT_BIT_POSITION:
      INTEGER range PARALLEL_BIT_COUNT downto 0;
  signal CURRENT_PARALLEL_OUT, NEXT_PARALLEL_OUT:
     PARALLEL_TYPE;
NEXT_ST: process(SERIAL_IN, CURRENT_STATE, RESET,
                 CURRENT_BIT_POSITION, CURRENT_PARITY,
                 CURRENT_PARALLEL_OUT)
  -- This process computes all outputs, the next
  -- state, and the next value of all stored values
  begin
   PARITY_ERROR <= '0'; -- Default values for all
   READ ENABLE <= '0'; -- outputs and stored values
   NEXT_STATE <= CURRENT_STATE;</pre>
   NEXT_BIT_POSITION <= 0;</pre>
   NEXT_PARITY <= '0';</pre>
   NEXT_PARALLEL_OUT <= CURRENT_PARALLEL_OUT;</pre>
    if (RESET = '1') then
                               -- Synchronous reset
     NEXT_STATE <= WAIT_FOR_START;</pre>
    else
      case CURRENT_STATE is -- State processing
        when WAIT_FOR_START =>
          if (SERIAL_IN = '1') then
            NEXT_STATE <= READ_BITS;</pre>
            NEXT_PARALLEL_OUT <=
                PARALLEL_TYPE'(others=>'0');
          end if;
        when READ_BITS =>
          if (CURRENT_BIT_POSITION =
```

```
PARALLEL_BIT_COUNT) then
            if (CURRENT_PARITY = SERIAL_IN) then
              NEXT_STATE <= ALLOW_READ;</pre>
              READ_ENABLE <= '1';
              NEXT_STATE <= PARITY_ERROR_DETECTED;</pre>
            end if;
          else
            NEXT_PARALLEL_OUT(CURRENT_BIT_POSITION) <=</pre>
                 SERIAL_IN;
            NEXT_BIT_POSITION <=</pre>
                CURRENT_BIT_POSITION + 1;
            NEXT_PARITY <= CURRENT_PARITY xor</pre>
                            SERIAL_IN;
          end if;
        when PARITY_ERROR_DETECTED =>
          PARITY_ERROR <= '1';
        when ALLOW READ =>
          NEXT_STATE <= WAIT_FOR_START;</pre>
      end case;
    end if;
 end process;
 SYNCH: process
    -- This process remembers the stored values
    -- across clock cycles
 begin
   wait until CLOCK'event and CLOCK = '1';
    CURRENT_STATE <= NEXT_STATE;</pre>
    CURRENT_BIT_POSITION <= NEXT_BIT_POSITION;
    CURRENT_PARITY <= NEXT_PARITY;</pre>
    CURRENT_PARALLEL_OUT <= NEXT_PARALLEL_OUT;
 end process;
 PARALLEL_OUT <= CURRENT_PARALLEL_OUT;
end BEHAVIOR;
```

## Serial-to-Parallel Converter—Shifting Bits

This example describes another implementation of the serial-to-parallel converter in the last example. This design performs the same function as the previous one but uses a different algorithm to do the conversion.

The previous implementation used a counter to indicate the bit of the output that was set when a new serial bit was read. In this implementation, the serial bits are shifted into place. Before the conversion occurs, a '1' is placed in the least-significant bit position. When that '1' is shifted out of the most significant position (position 0), the signal NEXT\_HIGH\_BIT is set to '1' and the conversion is complete.

Example A-13 shows the listing of the second implementation. The differences are highlighted in bold. The differences relate to the removal of the ...\_BIT\_POSITION signals,

the addition of ...\_HIGH\_BIT signals, and the change in the way NEXT\_PARALLEL\_OUT is computed.

#### Example A-13 Serial-to-Parallel Converter—Shifting Bits

```
package TYPES is
  -- Declares types used in the rest of the design
  type STATE_TYPE is (WAIT_FOR_START,
                      READ_BITS,
                      PARITY_ERROR_DETECTED,
                      ALLOW READ);
  constant PARALLEL_BIT_COUNT: INTEGER := 8;
  subtype PARALLEL_RANGE is INTEGER
     range 0 to (PARALLEL_BIT_COUNT-1);
  subtype PARALLEL_TYPE is BIT_VECTOR(PARALLEL_RANGE);
end TYPES;
use WORK.TYPES.ALL;
                        -- Use the TYPES package
entity SER_PAR is
                         -- Declare the interface
  port(SERIAL_IN, CLOCK, RESET: in BIT;
       PARALLEL_OUT: out PARALLEL_TYPE;
       PARITY_ERROR, READ_ENABLE: out BIT);
end;
architecture BEHAVIOR of SER_PAR is
  -- Signals for stored values
  signal CURRENT_STATE, NEXT_STATE: STATE_TYPE;
  signal CURRENT_PARITY, NEXT_PARITY: BIT;
  signal CURRENT_HIGH_BIT, NEXT_HIGH_BIT: BIT;
  signal CURRENT_PARALLEL_OUT, NEXT_PARALLEL_OUT:
     PARALLEL_TYPE;
begin
NEXT_ST: process(SERIAL_IN, CURRENT_STATE, RESET,
                 CURRENT_HIGH_BIT, CURRENT_PARITY,
                 CURRENT_PARALLEL_OUT)
  -- This process computes all outputs, the next
  -- state, and the next value of all stored values
  begin
   PARITY_ERROR <= '0'; -- Default values for all
   READ_ENABLE <= '0'; -- outputs and stored values
   NEXT_STATE <= CURRENT_STATE;</pre>
   NEXT_HIGH_BIT <= '0';</pre>
   NEXT_PARITY <= '0';</pre>
   NEXT_PARALLEL_OUT <= PARALLEL_TYPE'(others=>'0');
    if(RESET = '1') then
                           -- Synchronous reset
      NEXT_STATE <= WAIT_FOR_START;</pre>
    else
      case CURRENT_STATE is -- State processing
        when WAIT_FOR_START =>
          if (SERIAL_IN = '1') then
            NEXT_STATE <= READ_BITS;</pre>
            NEXT_PARALLEL_OUT <=
                PARALLEL_TYPE'(others=>'0');
          end if;
        when READ_BITS =>
          if (CURRENT_HIGH_BIT = '1') then
            if (CURRENT_PARITY = SERIAL_IN) then
              NEXT_STATE <= ALLOW_READ;</pre>
```

```
READ_ENABLE <= '1';
            else
              NEXT STATE <= PARITY ERROR DETECTED;
            end if;
            NEXT_HIGH_BIT <= CURRENT_PARALLEL_OUT(0);</pre>
            NEXT_PARALLEL_OUT <=
                CURRENT_PARALLEL_OUT(
                    1 to PARALLEL_BIT_COUNT-1) &
                SERIAL_IN;
            NEXT_PARITY <= CURRENT_PARITY xor</pre>
                           SERIAL_IN;
          end if;
        when PARITY_ERROR_DETECTED =>
          PARITY_ERROR <= '1';
        when ALLOW_READ =>
         NEXT_STATE <= WAIT_FOR_START;</pre>
      end case;
    end if;
  end process;
  SYNCH: process
    -- This process remembers the stored values
         across clock cycles
  begin
    wait until CLOCK'event and CLOCK = '1';
    CURRENT_STATE <= NEXT_STATE;
    CURRENT_HIGH_BIT <= NEXT_HIGH_BIT;
   CURRENT_PARITY <= NEXT_PARITY;
   CURRENT_PARALLEL_OUT <= NEXT_PARALLEL_OUT;
  end process;
  PARALLEL_OUT <= CURRENT_PARALLEL_OUT;
end BEHAVIOR;
```

## Note:

The synthesized schematic for the shifter implementation is much simpler than that of the previous count implementation in Example A-12 on page A-31. It is simpler because the shifter algorithm is inherently easier to implement.

With the count algorithm, each of the flip-flops holding the PARALLEL\_OUT bits needed logic that decoded the value stored in the BIT\_POSITION flip-flops to see when to route in the value of SERIAL\_IN. Also, the BIT\_POSITION flip-flops needed an incrementer to compute their next value.

In contrast, the shifter algorithm requires neither an incrementer nor flip-flops to hold BIT\_POSITION. Additionally, the logic in front of most PARALLEL\_OUT bits needs to read-only the value of the previous flip-flop or '0'. The value depends on whether bits are currently being read. In the shifter algorithm, the SERIAL\_IN port needs to be connected only to the least significant bit (number 7) of the PARALLEL\_OUT flip-flops.

These two implementations illustrate the importance of designing efficient algorithms. Both work properly, but the shifter algorithm produces a faster, more area-efficient design.

## **Programmable Logic Arrays**

This example shows a way to build programmable logic arrays (PLAs) in VHDL. The PLA function uses an input lookup vector as an index into a constant PLA table and then returns the output vector specified by the PLA.

The PLA table is an array of PLA rows, where each row is an array of PLA elements. Each element is either a one, a zero, a minus, or a space ('1', '0', '-', or ' '). The table is split between an input plane and an output plane. The input plane is specified by 0s, 1s, and minuses. The output plane is specified by 0s and 1s. The two planes' values are separated by a space.

In the PLA function, the output vector is first initialized to be all 0s. When the input vector matches an input plane in a row of the PLA table, the 1s in the output plane are assigned to the corresponding bits in the output vector. A match is determined as follows:

- If a 0 or 1 is in the input plane, the input vector must have the same value in the same position.
- If a minus is in the input plane, it matches any input vector value at that position.

The generic PLA table types and the PLA function are defined in a package named LOCAL. An entity PLA\_VHDL that uses LOCAL needs only to specify its PLA table as a constant, then call the PLA function.

The PLA function does not explicitly depend on the size of the PLA. To change the size of the PLA, change the initialization of the TABLE constant and the initialization of the constants INPUT\_COUNT, OUTPUT\_COUNT, and ROW\_COUNT. In Example A-14, these constants are initialized to a PLA equivalent to the ROM shown previously (Example A-1 on page A-3). Accordingly, the synthesized schematic is the same as that of the ROM, with one difference: in Example A-1, the DATA output port range is 1 to 5; in Example A-14, the OUT\_VECTOR output port range is 4 down to 0.


Example A-14 shows the capabilities of VHDL. It is more efficient to define the PLA directly by using the PLA input format. See the *Synopsys Timing Constraints and Optimization User Guide* for more information about the PLA input format.

## Example A-14 Programmable Logic Array

```
PLA VECTOR(ROW SIZE - 1 downto 0);
  subtype PLA OUTPUT is
     PLA_VECTOR(OUTPUT_COUNT - 1 downto 0);
  type PLA_TABLE is
     array(ROW_COUNT - 1 downto 0) of PLA_ROW;
  function PLA(IN VECTOR: BIT VECTOR;
               TABLE: PLA_TABLE)
      return BIT_VECTOR;
end LOCAL;
package body LOCAL is
  function PLA(IN VECTOR: BIT VECTOR;
               TABLE: PLA_TABLE)
      return BIT_VECTOR is
    subtype RESULT_TYPE is
        BIT_VECTOR(OUTPUT_COUNT - 1 downto 0);
    variable RESULT: RESULT_TYPE;
    variable ROW: PLA ROW;
    variable MATCH: BOOLEAN;
    variable IN_POS: INTEGER;
  begin
    RESULT := RESULT_TYPE'(others => BIT'( '0' ));
    for I in TABLE'range loop
     ROW := TABLE(I);
     MATCH := TRUE;
      IN_POS := IN_VECTOR'left;
      -- Check for match in input plane
      for J in ROW_SIZE - 1 downto OUTPUT_COUNT loop
        if(ROW(J) = PLA\_ELEMENT'('1')) then
          MATCH := MATCH and
                   (IN_VECTOR(IN_POS) = BIT'('1'));
        elsif(ROW(J) = PLA_ELEMENT'( '0' )) then
          MATCH := MATCH and
                   (IN VECTOR(IN POS) = BIT'('0'));
        else
          null;
                  -- Must be minus ("don't care")
        end if;
        IN_POS := IN_POS - 1;
      end loop;
      -- Set output plane
      if(MATCH) then
        for J in RESULT'range loop
          if(ROW(J) = PLA\_ELEMENT'('1')) then
            RESULT(J) := BIT'('1');
          end if;
        end loop;
      end if;
    end loop;
```

```
return(RESULT);
  end;
end LOCAL;
use WORK.LOCAL.all;
entity PLA_VHDL is
  port(IN_VECTOR: BIT_VECTOR(2 downto 0);
       OUT_VECTOR: out BIT_VECTOR(4 downto 0));
end;
architecture BEHAVIOR of PLA_VHDL is
  constant TABLE: PLA_TABLE := PLA_TABLE"(
       PLA ROW'("--- 10000"),
       PLA_ROW'("-1- 01000"),
       PLA_ROW'("0-0 00101"),
       PLA_ROW'("-1- 00101"),
       PLA_ROW'("1-1 00101"),
       PLA_ROW'("-1- 00010"));
begin
  OUT_VECTOR <= PLA(IN_VECTOR, TABLE);
end BEHAVIOR;
```

Figure A-7 Synthesized Circuit of the PLA



# В

## **Predefined Libraries**

This appendix describes the following packages that are included in an HDL Compiler installation:

- std\_logic\_1164
- std\_logic\_arith
- numeric\_std
- std\_logic\_misc
- Standard Package
- Synopsys Package—ATTRIBUTES

## std\_logic\_1164

The std\_logic\_1164 package is typically installed in the \$SYNOPSYS/packages/IEEE/src/std\_logic\_1164.vhd subdirectory of the Synopsys root directory. The std\_logic\_1164.vhd file has been updated with Synopsys synthesis directives, such as the built\_in HDL compiler directive described below. HDL Compiler automatically uses the built\_in compiler directives to improve performance. You can also write your own built\_in compiler directives.

## built\_in HDL Compiler Directives

The Synopsys IEEE std\_logic\_1164 package contains the following built\_in functions that enable HDL Compiler to quickly and easily interpret your code:

- SYN AND
- SYN OR
- SYN NAND
- SYN NOR
- SYN XOR
- SYN XNOR
- SYN NOT
- SYN BUF

These functions are automatically enabled by HDL Compiler for the respective operators in your code; you do not have to use them. If you create your own <code>built\_in</code> functions, label them with a <code>built\_in</code> compiler directive, as shown in <code>Example B-1</code>. (HDL Compiler interprets a comment as a directive if the first word of the comment is "pragma".) When you use a <code>built\_in</code> compiler directive, HDL Compiler parses but ignores the body of the function and directly substitutes the appropriate logic for the function.

Example B-1 shows the XOR built in function.

## Example B-1 XOR built\_in Function

```
function "XOR" (L, R: STD_LOGIC_VECTOR) return STD_LOGIC_VECTOR is
  -- pragma built_in SYN_XOR
  begin
     if (L = '1') xor (R = '1') then
         return '1';
     else
         return '0';
     end if;
end "XOR";
```

#### Example B-2 shows the SYN\_AND built\_in function.

#### Example B-2 SYN\_AND built\_in Function

```
function "AND" (L, R: STD_LOGIC_VECTOR) return
STD_LOGIC_VECTOR is
  -- pragma built_in SYN_AND
    variable MY_L: STD_LOGIC_VECTOR (L'length-1 downto 0);
    variable MY_R: STD_LOGIC_VECTOR (L'length-1 downto 0);
    variable RESULT: STD_LOGIC_VECTOR (L'length-1 downto 0);
begin
    assert L'length = R'length;
    MY L := L;
   MY_R := R;
    for i in RESULT'range loop
        if (MY L(i) = '1') and (MY R(i) = '1') then
            RESULT(i) := '1';
        else
            RESULT(i) := '0';
        end if;
    end loop;
    return RESULT;
end "AND";
```

## Example B-3 shows the SYN\_NOT built\_in function.

## Example B-3 SYN\_NOT built\_in Function

```
function "NOT" (L: STD_LOGIC_VECTOR) return STD_LOGIC_VECTOR is
  -- pragma built_in SYN_NOT
     variable MY_L: STD_LOGIC_VECTOR (L'length-1 downto 0);
     variable RESULT: STD_LOGIC_VECTOR (L'length-1 downto 0);
    MY_L := L;
    for i in result'range loop
        if (MY_L(i) = '0' \text{ or } MY_L(i) = 'L') then
            RESULT(i) := '1';
        elsif (MY_L(i) = '1' \text{ or } MY_L(i) = 'H') then
            RESULT(i) := '0';
        else
            RESULT(i) := 'X';
        end if;
    end loop;
    return RESULT;
end "NOT";
```

Example B-4 shows the SYN\_FEED\_THRU built\_in function which performs type conversion between unrelated types. The synthesized logic from SYN\_FEED\_THRU wires the single input of a function to the return value.

## Example B-4 SYN\_FEED\_THRU built\_in Function

```
type COLOR is (RED, GREEN, BLUE);
attribute ENUM_ENCODING : STRING;
attribute ENUM_ENCODING of COLOR : type is "01 10 11";
...

function COLOR_TO_BV (L: COLOR) return BIT_VECTOR is
    -- pragma built_in SYN_FEED_THRU
begin
    case L is
        when RED => return "01";
        when GREEN => return "10";
        when BLUE => return "11";
    end case;
end COLOR_TO_BV;
```

## std\_logic\_arith

This section contains the following subsections:

- std\_logic\_arith Package Overview
- Modifying the std\_logic\_arith Package
- std\_logic\_arith Data Types
- UNSIGNED
- SIGNED
- Conversion Functions
- Arithmetic Functions
- Comparison Functions
- Shift Functions
- Multiplication Using Shifts

## std\_logic\_arith Package Overview

The std\_logic\_arith package is typically installed in the \$SYNOPSYS/packages/IEEE/src/std\_logic\_arith.vhd subdirectory of the Synopsys root directory. To use this package in a VHDL source file, include the following lines at the beginning of the source file:

```
library IEEE;
use IEEE.std_logic_arith.all;
```

Functions defined in the std\_logic\_arith package provide conversion to and from the predefined VHDL data type INTEGER, arithmetic, comparison, and BOOLEAN operations. This package lets you perform arithmetic operations and numeric comparisons on array data types. The package defines some arithmetic operators (+, -, \*, ABS) and the relational operators (<, >, <=, >=, =, /=). (IEEE VHDL does not define arithmetic operators for arrays and defines the comparison operators in a manner inconsistent with an arithmetic interpretation of array values.)

The package also defines two major data types of its own: UNSIGNED and SIGNED (see "std\_logic\_arith Data Types" on page B-6 for details). The std\_logic\_arith package is legal VHDL; you can use it for both synthesis and simulation.

You can configure the std\_logic\_arith package to work on any array of single-bit types. You encode single-bit types in 1 bit with the ENUM\_ENCODING attribute.

You can make the vector type (for example, std\_logic\_vector) synonymous with either SIGNED or UNSIGNED. This way, if you plan to use mostly UNSIGNED numbers, you do not need to convert your vector type to call UNSIGNED functions. The disadvantage of making your vector type synonymous with either UNSIGNED or SIGNED is that it causes redefinition of the standard VHDL comparison operators (=, /=, <, >, <=, >=).

Table B-1 shows that the standard comparison functions for BIT\_VECTOR do not match the SIGNED and UNSIGNED functions.

Table B-1	UNSIGNED, SIGNED, and BIT_VECTOR Comparison
	Functions

ARG1	ор	ARG2	UNSIGNED	SIGNED	BIT_VECTOR
"000"	=	"000"	true	true	true
"00"	=	"000"	true	true	false
"100"	=	"0100"	true	false	false
"000"	<	"000"	false	false	false
"00"	<	"000"	false	false	true
"100"	<	"0100"	false	true	false

## Modifying the std\_logic\_arith Package

The std\_logic\_arith package is written in standard VHDL. You can modify or add to it. When you change the content, you must reanalyze the package.

For example, to convert a vector of multivalued logic to an INTEGER, you can write the function shown in Example B-5. This MVL\_TO\_INTEGER function returns the integer value corresponding to the vector when the vector is interpreted as an unsigned (natural) number. If unknown values are in the vector, the return value is -1.

## Example B-5 New Function Based on a std\_logic\_arith Package Function

```
library IEEE;
use IEEE.std_logic_1164.all;
function MVL_TO_INTEGER(ARG : MVL_VECTOR)
  return INTEGER is
  -- pragma built in SYN FEED THRU
  variable uns: UNSIGNED (ARG'range);
begin
    for i in ARG'range loop
        case ARG(i) is
            when '0' | 'L' => uns(i) := '0';
            when '1' | 'H' => uns(i) := '1';
            when others => return -1;
        end case;
    end loop;
    return CONV_INTEGER(uns);
end;
```

Note the use of the CONV\_INTEGER function in Example B-5.

Design Compiler performs almost all synthesis directly from the VHDL descriptions. However, several functions are hard-wired for efficiency. They can be identified by the following comment in their declarations:

```
-- pragma built_in
```

This statement marks functions as special, causing the body of the function to be ignored. Modifying the body does not change the synthesized logic unless you remove the built\_in comment. If you want new functionality, write it by using the built\_in function; this is more efficient than removing the built\_in function and modifying the body of the function.

## std\_logic\_arith Data Types

The std logic arith package defines two data types: UNSIGNED and SIGNED.

```
type UNSIGNED is array (natural range <>) of std_logic;
type SIGNED is array (natural range <>) of std_logic;
```

These data types are similar to the predefined VHDL type BIT\_VECTOR, but the std\_logic\_arith package defines the interpretation of variables and signals of these types as numeric values.

## UNSIGNED

The UNSIGNED data type represents an unsigned numeric value. HDL Compiler interprets the number as a binary representation, with the farthest-left bit being most significant. For example, the decimal number 8 can be represented as

```
UNSIGNED'("1000")
```

When you declare variables or signals of type UNSIGNED, a larger vector holds a larger number. A 4-bit variable holds values up to decimal 15, an 8-bit variable holds values up to 255, and so on. By definition, negative numbers cannot be represented in an UNSIGNED variable. Zero is the smallest value that can be represented.

Example B-6 illustrates some UNSIGNED declarations. The most significant bit is the farthest-left array bound, rather than the high- or low-range value.

## Example B-6 UNSIGNED Declarations

```
variable VAR: UNSIGNED (1 to 10);
   -- 10-bit number
   -- VAR(VAR'left) = VAR(1) is the most significant bit
signal SIG: UNSIGNED (5 downto 0);
   -- 6-bit number
   -- SIG(SIG'left) = SIG(5) is the most significant bit
```

## **SIGNED**

The SIGNED data type represents a signed numeric value. HDL Compiler interprets the number as a 2's-complement binary representation, with the farthest-left bit as the sign bit. For example, you can represent decimal 5 and -5 as

```
SIGNED'("0101") -- represents +5
SIGNED'("1011") -- represents -5
```

When you declare SIGNED variables or signals, a larger vector holds a larger number. A 4-bit variable holds values from –8 to 7; an 8-bit variable holds values from –128 to 127. A SIGNED value cannot hold as large a value as an UNSIGNED value with the same bit-width.

Example B-7 shows some SIGNED declarations. The sign bit is the farthest-left bit, rather than the highest or lowest.

## Example B-7 SIGNED Declarations

```
variable S_VAR: SIGNED (1 to 10);
  -- 10-bit number
  -- S_VAR(S_VAR'left) = S_VAR(1) is the sign bit
signal S_SIG: SIGNED (5 downto 0);
  -- 6-bit number
  -- S_SIG(S_SIG'left) = S_SIG(5) is the sign bit
```

## **Conversion Functions**

The std\_logic\_arith package provides three sets of functions to convert values between its UNSIGNED and SIGNED types and the predefined type INTEGER. This package also provides the std\_logic\_vector. Example B-8 shows the declarations of these conversion functions, with BIT and BIT\_VECTOR types.

## Example B-8 Conversion Functions

```
subtype SMALL INT is INTEGER range 0 to 1;
function CONV_INTEGER(ARG: INTEGER) return INTEGER;
function CONV_INTEGER(ARG: UNSIGNED) return INTEGER;
function CONV_INTEGER(ARG: SIGNED) return INTEGER;
function CONV INTEGER(ARG: STD ULOGIC) return SMALL INT;
function CONV_UNSIGNED(ARG: INTEGER;
                       SIZE: INTEGER) return UNSIGNED;
function CONV_UNSIGNED(ARG: UNSIGNED;
                       SIZE: INTEGER) return UNSIGNED;
function CONV UNSIGNED(ARG: SIGNED;
                       SIZE: INTEGER) return UNSIGNED;
function CONV_UNSIGNED(ARG: STD_ULOGIC;
                      SIZE: INTEGER) return UNSIGNED;
function CONV_SIGNED(ARG: INTEGER;
                     SIZE: INTEGER)
                                     return SIGNED;
function CONV_SIGNED(ARG: UNSIGNED;
                     SIZE: INTEGER)
                                     return SIGNED;
function CONV_SIGNED(ARG: SIGNED;
                                     return SIGNED;
                     SIZE: INTEGER)
function CONV_SIGNED(ARG: STD_ULOGIC;
                     SIZE: INTEGER)
                                     return SIGNED;
function CONV_STD_LOGIC_VECTOR(ARG: INTEGER;
                     SIZE: INTEGER) return STD LOGIC VECTOR;
function CONV_STD_LOGIC_VECTOR(ARG: UNSIGNED;
                     SIZE: INTEGER) return STD_LOGIC_VECTOR;
function CONV STD LOGIC VECTOR(ARG: SIGNED;
                     SIZE: INTEGER) return STD LOGIC VECTOR;
function CONV_STD_LOGIC_VECTOR(ARG: STD_ULOGIC;
                     SIZE: INTEGER) return STD LOGIC VECTOR;
```

There are four versions of each conversion function. The VHDL operator overloading mechanism determines the correct version from the function call's argument types.

The CONV\_INTEGER functions convert an argument of type INTEGER, UNSIGNED, SIGNED, or STD\_ULOGIC to an INTEGER return value. The CONV\_UNSIGNED and CONV\_SIGNED functions convert an argument of type INTEGER, UNSIGNED, SIGNED, or STD\_ULOGIC to an UNSIGNED or SIGNED return value whose bit width is SIZE.

The CONV\_INTEGER functions have a limitation on the size of operands. VHDL defines INTEGER values as being between –2147483647 and 2147483647. This range corresponds to a 31-bit UNSIGNED value or a 32-bit SIGNED value. You cannot convert an argument outside this range to an INTEGER.

The CONV\_UNSIGNED and CONV\_SIGNED functions each require two operands. The first operand is the value converted. The second operand is an INTEGER that specifies the expected size of the converted result. For example, the following function call returns a 10-bit UNSIGNED value representing the value in sig.

```
ten_unsigned_bits := CONV_UNSIGNED(sig, 10);
```

If the value passed to CONV\_UNSIGNED or CONV\_SIGNED is smaller than the expected bit-width (such as representing the value 2 in a 24-bit number), the value is bit-extended appropriately. HDL Compiler places 0s in the more significant (left) bits for an UNSIGNED return value, and it uses sign extension for a SIGNED return value.

You can use the conversion functions to extend a number's bit-width even if conversion is not required. For example,

```
CONV_SIGNED(SIGNED'("110"), 8) -> "111111110"
```

An UNSIGNED or SIGNED return value is truncated when its bit-width is too small to hold the ARG value. For example,

```
CONV_SIGNED(UNSIGNED'("1101010"), 3) -> "010"
```

## **Arithmetic Functions**

The std\_logic\_arith package provides arithmetic functions for use with combinations of the Synopsys UNSIGNED and SIGNED data types and the predefined types STD\_ULOGIC and INTEGER. These functions produce adders and subtracters.

There are two sets of arithmetic functions: binary functions having two arguments, such as A+B or A\*B, and unary functions having one argument, such as –A. Example B-9 and Example B-10 show the declarations for these functions.

#### Example B-9 Binary Arithmetic Functions

```
function "+"(L: UNSIGNED; R: UNSIGNED) return UNSIGNED;
function "+"(L: SIGNED; R: SIGNED) return SIGNED;
function "+"(L: UNSIGNED; R: SIGNED) return SIGNED;
function "+"(L: SIGNED; R: UNSIGNED) return SIGNED;
function "+"(L: UNSIGNED; R: INTEGER) return UNSIGNED;
function "+"(L: INTEGER; R: UNSIGNED) return UNSIGNED;
function "+"(L: SIGNED; R: INTEGER) return SIGNED;
function "+"(L: INTEGER; R: SIGNED) return SIGNED;
function "+"(L: UNSIGNED; R: STD_ULOGIC) return UNSIGNED;
function "+"(L: STD_ULOGIC; R: UNSIGNED) return UNSIGNED;
function "+"(L: SIGNED; R: STD_ULOGIC) return SIGNED;
function "+"(L: STD_ULOGIC; R: SIGNED) return SIGNED;
function "+"(L: UNSIGNED; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "+"(L: SIGNED; R: SIGNED) return STD_LOGIC_VECTOR;
function "+"(L: UNSIGNED; R: SIGNED) return STD_LOGIC_VECTOR;
function "+"(L: SIGNED; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "+"(L: UNSIGNED; R: INTEGER) return STD_LOGIC_VECTOR;
function "+"(L: INTEGER; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "+"(L: SIGNED; R: INTEGER) return STD_LOGIC_VECTOR;
function "+"(L: INTEGER; R: SIGNED) return STD_LOGIC_VECTOR;
function "+"(L: UNSIGNED; R: STD_ULOGIC) return STD_LOGIC_VECTOR;
function "+"(L: STD_ULOGIC; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "+"(L: SIGNED; R: STD_ULOGIC) return STD_LOGIC_VECTOR;
function "+"(L: STD_ULOGIC; R: SIGNED) return STD_LOGIC_VECTOR;
function "-"(L: UNSIGNED; R: UNSIGNED) return UNSIGNED;
function "-"(L: SIGNED; R: SIGNED) return SIGNED;
function "-"(L: UNSIGNED; R: SIGNED) return SIGNED;
function "-"(L: SIGNED; R: UNSIGNED) return SIGNED;
function "-"(L: UNSIGNED; R: INTEGER) return UNSIGNED;
function "-"(L: INTEGER; R: UNSIGNED) return UNSIGNED;
function "-"(L: SIGNED; R: INTEGER) return SIGNED;
function "-"(L: INTEGER; R: SIGNED) return SIGNED;
function "-"(L: UNSIGNED; R: STD_ULOGIC) return UNSIGNED;
function "-"(L: STD_ULOGIC; R: UNSIGNED) return UNSIGNED;
function "-"(L: SIGNED; R: STD_ULOGIC) return SIGNED;
function "-"(L: STD_ULOGIC; R: SIGNED) return SIGNED;
function "-"(L: UNSIGNED; R: UNSIGNED) return STD LOGIC VECTOR;
function "-"(L: SIGNED; R: SIGNED) return STD_LOGIC_VECTOR;
function "-"(L: UNSIGNED; R: SIGNED) return STD_LOGIC_VECTOR;
function "-"(L: SIGNED; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "-"(L: UNSIGNED; R: INTEGER) return STD_LOGIC_VECTOR;
function "-"(L: INTEGER; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "-"(L: SIGNED; R: INTEGER) return STD_LOGIC_VECTOR;
function "-"(L: INTEGER; R: SIGNED) return STD_LOGIC_VECTOR;
function "-"(L: UNSIGNED; R: STD_ULOGIC) return STD_LOGIC_VECTOR;
function "-"(L: STD_ULOGIC; R: UNSIGNED) return STD_LOGIC_VECTOR;
function "-"(L: SIGNED; R: STD_ULOGIC) return STD_LOGIC_VECTOR;
function "-"(L: STD_ULOGIC; R: SIGNED) return STD_LOGIC_VECTOR;
function "*"(L: UNSIGNED; R: UNSIGNED) return UNSIGNED;
function "*"(L: SIGNED; R: SIGNED) return SIGNED;
function "*"(L: SIGNED; R: UNSIGNED) return SIGNED;
function "*"(L: UNSIGNED; R: SIGNED) return SIGNED;
```

## Example B-10 Unary Arithmetic Functions

```
function "+"(L: UNSIGNED) return UNSIGNED;
function "+"(L: SIGNED) return SIGNED;
function "-"(L: SIGNED) return SIGNED;
function "ABS"(L: SIGNED) return SIGNED;
```

The binary and unary arithmetic functions in Example B-9 and Example B-10 determine the width of their return values, as follows:

- 1. When only one UNSIGNED or SIGNED argument is present, the width of the return value is the same as the width of that argument.
- 2. When both arguments are either UNSIGNED or SIGNED, the width of the return value is the larger of the two argument widths. An exception is that when an UNSIGNED number is added to or subtracted from a SIGNED number that is the same size or smaller, the return value is a SIGNED number 1 bit wider than the UNSIGNED argument. This size guarantees that the return value is large enough to hold any (positive) value of the UNSIGNED argument.

Table B-2 illustrates the number of bits returned by addition (+) and subtraction (–).

```
signal U4: UNSIGNED (3 downto 0);
signal U8: UNSIGNED (7 downto 0);
signal S4: SIGNED (3 downto 0);
signal S8: SIGNED (7 downto 0);
```

Table B-2 Number of Bits Returned by Addition and Subtraction

+ or -	U4	U8	S4	S8
U4	4	8	5	8
U8	8	8	9	9
S4	5	9	4	8
S8	8	9	8	8

In some circumstances, you might need to obtain a carry-out bit from the addition or subtraction operation. To do this, extend the larger operand by 1 bit. The high bit of the return value is the carry, as illustrated in Example B-11.

## Example B-11 Using the Carry-Out Bit

```
process
   variable a, b, sum: UNSIGNED (7 downto 0);
   variable temp: UNSIGNED (8 downto 0);
   variable carry: BIT;
begin
   temp := CONV_UNSIGNED(a,9) + b;
   sum := temp(7 downto 0);
   carry := temp(8);
end process;
```

## **Comparison Functions**

The std\_logic\_arith package provides functions for comparing UNSIGNED and SIGNED data types with each other and with the predefined type INTEGER. HDL Compiler compares the numeric values of the arguments, returning a BOOLEAN value. For example, the following expression evaluates true.

```
UNSIGNED'("001") > SIGNED'("111")
```

The std\_logic\_arith comparison functions are similar to the built-in VHDL comparison functions. The only difference is that the std\_logic\_arith functions accommodate signed numbers and varying bit-widths. The predefined VHDL comparison functions perform bitwise comparisons and do not have the correct semantics for comparing numeric values (see "Ordering of Enumerated Types Using the ENUM\_ENCODING attribute" on page 2-52).

These functions produce comparators. The function declarations are listed in two groups: ordering operators ("<", "<=", ">="), shown in Example B-12, and equality functions ("=", "/="), shown in Example B-13.

#### Example B-12 Ordering Functions

```
function "<"(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "<"(L: SIGNED; R: SIGNED) return BOOLEAN;
function "<"(L: UNSIGNED; R: SIGNED) return BOOLEAN;
function "<"(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "<"(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "<"(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "<"(L: SIGNED; R: INTEGER) return BOOLEAN;
function "<"(L: SIGNED; R: INTEGER) return BOOLEAN;
function "<"(L: SIGNED; R: INTEGER) return BOOLEAN;
function "<="(L: SIGNED; R: SIGNED) return BOOLEAN;
function "<="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "<="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "<="(L: INTEGER; R: SIGNED) return BOOLEAN;
function "<="(L: INTEGER; R: SIGNED) return BOOLEAN;
function "<="(L: SIGNED; R: INTEGER) return BOOLEAN;
function ">="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: SIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: SIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: SIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: SIGNED) return BOOLEAN;
function ">="(L: SIGNED; R: SIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function ">="(L: UNSIGNED; R: UNSIGNED) ret
```

## Example B-13 Equality Functions

```
function "="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "="(L: SIGNED; R: SIGNED)
                                      return BOOLEAN;
function "="(L: UNSIGNED; R: SIGNED)
                                      return BOOLEAN;
function "="(L: SIGNED; R: UNSIGNED) return BOOLEAN;
function "="(L: UNSIGNED; R: INTEGER) return BOOLEAN;
function "="(L: INTEGER; R: UNSIGNED) return BOOLEAN;
function "="(L: SIGNED; R: INTEGER) return BOOLEAN;
                                      return BOOLEAN;
function "="(L: INTEGER; R: SIGNED)
function "/="(L: UNSIGNED; R: UNSIGNED) return BOOLEAN;
function "/="(L: SIGNED; R: SIGNED) return BOOLEAN;
function "/="(L: UNSIGNED; R: SIGNED)
                                       return BOOLEAN;
function "/="(L: SIGNED; R: UNSIGNED) return BOOLEAN;
function "/="(L: UNSIGNED; R: INTEGER) return BOOLEAN;
function "/="(L: INTEGER; R: UNSIGNED) return BOOLEAN;
function "/="(L: SIGNED; R: INTEGER) return BOOLEAN;
function "/="(L: INTEGER; R: SIGNED)
                                       return BOOLEAN;
```

## **Shift Functions**

The std\_logic\_arith package provides functions for shifting the bits in SIGNED and UNSIGNED numbers. These functions produce shifters. Example B-14 shows the shift function declarations. For a list of shift and rotate operators, see "Operators" on page C-7.

## Example B-14 Shift Functions

The SHL function shifts the bits of its argument ARG left by COUNT bits. SHR shifts the bits of its argument ARG right by COUNT bits.

The SHL functions work the same for both UNSIGNED and SIGNED values of ARG, shifting in zero bits as necessary. The SHR functions treat UNSIGNED and SIGNED values differently. If ARG is an UNSIGNED number, vacated bits are filled with 0s; if ARG is a SIGNED number, the vacated bits are copied from the ARG sign bit.

Example B-15 shows some shift function calls and their return values.

#### Example B-15 Shift Operations

```
variable U1, U2: UNSIGNED (7 downto 0);
variable S1, S2: SIGNED (7 downto 0);
variable COUNT: UNSIGNED (1 downto 0);
U1 := "01101011";
U2 := "11101011";
S1 := "01101011";
S2 := "11101011";
COUNT := CONV_UNSIGNED(ARG => 3, SIZE => 2);
SHL(U1, COUNT) = "01011000"
SHL(S1, COUNT) = "01011000"
SHL(U2, COUNT) = "01011000"
SHL(S2, COUNT) = "01011000"
SHR(U1, COUNT) = "00001101"
SHR(S1, COUNT) = "00001101"
SHR(U2, COUNT) = "00011101"
SHR(S2, COUNT) = "111111101"
```

# **Multiplication Using Shifts**

You can use shift operations for simple multiplication and division of UNSIGNED numbers if you are multiplying or dividing by a power of 2.

For example, to divide the following UNSIGNED variable U by 4, use this syntax:

```
variable U: UNSIGNED (7 downto 0) := "11010101";
variable quarter_U: UNSIGNED (5 downto 0);
quarter_U := SHR(U, "01");
```

# numeric\_std

This section describes HDL Compiler support for the numeric\_std, the IEEE Standard VHDL Synthesis Package, which defines numeric types and arithmetic functions.

This section contains the following:

- Unsupported Constructs and Operators
- Using the numeric std Package
- numeric std Data Types
- Conversion Functions
- Resize Functions

- Arithmetic Functions
- Comparison Functions
- Defining Logical Operators Functions
- Shift and Rotate Functions
- Shift and Rotate Operators

#### Note:

The numeric\_std package and the std\_logic\_arith package have overlapping operations. Use of these two packages simultaneously during analysis could cause type mismatches.

# **Unsupported Constructs and Operators**

HDL Compiler does not support the following numeric\_std package component:

• TO\_01 function as a simulation construct

# Using the numeric\_std Package

The numeric\_std package is typically installed in the Synopsys root directory. Access it with the following statement in your VHDL code:

```
library IEEE;
use IEEE.numeric std.all;
```

# numeric\_std Data Types

The numeric\_std package defines the following two data types in the same way that the std\_logic\_arith package does:

USIGNED

```
type UNSIGNED is array (NATURAL range <>) of STD_LOGIC;
```

See "UNSIGNED" on page B-7 for more information.

SIGNED

```
type SIGNED is array (NATURAL range <>) of STD_LOGIC;
```

See "SIGNED" on page B-7 for more information.

#### **Conversion Functions**

The numeric\_std package provides functions to convert values between its UNSIGNED and SIGNED types. Table B-3 shows the declarations of these conversion functions.

Table B-3 numeric std Conversion Functions

Parameters			
Operator	Arg	Size	Return type
TO_INTEGER	UNSIGNED		NATURAL
TO_INTEGER	SIGNED		INTEGER
TO_UNSIGNED	INTEGER	NATURAL	UNSIGNED
TO_SIGNED	INTEGER	NATURAL	SIGNED

TO\_INTEGER, TO\_SIGNED, and TO\_UNSIGNED are similar to CONV\_INTEGER, CONV\_SIGNED, and CONV\_UNSIGNED in std\_logic\_arith (see "Conversion Functions" on page B-8).

#### **Resize Functions**

The resize function numeric std supports is shown in the declarations in Table B-4.

Table B-4 numeric\_std Resize Functions

Parameters			
Operator	Arg	Size	Return type
RESIZE	NATURAL	NATURAL	SIGNED
RESIZE	NATURAL	NATURAL	UNSIGNED

#### **Arithmetic Functions**

The numeric\_std package provides arithmetic functions for use with combinations of Synopsys UNSIGNED and SIGNED data types and the predefined types STD\_ULOGIC and INTEGER. These functions produce adders and subtracters.

There are two sets of arithmetic functions, which the numeric\_std package defines in the same way the std\_logic\_arith package does (see "Arithmetic Functions" on page B-9 for more information):

· Binary functions having two arguments, such as

A+B

A\*B

Table B-5 shows the declarations for these functions.

• Unary functions having one argument, such as

-A

abs A

Table B-5 numeric\_std Binary Arithmetic Functions

	Parameters		
Operator	L	R	Return type
+	UNSIGNED	UNSIGNED	UNSIGNED
+	SIGNED	SIGNED	SIGNED
+	UNSIGNED	NATURAL	UNSIGNED
+	NATURAL	UNSIGNED	UNSIGNED
+	INTEGER	SIGNED	SIGNED
+	SIGNED	INTEGER	SIGNED
_	UNSIGNED	UNSIGNED	UNSIGNED
_	SIGNED	SIGNED	SIGNED
_	UNSIGNED	NATURAL	UNSIGNED
_	NATURAL	UNSIGNED	UNSIGNED
_	SIGNED	INTEGER	SIGNED
_	INTEGER	SIGNED	SIGNED
*	UNSIGNED	UNSIGNED	UNSIGNED
*	SIGNED	SIGNED	SIGNED

Table B-5 numeric\_std Binary Arithmetic Functions (Continued)

Parameters			
Operator	L	R	Return type
*	UNSIGNED	NATURAL	UNSIGNED
*	NATURAL	UNSIGNED	UNSIGNED
*	SIGNED	INTEGER	SIGNED
*	INTEGER	SIGNED	SIGNED

Table B-6 shows the declarations for unary functions.

Table B-6 numeric\_std Unary Arithmetic Functions

Operator	Arg	Return type
abs	SIGNED	SIGNED
-	SIGNED	SIGNED

# **Comparison Functions**

The numeric\_std package provides functions to compare UNSIGNED and SIGNED data types with each other and with the predefined type INTEGER. HDL Compiler compares the numeric values of the arguments and returns a BOOLEAN value.

These functions produce comparators. The function declarations are listed in two groups:

- Ordering functions (<, <=, >, >=)
- Equality functions (=, /=)

Table B-7 shows the ordering functions.

Table B-7 numeric\_std Ordering Functions

Parameters			
Operator	L	R	Return type
>	UNSIGNED	UNSIGNED	BOOLEAN

Table B-7 numeric\_std Ordering Functions (Continued)

Parameters			
Operator	L	R	Return type
>	SIGNED	SIGNED	BOOLEAN
>	NATURAL	UNSIGNED	BOOLEAN
>	INTEGER	SIGNED	BOOLEAN
>	UNSIGNED	NATURAL	BOOLEAN
>	SIGNED	INTEGER	BOOLEAN
<	UNSIGNED	UNSIGNED	BOOLEAN
<	SIGNED	SIGNED	BOOLEAN
<	NATURAL	UNSIGNED	BOOLEAN
<	INTEGER	SIGNED	BOOLEAN
<	UNSIGNED	NATURAL	BOOLEAN
<	SIGNED	INTEGER	BOOLEAN
<=	UNSIGNED	UNSIGNED	BOOLEAN
<=	SIGNED	SIGNED	BOOLEAN
<=	NATURAL	UNSIGNED	BOOLEAN
<=	INTEGER	SIGNED	BOOLEAN
<=	UNSIGNED	NATURAL	BOOLEAN
<=	SIGNED	INTEGER	BOOLEAN
>=	UNSIGNED	UNSIGNED	BOOLEAN
>=	SIGNED	SIGNED	BOOLEAN
>=	NATURAL	UNSIGNED	BOOLEAN
>=	INTEGER	SIGNED	BOOLEAN

Table B-7 numeric\_std Ordering Functions (Continued)

Parameters			
Operator	L	R	Return type
>=	UNSIGNED	NATURAL	BOOLEAN
>=	SIGNED	INTEGER	BOOLEAN

Table B-8 shows the equality functions.

Table B-8 numeric\_std Equality Functions

Parameters			
Operator	L	R	Return type
=	UNSIGNED	UNSIGNED	BOOLEAN
=	SIGNED	SIGNED	BOOLEAN
=	NATURAL	UNSIGNED	BOOLEAN
=	INTEGER	SIGNED	BOOLEAN
=	UNSIGNED	NATURAL	BOOLEAN
=	SIGNED	INTEGER	BOOLEAN
/=	UNSIGNED	UNSIGNED	BOOLEAN
/=	SIGNED	SIGNED	BOOLEAN
/=	NATURAL	UNSIGNED	BOOLEAN
/=	INTEGER	SIGNED	BOOLEAN
/=	UNSIGNED	NATURAL	BOOLEAN
/=	SIGNED	INTEGER	BOOLEAN

# **Defining Logical Operators Functions**

The numeric\_std package provides functions that define all of the logical operators: NOT, AND, OR, NAND, NOR, XOR, and XNOR. These functions work just like similar functions in std\_logic\_1164, except that they operate on SIGNED and UNSIGNED values rather than on STD\_LOGIC\_VECTOR values. Table B-9 shows these function declarations.

Table B-9 numeric\_std Logical Operators Functions

Parameters			
Operator	L	R	Return type
not	UNSIGNED		UNSIGNED
and	UNSIGNED	UNSIGNED	UNSIGNED
or	UNSIGNED	UNSIGNED	UNSIGNED
nand	UNSIGNED	UNSIGNED	UNSIGNED
nor	UNSIGNED	UNSIGNED	UNSIGNED
xor	UNSIGNED	UNSIGNED	UNSIGNED
xnor	UNSIGNED	UNSIGNED	UNSIGNED
not	SIGNED		SIGNED
and	SIGNED	SIGNED	SIGNED
or	SIGNED	SIGNED	SIGNED
nand	SIGNED	SIGNED	SIGNED
nor	SIGNED	SIGNED	SIGNED
xor	SIGNED	SIGNED	SIGNED
xnor	SIGNED	SIGNED	SIGNED

#### **Shift and Rotate Functions**

The numeric\_std package provides functions for shifting the bits in UNSIGNED and SIGNED numbers. These functions produce shifters. Table B-10 shows the shift function declarations.

Table B-10 numeric std Shift and Rotate Functions

	Parameters		
Operator	Arg	Count	Return type
SHIFT_LEFT	UNSIGNED	NATURAL	UNSIGNED
SHIFT_RIGHT	UNSIGNED	NATURAL	UNSIGNED
SHIFT_LEFT	SIGNED	NATURAL	SIGNED
SHIFT_RIGHT	SIGNED	NATURAL	SIGNED
ROTATE_LEFT	UNSIGNED	NATURAL	UNSIGNED
ROTATE_RIGHT	UNSIGNED	NATURAL	UNSIGNED
ROTATE_LEFT	SIGNED	NATURAL	SIGNED
ROTATE_RIGHT	SIGNED	NATURAL	SIGNED

The SHIFT\_LEFT function shifts the bits of its argument ARG left by COUNT bits. SHIFT\_RIGHT shifts the bits of its argument ARG right by COUNT bits.

The SHIFT\_LEFT functions work the same for both UNSIGNED and SIGNED values of ARG, shifting in zero bits as necessary. The SHIFT\_RIGHT functions treat UNSIGNED and SIGNED values differently:

- If ARG is an UNSIGNED number, vacated bits are filled with 0s.
- If ARG is a SIGNED number, the vacated bits are copied from the ARG sign bit.

Example B-17 on page B-26 shows some shift function calls and their return values.

The ROTATE\_LEFT and ROTATE\_RIGHT functions are similar to the shift functions. Example B-16 on page B-25 shows some rotate function declarations.

# **Shift and Rotate Operators**

The numeric\_std package provides shift operators and rotate operators, which work in the same way that shift functions and rotate functions do. The shift operators are sll, srl, sla, and sra. Table B-11 shows some shift and rotate operator declarations. Example B-16 on page B-25 includes some shift and rotate operators.

Table B-11 numeric\_std Shift and Rotate Operators

Parameters			
Operator	Arg	Count	Return type
sll	UNSIGNED	INTEGER	UNSIGNED
sll	SIGNED	INTEGER	SIGNED
srl	UNSIGNED	INTEGER	UNSIGNED
srl	SIGNED	INTEGER	SIGNED
rol	UNSIGNED	INTEGER	UNSIGNED
rol	SIGNED	INTEGER	SIGNED
ror	UNSIGNED	INTEGER	UNSIGNED
ror	SIGNED	INTEGER	SIGNED

# Example B-16 Some numeric\_std Shift and Rotate Functions and Shift and Rotate Operators

```
Variable U1, U2: UNSIGNED (7 downto 0);
Variable S1, S2: SIGNED (7 downto 0);
Variable COUNT: NATURAL;
U1 := "01101011";
U2 := "11101011";
S1 := "01101011";
S2 := "11101011";
COUNT := 3;
SHIFT LEFT (U1, COUNT) = "01011000"
SHIFT_LEFT (S1, COUNT) = "01011000"
SHIFT_LEFT (U2, COUNT) = "01011000"
SHIFT_LEFT (S2, COUNT) = "01011000"
SHIFT_RIGHT (U1, COUNT) = "00001101"
SHIFT_RIGHT (S1, COUNT) = "00001101"
SHIFT_RIGHT (U2, COUNT) = "00011101"
SHIFT_RIGHT (S2, COUNT) = "111111101"
ROTATE_LEFT (U1, COUNT) = "01011011"
ROTATE_LEFT (S1, COUNT) = "01011011"
ROTATE_LEFT (U2, COUNT) = "01011111"
ROTATE_LEFT (S2, COUNT) = "01011111"
ROTATE_RIGHT (U1, COUNT) = "01101101"
ROTATE_RIGHT (S1, COUNT) = "01101101"
ROTATE_RIGHT (U2, COUNT) = "01111101"
ROTATE_RIGHT (S2, COUNT) = "01111101"
U1 sll COUNT = "01011000"
S1 sll COUNT = "01011000"
U2 sll COUNT = "01011000"
S2 sll COUNT = "01011000"
U1 srl COUNT = "00001101"
S1 srl COUNT = "00001101"
U2 srl COUNT = "00011101"
S2 srl COUNT = "111111101"
U1 rol COUNT = "01011011"
S1 rol COUNT = "01011011"
U2 rol COUNT = "01011111"
S2 rol COUNT = "01011111"
U1 ror COUNT = "01101101"
S1 ror COUNT = "01101101"
U2 ror COUNT = "01111101"
S2 ror COUNT = "01111101"
```

# std\_logic\_misc

The std\_logic\_misc package is typically installed in the \$SYNOPSYS/packages/IEEE/src/std\_logic\_misc.vhd directory. It declares the primary data types that the Synopsys VSS tools support.

Boolean reduction functions take one argument (an array of bits) and return a single bit. For example, the AND reduction of "101" is "0", the logical AND of all 3 bits.

Several functions in the std\_logic\_misc package provide Boolean reduction operations for the predefined type STD\_LOGIC\_VECTOR. Example B-17 shows the declarations of these functions.

#### Example B-17 Boolean Reduction Functions

```
function AND_REDUCE (ARG: STD_LOGIC_VECTOR) return UX01; function NAND_REDUCE (ARG: STD_LOGIC_VECTOR) return UX01; function OR_REDUCE (ARG: STD_LOGIC_VECTOR) return UX01; function NOR_REDUCE (ARG: STD_LOGIC_VECTOR) return UX01; function XOR_REDUCE (ARG: STD_LOGIC_VECTOR) return UX01; function XNOR_REDUCE (ARG: STD_LOGIC_VECTOR) return UX01; function AND_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function NAND_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function OR_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function NOR_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function XOR_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function XOR_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function XOR_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01; function XNOR_REDUCE (ARG: STD_ULOGIC_VECTOR) return UX01;
```

These functions combine the bits of the STD\_LOGIC\_VECTOR, as the name of the function indicates. For example, XOR\_REDUCE returns the XOR of all bits in ARG. Example B-18 shows some reduction function calls and their return values.

#### Example B-18 Boolean Reduction Operations

```
AND_REDUCE("111") = '1'
AND_REDUCE("011") = '0'

OR_REDUCE("000") = '0'

XOR_REDUCE("100") = '1'

XOR_REDUCE("101") = '0'

NAND_REDUCE("111") = '0'

NAND_REDUCE("011") = '1'

NOR_REDUCE("000") = '1'

XOR_REDUCE("100") = '0'

XNOR_REDUCE("100") = '0'

XNOR_REDUCE("100") = '1'

XNOR_REDUCE("101") = '1'
```

# **Standard Package**

The STANDARD package of data types is included in all VHDL source files by an implicit use clause.

HDL Compiler implements the synthesizable subset of the STANDARD package listed in Example B-19.

#### Example B-19 HDL Compiler STANDARD Package

```
package STANDARD is
  type BOOLEAN is (FALSE, TRUE);
  type BIT is ('0', '1');
  type CHARACTER is (
    NUL, SOH, STX, ETX, EOT, ENQ, ACK, BEL,
    BS, HT, LF, VT, FF, CR, SO, SI, DLE, DC1, DC2, DC3, DC4, NAK, SYN, ETB,
    CAN, EM, SUB, ESC, FSP, GSP, RSP, USP,
    ' ', '!', '"', '#', '$', '%', '&', ''',
    '(', ')', '*', '+', ',', '-', '.', '/',
    '0', '1', '2', '3', '4', '5', '6', '7',
     18', 19', 1:', 1;', 1<', 1=', 1>', 1?',
    '@', 'A', 'B', 'C', 'D', 'E', 'F', 'G',
     'H', 'I', 'J', 'K', 'L', 'M', 'N', 'O',
     'P', 'Q', 'R', 'S', 'T', 'U', 'V', 'W',
    'X', 'Y', 'Z', '[', '\', ']', '^', '_',
     ''', 'a', 'b', 'c', 'd', 'e', 'f', 'g',
    'h', 'i', 'j', 'k', 'l', 'm', 'n', 'o', 'p', 'q', 'r', 's', 't', 'u', 'v', 'w', 'x', 'y', 'z', '{', '|', '}', '~', DEL);
  type INTEGER is range -2147483647 to 2147483647;
  subtype NATURAL is INTEGER range 0 to 2147483647;
  subtype POSITIVE is INTEGER range 1 to 2147483647;
  type STRING is array (POSITIVE range <>)
        of CHARACTER;
  type BIT_VECTOR is array (NATURAL range <>)
        of BIT;
end STANDARD;
```

This section describes the following synthesizable data types:

- Data Type BOOLEAN
- Data Type BIT
- Data Type CHARACTER
- Data Type INTEGER
- Data Type NATURAL
- Data Type POSITIVE
- Data Type STRING
- Data Type BIT\_VECTOR

# **Data Type BOOLEAN**

The BOOLEAN data type is actually an enumerated type with two values, false and true, where false < true. Logical functions, such as equality (=) and comparison (<) functions, return a BOOLEAN value.

Convert a BIT value to a BOOLEAN value as follows:

```
BOOLEAN_VAR := (BIT_VAR = '1');
```

# **Data Type BIT**

The BIT data type represents a binary value as one of two characters, '0' or '1'. Logical operations such as "and" can take and return BIT values.

Convert a BOOLEAN value to a BIT value as follows:

```
if (BOOLEAN_VAR) then
  BIT_VAR := '1';
else
  BIT_VAR := '0';
end if;
```

# Data Type CHARACTER

The CHARACTER data type enumerates the ASCII character set. Nonprinting characters are represented by a three-letter name, such as NUL for the null character. Printable characters are represented by themselves, in single quotation marks, as follows:

```
variable CHARACTER_VAR: CHARACTER;
. . .
CHARACTER_VAR := 'A';
```

## **Data Type INTEGER**

The INTEGER data type represents positive and negative whole numbers.

## **Data Type NATURAL**

The NATURAL data type is a subtype of INTEGER that is used for representing natural (nonnegative) numbers.

# **Data Type POSITIVE**

The POSITIVE data type is a subtype of INTEGER that is used for representing positive (nonzero, nonnegative) numbers.

# **Data Type STRING**

The STRING data type is an unconstrained array of characters. A STRING value is enclosed in double quotation marks, as follows:

```
variable STRING_VAR: STRING(1 to 7);
. . .
STRING_VAR := "Rosebud";
```

# Data Type BIT\_VECTOR

The BIT VECTOR data type represents an array of BIT values.

# Synopsys Package—ATTRIBUTES

The ATTRIBUTES package declares all supported synthesis attributes; the source code is typically installed in the Synopsys libraries \$SYNOPSYS/packages/synopsys/src/attributes.vhd directory. Supported attributes include

- Design Compiler constraint attributes, described in "Synopsys Defined Attributes" on page 6-8
- State vector attribute, described in "State Vector Attribute" on page 2-47

• Enumeration encoding attribute, described in "Enumeration Encoding" on page 2-25

Reference this package when you use synthesis attributes:

library SYNOPSYS;
use SYNOPSYS.ATTRIBUTES.all;

# C

# **VHDL Constructs**

Many VHDL language constructs, although useful for simulation and other stages in the design process, are not relevant to synthesis. Because these constructs cannot be synthesized, HDL Compiler does not support them.

This appendix provides a list of synthesizable VHDL language constructs, with the level of support for each, followed by a list of VHDL reserved words.

This appendix includes the following sections:

- VHDL Construct Support
- Predefined Language Environment
- VHDL Reserved Words

# **VHDL Construct Support**

A construct can be fully supported, ignored, or unsupported. Ignored and unsupported constructs are defined as follows:

- Ignored means that the construct is allowed in the VHDL source but is ignored by HDL Compiler.
- Unsupported means that the construct is not allowed in the VHDL source and that HDL Compiler flags it as an error. If errors are in a VHDL description, the description is not read.

The following subsections describe the constructs:

- Configurations
- Design Units
- Data Types
- Declarations
- Specifications
- Names
- Operators
- Operands and Expressions
- Sequential Statements
- Concurrent Statements
- Lexical Elements

# **Configurations**

The HDL Compiler tool supports standalone, nested, and embedded configurations. For details, see "Configuration Support" on page 1-18.

# **Design Units**

entity

The entity statement part is ignored.

Default values for ports are ignored.

#### generics

In addition to supporting integer-type generics, HDL Compiler adds support for the following types: bit, bit\_vector, std\_ulogic, std\_ulogic\_vector, std\_logic, std\_logic\_vector, signed, and unsigned. HDL Compiler also supports integer arrays and strings as generics.

#### architecture

Multiple architectures are allowed. Global signal interaction between architectures is unsupported.

#### configuration

Configuration declarations and block configurations are supported, but only to specify the top-level architecture for a top-level entity. See "Configuration Support" on page 1-18.

The use clauses and attribute specifications are unsupported.

#### package

Packages are fully supported.

#### library

Libraries and separate compilation are supported.

#### subprogram

Default values for parameters are unsupported. Assigning to indexes and slices of unconstrained out parameters is unsupported, unless the actual parameter is an identifier.

Subprogram recursion is unsupported if the recursion is not bounded by a static value.

Resolution functions are supported for wired-logic and three-state functions only.

Subprograms can be declared only in packages and in the declaration part of an architecture.

# **Data Types**

#### enumeration

Enumeration is fully supported.

#### real

Constant real data types are fully supported.

#### integer

Infinite-precision arithmetic is unsupported.

Integer types are automatically converted to bit vectors whose width is as small as possible to accommodate all possible values of the type's range. The type's range can be either in unsigned binary for nonnegative ranges or in 2's-complement form for ranges that include negative numbers.

#### physical

Physical type declarations are ignored. The use of physical types is ignored in delay specifications.

#### floating

Floating-point type declarations are ignored. The use of floating-point types is unsupported except for floating-point constants used with Synopsys defined attributes.

#### array

Array ranges and indexes other than integers are unsupported.

By default, the tool infers MUX\_OP cells for arrays during synthesis.

Multidimensional arrays are supported.

#### record

Record data types are fully supported.

#### access

Access type declarations are ignored, and the use of access types is unsupported.

#### file

File type declarations are ignored, and the use of file types is unsupported.

#### incomplete type declarations

Incomplete type declarations are unsupported.

#### **Declarations**

#### constant

Constant declarations are supported except for deferred constant declarations.

#### signal

Register and bus declarations are unsupported. Resolution functions are supported for wired and three-state functions only. Declarations other than from a globally static type are unsupported. Initial values are unsupported.

#### variable

Declarations other than from a globally static type are unsupported. Initial values are unsupported.

#### shared variable

Variable shared by different processes. Shared variables are fully supported.

#### file

File declarations are unsupported.

#### interface

Buffer and linkage are translated to out and inout, respectively.

#### alias

Alias declarations are supported.

#### component

Component declarations that list a name other than a valid entity name are unsupported. However, HDL Compiler allows components to be directly instantiated in the design without a component declaration. See "Direct Instantiation of Components" on page 2-10.

#### attribute

Attribute declarations are fully supported, but the use of user-defined attributes is unsupported.

#### group

HDL Compiler supports VHDL-93 group declarations. This allows you to create groups of named entities. One useful application of this feature is that you can apply attributes to the group as a whole instead of referencing individual signals. See "Groups" on page 2-23.

# **Specifications**

#### attribute

HDL Compiler supports the `leftof, `rightof, pos, val, succ, and pred attributes for enum data types. HDL Compiler supports the pos, val, succ, and pred attributes for integer and range data types. HDL Compiler supports the 'high(n),'low(n),'left(n),'right(n), and 'length(n) attributes on multidimensional arrays. Others and all are unsupported in attribute specifications. User-defined attributes can be specified, but the use of user-defined attributes is unsupported.

#### configuration

Configuration specifications are unsupported.

#### disconnection

Disconnection specifications are unsupported. Attribute declarations are fully supported, but the use of user-defined attributes is unsupported.

#### **Names**

#### simple

Simple names are fully supported.

#### selected

Selected (qualified) names outside a use clause are unsupported. Overriding the scopes of identifiers is unsupported.

#### operator symbol

Operator symbols are fully supported.

#### indexed

Indexed names are fully supported, with one exception: Indexing an unconstrained out parameter in a procedure is unsupported.

#### slice

Slice names are fully supported, with one exception: Using a slice of an unconstrained out parameter in a procedure is unsupported unless the actual parameter is an identifier.

#### attribute

Only the following predefined attributes are supported: base, left, right, high, low, range, reverse\_range, length, and ascending. The event and stable attributes are supported only as described with the wait and if statements. User-defined attribute

names are unsupported. The use of attributes with selected names (name.name'attribute) is unsupported.

Table C-1 shows the values of some array attributes for the variable MY\_VECTOR in Example C-1.

Table C-1 Array Index Attributes

Attribute expression	Value
MY_VECTOR'left	5
MY_VECTOR'right	<b>-</b> 5
MY_VECTOR'high	5
MY_VECTOR'low	<b>-</b> 5
MY_VECTOR'length	11
MY_VECTOR'range	(5 downto -5)
MY_VECTOR'reverse_range	(–5 to 5)

#### Example C-1 Unconstrained Array Type Definition

```
type BIT_VECTOR is array(INTEGER range <>) of BIT;
   -- An unconstrained array definition
. . .
variable MY_VECTOR : BIT_VECTOR(5 downto -5);
```

See Table 6-3 on page 6-10 for Synopsys defined attributes.

# **Operators**

#### logical

Logical operators are fully supported.

#### relational

Relational operators are fully supported.

#### addition

Concatenation and arithmetic operators are fully supported. The default (and only) concatenation support is for the 93 LRM definition. For more information, see "Concatenation" on page 2-36.

#### signing

Signing operators are fully supported.

#### divide, mod, rem

The / (division), mod, and rem operators are fully supported in the std\_logic\_arith and the numeric\_std packages.

#### multiply

The \* multiply operator is fully supported.

#### exponentiation

The \*\* operator is supported only when both operands are constant or when the left operand is 2. HDL Compiler predefines the exponentiation operator for all integer types.

#### absolute value

The abs operator is fully supported. HDL Compiler predefines the absolute value operator for all integer types.

#### operator overloading

Operator overloading is fully supported.

#### short-circuit operation

The short-circuit behavior of operators is not supported.

#### Shift and rotate operators

You can define shift and rotate operators for any one-dimensional array type whose element type is either of the predefined types, BIT or Boolean. The right operand is always of type integer. The type of the result of a shift operator is the same as the type of the left operand. The shift and rotate operators are included in the list of VHDL reserved words in Table on page C-14. There is more information about the shift and rotate operators that numeric\_std supports in "Shift and Rotate Functions" on page B-23. The shift operators are

sll

Shift left logical

srl

Shift right logical

sla

Shift left arithmetic

sra

Shift right arithmetic

The rotate operators are

rol

Rotate left logical

ror

Rotate right logical

#### Example C-2 illustrates the use of shift and rotate operators.

#### Example C-2 Use of Shift and Rotate Operators

```
architecture arch of shft_op is begin

a <= "01101";
q1 <= a sll 1; -- q1 = "11010"
q2 <= a srl 3; -- q2 = "00001"
q3 <= a rol 2; -- q3 = "10101"
q4 <= a ror 1; -- q4 = "10110"
q5 <= a sla 2; -- q5 = "10100"
q6 <= a sra 1; -- q6 = "00110"
```

#### **XNOR Operator**

You can define the binary logical operator XNOR for predefined types BIT and Boolean as well as for any one-dimensional array type whose element type is BIT or Boolean. The operands must be the same type and length. The result also has the same type and length. The XNOR operator is included in the list of VHDL reserved words in Table on page C-14.

#### Example C-3 Showing Use of XNOR Operator

```
a <= "10101";
b <= "11100";
c <= a xnor b; -- c = "10110"
```

# **Operands and Expressions**

based literal

Based literals are fully supported.

null literal

Null slices, null ranges, and null arrays are supported.

physical literal

Physical literals are ignored.

string

Strings are fully supported.

aggregate

The use of types as aggregate choices is supported. Record aggregates are supported.

function call

Function calls are supported. Function conversions on input ports are supported, because type conversions on formal ports in a connection specification (port map) are supported. HDL Compiler supports the usage of unconstrained type ports when the type of the ports can be deduced. In these cases, you must use analyze/elaborate to read your design. The read command does not support type conversion on formal ports.

qualified expression

Qualified expressions are fully supported.

type conversion

Type conversion is fully supported.

allocator

Allocators are unsupported.

static expression

Static expressions are fully supported.

universal expression

Floating-point expressions are unsupported, except in a Synopsys-recognized attribute definition. Infinite-precision expressions are not supported. Precision is limited to 32 bits; all intermediate results are converted to integers.

# **Sequential Statements**

wait

The wait statement is unsupported unless it is in one of the following forms:

Where, VALUE is '0', '1', or an enumeration literal whose encoding is 0 or 1. A wait statement in this form is interpreted to mean "wait until the falling (VALUE is '0') or rising (VALUE is '1') edge of the signal named clock." You cannot use wait statements in subprograms or for-loop statements. If any path through the logic has a wait statement, all the paths must have a wait statement. HDL Compiler supports only one wait statement per process.

#### assert

Assert statements are treated like display statements, as shown in the following code snippet:

```
Assert (c) report "...";
-- is the same as
If (!c)
  $display ("...");
```

#### report

Report statements are ignored.

#### statement label

Statement labels are ignored.

#### signal

Guarded signal assignment is unsupported. The transport and after signals are ignored. Multiple waveform elements in signal assignment statements are unsupported.

#### variable

Variable statements are fully supported.

#### procedure call

Type conversion on formal parameters is unsupported. Assignment to single bits of vectored ports is unsupported.

if

The if statements are fully supported.

#### case

The case statements are fully supported.

loop

The for loops are supported, with two constraints: The loop index range must be globally static, and the loop body must not contain a wait statement. The while loops are supported, but the loop body must contain at least one wait statement. Combinational while loops are supported if the iterative bound is statically determinable. The loop statements with no iteration scheme (infinite loops) are supported, but the loop body must contain at least one wait statement.

next

Next statements are fully supported.

exit

Exit statements are fully supported.

return

Return statements are fully supported.

null

Null statements are fully supported.

#### **Concurrent Statements**

block

Guards on block statements are supported. Ports and generics in block statements are unsupported.

process

Sensitivity lists in process statements are ignored.

concurrent procedure call

Concurrent procedure call statements are fully supported.

concurrent assertion

Concurrent assertion statements are ignored.

concurrent signal assignment

The guarded keyword is supported. The transport keyword is ignored. Multiple waveforms are unsupported.

#### component instantiation

Type conversion on formal ports of a connection specification is supported. HDL Compiler supports the usage of unconstrained type ports when the type of the ports can be deduced. In these cases, you must use analyze/elaborate to read your design. The read command does not support type conversion on formal ports.

#### generate

The generate statements are fully supported.

#### **Lexical Elements**

An identifier in VHDL is a user-defined name for any of these: constant, variable, function, signal, entity, port, subprogram, parameter, or instance.

# **Specifics of Identifiers**

The characteristics of identifiers are as follows:

- They can be composed of letters, digits, and the underscore character ( \_ ).
- Their first character must be a letter, unless it is an extended identifier (see Example C-4 on page C-14).
- They can be of any length.
- They are case-insensitive.
- All of their characters are significant.

# **Specifics of Extended Identifiers**

The characteristics of extended identifiers are as follows:

- Any of the following can be defined as one:
  - Identifiers that contain special characters
  - Identifiers that begin with numbers
  - Identifiers that have the same name as a keyword
- They start with a backslash character (\), followed by a sequence of characters, followed by another backslash (\).
- They are case-sensitive.

Example C-4 shows some extended identifiers.

#### Example C-4 Sample Extended Identifiers

\a+b\	\3state\
\type\	\(a&b) c\

# **Predefined Language Environment**

```
severity_level type
```

The severity\_level type is unsupported.

#### time type

The time type is ignored if time variables and constants are used only in after clauses. In the following two code fragments, both the after clause and TD are ignored:

```
constant TD: time := 1.4 ns;
X <= Y after TD;
X <= Y after 1.4 ns;</pre>
```

#### now function

The now function is unsupported.

#### TEXTIO package

The TEXTIO package is unsupported. The TEXTIO package defines types and operations for communication with a standard programming environment (terminal and file I/O). This package is not needed for synthesis; therefore, HDL Compiler does not support it.

#### predefined attributes

These predefined attributes are supported: base, left, right, high, low, range, reverse\_range, ascending, and length. The event and stable attributes are supported only in the if and wait statements.

#### **VHDL Reserved Words**

Table lists the words that are reserved for the VHDL language and cannot be used as identifiers:

abs	access	after	alias	all	and
architecture	array	assert	attribute	begin	block
body	buffer	bus	case	component	configuration

constant	disconnect	downto	else	elsif	end
entity	exit	file	for	function	generate
generic	group	guarded	if	impure	in
inertial	inout	is	label	library	linkage
literal	loop	map	mod	nand	new
next	nor	not	null	of	on
open	or	others	out	package	port
postponed	procedure	process	pure	range	record
register	reject	rem	report	return	rol
ror	select	severity	shared	signal	sla
sll	sra	srl	subtype	then	to
transport	type	unaffected	units	until	use
variable	wait	when	while	with	xnor
xnor					

# Glossary

#### anonymous type

A predefined or underlying type with no name, such as a universal integer.

#### architecture body

The VHDL description of the internal organization or operation of a design entity.

#### **ASIC**

Application-specific integrated circuit.

#### behavioral view

The set of VHDL statements that describe the behavior of a design by using sequential statements. These statements are similar in expressive capability to those found in many other programming languages. See also *data flow view, sequential statement,* and *structural view.* 

#### bit-width

The width of a variable, signal, or expression in bits. For example, the bit-width of the constant "5" is 3 bits.

#### character literal

Any value of type CHARACTER in single quotation marks.

#### computable

Any expression whose (constant) value can be determined.

#### concurrent statements

VHDL statements that execute asynchronously in no defined relative order. Concurrent statements make up the data flow and structural views in VHDL.

#### configuration body

The VHDL description of how component instances are bound to design entities to form a complete, linked design.

#### constraints

The designer's specification of design performance goals. Design Compiler uses constraints to direct the optimization of a design to meet area and timing goals.

#### convert

To change one type to another. Only integer types and subtypes are convertible, along with same-size arrays of convertible element types.

#### data flow view

The set of VHDL statements that describe the behavior of a design by using concurrent statements. These descriptions are usually at the level of Boolean equations combined with other operators and function calls. See also *behavioral view*, *concurrent statements*, and *structural view*.

#### **Design Compiler**

The Synopsys tool that synthesizes and optimizes ASIC designs from multiple input sources and formats.

#### design constraints

See constraints.

#### design entity

In VHDL, the combination of an entity declaration and one or more architectural bodies constitute a design entity.

#### flip-flop

An edge-sensitive memory device.

#### **HDL**

Hardware Description Language.

#### identifier

A sequence of letters, underscores, and numbers. An identifier cannot be a VHDL reserved word, such as type or loop. An identifier must begin with a letter or an underscore.

#### latch

A level-sensitive memory device.

#### netlist

A network of connected components that together define a design.

#### optimization

The modification of a design in an attempt to improve some performance aspect of the design. Design Compiler optimizes designs and tries to meet specified design constraints for area and speed.

#### package

A collection of declarations that is available to more than one design entity.

#### port

A signal declared in the interface list of an entity.

#### reduction operator

An operator that takes an array of bits and produces a single-bit result, namely the result of the operator applied to each successive pair of array elements.

#### register

A memory device containing one or more flip-flops or latches used to hold a value.

#### resource sharing

The assignment of similar VHDL operations, such as +, to a common netlist cell. Netlist cells are the resources—they are equivalent to built hardware.

#### **RTL**

Register transfer level, a set of structural and data flow statements.

#### sequential statement

The set of VHDL statements that execute in sequence.

#### signal

An electrical quantity that can be used to transmit information. A signal is declared with a type and receives its value from one or more drivers. Signals are created in VHDL through either signal or port declarations.

#### signed value

A value that can be positive, 0, or negative.

#### structural view

The set of VHDL statements used to instantiate primitive and hierarchical components in a design. A VHDL design at the structural level is also called a netlist. See also behavioral view and data flow view.

#### subtype

A type declared as a constrained version of another type.

#### synthesis

The creation of optimized circuits from a high-level description.

#### translation

The mapping of high-level language constructs onto a lower-level form.

#### type

In VHDL, the mechanism by which objects are restricted in the values they are assigned and the operations that can be applied to them.

#### unsigned

A value that can be only positive or 0.

#### variable

A VHDL object local to a process or subprogram that has a single current value.

#### **VHDL**

VHSIC Hardware Description Language, used to describe discrete systems.

#### **VHSIC**

Very-high-speed integrated circuit, a high-technology program of the United States Department of Defense.

## Index

Symbols " - " operator 3-4 " + " operator 3-4 "* " operator C-8 "**" operator C-8 "<" operator 3-4 "<=" operator B-12 ">" operator 3-4 ">=" operator B-12	numeric_std package binary B-17 assert statement C-11 assignment statement indexed name target 2-35 asynchronous processes 2-53 attribute declarations C-5 attributes ascending C-6 ENUM_ENCODING 6-12
"/" operator C-8	event C-6 high C-6
A	infer_mux 6-8 left C-6
adders carry-lookahead adder A-20 Definable-Width Adder-Subtracter A-6 numeric_std package B-17 adder-subtracter (example) A-6 aggregates C-10 alias declarations supported C-5 architecture consistency component instantiation 2-14 arithmetic functions numeric_std unary B-18	length C-6 load 6-9 logic_one 6-9 logic_zero 6-9 low C-6 map_only 2-13 max_area 6-9 max_delay 6-9 max_fall_delay 6-9 max_transition 6-9 min_delay 6-9 min_fall_delay 6-9 min_rise_delay 6-9 min_rise_delay 6-9

one_cold 6-9	С
one_hot 6-9	carry-out bit
opposite 6-9	example of using B-12
range C-6	case statements
reverse_range C-6	embedded in if-then-else statements, unless
right C-6	the case statement appears in an if
rise_arrival 6-9	(CLK'event) 3-16
rise_drive 6-9	FSM coding requirements 2-44
stable C-6	generate MUX_OP cells 3-10
STATE_VECTOR 2-47	hdlin_infer_mux 3-12
sync_set_reset 6-9	hdlin_mux_size_limit 3-12
Synopsys-defined C-7	in an elsif (CLK'event) branch 3-16
unconnected 6-9	in while loops 3-16
VHDL	infer multibit components 2-48
ENUM_ENCODING 2-25, 6-12	infer MUX OP cells 3-10
ENUM_ENCODING values 6-13	infer mux attribute 3-10
ATTRIBUTES package 1-50, B-1, B-29	infer mux directive 3-11
	missing assignment in a case statement
D	branch 3-16
В	SELECT_OP Inference 3-8
binary arithmetic functions	supported constructs C-11
example B-10	used in multiplexing logic 3-7
numeric_std package B-18	clock, bused 4-16
bit name	combinational feedback
variable type 7-5	paths 3-17
bit vectors	comparison functions
variable type 7-5	numeric_std B-19
BIT_VECTOR type B-5, B-27	component
bit-blasting 7-7	declaration
bit-width (of operands) 2-31	writing out 7-4
Boolean reduction functions B-26	implication
built_in directive	three-state driver 5-1
logic functions B-2	instantiation
type conversion B-3	search order 2-12
using B-2	mapping subprogram to 2-14
•	component declarations C-5
built_in pragma example of using B-2	computable operands 2-33
	conditionally assigned variable 4-14
bused clock	conditionally specified signal 3-18
syntax 4-16	
	constant declaration
	supported C-4

constant propagation 3-5	vhdlout_bit_vector_type 7-5
continuous assignments	vhdlout_dont_create_dummy_nets 7-3
hdlin_prohibit_nontri_multiple_drivers 6-16	vhdlout_equations 7-3
control unit (example)	vhdlout_follow_vector_direction 7-3
counting A-14	vhdlout_local_attributes 7-3
state machine A-11	vhdlout_one_name 7-6
Controlling Register Inference 4-5	vhdlout_preserve_hierarchical_types 7-7
conventions for documentation 2-4	vhdlout_separate_scan_in 7-3
conversion functions	vhdlout_single_bit 7-7
arithmetic	vhdlout_three_state_name 7-6
binary B-9	vhdlout_three_state_res_func 7-6
numeric_std package	vhdlout_unknown_name 7-6
TO_INTEGER B-17	vhdlout_upcase 7-4
TO_SIGNED B-17	vhdlout_use_packages 7-4
TO_UNSIGNED B-17	vhdlout_wired_and_res_func 7-6
std_logic_arith package B-8	vhdlout_wired_or_res_func 7-6
customer support 2-5	vhdlout_write_components 7-4
• •	vhdlout_zero_name 7-6
<b>D</b>	write variables 7-3
D	Design Compiler 2-43
data type	component instantiation 2-12
abstract	write command 7-2
BOOLEAN B-28	directives
array attributes	built_in 7-12, B-6
index C-7	identifying B-6
BIT B-28	dc_script_begin 6-5
BIT_VECTOR B-29	dc_script_end 6-5
BOOLEAN B-28	keep_signal_name 2-41
CHARACTER B-28	map_to_entity 2-14, 6-5
integer	return_port_name 2-14, 6-5
defined B-29	rp_array_dir 2-6, 6-5
supported C-3	rp_endgroup 2-3, 6-3
SYNOPSYS	rp_fill 2-5, 6-4
std_logic_signed 2-24	rp_group 2-3, 6-3
data types	rp_place 2-4, 6-4
numeric_std	don't care 3-16
SIGNED B-16 UNSIGNED B-16	don't care inference
	simulation versus synthesis 2-52
dc_script_end directive 6-6	don't cares
dc_shell variables	encoding values for the ENUM_ENCODING
vhdlout_ 7-3	attribute 6-13
vhdlout_bit_type 7-5	in case statements 3-16

simulation/synthesis mismatch 2-52	combinational A-7
	sequential A-9
E	Mealy finite state machine A-18  Moore finite state machine A-16
edge expression 4-38	PLA A-36
elaboration reports 1-8	ROM A-2
embedding constraints and attributes	serial-to-parallel converter
dc_script_begin 6-5	counting bits A-27
dc_script_end 6-5	shifting bits A-32
encoding	three-state component
values	registered input 5-7
ENUM_ENCODING attribute 6-13	two-phase clocked design 4-36
entity	waveform generator
consistency	simple A-4
component instantiation 2-14	writing out port types 7-8
ENUM_ENCODING attribute 2-25, 6-12	Explicit bit-truncation 3-5
values 6-13	extended identifier C-13
vectors 6-13	
enumerated types	F
ordering 2-52	•
enumeration data type	falling_edge 4-19
encoding	feedback paths 3-17
ENUM_ENCODING attribute 2-25, 6-12	file declarations C-5
ENUM_ENCODING value 6-13	file formats, automatic detection of 1-8
literal value 2-25	finite state machine 2-44
example	automatic detection 2-43
encoding 2-25	finite state machines
literal, overloaded 2-24	automatic detection 2-43
equality functions	coding guidelines 2-44
example B-14	fsm_auto_inferring 2-44
errors 6-6, 6-16	Inference Report 2-47
escaped identifier. See extended identifier	Mealy finite state machine A-18
examples	Moore finite state machine A-16
adder-subtracter A-6	STATE_VECTOR attribute 2-47
asynchronous design	flip 1-17, 4-38
incorrect 2-43	flip-flop
carry-lookahead adder A-20	async_set_reset 4-6
component implication 2-16 control unit	clocked_on_also 4-7
counting A-14	clocked_on_also attribute 4-33
state machine A-11	creating parameterized models 1-17
count zeros	D Flip-Flop With Asynchronous Reset 4-21

Multiple Flip-Flops with Asynchronous and D Flip-Flop With Asynchronous Set 4-20 Synchronous Controls 4-28 D Flip-Flop With Asynchronous Set and on the input pin of a three-state buffer 5-7 Reset 4-22 D Flip-Flop With Synchronous and one cold 4-7 Asynchronous Load 4-27 Positive-Edge-Triggered D Flip-Flop 4-17 D Flip-Flop With Synchronous Reset 4-24 Positive-Edge-Triggered D Flip-Flop Using D Flip-Flop With Synchronous Set 4-23 'event Attribute 4-17 forcing specific GTECH components 2-12 Register banks 4-37 hdlin ff always async set reset 4-6 SEQGENs 4-2 hdlin\_ff\_always\_ sync\_set\_reset 4-5 SIGNAL'event and SIGNAL = '0' 4-16 hdlin keep feedback 4-5 sync set reset 4-6 unmapped master-slave generic cell if (falling\_edge (CLK)) then 4-16 (MSGEN) 4-33 if (rising edge (CLK)) then 4-16 If the logic library does not contain the used to describe the master-slave latch 4-33 specific inferred flip-flop 4-3 using the IEEE std\_logic\_1164 package 4-16 infer a register as an FSM state register 2-44 with bidirectional pins 4-37 inference design requirements 4-38 with multiple clock inputs 4-37 Inference Report for a D Flip-Flop With with three-state outputs 4-37 Asynchronous Reset 4-22 FSM inference report 2-45 Inference Report for a D Flip-Flop With fully specified Asynchronous Set 4-21 signal 3-17 Inference Report for a D Flip-Flop With variable 3-17 Asynchronous Set and Reset 4-23 functions 6-6 Inference Report for a D Flip-Flop With implementations Synchronous and Asynchronous Load mapped to gates 2-18 4-28 Inference Report for a D Flip-Flop With Synchronous Reset 4-25 G Inference Report for a D Flip-Flop With Synchronous Set 4-24 GTECH.db generic library Inference Report for a JK Flip-Flop 4-31 component instantiation Inference Report for a JK Flip-Flop With structural design 2-12 Asynchronous Set and Reset 4-33 link library variable Inference Report for Design Compiler 2-14 Negative-Edge-Triggered D Flip-Flop guard 4-20 on block statement C-12 Inference Report for Rising-Edge-Triggered guarded keyword C-12 D Flip-Flop 4-18 Inferring D Flip-Flops 4-15 JK Flip-Flop With Asynchronous Set and Н Reset 4-32 hdlin infer enumerated types 6-14 JK flip-flops 4-30 hdlin infer function local latches 6-14 master-slave latches 4-33 hdlin\_infer\_function\_local\_latches 6-14

hdlin_infer_mux 3-12	incompletely specified signals and variables
hdlin_keep_signal_name variable 2-41	3-17
hdlin_mux_oversize_ratio 3-12, 6-15	indexed name target 2-35
hdlin_mux_size_limit 3-12	infer_mux 3-10, 3-11
hdlin_mux_size_min 3-12, 6-15	inference report
hdlin_mux_size_only variable 3-13, 6-15	description 5-2
hdlin_no_sequential_mapping 6-15	inference reports 4-4, 5-2
hdlin_one_hot_one_cold_on 6-15	inferred registers
hdlin_optimize_array_references 6-15	limitations 4-37 instantiation
hdlin_optimize_enum_types 6-15	component
hdlin_preserve_sequential variable 4-38	search order 2-12
hdlin_prohibit_nontri_multiple _drivers 6-16	integer data type
hdlin_reporting_level directive 2-44	encoding 2-24
hdlin_reporting_level variable 1-8, 2-45, 4-4,	subrange 2-24
5-2	
hdlin_vrlg_std 1-8	K
hierarchy	
preserving types 7-7	keep_signal_name directive 2-41
high impedance state 5-1	Keeping Signal Names 2-41
1	ı
1	L
identifiers	language constructs, VHDL
characteristics C-13	concurrent statements
extended C-13	assertion C-12 block C-12
if statements	generate C-13
D flip-flop inference requirements 4-38	procedure call C-12
hdlin_infer_mux 3-12 in an invalid use of a conditionally assigned	process C-12
variable 4-14	signal assignment C-12
in case statements 3-16	data types
incompletely specified 4-9	access C-4
infer MUX_OP cells 3-10	array C-4
infers a D flip-flop 4-15	enumeration C-3
infers a D latch 4-9	file C-4
support for the event and stable attributes	floating C-4
C-6	incomplete type declarations C-4
supported construct C-11	integer C-4
Implicit bit-truncation 3-6	physical C-4
incompletely specified case statement 3-17	record C-4 declaration

universal expression C-10
operators
addition C-7
logical C-7
miscellaneous C-8
multiplying C-8
relational C-7
short-circuit operation C-8
signing C-8
predefined language environment
now function C-14
predefined attributes C-14
severity_level type C-14
TEXTIO package C-14
time type C-14
reserved words C-14
sequential statements
assertion C-11
case C-11
exit C-12
if C-11
loop C-12
next C-12
null C-12
procedure call C-11
report C-11
return C-12
signal C-11
statement labels C-11
variable C-11
wait C-10
specifications
attribute C-6
configuration C-6
disconnection C-6
latches
async_set_reset attribute 4-11
clocked_on_also 4-33
D latch inference 4-10
D latch with an asynchronous reset 4-12
D Latch With Asynchronous Set 4-11
generic sequential cells (SEQGENs) 4-2

hdlin_infer_block_local_latches 6-14  If the logic library does not contain the specific inferred latch 4-3  infer multibit components 2-48  Inference Report for an SR Latch 4-9  Inference Report for D Latch With Asynchronous Set 4-12  master-slave latches 4-33  Multiport latches 4-37  one_cold attribute 4-13  read a conditionally assigned variable 4-14  Register banks 4-37  SR latch inference 4-8  Unintended Latches in Combinational Logic 3-17  variables declared in subprograms 4-10  Verbose Inference Report for a D Latch 4-11  with three-state outputs 4-37  license requirements 1-51  loops  case statements  in while loops 3-16  combinational feedback loop 3-18  create a ripple carry adder A-7  enumerated types as indexes 2-23  forloop parameters 2-33  generate loop 2-9  hdlin_keep_feedback 4-5  support in VHDL C-12  that iterates across each bit in the given value A-8	case statements embedded in if-then-else statements 3-16 case statements in an elsif (CLK'event) 3-16 case statements in while loops 3-16 case statements that contain an if statement 3-16 case statements that contain don't care values 3-16 case statements that have a missing case statement branch 3-16 Design Compiler implementation 3-9 hdlin_infer_mux variable 3-11 hdlin_mux_oversize_ratio 3-12 hdlin_mux_oversize_ratio 6-15 hdlin_mux_size_limit 3-12 hdlin_mux_size_min 3-12, 6-15 implement conditional operations implied by if and case statements 3-8 incompletely specified case statement 3-17 infer MUX_OP cells 3-9 infer_mux attribute 3-10, 6-8 inference report for MUX_OPs 3-13 MUX_OP cells 3-7 MUX_OP Inference Limitations 3-16 preferentially map multiplexing logic to multiplexers 3-7 SELECT_OP cells 3-7synopsys infer_mux directive 3-10 warning message 3-17 with if and case statements 3-7 multiplication using shifts B-15
•	multiplication using shifts B-15 MUX_OP cells, setting the size_only attribute 3-13
M	MUX_OP Inference 3-9
map_only attribute 2-13 map_to_entity directive 2-14 math_real package support 2-28 Mealy finite state machine (example) A-18 Moore finite state machine (example) A-16 multiplexing logic	N names slice names 2-31 N-bit adder declaration
	example, ripple-carry 2-13

ripple-carry design 2-13	optimization 2-43
noncomputable operands 2-33	ordering
numeric_std package	functions
accessing B-16	example B-13
arithmetic functions	overloading
binary B-18	enumeration
unary B-18	literal 2-24
comparison functions	
ordering B-19	<b>D</b>
data types	Р
UNSIGNED B-16	PLA (example) A-36
IEEE documentation 1-50, B-1	ports
location B-16	bit-blasting 7-7
logical operators	pragmas.See directives
AND B-22	predefined attributes
NAND B-22	supported C-14
NOR B-22	• •
NOT B-22	processes
OR B-22	asynchronous 2-53
XNOR B-22	sensitivity lists 2-53
XOR B-22	synchronous 2-53
resize function B-17	
rotate	R
functions B-23	
operators B-24	read_file -format command 1-8
shift	register inference
functions B-23	D latch 4-9
operators B-24	edge expressions 4-15
use with std_logic_arith package B-15	if versus wait 4-16
_ 0 _ 1 0	signal edge 4-15
	SR latch 4-8
O	wait versus if 4-16
operands	relative placement
bit-width 2-31	creating groups 2-3, 6-3
computable 2-33	example 2-6
operators	figure 2-8
ordering	placing cells automatically 2-5, 6-4
and enumerated types 2-52	specifying placement 2-6, 6-5
rotate	specifying subgroups, keepouts, and
numeric_std package B-24	instances 2-4, 6-4
shift	report statement C-11
numeric_std package B-24	resize function
- · · · ·	numeric std package B-17

resolution function	state vector
writing out 7-6	attribute 2-47
vhdlout_wired_and_res_func 7-6	STATE_VECTOR attribute 2-47
vhdlout_wired_or_res_func 7-6	statement
rising_edge 1-3, 4-18	assignment
ROM (example) A-2	indexed name target, syntax 2-35
rotate	statement labels C-11
functions	std_logic_1164 package B-2
numeric_std package B-23	std_logic_arith package
operators C-9	"<=" function B-12
numeric_std package B-24	">" function B-12
	">=" function B-12
S	arithmetic functions B-9
3	Boolean reduction functions B-26
SELECT_OP 3-8	built_in functions B-6
sensitivity lists 2-53	comparison functions B-12
serial-to-parallel converter (example)	conversion functions B-9
shifting bits A-32	data types B-6
set_map_only command 2-13	modifying the package B-5
shared variable C-5	ordering functions B-12
shift	shift function B-14
functions	using the package B-4
example B-14	std_logic_misc package B-26
numeric_std B-23	subprogram
operations B-15	mapping to components
operators	example 2-15
numeric_std package B-24	matching entity 2-14
signals	subrange
edge detection 4-15	integer data type 2-24
supported C-5	SYN_FEED_THRU_
SIGNED data type	example of using B-4
defined B-6, B-7	synchronous
simulation	processes 2-53
don't care values 2-52	Synopsys packages
SolvNet	std_logic_misc B-26
accessing 2-5	Synopsys-defined VHDL attributes C-7
documentation 2-2	synthetic comments. See directives
state machine (example)	
controller A-11	Т
Mealy A-18	•
Moore A-16	three-state

gate 5-5 registered enable 5-7	BOOLEAN data type B-28 CHARACTER data type B-28
without registered enable 5-7	component
inference 5-1	implication 2-14
registered drivers 5-5, 5-7	concurrent statements
registered input 5-7	supported C-12
vhdlout_three_state_name variable 7-6	data type, supported
ime type C-14	enumeration C-3
ransport keyword C-12	data type, unsupported
	integer C-4
wo-phase design 4-36	declarations C-4
ype	design
conversion variable	units C-2
functions 7-7 variable	writing out 7-2
preserving hierarchy 7-7	expressions, supported C-9
preserving meranciny 7-7	integer data type 2-24, B-29
	names C-6
U	NATURAL subtype B-29
Inory.	operators
unary arithmetic functions	supported C-7
example B-11	package
numeric_std B-18	composition 2-14
unconstrained arrays	ports, writing out 7-7
example using A-6	POSITIVE subtype B-29
. •	predefined
unloaded sequential cell preservation 4-38	language environment C-14
JNSIGNED data type defined B-6	sensitivity lists 2-53
	sequential statements, supported C-10
numeric_std package B-16	specifications C-6
	STRING type B-29
V	three-state components 5-1
• variables	writing out 7-2
conditionally assigned 4-14	VHDL assertions 4-8
hdlin_keep_signal_name 2-41	VHDL Compiler
vhdlout_top_configuration_arch_name 7-8	attributes
vhdlout_top_configuration_entity_name 7-8	Synopsys C-6
vhdlout_top_configuration_name 7-8	write_script command 7-3
· -	component
Verilog language version, controlling 1-8	instantiation, entities 2-14
VHDL	don't care information 2-43
BIT data type B-28	enumeration encoding 2-25
BIT_VECTOR data type B-29	integer encoding 2-24

sensitivity lists 2-53 STATE VECTOR attribute 2-47 vhdlout\_variables 7-3 vhdlout\_bit\_type variable 7-5 vhdlout bit vector type variable 7-5 vhdlout dont create dummy nets variable 7-3 vhdlout equations variable 7-3 vhdlout follow vector direction variable 7-3 vhdlout\_local\_attributes variable 7-3 vhdlout\_one\_name variable 7-6 vhdlout package naming style 7-7 vhdlout preserve hierarchical types variable 7-7 vhdlout\_separate\_scan\_in variable 7-3 vhdlout\_single\_bit variable 7-7 vhdlout three state name variable 7-6 vhdlout\_three\_state\_res\_func variable 7-6 vhdlout\_top\_configuration\_arch\_name 7-8

vhdlout\_top\_configuration\_entity\_name

variable 7-8

vhdlout\_top\_configuration\_name variable 7-8
vhdlout\_unknown\_name variable 7-6
vhdlout\_upcase variable 7-4
vhdlout\_use\_packages variable 7-4
vhdlout\_wired\_and\_res\_func variable 7-6
vhdlout\_wired\_or\_res\_func variable 7-6
vhdlout\_write\_architecture variable 7-4
vhdlout\_write\_components variable 7-4
vhdlout\_write\_entity variable 7-4
vhdlout\_write\_top\_configuration variable 7-5
vhdlout\_zero\_name variable 7-6

## W

warnings
asynchronous designs 2-43
waveform generator (example)
simple A-4
write command 7-2
writing out VHDL 7-2