# Library Compiler™ Tool Commands

Version O-2018.06, June 2018



# **Copyright Notice and Proprietary Information**

© 2018 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

#### **Destination Control Statement**

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

#### **Disclaimer**

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

#### **Trademarks**

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at http://www.synopsys.com/Company/Pages/Trademarks.aspx.

All other product or company names may be trademarks of their respective owners.

#### Free and Open-Source Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

#### **Third-Party Links**

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc. 690 E. Middlefield Road Mountain View, CA 94043 www.synopsys.com

#### **Copyright Notice for the Command-Line Editing Feature**

 $\hat{A}$ © 1992, 1993 The Regents of the University of California. All rights reserved. This code is derived from software contributed to Berkeley by Christos Zoulas of Cornell University.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by the University of California, Berkeley and its contributors.
- 4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE

### **Copyright Notice for the Line-Editing Library**

© 1992 Simmule Turner and Rich Salz. All rights reserved.

This software is not subject to any license of the American Telephone and Telegraph Company or of the Regents of the University of California.

Permission is granted to anyone to use this software for any purpose on any computer system, and to alter it and redistribute it freely, subject to the following restrictions:

- 1. The authors are not responsible for the consequences of use of this software, no matter how awful, even if they arise from flaws in it.
- 2. The origin of this software must not be misrepresented, either by explicit claim or by omission. Since few users ever read sources, credits must appear in the documentation.
- 3. Altered versions must be plainly marked as such, and must not be misrepresented as being the original software. Since few users ever read sources, credits must appear in the documentation.
- 4. This notice may not be removed or altered.

## Copyright Notice for the Nonlinear Optimization Library

© 2011 by Massachusetts Institute of Technology.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- 1. The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.
- 2. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Contents 3

#### Contents

add_to_collection	6
alias	9
align_lib_objects	11
analyze_trend	14
append_to_collection	16
apropos	18
check_library	20
check_license	24
check_script	26
compare_collections	30
copy_collection	32
cputime	34
create_command_group	36
create_scaling_lib_group	38
date	40
debug_script	42
define_proc_attributes	45
echo	50
error_info	52
exit	54
filter_collection	56
foreach_in_collection	59
get_app_var	62
get_command_option_values	65
get_defined_commands	68
get_lib_attribute	71
get_lib_cells	73
get_lib_grid_points	76
get_lib_objects	79
get_lib_pins	82
get_lib_timing_arcs	85
get_libs	87
get_license	90
get_lookup_tables	92
get_message_ids	94
get_message_info	96
get_object_name	99
get_scale	101
get_unix_variable	103

getenv	. 104
help	. 106
history	. 109
index_collection	
is_false	. 115
is_null_object	117
is_true	. 119
lib2saif	121
license_users	. 123
list_attributes	. 125
list_libs	. 127
Iminus	129
lookup_table	. 131
ls	. 136
man	. 138
mem	140
merge_lib	. 142
parse proc arguments	. 144
preview	. 147
print_message_info	
print_proc_new_vars	
rint_suppressed_messages	
printenv	
printvar	
proc args	
proc body	
query objects	
quit	
read db	
read lib	
redirect	
remove from collection	
remove_host_options	
remove_lib	
remove license	
rename	
report_app_var	
report_check_library_options	
report_host_options	
report_lib	
set_app_var	
set_app_vaiset_check_library_options	
set_command_option_value	
set_current_command_mode	
set_host_options	
3EL 1103L UPUIUTIS	. ∠১∠

set_lib_attribute
set_lib_group
set_lib_mismatch_fix_options
set_message_info
set_process_label
set_unix_variable
setenv
sh247
sizeof_collection
sort_collection
sort_lib_objects
source
suppress_message257
unalias
unsetenv
unsuppress_message263
which
write_app_var
write_lib
write_lib_group
write scaling lib group

# add\_to\_collection

Adds objects to a collection, resulting in a new collection. The base collection remains unchanged.

#### **SYNTAX**

collection add\_to\_collection
[-unique]
collection1
object spec

#### **Data Types**

collection1
object spec

collection list

## **ARGUMENTS**

#### -unique

Indicates that duplicate objects are to be removed from the resulting collection. By default, duplicate objects are not removed.

#### collection1

Specifies the base collection to which objects are to be added. This collection is copied to the result collection, and objects matching *object\_spec* are added to the result collection. The *collection1* option can be the empty collection (empty string), subject to some constraints, as explained in the DESCRIPTION section.

#### object\_spec

Specifies a list of named objects or collections to add.

If the base collection is heterogeneous, only collections can be added to it.

If the base collection is homogeneous, the object class of each element in this list must be the same as in the base collection. If it is not the same class, it is ignored. From heterogeneous collections in the *object\_spec*, only objects of the same class of the base collection are added. If the name matches an existing collection, the collection is used. Otherwise, the objects are searched for in the database using the object class of the base collection.

add to collection 7

The *object\_spec* has some special rules when the base collection is empty, as explained in the DESCRIPTION section.

#### DESCRIPTION

The **add\_to\_collection** command allows you to add elements to a collection. The result is a new collection representing the objects in the *object\_spec* added to the objects in the base collection.

Elements that exist in both the base collection and the *object\_spec*, are duplicated in the resulting collection. Duplicates are not removed unless you use the *-unique* option. If the *object\_spec* is empty, the result is a copy of the base collection.

If the base collection is homogeneous, the command searches in the database for any elements of the *object\_spec* that are not collections, using the object class of the base collection. If the base collection is heterogeneous, all implicit elements of the *object\_spec* are ignored.

When the *collection1* argument is the empty collection, some special rules apply to the *object\_spec*. If the *object\_spec* is non-empty, there must be at least one homogeneous collection somewhere in the *object\_spec* list (its position in the list does not matter). The first homogeneous collection in the *object\_spec* list becomes the base collection and sets the object class for the function. The examples show the different errors and warnings that can be generated.

The **append\_to\_collection** command has similar semantics as the **add\_to\_collection** command; however, the **append\_to\_collection** command can be much more efficient in some cases. For more information about the command, see the man page.

For background on collections and querying of objects, see the **collections** man page.

### **EXAMPLES**

The following example from PrimeTime uses the **get\_ports** command to get all of the ports beginning with 'mode' and then adds the "CLOCK" port.

```
pt_shell> set xports [get_ports mode*]
{"mode[0]", "mode[1]", "mode[2]"}
pt_shell> add_to_collection $xports [get_ports CLOCK]
{"mode[0]", "mode[1]", "mode[2]", "CLOCK"}
```

The following example from PrimeTime adds the cell u1 to a collection containing the SCANOUT port.

```
pt_shell> set so [get_ports SCANOUT]
{"SCANOUT"}
pt_shell> set u1 [get_cells u1]
{"u1"}
pt_shell> set het [add_to_collection $so $u1]
{"u1"}
pt_shell> query_objects -verbose $het
{"port:SCANOUT", "cell:u1"}
```

add to collection 8

The following examples show how the **add\_to\_collection** command behaves when the base collection is empty. Adding two empty collections yields the empty collection. Adding an implicit list of only strings or heterogeneous collections to the empty collection generates an error message, because no homogeneous collections are present in the *object\_spec* list. Finally, as long as one homogeneous collection is present in the *object\_spec* list, the command succeeds, even though a warning message is generated. The example uses the variable settings from the previous example.

```
pt_shell> sizeof_collection [add_to_collection "" ""]
0

pt_shell> set A [add_to_collection "" [list a $het c]]
Error: At least one homogeneous collection required for argument 'object_spec' to add_to_collection when the 'collection' argument is empty (SEL-014)

pt_shell> add_to_collection "" [list a $het $sp]]
Warning: Ignored all implicit elements in argument 'object_spec' to add_to_collection because the class of the base collection could not be determined (SEL-015)
{"SCANOUT", "u1", "SCANOUT"}
```

#### **SEE ALSO**

```
append_to_collection(2)
collections(2)
query_objects(2)
remove_from_collection(2)
sizeof collection(2)
```

alias 9

# alias

Creates a pseudo-command that expands to one or more words, or lists current alias definitions.

### **SYNTAX**

```
string alias
[name]
[def]
```

#### **Data Types**

```
name string
def string
```

## **ARGUMENTS**

#### name

Specifies a name of the alias to define or display. The name must begin with a letter, and can contain letters, underscores, and numbers.

#### def

Expands the alias. That is, the replacement text for the alias name.

## **DESCRIPTION**

The **alias** command defines or displays command aliases. With no arguments, the **alias** command displays all currently defined aliases and their expansions. With a single argument, the **alias** command displays the expansion for the given alias name. With more than one argument, an alias is created that is named by the first argument and expanding to the remaining arguments.

You cannot create an alias using the name of any existing command or procedure. Thus, you cannot use **alias** to redefine existing commands.

alias 10

Aliases can refer to other aliases.

Aliases are only expanded when they are the first word in a command.

#### **EXAMPLES**

Although commands can be abbreviated, sometimes there is a conflict with another command. The following example shows how to use **alias** to get around the conflict:

```
prompt> alias q quit
```

The following example shows how to use **alias** to create a shortcut for commonly-used command invocations:

```
prompt> alias include {source -echo -verbose}
prompt> alias rt100 {report timing -max paths 100}
```

After the previous commands, the command **include script.tcl** is replaced with **source -echo -verbose script.tcl** before the command is interpreted.

The following examples show how to display aliases using **alias**. Note that when displaying all aliases, they are in alphabetical order.

```
prompt> alias rt100
rt100 report_timing -max_paths 100
prompt> alias
include source -echo -verbose
q quit
rt100 report timing -max paths 100
```

## **SEE ALSO**

```
unalias(2)
```

align\_lib\_objects 11

# align\_lib\_objects

Sort and match multiple(>=2) Tcl collections based on one or more attributes, resulting in a list of collection and each collection is N-tuple (paired) list of grouped object from each input collection.

#### **SYNTAX**

```
collection align_lib_objects
  [-matching match_rule_list]
  collection1 collection2 ... collectionN
```

## **Data Types**

## **ARGUMENTS**

```
collection1 collection2 ...collectionN
```

Specifies multiple (>=2) collections to be aligned. Only following library object types are supported.

```
library
cell
pin
pg_pin
timing
internal_power
leakage_power
ccsn stage
```

#### -matching match rule list

Specifies a list of one or more application or user-defined attributes to use as align keys. following are two kinds of format for *match\_rule\_list* 

```
-matching {attrib1 attrib2 ...}
-matching { + {attrib1 attrib2 ...} - {attrib3 attrib4 ...}}
```

The first format is to explictly provide attribute list to be used as align keys. The second format is to add or delete attributes from default list. \* If the option is not specified \* the object in the collection

align lib objects 12

has name, the command uses name as align key. following class types are affected. \* library \* cell \*  $pin * pg_pin$ 

\* the object in the collection does not have name, the command uses following default attributes as align keys.

### **DESCRIPTION**

You can use the **align\_lib\_objects** command to sort and match objects in collections based on one or more attributes. NULL is for mismatching elements.

#### **EXAMPLES**

The following exmaple aligns a collection of pins and use pin name as key. the result is six collections and each collection has two pins.

```
lc shell>set cell1 test/BUF/*
test/BUF/*
lc shell>set cell2 test/CKGT/*
test/CKGT/*
lc shell>set pinlist1 [get lib pins $cell1]
{"test/BUF/A", "test/BUF/X"}
lc_shell>set pinlist2 [get_lib_pins $cell2]
{"test/CKGT/CK", "test/CKGT/EN", "test/CKGT/Q", "test/CKGT/SE"}
lc_shell>set aligned_pinlist [align_lib_objects $pinlist1 $pinlist2]
_sel4 _sel5 _sel6 _sel7 _sel8 _sel
lc shell> set i 0
lc shell>foreach pair $aligned pinlist {
set element1 [index collection $pair 0]
set element2 [index collection $pair 1]
set ret1 [is null object $element1]
set ret2 [is null object $element2]
if {$ret1 == "1"} {
 set name1 "null"
} else {
 set name1 [get_object_name $element1]
if {$ret2 == "1"} {
```

align lib objects

```
set name2 "null"
} else {
  set name2 [get_object_name $element2]
}
echo "pair $i:($name1, $name2)"
incr i
}
pair 0:(null, EN)
pair 1:(null, CK)
pair 2:(null, SE)
pair 3:(A, null)
pair 4:(null, Q)
pair 5:(X, null)
```

## **SEE ALSO**

collections(2)

analyze\_trend 14

# analyze\_trend

analyze the trend of a list of float.

#### **SYNTAX**

#### analyze trend

```
float_list
[-relative_tolerance relative_tolerance]
[-absolute tolerance absolute tolerance]
```

#### **Data Types**

```
float_list
relative_tolerance float
absolute_tolerance float
```

#### **ARGUMENTS**

```
float list
```

Specifies the sorted float list for analysis.

```
-relative_tolerance relative_tolerance
```

Specifies the relative tolerance for the float equal comparing, default is 0.01.

```
-absolute_tolerance absolute_tolerance
```

Specifies the absolute tolerance for the float equal comparing, default is 1e-6.

## **DESCRIPTION**

This command analyzes the trend of the float data list, and returns the trend symbol of the data. The return trend symbo is listed below.

```
/: monotonously increasing
```

analyze trend 15

```
\: monotonously decreasing
^: non-monotonous up
V: non-monotonous down
-: flat
M: multiple peaks
W: multiple troughs
N: >=2 peaks with 2nd not turning low
u: >=2 troughs with 2nd not turning up (shape V\)
X: None of the above trends
```

The tolerance (absolute/relative) is for filter out small noise. Different tolerances may result in different trend shapes.

## **EXAMPLES**

The following example shows trend analysis for a float array

```
lc_shell>analyze_trend {0.1 0.2 0.19 0.3}
N
lc_shell>analyze_trend {0.1 0.2 0.19 0.3} -relative_tolerance 0.1
/
```

## **SEE ALSO**

```
get scale(2)
```

append\_to\_collection 16

# append\_to\_collection

Adds objects to a collection and modifies a variable.

#### **SYNTAX**

```
collection append_to_collection
[-unique]
  var_name
  object spec
```

#### **Data Types**

var\_name
object\_spec

collection list

## **ARGUMENTS**

#### -unique

Indicates that duplicate objects are to be removed from the resulting collection. By default, duplicate objects are not removed.

#### var\_name

Specifies a variable name. The objects matching *object\_spec* are added into the collection referenced by this variable.

#### object\_spec

Specifies a list of named objects or collections to add.

#### **DESCRIPTION**

The **append\_to\_collection** command allows you to add elements to a collection. This command treats the variable name given by the *var\_name* option as a collection, and it appends all of the elements in *object\_spec* to that collection. If the variable does not exist, it is created as a collection with elements

append\_to\_collection 17

from the *object\_spec* as its value. If the variable does exist and it does not contain a collection, it is an error.

The result of the command is the collection that was initially referenced by the *var\_name* option, or the collection created if the variable did not exist.

The **append\_to\_collection** command provides the same semantics as the common use of the **add\_to\_collection** command; however, this command shows significant improvements in performance.

An example of replacing the **add\_to\_collection** command with the **append\_to\_collection** command is provided below. For example,

```
set var name [add to collection $var name $objs]
```

Using the **append\_to\_collection** command, the command becomes:

```
append_to_collection var_name $objs
```

The **append\_to\_collection** command can be much more efficient than the **add\_to\_collection** command if you are building up a collection in a loop. The arguments of the command have the same restrictions as the **add\_to\_collection** command. For more information about these restrictions, see the **add\_to\_collection** man page.

#### **EXAMPLES**

The following example from PrimeTime shows how a collection can be built up using the **append\_to\_collection** command:

# **SEE ALSO**

```
add_to_collection(2)
foreach_in_collection(2)
index_collection(2)
remove_from_collection(2)
sizeof collection(2)
```

apropos 18

# apropos

Searches the command database for a pattern.

#### **SYNTAX**

```
string apropos
    [-symbols_only]
    pattern
```

#### **Data Types**

pattern string

## **ARGUMENTS**

```
-symbols_only
```

Searches only command and option names.

pattern

Searches for the specified *pattern*.

## **DESCRIPTION**

The **apropos** command searches the command and option database for all commands that contain the specified *pattern*. The *pattern* argument can include the wildcard characters asterisk (\*) and question mark (?). The search is case-sensitive. For each command that matches the search criteria, the command help is printed as though **help-verbose** was used with the command.

Whereas **help** looks only at command names, **apropos** looks at command names, the command one-line description, option names, and option value-help strings. The search can be restricted to only command and option names with the **-symbols\_only** option.

When searching for dash options, do not include the leading dash. Search only for the name.

apropos 19

#### **EXAMPLES**

In the following example, assume that the **get\_cells** and **get\_designs** commands have the **-exact** option. Note that without the **-symbols\_only** option, the first search picks up commands which have the string "exact" in the one-line description.

```
prompt> apropos exact
get_cells
                   # Create a collection of cells
  [-exact]
                       (Wildcards are considered as plain characters)
                       (Match cell names against patterns)
  patterns
 get_designs
                  # Create a collection of designs
  [-exact]
                       (Wildcards are considered as plain characters)
  patterns
                       (Match design names against patterns)
                   # Return the exact time of day
 real time
prompt> apropos exact -symbols only
 get_cells # Create a collection of cells
  [-exact]
                       (Wildcards are considered as plain characters)
  patterns
                       (Match cell names against patterns)
 [-exact]
                       (Wildcards are considered as plain characters)
  patterns
                       (Match design names against patterns)
```

## **SEE ALSO**

help(2)

# check\_library

Performs consistency checks cross logic libraries, logic vs. physical libraries and physical libraries.

## **SYNTAX**

```
status check_library
[-logic_library_name logic_library_name_list]
[-physical_library_name phys_library_name_list]
[-cells cell_list]
```

## **Data Types**

### **ARGUMENTS**

```
-logic library name logic library name list
```

Specifies the logic libraries (.db) to be checked. This can be in regexp, e.g. "\*.db" in search\_path. Other types of libraries such as .ILM are not supported.

For logic vs. logic library checking, specify two or more libraries, such as libraries at different corners. If you have set the **-compare {attribute value}** option in the **set\_check\_library\_options** command, specify only two libraries.

If you have set the **-scaling** option in the **set\_check\_library\_options** command, specify scaling libraries by the **create\_scaling\_lib\_group** command.

For logic vs. logic library checking, the command first groups the libraries by cell set, and within each group or family the command checks consistencies across all libraries in the same group. The grouping is by majority (> 50%) of same name cells. For example, if lib1 has 9 cells and lib2 has 6, and 5 of them are the same, then they are grouped together.

```
-physical library name phys library name list
```

Specifies the physical libraries (.frame) to be checked. You can specify multiple physical libraries.

For cross checking, specify both logic and physical libraries. If libraries are not specified explicitly in

check\_library, the ones loaded/opened at runtime will be used. The libraries to be checked are in the following priority:

- 1) explicitly specified in check\_library command
- 2) logic libraries associated with the specified physical library
- 3) loaded or opened logic and physical libraries at runtime

```
-cells cell list
```

Specifies a list of cell names to be checked. If not specified, all cells in the libraries are checked.

#### DESCRIPTION

The **check\_library** command checks and reports the items described below, based on the settings of the **set\_check\_library\_options** command.

Use the **check\_library** command to qualify the libraries before reading in a design.

This command checks library qualities in following areas:

Logic vs. logic library consistency

## **Logic vs. Logic Library Consistency Checking**

Logic vs. logic library consistency checks include:

- General or default checking at library, cell, pin, and timing group levels for missing cells, missing and mismatched pins or pg\_pins, and timing arcs.
- Special checking for timing, noise, and power scaling
- Special checking for the UPF or multivoltage flow, such as pg\_pins, power management cells, and power data.
- Special checking for the multicorner-multimode flow, such as operating conditions and power-down functions
- Library characterization and validation

For logic vs. logic library checking, at the end of checking the command reports a summary for each specified option. For example, for the **-mcmm** option, it reports:

Logic library consistency check FAILED for MCMM.

## **Logic vs. physical Library Consistency Checking**

Logic vs. physical library consistency checks include:

1) default checks: missing cells, missing or mismatched pins/pg\_pins in either DB or FRAME

- 2) cell areas between DB and FRAME
- 3) cell footprint vs. PR boundary
- 4) bus delimiters in the libraries.

For logic vs. physical library checking, after reporting issues in tables, at the end of checking, a summary message is printed out, for example,

Logic library is inconsistent with physical library (LIBCHK-220)

#### **EXAMPLES**

#END LIBSCREEN UPF

In the following example, the lib1.db logic library is checked for upf:

```
prompt> set check library options -upf
prompt> check library -logic library name lib1.db
#BEGIN XCHECK LIBRARY
Logic Library #1:
   Library name
                            /home/goose/tmp/lib1.db
   File name
                           pg_pin based db
   Library type
   Library Version
                             1.000000
                            J-2014.09
   Tool Created
                           J-2014.05
Thu Mar 9 14:21:29 2006
   Data Created
                            1ns
   Time unit
                            1000ff
   Capacitance unit
                            1mW
   Leakage power unit
                            1mA
   Current unit
check library options
                             -upf
                            J-2014.09-ALPHA5
Version
                            Thu Jul 10 03:01:46 2014
Check date and time
#BEGIN LIBSCREEN UPF
Library#1 (lib1):
Warning: Cell 'isolation cell' is missing 'backup power' pg pin, so it will become a black-box cell
Warning: Cell 'ls 1', pin 'A', The pin 'A' is missing the attribute 'input voltage range'. (LBDB-
Warning: Cell 'ls 1', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
Warning: Cell 'ls 2', pin 'A', The pin 'A' is missing the attribute 'input voltage range'. (LBDB-
Warning: Cell 'ls_2', pin 'Y', The pin 'Y' is missing the attribute 'output_voltage_range'.
Warning: Cell 'LVLLHX2M', pin 'A', The pin 'A' is missing the attribute 'input_voltage_range'. (L
Warning: Cell 'LVLLHX2M', pin 'Y', The pin 'Y' is missing the attribute 'output_voltage_range'.
Warning: Cell 'LVLLHX8M', pin 'A', The pin 'A' is missing the attribute 'input voltage range'.
                                                                                                (L
Warning: Cell 'LVLLHX8M', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
Warning: Cell 'LVLLHEHX2M', pin 'A', The pin 'A' is missing the attribute 'input voltage range'.
Warning: Cell 'LVLLHEHX2M', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
Warning: Cell 'LVLLHEHX8M', pin 'A', The pin 'A' is missing the attribute 'input voltage range'.
Warning: Cell 'LVLLHEHX8M', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
Power management cell checking passed.
```

```
Information: List of cell classification (LIBCHK-312)
______
Library name
                       lib1(lib#1)
______
Total number
Inverter
Buffer
Level shifter
Differential level shifter 0
Isolation cell
Clock Isolation cell
Retention cell
Switch cell
Always on cell
#BEGIN XCHECK LOGICCELLS
#END XCHECK LOGICCELLS
#BEGIN XCHECK LOGICPINS
#END XCHECK LOGICPINS
#BEGIN XCHECK LOGICPGPINS
Number of cells missing pg pins in library 1: 0 (out of 7)
#END XCHECK LOGICPGPINS
#BEGIN XCHECK ARCS
#END XCHECK ARCS
Logic vs. logic library check summary:
Logic library consistency check PASSED for UPF.
#END XCHECK LIBRARY
1
In the following example, the default cross checks are performed between
logic libraries al.db and a2.db and physical library a.nlib:
prompt> check_library -logic_library_name "a1.db a2.db" -physical_library_name a.nlib
```

#### **SEE ALSO**

```
report_check_library_options(2)
set check library options(2)
```

check license 24

# check\_license

Checks the availability of a license for a feature.

#### **SYNTAX**

status check\_license feature list

#### **Data Types**

feature\_list list

## **ARGUMENTS**

feature list

Specifies the list of features to be checked. If more than one feature is specified, they must be enclosed in curly braces ({}). By looking at your key file, you can determine all of the features licensed at your site.

## **DESCRIPTION**

The **check\_license** command checks on a license for the named features. It does not check out the license.

The **list\_licenses** command provides a list of the features that you are currently using.

## **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

check\_license 25

## **EXAMPLES**

This example checks on the license for the multivoltage feature:

```
prompt> check_license {Galaxy-MV}
```

## **SEE ALSO**

```
get_license(2)
license_users(2)
list_licenses(2)
remove_license(2)
```

check\_script 26

# check\_script

Statically check a script using the a static Tcl syntax checker based on TclPro Procheck and the Synopsys checking extensions for this tool.

## **SYNTAX**

```
string snpsTclPro::check_script [-no_tclchecker_warning]
  [-quiet]
  [-onepass]
  [-verbose]
  [-suppress messageID]
  [-application appName]
  [-W1]
  [-W2]
  [-W3]
  [-Wall]
  filePattern

string messageID
string appName
string filePattern
```

### **ARGUMENTS**

```
-no_tclchecker_warning

Don't warn that TclDevKit cannot be found

-quiet

prints minimal error information

-onepass

perform a single pass without checking proc args

-verbose

prints summary information

-suppress messageIDs

prevent given messageIDs from being printed
```

check\_script 27

```
-application appName
   Check script against application other than this one
-W1
   print only error messages
-W2
   print only error and usage warnings
-W3
   print all errors and warnings
-Wall
   print all types of messages (same as W3)
filePattern
   file(s) to be checked
```

#### **USING THE PACKAGE**

The **check\_script** command is in the snpsTclPro Tcl package, and all of the commands in this package are defined in the namespace snpsTclPro. The way to use this command is to load the package, which will import the commands it exports into the global namespace. This is shown below.

```
shell> package require snpsTclPro
1.0
```

These commands can be added to the .synopsys setup file for the system, user, or current directory, or the commands can be typed when the package is needed.

## **DESCRIPTION**

The **check\_script** command simplifies running the TclDevKit tclchecker program. This application is available for purchase from ActiveState (http://www.activestate.com). If the TclDevKit is not available then there is a limited Synopsys Tcl syntax checker that is used by this command. The Synopsys version of this code does not understand Tcl8.4 constructs, and some other checking is limited.

These checkers will check builtin Tcl commands, as well as the Synopsys extension commands which are found in the script. **check\_script** will locate the Synopsys checking extensions for the application and will then invoke the checker. The limited checker does not require any external license. It is part of the Synopsys installation.

check script 28

The **check\_script** command will raise a Tcl error if the checker detects errors in the scripts being checked.

The **check\_script** command is provided as a convenience to streamline the use of the syntax checker within Synopsys applications. The checker can also be called directly on scripts, without requiring a license for the Synopsys application whose script is being checked. This checker script is available in the auxx/tcllib/bin/check\_script in the installation directory of your application. When run standalone the application option must be specified.

## **Synopsys Checker Extensions**

The Synopsys extensions to the TclPro checker define a number of new warnings and errors. These messages are listed below, along with a short explanation of them.

#### Error MisVal

An option to a command which requires a value is missing its value.

#### Error MisRea

A required option or argument was not specified.

#### Error **Excl**

Two options which are mutually exclusive were both specified.

#### Error ExtraPos

An extra positional argument was specified to a command.

#### Error BadRange

The value specified for a given argument was outside of the legal range.

#### Error UnkCmd

The command specified is not known by the application.

#### Error **UnkOpt**

The specified option is not legal for the command.

#### Error **AmbOpt**

The option specified is not complete and matches 2 or more options for the command.

#### Warning **NotLit**

This warning indicates that the argument specified to an option was not a literal and therefore could not be checked. This message is suppressed by default. It can be enabled by setting the environment variable SNPS\_TCL\_NOLITERALWAN to true.

#### Warning **DupIgn**

An option was specified multiple times to the command, and the first value specified will be the one used. The other values will be ignored.

#### Warning **DupOver**

An option was specified multiple times to the command, and the last value specified will be the one used. The other values will be ignored.

check script 29

#### **EXAMPLES**

```
shell> check_script myscript.tcl
Loading snps tcl.pcx...
Loading coreConsultant.pcx...
scanning: /u/user1/myscript.tcl
checking: /u/user1/myscript.tcl
test.tcl:3 (warnVarRef) variable reference used where variable name expected
set $a $b
test.tcl:5 (SnpsE-MisReq) Missing required positional options for foreach in collection: body
foreach in collection x {
test.tcl:9 (SnpsE-BadRange) Value -1 for 'index collection index' must be >= 0
index collection $a -1
child process exited abnormally
Error: Errors found in script.
       Use error info for more info. (CMD-013)
shell> check_script -Wall anotherScript.tcl
Loading snps_tcl.pcx...
scanning: /u/user1/anotherScript.tcl
checking: /u/user1/anotherScript.tcl
```

## **CAVEATS**

The Synopsys extension messages cannot be suppressed.

Aliases and abbreviated commands will be flagged as undefined procedures.

## **SEE ALSO**

```
debug_script(2)
package(2)
namespace(2)
```

compare collections 30

# compare\_collections

Compares the contents of two collections. If the same objects are in both collections, the result is "0" (like string compare). If they are different, the result is nonzero. The order of the objects can optionally be considered.

#### **SYNTAX**

int compare\_collections
 [-order\_dependent]
 collection1
 collection2

## **Data Types**

collection1
collection2

collection collection

#### **ARGUMENTS**

#### -order\_dependent

Indicates that the order of the objects is to be considered; that is, the collections are considered to be different if the objects are ordered differently.

#### collection1

Specifies the base collection for the comparison. The empty string (the empty collection) is a legal value for the *collection1* argument.

#### collection2

Specifies the collection with which to compare to *collection1*. The empty string (the empty collection) is a legal value for the *collection2* argument.

### **DESCRIPTION**

compare\_collections 31

The **compare\_collections** command is used to compare the contents of two collections. By default, the order of the objects does not matter, so that a collection of cells u1 and u2 is the same as a collection of the cells u2 and u1. By using the **-order\_dependent** option, the order of the objects is considered.

Either or both of the collections can be the empty string (the empty collection). If two empty collections are compared, the comparison succeeds (that is, **compare\_collections** considers them identical), and the result is "0".

#### **EXAMPLES**

The following example from PrimeTime shows a variety of comparisons. Note that a result of "0" from **compare\_collections** indicates success. Any other result indicates failure.

```
pt_shell> compare_collections [get_cells *] [get_cells *]
0
pt_shell> set c1 [get_cells {u1 u2}]
{"u1", "u2"}
pt_shell> set c2 [get_cells {u2 u1}]
{"u2", "u1"}
pt_shell> set c3 [get_cells {u2 u4 u6}]
{"u2", "u4", "u6"}
pt_shell> compare_collections $c1 $c2
0
pt_shell> compare_collections $c1 $c2 -order_dependent
-1
pt_shell> compare_collections $c1 $c3
-1
```

The following example builds on the previous example by showing how empty collections are compared.

```
pt_shell> set c4 ""
pt_shell> compare_collections $c1 $c4
-1
pt_shell> compare_collections $c4 $c4
0
```

# **SEE ALSO**

```
collections(2)
```

copy collection 32

# copy\_collection

Duplicates the contents of a collection, resulting in a new collection. The base collection remains unchanged.

#### **SYNTAX**

```
collection copy_collection
     collection1
```

#### **Data Types**

collection1

collection

#### **ARGUMENTS**

collection1

Specifies the collection to be copied. If an empty string is used for the *collection1* argument, the command returns the empty string (a copy of the empty collection is an empty collection).

## **DESCRIPTION**

The **copy\_collection** command is an efficient mechanism for creating a duplicate of an existing collection. It is more efficient and almost always sufficient to simply have more than one variable referencing the same collection. For example, if you create a collection of ports in PrimeTime and save a reference to it in a **c1** variable, assigning the value of the **c1** variable to another **c2** variable creates a second reference to the same collection:

```
pt_shell> set c1 [get_cells "U1*"]
{"U1", "U10", "U11", "U12"}
pt_shell> set c2 $c1
{"U1", "U10", "U11", "U12"}
```

This has not copied the collection. There are now two references to the same collection. If you change the c1 variable, the c2 variable continues to reference the same collection:

copy\_collection 33

```
pt_shell> set c1 [get_cells "block1"]
{"block1"}
pt_shell> query_objects $c2
{"U1", "U10", "U11", "U12"}
```

There might be instances when you really do need a copy. In those cases, the **copy\_collection** command is used to create a new collection that is a duplicate of the original.

#### **EXAMPLES**

The following example from PrimeTime shows the result of copying a collection. Functionally, it is not much different that having multiple references to the same collection.

```
pt_shell> set c1 [get_cells "U1*"]
{"U1", "U10", "U11", "U12"}
pt_shell> set c2 [copy_collection $c1]
{"U1", "U10", "U11", "U12"}
pt_shell> unset c1
pt_shell> query_objects $c2
{"U1", "U10", "U11", "U12"}
```

## **SEE ALSO**

collections(2)

cputime 34

# cputime

Reports the CPU time in seconds.

## **SYNTAX**

status cputime
[-all]
[-verbose]

#### **ARGUMENTS**

-all

Reports the total CPU time of the main process and its child processes. This is the default; this option is kept for backward compatibility.

#### -verbose

Reports in detail the CPU time and elapsed (wall-clock) time of the main process and each child process, including placement, extraction, and routing.

#### **DESCRIPTION**

The **cputime** command reports the CPU time in seconds. If you specify **-verbose**, it reports the CPU time and elapsed (wall-clock) time for the main process and each child process. The runtime numbers are collected from the operating system.

When you use the **set\_host\_options** command, the tool runs multiple threads. Currently the operating system measures the CPU time by adding the usage for all threads. It does not take into account parallelization of the threads. This means that the report might show a larger CPU time than elapsed time when you use **set\_host\_options**. The elapsed time (wall-clock time) is more appropriate for measuring multicore runtime.

The elapsed time depends on many external factors and can vary for every session. It depends on factors such as the I/O traffic, the network traffic, RAM and swap usage, and the other processes running on the

cputime 35

same machine. When the elapsed time is much longer than the CPU time, it might point out an inefficiency of the computing environment, such as insufficient memory, too many processes running on the same machine, or a slow network. The only way to make the elapsed time close to the CPU time is to run only one session on a machine with enough RAM and using the local disk.

#### **EXAMPLES**

The following example shows the default command output:

```
prompt> cputime
1202
```

The following example shows the output when using the **-verbose** option:

```
prompt> cputime -verbose
Main process CPU: 1202 s (0.33 hr) Elapse: 1800 s (0.50 hr)
Child "placement" called 3 times, total CPU: 200 s (0.06 hr)
    Elapse: 250 s (0.07 hr)
Child "extraction" called 2 times, total CPU: 100 s (0.03 hr)
    Elapse: 150 s (0.04 hr)
Total CPU: 1502 s ( 0.42 hr) Elapse: 1800 s ( 0.50 hr)
```

## **SEE ALSO**

```
mem(2)
set_host_options(2)
monitor_cpu_memory(3)
.prod psyn icc
PSYN-508(n)
.prod all
```

# create\_command\_group

Creates a new command group.

### **SYNTAX**

```
string create_command_group [-info info_text]
group name
```

# **ARGUMENTS**

```
-info info_text
  Help string for the group
group_name
  Specifies the name of the new group.
```

### **DESCRIPTION**

The **create\_command\_group** command is used to create a new command group, which you can use to separate related user-defined procedures into functional units for the online help facility. When a procedure is created, it is placed in the "Procedures" command group. With the **define\_proc\_attributes** command, you can move the procedure into the group you created.

The *group\_name* can contain any characters, including spaces, as long as it is appropriately quoted. If *group\_name* already exists, **create\_command\_group** quietly ignores the command. The result of **create\_command\_group** is always an empty string.

create\_command\_group 37

# **EXAMPLES**

The following example demonstrates the use of the **create\_command\_group** command:

```
prompt> create_command_group {My Procedures} -info "Useful utilities"
prompt> proc plus {a b} { return [expr $a + $b] }
prompt> define_proc_attributes plus -command_group "My Procedures"
prompt> help
My Procedures:
    plus
...
```

# **SEE ALSO**

```
define_proc_attributes(2)
help(2)
proc(2)
```

# create\_scaling\_lib\_group

Specifies a scaling library group to qualify by check\_library.

## **SYNTAX**

```
status create_scaling_lib_group
library_list
[-name group_name]
[-exact_match_only]
[-exclude voltage names voltage name list]
```

### **Data Types**

```
library list list
```

## **ARGUMENTS**

### library list

Specifies a list of library file names in the scaling library group by cell set. These libraries in the group should have the same set of cells.

### -name group\_name

Specifies a group name to associate with the library group. This is used especially when multiple groups are defined.

```
-exact match only
```

Specifies the library\_list to be used for exact match only without scaling. If not specified, the group is for scaling.

```
-exclude_voltage_names voltage_name_list
```

Excludes these voltage\_names in scaling. For example, -exclude\_voltage\_names {VBP} excludes bias pin voltage\_name VBP to reduce scaling dimension. Normally, a voltage\_name that has dependency on other rails can be ignored. This may include, but not limited to, bias pins. By default, all the rail voltage\_names that are in use are taken as independent dimension for scaling.

# **DESCRIPTION**

The **create\_scaling\_lib\_group** command specifies a scaling library group to qualify by check\_library. The scaling library groups after qualified can be used by downstream tools such as PT for library scaling.

To remove a defined scaling library group, specify an empty library list with the group name -name to be removed:

```
create_scaling_lib_group -name grp2 ""
```

To remove all the defined scaling library groups, specify an empty library list without -name:

```
create_scaling_lib_group ""
```

### **EXAMPLES**

In the following example, a library group consisting of 3 libraries is specified in the group name of grp1:

```
prompt> create_scaling_lib_group -name grp1 "1.db 2.db 3.db"
```

# **SEE ALSO**

```
check_library(2)
write_scaling_lib_group(2)
```

date 40

# date

Returns a string containing the current date and time.

### **SYNTAX**

string date

## **DESCRIPTION**

The **date** command generates a string containing the current date and time, and returns that string as the result of the command. The format is fixed as follows:

```
ddd mmm nn hh:mm:ss yyyy
```

#### Where:

```
ddd is an abbreviation for the day
mmm is an abbreviation for the month
nn is the day number
hh is the hour number (24 hour system)
mm is the minute number
ss is the second number
yyyy is the year
```

The **date** command is useful because it is native. It does not fork a process. On some operating systems, when the process becomes large, no further processes can be forked from it. With it, there is no need to call the operating system with **exec** to ask for the date and time.

# **EXAMPLES**

The following command prints the date.

```
prompt> echo "Date and time: [date]"
Date and time: Thu Dec 9 17:29:51 1999
```

date 41

# **SEE ALSO**

exec(2)

debug\_script 42

# debug\_script

Debug a script using the TclDevKit Tcl debugger.

### **SYNTAX**

string debug\_script script [port] [hostname]

### **ARGUMENTS**

### script

This specifies the Tcl script(s) to be debugged. This script will be sourced and instrumented for debugging.

### port

Specifies the port number that the debugger is listening on for a remote debugging application. By default the debugger will be launched on an available port.

### hostname

Specifies the host where Prodebug is already running. This is used to connect to an existing remote Prodebug session.

```
::env(SNPS TCLPRO HOME)
```

This Tcl variable is used to specify the root of the TclPro installation. It is initialized from the environment variable SNPS\_TCLPRO\_HOME in the user's environment.

### **USING THE PACKAGE**

The **debug\_script** command is in the snpsTclPro Tcl package, and all of the commands in this package are defined in the namespace snpsTclPro. The way to use this command is to load the package, which will import the commands it exports into the global namespace. This is shown below.

debug script 43

```
shell> package require snpsTclPro
1.0
```

These commands can be added to the .synopsys setup file for the system, user, or current directory, or the commands can be typed when the pacakge is needed.

### DESCRIPTION

The **debug\_script** command simplifies the use of the TclDevKit Tcl debugger available from ActiveState (http://www.activestate.com). First it ensures a connection to the Prodebug debugger either by connecting to a running debug session (given a *hostname* and *port*), or by launching the debugger on *localhost* using an available port, and then connecting to it. If there is already an active connection to the debugger then that debugger will simply be used.

Once the connection to the debugger is set up, the specified script will be sourced and debugged. The default behavior for the debugger is to stop at the first line of the source'd script.

The debugger must be run using a "remote" debugging project if you want to connect the Synopsys tools to a running prodebug session. The port number in use by the debugger can be viewed via the Application tab of the "File->Project" Settings dialog.

## **EXAMPLES**

```
# Launch the debugger and then debug the script myscript.tcl.
shell> debug_script myscript.tcl
Selected port 2576 on host localhost
launching prodebug

# now debug another script using the same session
shell> debug_script anotherScript.tcl

# debug myscript.tcl, connecting to the specified debugger session or
# creating one if the connection fails.
shell> debug script myscript.tcl 2576 localhost
```

## **CAVEATS**

The debugger currently kills the process that started the debugger when you exit, despite the preferences being set differently in the debugger.

When the Synopsys tool has spawned a debugger, that debugger must be exited before the Synopsys tool can exit. If this is not the case then the Synopsys tool will hang on exit, until the debugger is exited.

debug script 44

The **debug\_script** command waits for the debug process to start up, before it tries to connect to the debugger. If **debug\_script** times out before the debugger is started due to machine or network loading, simply close the debugger that was launched, and then increase the timeout setting with the command **set\_debugger\_start\_timeout**, and then re-run the debugger. The **set\_debugger\_start\_timeout** command takes a single argument which is the value of the timeout in miliseconds, and the default value for the timeout is 10000.

# **SEE ALSO**

check\_script(2)
package(2)
namespace(2)

# define\_proc\_attributes

Defines attributes of a Tcl procedure, including an information string for help, a command group, a set of argument descriptions for help, and so on. The command returns the empty string.

### **SYNTAX**

```
string define_proc_attributes
```

```
proc_name
[-info info_text]
[-define_args arg_defs]
[-define_arg_groups group_defs]
[-command_group group_name]
[-return type_name]
[-hide_body]
[-hidden]
[-dont_abbrev]
[-permanent]
```

# **Data Types**

```
proc_name string
info_text string
arg_defs list
group_defs list
group_name string
type name string
```

# **ARGUMENTS**

### proc\_name

Specifies the name of the existing procedure.

```
-info info_text
```

Provides a help string for the procedure. This is printed by the **help** command when you request help for the procedure. If you do not specify *info\_text*, the default is "Procedure".

```
-define_args arg_defs
```

Defines each possible procedure argument for use with **help-verbose**. This is a list of lists where each list element defines one argument.

### -define\_arg\_groups group\_defs

Defines argument checking groups. These groups are checked for you in parse\_proc\_arguments. each list element defines one group

#### -command group group name

Defines the command group for the procedure. By default, procedures are placed in the "Procedures" command group.

### -return type\_name

Specifies the type of value returned by this proc. Any value may be specified. Some applications use this information for automatically generated dialogs etc. Please see the type\_name option attribute described below.

### -hide body

Hides the body of the procedure from **info body**.

#### -hidden

Hides the procedure from **help** and **info proc**.

### -dont abbrev

Specifies that the procedure can never be abbreviated. By default, procedures can be abbreviated, subject to the value of the **sh\_command\_abbrev\_mode** variable.

#### -permanent

Defines the procedure as permanent. You cannot modify permanent procedures in any way, so use this option carefully.

#### -deprecated

Defines the procedure as deprecated i.e. it should no longer be called but is still available.

#### -obsolete

Defines the procedure as obsolete i.e. it used to exist but can no longer be called.

### **DESCRIPTION**

The **define\_proc\_attributes** command associates attributes with a Tcl procedure. These attributes are used to define help for the procedure, locate it in a particular command group, and protect it.

When a procedure is created with the **proc** command, it is placed in the Procedures command group. There is no help text for its arguments. You can view the body of the procedure with **info body**, and you can modify the procedure and its attributes. The **define\_proc\_attributes** command allows you to change these aspects of a procedure.

Note that the arguments to Tcl procedures are all named, positional arguments. They can be programmed with default values, and there can be optional arguments by using the special argument name *args*. The

**define\_proc\_attributes** command does not relate the information that you enter for argument definitions with **-define\_args** to the actual argument names. If you are describing anything other than positional arguments, it is expected that you are also using **parse\_proc\_arguments** to validate and extract your arguments.

The *info\_text* is displayed when you use the **help** command on the procedure.

Use **-define\_args** to define help text and constraints for individual arguments. This makes the help text for the procedure look like the help for an application command. The value for **-define\_args** is a list of lists. Each element has the following format:

```
arg_name option_help value_help data_type attributes
```

The elements specify the following information:

- arg\_name is the name of the argument.
- *option\_help* is a short description of the argument.
- *value\_help* is the argument name for positional arguments, or a one word description for dash options. It has no meaning for a Boolean option.
- data\_type is optional and is used for option validation. The data\_type can be any of: string, list, boolean, int, float, or one\_of\_string. The default is string.
- attributes is optional and is used for option validation. The attributes is a list that can have any of the following entries:
  - o "required" This argument must be specified. This attribute is mutually exclusive with optional.
  - "optional" Specifying this argument is optional. This attribute is mutually exclusive with "required."
  - "value\_help" Indicates that the valid values for a one\_of\_string argument should be listed whenever argument help is shown.
  - "values { < list of allowable values > }" If the argument type is one\_of\_string, you must specify the "values" attribute.
  - "type\_name <name>" Give a descriptive name to the type that this argument supports.
     Some applications may use this information to provide features for automatically generated dialogs, etc. Please see product documentation for details. This attribute is not supported on boolean options.
  - "merge\_duplicates" When this option appears more than once in a command, its values are concatenated into a list of values. The default behavior is that the right-most value for the option specified is used.
  - "remainder" Specifies that any additional positional arguments should be returned in this option. This option is only valid for string option types, and by default the option is optional. You can require at least one item to be specified by also including the required option.
  - "deprecated" Specifying this option is deprecated i.e. it should no longer be used but is still available. A warning will be output if this option is specified. This attribute cannot be combined with obsolete or required.
  - o "obsolete" Specifying this option is obsolete i.e. it used to exist but can no longer be used. A

warning will be output if this option is specified. This attribute cannot be combined with deprecated or required.

- "min\_value" <value> Specify the minimum value for this option. This attribute is only valid for integer and float types.
- "max\_value" <value> Specify the maximum value for this option. This attribute is only valid for integer and float types.
- "default" <value> Specify the default value for this option. This attribute is only valid for string, integer and float option types. If the user does not specify this option when invoking the command this default value will be automatically passed to the associated tcl procedure.

The default for attributes is "required."

Use the **-define\_arg\_groups** to define argument checking groups. The format of this option is a list where each element in the list defines an option group. Each element has the following format:

```
{<type> {<opt1> <opt2> ...} [<attributes>]}
```

The types of groups are

- "exclusive" Only one option in an exclusive group is allowed. All the options in the group must have the same required/optional status. This group can contain any number of options.
- "together" If the first option in the group is specified then the second argument is also required. This type of group can contain at most two options.
- \fi"related" These options are related to each other. An automatic dialog builder for this command may try to group these options together.

The supported attributes are:

- {"label" <text>} An optional label text to identify this group. The label may be used by an application to automatically build a grouping in a generated dialog.
- "bidirectional" This is only valid for a together group. It means that both options must be specified together.

Change the command group of the procedure using the **-command\_group** command. Protect the contents of the procedure from being viewed by using **-hide\_body**. Prevent further modifications to the procedure by using **-permanent**. Prevent abbreviation of the procedure by using **-dont\_abbrev**.

### **EXAMPLES**

The following procedure adds two numbers together and returns the sum. For demonstration purposes, unused arguments are defined.

```
prompt> proc plus {a b} { return [expr $a + $b]}
prompt> define_proc_attributes plus -info "Add two numbers" \
? -define_args {
    {a "first addend" a string required}
```

In the following example, the argHandler procedure accepts an optional argument of each type supported by **define\_proc\_attributes**, then displays the options and values received. Note the only one of -Int, -Float, or -Bool may be specified to the command:

```
proc argHandler {args} {
 parse proc arguments -args $args results
 foreach argname [array names results] {
   echo $argname = $results($argname)
define proc attributes argHandler \
 -info "Arguments processor" \
 -define args {
    {-Oos "oos help" AnOos one of string
       {required value help {values {a b}}}}
    {-Int "int help" AnInt int optional}
    {-Float "float help" AFloat float optional}
    {-Bool "bool help" "" boolean optional}
    {-String "string help" AString string optional}
    {-List "list help" AList list optional}
    {-IDup "int dup help" AIDup int {optional merge_duplicates}}
  } \
  -define_arg_groups {
    {exclusive {-Int -Float -Bool}}
```

# **SEE ALSO**

```
help(2)
info(2)
parse_proc_arguments(2)
proc(2)
sh_command_abbrev_mode(3)
```

echo 50

# echo

Echos arguments to standard output.

## **SYNTAX**

```
string echo
[-n]
[arguments]
```

### **Data Types**

arguments

string

# **ARGUMENTS**

-n

Suppresses the new line. By default, **echo** adds a new line.

### arguments

Specifies the arguments to be printed.

## **DESCRIPTION**

The **echo** command prints out the value of the given arguments. Each of the arguments are separated by a space. The line is normally terminated with a new line, but if the **-n** option is specified, multiple **echo** command outputs are printed onto the same output line.

The **echo** command is used to print out the value of variables and expressions in addition to text strings. The output from **echo** can be redirected using the > and >> operators.

echo 51

# **EXAMPLES**

The following are examples of using the **echo** command:

```
prompt> echo
"Running version" $sh_product_version
Running version v3.0a

prompt> echo -n "Printing to" [expr (3 - 2)] > foo
prompt> echo " line." >> foo
prompt> sh cat foo
Printing to 1 line.
```

# **SEE ALSO**

sh(2)

error\_info 52

# error\_info

Prints extended information on errors from the last command.

### **SYNTAX**

string error info

### **ARGUMENTS**

This **error\_info** command has no arguments.

### **DESCRIPTION**

The **error\_info** command is used to display information after an error has occurred. Tcl collects information showing the call stack of commands and procedures. When an error occurs, the **error\_info** command can help you to focus on the exact line in a block that caused the error.

## **EXAMPLES**

This example shows how **error\_info** can be used to trace an error. The error is that the iterator variable "s" is not dereferenced in the 'if' statement. It should be \$ == "a" '.

```
prompt> foreach s $my_list {
        if { s == "a" } {
            echo "Found 'a'!"
        }
    }
Error: syntax error in expression " s == "a" "
        Use error_info for more info. (CMD-013)
shell> error_info
```

error\_info 53

```
Extended error info:
syntax error in expression " s == "a" "
    while executing
"if { s == a } {
        echo "Found 'a'"
}"
    ("foreach" body line 2)
    invoked from within
"foreach s [list a b c] {
    if { s == a } {
        echo "Found 'a'"
}
}"
-- End Extended Error Info
```

exit 54

# exit

Terminates the application.

### **SYNTAX**

```
integer exit
  [exit_code]
```

### **Data Types**

exit\_code

integer

# **ARGUMENTS**

exit\_code

Specifies the return code to the operating system. The default value is 0.

# **DESCRIPTION**

This command exits from the application. You have the option to specify a code to return to the operating system.

# **EXAMPLES**

The following example exits the current session and returns the code 5 to the operating system. At a UNIX operating system prompt, verify (**echo**) the return code as shown.

```
prompt> exit 5
```

exit 55

% echo \$status

# **SEE ALSO**

quit(2)

filter\_collection 56

# filter\_collection

Filters an existing collection, resulting in a new collection. The base collection remains unchanged.

## **SYNTAX**

collection filter\_collection
[-regexp]
[-nocase]
collection1

### **Data Types**

expression

collection1 expression

collection string

## **ARGUMENTS**

#### -regexp

Specifies that the  $=\sim$  and  $!\sim$  filter operators will use real regular expressions. By default, the  $=\sim$  and  $!\sim$  filter operators use simple wildcard pattern matching with the \* and ? wildcards.

#### -nocase

Makes the pattern match case-insensitive.

### collection1

Specifies the base collection to be filtered. This collection is copied to the result collection. Objects are removed from the result collection if they are evaluated as **false** by the conditional *expression* value. Substitute the collection you want for *collection1*.

### expression

Specifies an expression with which to filter collection1. Substitute the string you want for expression.

filter collection 57

### DESCRIPTION

Filters an existing collection, resulting in a new collection. The base collection remains unchanged. In many cases, application commands that create collections support a *-filter* option that filters as part of the collection process, rather than after the collection has been made.

This type of filtering is almost always more efficient than using the **filter\_collection** command after a collection has been formed. The **filter\_collection** command is most useful if you plan to filter the same large collection many times using different criteria.

The **filter\_collection** command results in either a new collection or an empty string. A resulting new collection contains the subset of the objects in the input *collection1*. A resulting empty string (the empty collection) indicates that the *expression* filtered out all elements of the input *collection1*.

The basic form of the conditional expression is a series of relations joined together with AND and OR operators. Parentheses () are also supported. The basic relation contrasts an attribute name with a value through a relational operator. For example,

```
always on == true and cell leakage power <= 1.6
```

The value side of a relation can be a simple string, quoted string, or an attribute name prefixed with "@". For example:

```
input_delay<=@output_delay
input_delay<=0.24
name=="@literal name"</pre>
```

### The relational operators are

```
== Equal
!= Not equal
> Greater than
< Less than
>= Greater than or equal to
<= Less than or equal to
=~ Matches pattern
!~ Does not match pattern</pre>
```

#### The basic relational rules are

- String attributes can be compared with any operator.
- Numeric attributes cannot be compared with pattern match operators.
- Boolean attributes can be compared only with == and !=. The value can be only either true or false.

Existence relations determine if an attribute is defined or not defined for the object. For example,

```
(sense == setup clk rise) and defined(sdf cond)
```

### The existence operators are

```
defined undefined !defined
```

filter collection 58

These operators apply to any attribute as long as it is valid for the object class.

Collection attributes support a special sizeof(attrName) operator that returns the number of objects in the attribute. If the attribute is not set then 0 is returned.

The **filter\_collection** command has a *-regexp* option that uses regular expressions when matching for string attributes. Regular expression matching is done in the same way as in the Tcl **regexp** command. When using the *-regexp* option, take care in the way you quote the filter *expression*. Using rigid quoting with curly braces around regular expressions is recommended.

Regular expressions are always anchored; that is, the expression is assumed to begin matching at the beginning of an object name and end matching at the end of an object name. You can widen the search simply by adding ".\*" to the beginning or end of the expressions as needed. You can make the regular expression search case-insensitive by using the *-nocase* option.

### **EXAMPLES**

The following example creates a collection of only always on cells.

```
lc_shell> set a [filter_collection [get_lib_cells */*] \
"always_on == true"]
{"cell1", "cell2"}
```

### **SEE ALSO**

```
collections(2)
regexp(2)
```

foreach in collection 59

# foreach\_in\_collection

Iterates over the elements of a collection.

### **SYNTAX**

```
string foreach_in_collection
  itr_var
  collections
  body
```

## **Data Types**

```
itr_var string
collections list
body string
```

## **ARGUMENTS**

```
itr_var
```

Specifies the name of the iterator variable.

### collections

Specifies a list of collections over which to iterate.

### body

Specifies a script to execute per iteration.

# **DESCRIPTION**

The **foreach\_in\_collection** command is used to iterate over each element in a collection. You cannot use the Tcl-supplied **foreach** command to iterate over collections because the **foreach** command requires a list, and a collection is not a list. Also, using the **foreach** command on a collection causes the collection to be deleted.

foreach\_in\_collection 60

The arguments for the **foreach\_in\_collection** command parallel those of the **foreach** command: an iterator variable, the collections over which to iterate, and the script to apply at each iteration. All arguments are required.

Note: The **foreach\_in\_collection** command does not allow a list of iterator variables.

During each iteration, the *itr\_var* option is set to a collection of exactly one object. Any command that accepts *collections* as an argument also accepts *itr\_var* because they are of the same data type (collection).

You can nest the **foreach\_in\_collection** command within other control structures, including another **foreach\_in\_collection** command.

Note that if the body of the iteration is modifying the netlist, it is possible that all or part of the collection involved in the iteration will be deleted. The **foreach\_in\_collection** command is safe for such operations. If a command in the body causes the collection to be removed, at the next iteration, the iteration ends with a message indicating that the iteration ended prematurely.

An alternative to collection iteration is to use complex filtering to create a collection that includes only the desired elements, then apply one or more commands to that collection. If the order of operations does not matter, the following are equivalent. The first is an example without iterators.

```
set s [get_cells {U1/*}]
command1 $s
command2 $s
unset s
```

The following is a similar approach using the **foreach\_in\_collection** command:

```
foreach_in_collection itr [get_cells {U1/*}] {
  command1 $itr
  command2 $itr
}
```

For collections with large numbers of objects, the non-iterator version is more efficient, though both produce the same results if the commands are order-independent.

## **EXAMPLES**

The following example from PrimeTime removes the wire load model from all hierarchical cells in the current instance.

foreach in collection 61

# **SEE ALSO**

collections(2)
foreach(2)

get\_app\_var 62

# get\_app\_var

Gets the value of an application variable.

### **SYNTAX**

```
string get_app_var
  [-default | -details | -list]
  [-only_changed_vars]
  var
```

## **Data Types**

var string

# **ARGUMENTS**

#### -default

Gets the default value.

### -details

Gets additional variable information.

#### -list

Returns a list of variables matching the pattern. When this option is used, then the var argument is interpreted as a pattern instead of a variable name.

### -only\_changed\_vars

Returns only the variables matching the pattern that are not set to their default values, when specified with **-list**.

### var

Specifies the application variable to get.

get\_app\_var 63

### DESCRIPTION

The **get\_app\_var** command returns the value of an application variable.

There are four legal forms for this command:

- get\_app\_var <var>
   Returns the current value of the variable.
- get\_app\_var <var> -default Returns the default value of the variable.
- get app var <var> -details

Returns more detailed information about the variable. See below for details.

• get\_app\_var -list [-only\_changed\_vars] <pattern>

Returns a list of variables matching the pattern. If *-only\_changed\_vars* is specified, then only variables that are changed from their default values are returned.

In all cases, if the specified variable is not an application variable, then a Tcl error is returned, unless the application variable **sh\_allow\_tcl\_with\_set\_app\_var** is set to true. See the **sh\_allow\_tcl\_with\_set\_app\_var** man page for details.

When **-details** is specified, the return value is a Tcl list that is suitable as input to the Tcl **array set** command. The returned value is a list with an even number of arguments. Each odd-numbered element in the list is a key, and each even-numbered element in the list is the value of the previous key.

The supported keys are as follows:

name

This key contains the name of the variable. This key is always present.

value

This key contains the current value of the variable. This key is always present.

default

This key contains the default value of the variable. This key is always present.

help

This key contains the help string for the variable. This key is always present, but sometimes the value is empty.

type

This key contains the type of the application variable. Legal values of for this key are: string, bool, int, real. This key is always present.

get app\_var 64

#### constraint

This key describes additional constraints placed on this variable. Legal values for this key are: none, list, range. This key is always present.

min

This key contains the min value of the application variable. This key is present if the constraint is range. The value of this key may be the empty string, in which case the variable only has a max value constraint.

max

This key contains the max value of the application variable. This key is present if the constraint is "range". The value of this key may be the empty string, in which case the variable only has a min value constraint.

list

This key contains the list of legal values for the application variable. This key is present if the constraint is "list".

### **EXAMPLES**

The following are examples of the **get\_app\_var** command:

```
prompt> get_app_var sh_enable_page_mode
1

prompt> get_app_var sh_enable_page_mode -default
false

foreach {key val} [get_app_var sh_enable_page_mode -details] {            echo "$key: $val" }

=> name: sh_enable_page_mode
            value: 1
            default: false
            help: Displays long reports one page at a time
            type: bool
            constraint: none

prompt> get_app_var -list sh_*message
sh_new_variable_message
```

# **SEE ALSO**

```
report_app_var(2)
set_app_var(2)
write app var(2)
```

# get\_command\_option\_values

Queries current or default option values.

### **SYNTAX**

```
get_command_option_values
  [-default | -current]
  -command_command_name
```

## **Data Types**

command name string

## **ARGUMENTS**

-default

Gets the default option values, if available.

-current

Gets the current option values, if available.

-command command name

Gets the option values for this command.

# **DESCRIPTION**

This command attempts to query a default or current value for each option (of the command) that has default and/or current-value-tracking enabled. Details of how the option value is queried depend on whether one of the **-current** or **-default** options is specified (see below).

A "Tcl array set compatible" (possibly empty) list of option names and values is returned as the Tcl result. The even-numbered entries in the list are the names of options that were enabled for default-value-tracking or current-value-tracking and had at least one of these values set to a not-undefined value). Each odd-numbered entry in the list is the default or current value of the option name preceding it in the list.

Any options that were not enabled for either default-value-tracking nor current-value-tracking are omitted from the output list. Similarly, options that were enabled for default-value-tracking or current-value-tracking, but for which no (not-undefined) default or current value is set, are omitted from the result list.

If neither **-current** nor **-default** is specified, then for each command option that has either default-value-tracking or current-value-tracking (or both) enabled, the value returned is as follows:

- The current value is returned if current-value-tracking is enabled and a (not-undefined) current value has been set;
- Otherwise the default value is returned if default-value-tracking is enabled and a (not-undefined) default value has been set;
- Otherwise the name and value pair for the option is not included in the result list.

If **-current** is specified, the value returned for an option is the current value if current-value-tracking is enabled, and a (not-undefined) current value has been set; otherwise the name and value pair for the option is omitted from the result list.

If **-default** is specified, the value returned for an option is the default value if default-value-tracking is enabled, and a (not-undefined) default value has been set; otherwise the name and value pair for the option is omitted from the result list.

The result list from **get\_command\_option\_values** includes option values of both dash options and positional options (assuming that both kinds of options of a command have been enabled for value-tracking).

The command issues a Tcl error in a variety of situations, such as if an invalid command name was passed in with **-command**.

## **EXAMPLES**

The following example shows the use of **get\_command\_option\_values**:

```
prompt> test -opt1 10 -opt2 20
1
prompt> get_command_option_values -command test
-bar1 10 -bar2 20
```

# **SEE ALSO**

preview(2)
set\_command\_option\_value(2)

get\_defined\_commands 68

# get\_defined\_commands

Get information on defined commands and groups.

### **SYNTAX**

```
string get_defined_commands [-details]
    [-groups]
    [pattern]
string pattern
```

## **ARGUMENTS**

-details

Get detailed information on specific command or group.

-groups

Search groups rather than commands

pattern

Return commands or groups matching pattern. The default value of this argument is "\*".

## **DESCRIPTION**

The **get\_defined\_commands** gets information about defined commands and command groups. By default the command returns a list of commands that match the specified pattern.

When **-details** is specified, the return value is a list that is suitable as input to the **array set** command. The returned value is a list with an even number of arguments. Each odd-numbered element in the list is a key name, and each even-numbered element in the list os the value of the previous key. The **-details** option is only legal if the pattern matches exactly one command or group.

When -group is specified with -details, the supported keys are as follows:

get defined commands 69

name

This key contains the name of the group.

info

This key contains the short help for the group.

commands

This key contains the commands in the group

When -details is used with a command, the supported keys are as follows:

name

This key contains the name of the command.

info

This key contains the short help for the command.

groups

This key contains the group names that this command belongs to.

options

This key contains the options defined for the command. The value is a list.

return

This key contains the return type for the command.

Each element in the *options* list also follows the key value pattern. The set of available keys for options are as follows:

name

This key contains the name of the option.

info

This key contains the short help for the option.

value\_info

This key contains the short help string for the value

type

The type of the option.

required

The value will be 0 or 1 depending if the option is optional or required.

is\_list

Will be 1 if the option requires a list.

### list\_length

If a list contains the list length constraint. One of any, even, odd, non\_empty or a number of elements.

### allowed\_values

The allowed values if the option has specified allowed values.

### min\_value

The minimum allowed value if the option has specified one.

### max\_value

The maximum allowed value if the option has specified one.

## **EXAMPLES**

```
prompt> get_defined_commands *collection
add_to_collection append_to_collection copy_collection filter_collection
foreach_in_collection index_collection sort_collection
prompt> get_defined_commands -details sort_collection
name sort_collection info {Create a sorted copy of the collection}
groups {} options {{name -descending info {Sort in descending order}}
value_info {} type boolean required 1 is_list 0} {name -dictionary info
{Sort strings dictionary order.} value_info {} type boolean required 1
is_list 0} {name collection info {Collection to sort} value_info
collection type string required 0 is_list 0} {name criteria info {Sort
criteria - list of attributes} value_info criteria type list required 0
is list 1 list length non empty}}
```

## **SEE ALSO**

help(2) man(2)

get lib attribute 71

# get\_lib\_attribute

Returns the value of an attribute on a list of design or library objects.

### **SYNTAX**

```
list get_lib_attribute
  object_list
  attribute name
```

## **Data Types**

```
object_list list
attribute_name string
[-line_number]
```

# **ARGUMENTS**

```
object list
```

Specifies a list of the design or library objects for which the attribute value is returned.

```
attribute name
```

Specifies the name of the attribute whose value is returned.

```
-line number
```

If this option is specified, will return the line number of the specified attribute under the specified object. If the attribute is like voltage\_map which can be defined multiple times, it returns a line number list. It only works on those objects which are compiled by read\_lib. If the object is loaded by read\_db, - line\_number always returns 0.

# **DESCRIPTION**

This command searches the object\_list for the specified attribute and returns a list of attribute values. By

get lib attribute 72

default, if a specified object cannot be found or the attribute does not exist on the object, that object is ignored.

# **Multicorner-Multimode Support**

This command uses information from the current scenario only.

The following example gets the value of the load attribute for all the pins under lib/IN1:

```
lc_shell> get_lib_attribute [get_lib_pins lib/IN1/*] load
1.0 2.0 2.5 1.0
```

The following example gets the value and line number of the **voltage\_map** attribute for the library:

```
lc_shell> get_lib_attribute [get_libs my_lib] voltage_map
{{COREVDD1 0.990000} {COREGND1 0.000000}}

lc_shell> get_lib_attribute [get_libs my_lib] voltage_map -line_number
100 101
```

# **SEE ALSO**

```
collections(2)
foreach_in_collection(2)
set attribute(2)
```

get\_lib\_cells 73

# get\_lib\_cells

Creates a collection of library cells from the libraries loaded into memory.

## **SYNTAX**

```
collection get_lib_cells
  [-quiet]
  [-regexp]
  [-nocase]
  [-filter expression]
  patterns
```

## **Data Types**

```
expression string
patterns list
```

# **ARGUMENTS**

#### -regexp

Views the patterns argument as a regular expression rather than a simple wildcard pattern.

This option also modifies the behavior of the  $=\sim$  and  $!\sim$  filter operators to use regular expressions rather than simple wildcard patterns.

The regular expression matching is similar to the Tcl **regexp** command. When using the **-regexp** option, be careful how you quote the *patterns* argument and filter expression. Using rigid quoting with curly braces around regular expressions is recommended. Note that regular expressions are always anchored; that is, the expression is assumed to begin matching at the beginning of an object name and end matching at the end of an object name. You can widen the search by adding ".\*" to the beginning or end of the expressions, as needed.

#### -nocase

Makes matches case-insensitive, both for the *patterns* argument and for the ==,  $=\sim$ , and  $!\sim$  filter operators.

#### -filter expression

Filters the collection with the specified expression. For each library cell in the collection, the expression

get lib cells 74

is evaluated based on the library cell's attributes. If the expression evaluates to true, the library cell is included in the result.

To see the list of library cell attributes that you can use in the expression, use the **list\_attributes - application -class lib\_cell** command.

For more information about how to use the **-filter** option, see the **filter\_collection** man page.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### patterns

Creates a collection of library cells whose names match the specified patterns. Patterns can include the \* (asterisk) and ? (question mark) wildcard characters. For more information about using and escaping wildcards, see the **wildcards** man page.

## DESCRIPTION

This command creates a collection of library cells from the libraries currently loaded into memory that match the specified criteria.

The command returns a collection if any library cells match the criteria. If no objects match the criteria, the command returns an empty string.

You can use this command at the command prompt or you can nest it as an argument to another command. In addition, you can assign the result to a variable.

By default, it displays a maximum of 100 objects. You can change this maximum by using the **collection\_result\_display\_limit** variable.

For information about collections and the querying of objects, see the **collections** man page.

# **Multicorner-Multimode Support**

By default, this command uses information from all active scenarios.

# **EXAMPLES**

The following example queries all library cells that are in the misc\_cmos library whose names begin with AN2. Although the output looks like a list, it is just a display.

```
prompt> get_lib_cells misc_cmos/AN2*
{misc cmos/AN2 misc cmos/AN2P}
```

get lib cells 75

# **SEE ALSO**

collections(2)
filter\_collection(2)
collection\_result\_display\_limit(3)
wildcards(3)

get\_lib\_grid\_points 76

# get\_lib\_grid\_points

Get the qualified grid points in library based on query parameter.

# **SYNTAX**

#### lookup table

input\_csv\_file
output\_csv\_file
[matching point]

# **Data Types**

```
input_csv_file string
output_csv_file string
matching point int
```

# **ARGUMENTS**

```
input_csv_file
```

Specifies the input file name contains query parameter.

```
output_csv_file
```

Specifies the output file name for query result.

```
matching point
```

## Query method:

```
'1' - get 1-closest grid point (by default)
'4' = get 4=closest bucket grid points.
```

## **DESCRIPTION**

This command will query the qualified charaterization data point based on the query parameters in the input csv file, and write out the query result to the output csv file. This commands depend on other tcl

get\_lib\_grid\_points 77

commands: get\_lib\_cells/get\_timing\_arcs/get\_lookup\_table/lookup\_table/get\_objects

The input csv file contains query paremters in a formal format. The first line should be the index line, all the allowed index names are listed below. These index sequence can be changed, but index names are pre-defined and can't be changed.

```
instance
db_filename
library
cell
pin
group
related_pin
timing_type
timing_sense
when_cond
related_pg_pin
input_slew
output load
```

The index names should be separated by comma in the csv file, and each sub record should have same number of fields as the index (specify NULL if any field is empty). User can choose to use part of these indexes or all of them for query, if any index is not needed, it can be missed in the file.

The output csv file contains all the input query-parameter file info, plus the qualified data points info. The query result indexes (listed below) are added after the query parameter indexes in the first line, and the result data for each record is added similarly.

### For 1-closest grid point matching:

```
idx1
idx2
value
```

## For 4-closest bucket points matching:

```
idx1_a
idx2_a
value_a
idx1_b
idx2_b
value_b
idx1_c
idx2_c
value_c
idx1_d
idx2_d
value_d
value_d
```

Not all the fields are filled after query. It depends on table dimension. For 1-closest grid point matching:

```
2-D table: 1 point value with 2 indexes.1-D table: 1 point value with only 1 index.Scalar table: 1 point value with no index.
```

#### For 4-closest bucket points matching:

```
2-D table: 4 point values with 2 indexes.1-D table: 2 points values with only 1 index.Scalar table: 1 point value with no index.
```

The index and point value is formatted with 7 significant digit float number (or scientific notation).

get lib grid points 78

## **EXAMPLES**

The following example shows query 1-closest-grid point

```
Input csv file: /slow/test/input.csv

db_filename,instance,library,cell,pin,related_pin,timing_type,timing_sense,when_cond,group,input_s1
/slow/lib/tsmc.db, INT1, tsmc16nm, AND2, Z, A, combinational, positive_unate, "B", cell_rise, 0.002
/slow/lib/tsmc.db, INT2, tsmc16nm, AND2, Z, B, combinational, positive_unate, "A", cell_rise, 0.003
/slow/lib/tsmc.db, INT3, tsmc16nm, OR2, Z, A, combinational, positive_unate, "!B", cell_rise, 0.004
lc_shell>get_lib_grid_points /slow/test/input.csv /slow/test/output.csv 1

Output csv file: /slow/test/output.csv

db_filename,instance,library,cell,pin,related_pin,timing_type,timing_sense,when_cond,group,input_s1
/slow/lib/tsmc.db, INT1, tsmc16nm, AND2, Z, A, combinational, positive_unate, "B", cell_rise, 0.002
/slow/lib/tsmc.db, INT2, tsmc16nm, AND2, Z, B, combinational, positive_unate, "A", cell_rise, 0.003
/slow/lib/tsmc.db, INT3, tsmc16nm, OR2, Z, A, combinational, positive_unate, "B", cell_rise, 0.004
```

# **SEE ALSO**

```
lookup_table(2)
get_lookup_table(2)
get_objects(2)
get_lib_cells(2)
get objects(2)
```

get lib objects 79

# get\_lib\_objects

Returns a collection of objects.

# **SYNTAX**

```
collection get_lib_objects
  [-class_type class_type]
  [-quiet]
  [-regexp]
  [-nocase]
  [-parent]
  [-line_number]
  [-user_defined_data]
  [-filter expression]
  [-traits expression]
  [patterns | -of_objects objects]
```

## **Data Types**

```
expression string
expression string
patterns string
```

# **ARGUMENTS**

### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

### -regexp

Views the *patterns* argument as a regular expression rather than a simple wildcard pattern.

This option also modifies the behavior of the  $=\sim$  and  $!\sim$  filter operators to use regular expressions rather than simple wildcard patterns.

The regular expression matching is similar to the Tcl **regexp** command. When using the **-regexp** option, be careful how you quote the *patterns* argument and filter expression. Using rigid quoting with curly braces around regular expressions is recommended. Note that regular expressions are always anchored; that is, the expression is assumed to begin matching at the beginning of an object name and

get lib objects 80

end matching at the end of an object name. You can widen the search by adding ".\*" to the beginning or end of the expressions, as needed.

## -class\_type

Specifies the liberty object class of the returned object collection. The valid values are: library, cell, pin,pg\_pin, timing, ccsn\_stage,pg\_pin,internal\_power, leakage\_power and all other legal liberty syntax groups.

#### -nocase

Makes matches case-insensitive, for the *patterns* argument.

### -parent

Specifies this option to return the parent objects of the *of\_objects* argument.

#### -line number

If this option is specified, it will return a list of line number of the objects specified in of\_objects option. It only works on those objects which are compiled by read\_lib. If the object is loaded by read\_db, - line\_number always returns 0.

### -user defined data

If this option is specified, it can return the object which is user defined with the object class specified by -class\_type.

### -filter expression

Filters the collection with the specified expression. For each library in the collection, the expression is evaluated based on the library's attributes. If the expression evaluates to true, the library is included in the result.

To see the list of library attributes that you can use in the expression, use the **list\_attributes - application -class class\_type** command.

For more information about how to use the **-filter** option, see the **filter\_collection** man page.

## -traits expression

Filters the collection with the specified trait. Traits is an expression which works in the same way as filter expression. It is used to filter high level property on an object. The following are supported trais for different class\_type objects. cell: std, macro, memory, multibit, flip\_flop, latch, nand\_cell, and\_cell, nor\_cell, or\_cell, inverter\_cell, buffer\_cell, is\_retention, is\_level\_shifter, multi\_voltage, icg, isolation ccsn\_stage: is\_first timing:input\_rising, input\_falling, output\_rising, output\_falling, related\_rising, related\_falling, delay, constraint, setup\_hold, sequential, combinational, noise\_arc.

#### patterns

Creates a collection of objects whose names match the specified patterns. Patterns can include the \* (asterisk) and ? (question mark) wildcard characters. Patterns are only useful when the returned objectc have names.

The *patterns* and **-of\_objects** arguments are mutually exclusive; you can specify only one. If you do not specify any of these arguments, the command uses the \* (asterisk) as the default pattern.

#### -of objects objects

get lib objects 81

Specifies the input owner collection. For each object in the of\_objects collection, get\_lib\_objects tries to find all the objects under it. The liberty group type of the input collection can also be the same as class\_type. In that case, get\_lib\_objects returns the objects that pass the filter and pattern matching.

If the liberty group type of the input collection is different from class\_type, get\_lib\_objects only finds the objects directly under the input collection and returns the objects if they are qualified.

The *patterns* and **-of\_objects** arguments are mutually exclusive; you can specify only one. If you do not specify any of these arguments, the command uses the \* (asterisk) as the default pattern.

# **DESCRIPTION**

This command returns a collection of objects currently loaded into memory that match the specified criteria.

If no objects match the criteria, the command returns an empty string.

For information about collections and the querying of objects, see the **collections** man pages.

# **EXAMPLES**

The following example queries cells and timings under my\_lib.

```
lc_shell> get_lib_objects my_libs/.* -class_type cell -regexp
{"my_lib/my_cell"}
lc_shell> get_lib_objects -of_objects [get_libs my_lib] -class_type cell -traits and_cell
{"my_lib/my_cell"}
lc_shell> get_lib_objects -of_objects [get_lib_cells my_lib/my_cell] -parent
{"my_lib"}
lc_shell> get_lib_objects -of_objects [get_lib_pins my_lib/my_cell/my_pin] -class_type timing
sel_5
lc_shell> get_lib_objects -of_objects [get_lib_cells my_lib/*] -line_number
100
lc_shell> get_lib_objects -user_defined_data -of_objects [get_lib_cells my_lib/*] -class_type "ud
sel_6
```

# **SEE ALSO**

```
collections(2)
filter collection(2)
```

get lib pins 82

# get\_lib\_pins

Creates a collection of library cell pins from libraries loaded into memory.

## **SYNTAX**

```
collection get_lib_pins
  [-regexp]
  [-nocase]
  [-filter expression]
  patterns
```

## **Data Types**

```
expression string
patterns list
```

# **ARGUMENTS**

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -regexp

Views the patterns argument as a regular expression rather than a simple wildcard pattern.

This option also modifies the behavior of the  $=\sim$  and  $!\sim$  filter operators to use regular expressions rather than simple wildcard patterns.

The regular expression matching is similar to the Tcl **regexp** command. When using the **-regexp** option, be careful how you quote the *patterns* argument and filter expression. Using rigid quoting with curly braces around regular expressions is recommended. Note that regular expressions are always anchored; that is, the expression is assumed to begin matching at the beginning of an object name and end matching at the end of an object name. You can widen the search by adding ".\*" to the beginning or end of the expressions, as needed.

#### -nocase

Makes matches case-insensitive, both for the patterns argument and for the ==,  $=\sim$ , and  $!\sim$  filter operators.

get lib pins 83

#### -filter expression

Filters the collection with the specified expression. For each library cell pin in the collection, the expression is evaluated based on the library cell pin's attributes. If the expression evaluates to true, the library cell pin is included in the result.

To see the list of library cell pin attributes that you can use in the expression, use the **list\_attributes - application -class lib\_pin** command.

For more information about how to use the **-filter** option, see the **filter\_collection** man page.

#### patterns

Creates a collection of library cell pins whose names match the specified patterns. Patterns can include the \* (asterisk) and ? (question mark) wildcard characters. For more information about using and escaping wildcards, see the **wildcards** man page.

## DESCRIPTION

This command creates a of library cell pins from the libraries currently loaded into memory that match the specified criteria.

If no libraries have been loaded into memory, the tool loads the libraries specified in the **link\_library** variable into memory the first time you run the **get\_libs**, **get\_lib\_cells**, or **get\_lib\_pins** command.

The command returns a collection if any library cell pins match the criteria. If no objects match the criteria, the command returns an empty string.

You can use this command at the command prompt or you can nest it as an argument to another command, such as **query\_objects**. In addition, you can assign the result to a variable.

By default, it displays a maximum of 100 objects. You can change this maximum by using the **collection\_result\_display\_limit** variable.

For information about collections and the querying of objects, see the **collections** man page.

## **Multicorner-Multimode Support**

This command uses information from all active scenarios.

## **EXAMPLES**

The following example queries all pins of the AN2 library cell in the misc\_cmos library. Although the output looks like a list, it is just a display.

```
prompt> get_lib_pins misc_cmos/AN2/*
{misc cmos/AN2/A misc cmos/AN2/B misc cmos/AN2/Z}
```

get lib pins 84

# **SEE ALSO**

collections(2)
filter\_collection(2)
get\_libs(2)
get\_lib\_cells(2)

get\_lib\_timing\_arcs 85

# get\_lib\_timing\_arcs

Returns a timing collection.

# **SYNTAX**

```
collection get_objects
  -of_objects object_list
[-to to_list]
[-from from_list]
[-filter expression]
[-arc_type delay_arc|constraint_arc]
[-quiet]
```

## **Data Types**

```
to_list list
from_list list
object_list list
expression string
```

# **ARGUMENTS**

```
-of_objects object_list
```

Required. Specifies a cell collection or a timing collection.

```
-to to_list
```

Specifies the owner pin of the timings users want to get.

```
-from from list
```

Specifies a list of related pins of the timings users want to get.

## -filter expression

Filters the collection with the specified expression. For each library in the collection, the expression is evaluated based on the library's attributes. If the expression evaluates to true, the library is included in the result.

To see the list of library attributes that you can use in the expression, use the **list\_attributes - application -class timing** command.

get lib\_timing\_arcs 86

For more information about how to use the **-filter** option, see the **filter\_collection** man page.

```
-arc_type delay_arc|constraint_arc
```

Specified the timing arc type. If it is not specified it returns all the timing arcs under the collections specified in **-of\_objects**.

### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

# **DESCRIPTION**

This command returns a collection of timing objects currently loaded into memory that match the specified criteria.

If no objects match the criteria, the command returns an empty string.

For information about collections and the querying of objects, see the **collections** man page.

# **EXAMPLES**

The following example queries all timing objects under my\_lib/my\_cell/A.

```
prompt> get_lib_timing_arcs -of_objects [get_lib_cell my_lib/my_cell] -to A
```

# **SEE ALSO**

collections(2)
filter\_collection(2)

get libs 87

# get\_libs

Creates a collection of libraries loaded into memory.

## **SYNTAX**

```
collection get_libs
  [-quiet]
  [-regexp]
  [-nocase]
  [-filter expression]
  [patterns]
```

## **Data Types**

```
expression string patterns list
```

## **ARGUMENTS**

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

### -regexp

Views the patterns argument as a regular expression rather than a simple wildcard pattern.

This option also modifies the behavior of the  $=\sim$  and  $!\sim$  filter operators to use regular expressions rather than simple wildcard patterns.

The regular expression matching is similar to the Tcl **regexp** command. When using the **-regexp** option, be careful how you quote the *patterns* argument and filter expression. Using rigid quoting with curly braces around regular expressions is recommended. Note that regular expressions are always anchored; that is, the expression is assumed to begin matching at the beginning of an object name and end matching at the end of an object name. You can widen the search by adding ".\*" to the beginning or end of the expressions, as needed.

### -nocase

Makes matches case-insensitive, for the *patterns* argument.

get libs 88

#### -filter expression

Filters the collection with the specified expression. For each library in the collection, the expression is evaluated based on the library's attributes. If the expression evaluates to true, the library is included in the result.

To see the list of library attributes that you can use in the expression, use the **list\_attributes - application -class library** command.

For more information about how to use the **-filter** option, see the **filter\_collection** man page.

#### patterns

Creates a collection of libraries whose names match the specified patterns. Patterns can include the \* (asterisk) and ? (question mark) wildcard characters. For more information about using and escaping wildcards, see the **wildcards** man page.

## DESCRIPTION

This command creates a collection of libraries from the libraries currently loaded into memory that match the specified criteria.

If no libraries have been loaded into memory, the tool loads the libraries specified in the **link\_library** variable into memory the first time you run the **get\_libs**, **get\_lib\_cells**, or **get\_lib\_pins** command.

The command returns a collection if any libraries match the criteria. If no objects match the criteria, the command returns an empty string.

By default, it displays a maximum of 100 objects. You can change this maximum by using the **collection\_result\_display\_limit** variable.

For information about collections and the querying of objects, see the **collections** man page.

# **Multicorner-Multimode Support**

By default, this command uses information from all active scenarios. You can select different scenarios by using the **-scenarios** option.

## **EXAMPLES**

The following example queries all loaded libraries. Use the **list\_libs** command to get a complete listing of the libraries.

```
prompt> get_libs
{misc_cmos misc_cmos_io}
```

get libs 89

# **SEE ALSO**

collections(2)
filter\_collection(2)

get\_license 90

# get\_license

Obtains a license for a feature.

# **SYNTAX**

```
status get_license
  feature_list
  [-quantity num licenses]
```

# **Data Types**

```
feature_list list
num licenses integer
```

# **ARGUMENTS**

#### feature list

Specifies a list of features to be obtained. If you specify more than one feature, the list must be enclosed in braces  $(\{\})$ .

By looking at your key file, you can determine all of the features licensed at your site.

```
-quantity num_licenses
```

Specifies the total number of licenses to be checked out for each feature after the command has completed. If some licenses have already been checked out, the command acquires only the additional licenses needed to bring the total to the specified quantity. If this option is not specified, only one license is checked out for each feature.

# **DESCRIPTION**

This command obtains a license for the specified features. These features are checked out by the current user until the **remove\_license** command is used or until the program exits.

get license 91

If multiple licenses are required for a multicore run, you can use the **-quantity** option to specify the total number of licenses needed (which might be different than the incremental number of licenses that the command checks out). You can use this option to reserve the required number of licenses early in the session, rather than risking a failure later in the session if the licenses are not available.

The **list\_licenses** command provides a list of the features that you are currently using.

## **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

## **EXAMPLES**

The following example obtains the multivoltage feature:

```
prompt> get license Galaxy-MV
```

The following example obtains two copies of the licenses required to run a multicore **compile\_ultra** command in Design Compiler:

```
prompt> get license -quantity 2 {DC-Expert DC-Ultra-Opt DC-Ultra-Features}
```

# **SEE ALSO**

```
check_license(2)
license_users(2)
list_licenses(2)
remove_license(2)
```

get\_lookup\_tables 92

# get\_lookup\_tables

Retrieve a collection of lookup table objects.

# **SYNTAX**

```
collection get_lookup_tables
  [-of_objects]
  [-quiet]
  group_type
```

# **Data Types**

```
of_objects list
group_type string
```

# **ARGUMENTS**

```
-of_objects
```

Specifies a collection of Tcl objects, which is the parent (owner) of the returned lookup table objects.

### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

### group\_type

Specifies lookup table group type. Types of regular lookup tables are valid, for example:

```
cell_rise
cell_fall
rise_transition
fall_transition
rise_constraint
fall_constraint
ocv_sigma_cell_rise
ocv_sigma_cell_fall
rise_power
fall_power
dc_current
......
```

get\_lookup\_tables 93

### Specific CCS group types are also valid, which include:

```
output_current_rise (CCS Timing object)
output_current_fall (CCS Timing object)
output_voltage_rise (CCS Noise object)
output_voltage_fall (CCS Noise object)
pg current (CCS Power object)
```

## **DESCRIPTION**

This command creates a collection of lookup\_table objects currently loaded into memory that match the specified criteria.

If no lookup table match the criteria, the command returns empty collection.

For information about collections and the querying of objects, see the **collections** man page.

For CCS groups, this command will created CCS objects by collecting all vector sub-groups, to form a 2-D lookup table where index\_1 and index\_2 are the indices, index\_3 and values are 2 lists storing the corresponding time-value waveform. Please refer to lookup\_table command for further information.

## **EXAMPLES**

The following example queries cell\_rise and output\_current\_rise tables from a timing object:

```
prompt> set luts [get_lookup_tables -of_objects $timing ocv_sigma_cell_rise]
prompt> set alut [index_collection $luts 0]
prompt> get_attribute $lut sigma_type
prompt> set ocr [get_lookup_table -of_objects $timing output_current_rise]
prompt> sizeof_collection $ocr
sel8
```

# **SEE ALSO**

```
collections(2)
filter collection(2)
```

get message ids 94

# get\_message\_ids

Get application message ids

# **SYNTAX**

```
string get_message_ids [-type severity]
[pattern]
string severity
string pattern
```

# **ARGUMENTS**

```
-type severity
Filter ids based on type (Values: Info, Warning, Error, Severe, Fatal)
pattern
Get IDs matching pattern (default: *)
```

# **DESCRIPTION**

The **get\_message\_ids** command retrieves the error, warning and informational messages used by the application. The result of this command is a Tcl formatted list of all message ids. Information about the id can be queried with the **get\_message\_info** command.

## **EXAMPLES**

The following code finds all error messages and makes the application stop script execution when one of

get\_message\_ids 95

## these messages is encountered.

```
foreach id [get_message_ids -type Error] {
   set_message_info -stop_on -id $id
}
```

# **SEE ALSO**

```
print_message_info(2)
set_message_info(2)
suppress_message(2)
```

get\_message\_info 96

# get\_message\_info

Returns information about diagnostic messages.

## **SYNTAX**

## **Data Types**

```
\begin{array}{ll} l\_id & \text{string} \\ o\_id & \text{string} \\ s\_id & \text{string} \\ i\_id & \text{string} \end{array}
```

# **ARGUMENTS**

```
-error count
```

Returns the number of error messages issued so far.

## -warning\_count

Returns the number of warning messages issued so far.

### -info count

Returns the number of informational messages issued so far.

```
-limit 1 id
```

Returns the current user-specified limit for a given message ID. The limit was set with the **set\_message\_info** command.

```
-occurrences o id
```

Returns the number of occurrences of a given message ID.

### -suppressed s id

Returns the number of times a message was suppressed either using suppress\_message or due to

get message info 97

exceeding a user-specified limit.

```
-id i id
```

Returns information about the specified message. The information is returned as a Tcl list compatible with the array set command.

# **DESCRIPTION**

The **get\_message\_info** command retrieves information about error, warning, and informational messages. For example, if the following message is generated, information about it is recorded:

Error: unknown command 'wrong\_command' (CMD-005)

It is useful to be able to retrieve recorded information about generated diagnostic messages. For example, you can stop a script after a certain number of errors have occurred, or monitor the number of messages issued by a single command.

You can also find out how many times a specific message has occurred, or how many times it has been suppressed. Also, you can find out if a limit has been set for a particular message ID.

# **EXAMPLES**

The following example uses the **get\_message\_info** command to count the number of errors that occurred during execution of a specific command, and to return from the procedure if the error count exceeds a given amount:

```
prompt> proc \
  do_command {limit} {
    set current_errors [get_message_info -error_count]
    command
    set new_errors [get_message_info -error_count]
    if {[expr $new_errors - $current_errors] > $limit} {
        return -code error "Too many errors"
    }
    ...
}
```

The following example uses the **get\_message\_info** command to retrieve information on the CMD-014 message:

```
prompt> get_message_info -id CMD-014
id CMD-014 severity Error limit 0 occurrences 0 suppressed 0 message
{Invalid %s value '%s' in list.}
```

get message info 98

# **SEE ALSO**

print\_message\_info(2)
set\_message\_info(2)
suppress\_message(2)

get\_object\_name 99

# get\_object\_name

Returns a list of names of the objects in a collection.

## **SYNTAX**

list get\_object\_name collection

## **Data Types**

collection string

# **ARGUMENTS**

collection

Specifies the name of the collection that contains objects whose names are requested.

-full path

Specifies whether to display the full path name of the object. For example, "my\_lib/my\_cell/my\_pin" is the full path name of "my\_pin". If this option is not specified, it displays as "my\_pin".

# **DESCRIPTION**

This command returns a list of names of the objects in a collection.

# **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

get\_object\_name 100

# **EXAMPLES**

The following example returns the name top as the object contained in the collection returned by the **current\_design** command.

```
prompt> get_object_name [current_design]
Current design is 'top'.
top
```

# **SEE ALSO**

collections(2)

get\_scale 101

# get\_scale

Get the scale value for target unit.

## **SYNTAX**

```
collection get_scale
  type
  target_unit
  library
```

## **Data Types**

```
type string
target_unit string
library list
```

# **ARGUMENTS**

### type

Specify unit type for scaling. Allowed unit type is: time| voltage| current | power| capacitance | resistance| energy

```
target_unit
```

Specify target unit for scaling.

#### library

Specify the source library Tcl collection.

# **DESCRIPTION**

This command analyzes the unit of specified unit type in the source library, and returns the scale value from the library unit to the target unit. If any error happens, return 0.

get scale 102

The "target\_unit" argument should be specified in a unified format: [float][magnitude][unit] Recommended unit type are listed below: For time: 1ps| 1ns For voltage: 1mv| 1v For current: 1ua| 1ma| 1a For power: 1pw| 1nw| 1uw| 1mw For capacitance: 1ff| 1pf For resistance: 1ohm| 1kohm For energy: 1fj| 1pj| 1nj| 1uj

# **EXAMPLES**

The following example gets the power scaling to 1nw for the source library

```
lc_shell>set lib [get_libs test]
{"test"}
lc_shell>get_scale power 1nw $lib
1000.0
```

# **SEE ALSO**

analyze\_trend(2)

get\_unix\_variable 103

# get\_unix\_variable

This is a synonym for the **getenv** command.

# **SEE ALSO**

gettenv(2) printenv(2) printvar(2) set(2) setenv(2) sh(2) unset(2)

getenv 104

# getenv

Returns the value of a system environment variable.

## **SYNTAX**

string **getenv**variable name

## **Data Types**

variable\_name

string

# **ARGUMENTS**

variable name

Specifies the name of the environment variable to be retrieved.

# **DESCRIPTION**

The **getenv** command searches the system environment for the specified *variable\_name* and sets the result of the command to the value of the environment variable. If the variable is not defined in the environment, the command returns a Tcl error. The command is catchable.

Environment variables are stored in the **env** Tcl array variable. The **getenv**, **setenv**, and **printenv** environment commands are convenience functions to interact with this array.

The application you are running inherited the initial values for environment variables from its parent process (that is, the shell from which you invoked the application). If you set the variable to a new value using the **setenv** command, you see the new value within the application and within any new child processes you initiate from the application using the **exec** command. However, these new values are not exported to the parent process. Further, if you set an environment variable using the appropriate system command in a shell you invoke using the **exec** command, that value is not reflected in the current application.

See the set, unset, and printvar commands for information about working with non-environment

getenv 105

variables.

## **EXAMPLES**

In the following example, **getenv** returns you to your home directory:

```
prompt> set home [getenv "HOME"]
/users/disk1/bill
prompt> cd $home
prompt> pwd
/users/disk1/bill
```

In the following example, **setenv** changes the value of an environment variable:

```
prompt> getenv PRINTER
laser1

prompt> setenv PRINTER "laser3"
laser3
```

In the following example, the requested environment variable is not defined. The error message shows that the Tcl variable **env** was indexed with the value UNDEFINED, which resulted in an error. In the second command, **catch** is used to suppress the message.

# **SEE ALSO**

```
catch(2)
exec(2)
printenv(2)
printvar(2)
set(2)
setenv(2)
unsetenv(2)
unset(2)
```

help 106

# help

Displays quick help for one or more commands.

## **SYNTAX**

```
string help
  [-verbose]
  [-groups]
  [pattern]
```

## **Data Types**

pattern string

# **ARGUMENTS**

#### -verbose

Displays the command options; for example *command\_name* **-help**.

# -groups

Displays a list of command groups only.

#### pattern

Displays commands matching the specified pattern.

# **DESCRIPTION**

The **help** command is used to get quick help for one or more commands or procedures. This is not the same as the **man** command that displays reference manual pages for a command. There are many levels of help.

By typing the **help** command, a brief informational message is printed followed by the available command groups.

help 107

List all of the commands in a group by typing the group name as the argument to **help**. Each command is followed by a one-line description of the command.

To get a one-line help description for a single command, type **help** followed by the command name. You can specify a wildcard pattern for the name; for example, all commands containing the string "alias". Use the **-verbose** option to get syntax help for one or more commands. Use the **-groups** option to show only the command groups in the application. This option cannot be combined with any other option.

## **EXAMPLES**

The following example lists the commands by command group:

```
prompt> help
Specify a command name or wild card pattern to get help on individual
commands. Use the '-verbose' option to get detailed option help for a
command. Commands also provide help when the '-help' option is passed to
the command.'

You can also specify a command group to get the commands available in
that group. Available groups are:

Procedures:
Help:
Help commands
Builtins:
Generic Tcl commands
```

The following example displays the list of procedures in the Procedures group:

The following example uses a wildcard character to display a one-line description of all commands beginning with a:

This example displays option information for the **source** command:

# **SEE ALSO**

help 108

```
man(2)
sh_help_shows_group_overview(3)
```

# history

Displays or modifies the commands recorded in the history list.

## **SYNTAX**

```
string history
[-h]
[-r]
[argument list]
```

# **Data Types**

```
argument list list
```

# **ARGUMENTS**

-h

Displays the history list without the leading numbers. You can use this for creating scripts from existing history. You can then source the script with the **source** command. You can combine this option with only a single numeric argument. Note that this option is a nonstandard extension to Tcl.

-r

Reverses the order of output so that most recent history entries display first rather than the oldest entries first. You can combine this option with only a single numeric argument. Note that this option is a nonstandard extension to Tcl.

```
argument_list
```

Additional arguments to **history** (see DESCRIPTION).

#### **DESCRIPTION**

The **history** command performs one of several operations related to recently-executed commands

recorded in a history list. Each of these recorded commands is referred to as an "event." The most commonly used forms of the command are described below. You can combine each with either the  $-\mathbf{h}$  or  $-\mathbf{r}$  option, but not both.

- With no arguments, the **history** command returns a formatted string (intended for you to read) giving the event number and contents for each of the events in the history list.
- If a single, integer argument *count* is specified, only the most recent *count* events are returned. Note that this option is a nonstandard extension to Tcl.
- Initially, 20 events are retained in the history list. You can change the length of the history list using the following:

#### history keep count

Tcl supports many additional forms of the **history** command. See the "Advanced Tcl History" section below.

#### **EXAMPLES**

The following examples show the basic forms of the **history** command. The first is an example of how to limit the number of events shown using a single numeric argument:

```
prompt> history 3
    7    set base_name "my_file"
    8    set fname [format "%s.db" $base_name]
    9    history 3
```

Using the **-r** option creates the history listing in reverse order:

Using the -h option removes the leading numbers from each history line:

```
prompt> history -h 3
set base_name "my_file"
set fname [format "%s.db" $base_name]
history -h 3
```

# **Advanced Tcl History**

The **history** command performs one of several operations related to recently-executed commands recorded in a history list. Each of these recorded commands is referred to as an "event." When specifying an event to the **history** command, the following forms may be used:

A number, which if positive, refers to the event with that number (all events are numbered starting at 1). If the number is negative, it selects an event relative to the current event; for example, -1 refers to the previous event, -2 to the one before that, and so on. Event 0 refers to the current event.

• A string selects the most recent event that matches the string. An event is considered to match the string either if the string is the same as the first characters of the event, or if the string matches the event in the sense of the **string match** command.

The **history** command can take any of the following forms:

#### history

Same as **history info**, described below.

#### history add command [exec]

Adds the *command* argument to the history list as a new event. If **exec** is specified (or abbreviated), the command is also executed and its result is returned. If **exec** is not specified, an empty string is returned.

#### history change newValue [event\_number]

Replaces the value recorded for an event with <code>newValue</code>. The <code>event\_number</code> specifies the event to replace, and defaults to the <code>current</code> event (not event <code>-1</code>). This command is intended for use in commands that implement new forms of history substitution and want to replace the current event (that invokes the substitution) with the command created through substitution. The return value is an empty string.

#### history clear

Erases the history list. The current keep limit is retained. The history event numbers are reset.

#### history event [event\_number]

Returns the value of the event given by event\_number. The default value of event\_number is -1.

#### **history info** [count]

Returns a formatted string, giving the event number and contents for each of the events in the history list except the current event. If *count* is specified, then only the most recent *count* events are returned.

#### history keep [count]

Changes the size of the history list to *count* events. Initially, 20 events are retained in the history list. If *count* is not specified, the current keep limit is returned.

#### history nextid

Returns the number of the next event to be recorded in the history list. Use this for printing the event number in command-line prompts.

#### history redo [event\_number]

Reruns the command indicated by *event* and returns its result. The default value of *event\_number* is **- 1**. This command results in history revision. See the following section for details.

#### **History Revision**

Pre-8.0 Tcl had a complex history revision mechanism. The current mechanism is more limited, and the **substitute** and **words** history operations have been removed. The **clear** operation was added.

The **redo** history option results in much simpler "history revision." When this option is invoked, the most recent event is modified to eliminate the history command and replace it with the result of the history command. If you want to redo an event without modifying the history, use the **event** operation to retrieve an event, and use the **add** operation to add it to history and execute it.

index\_collection 113

# index\_collection

Given a collection and an index into it, if the index is in range, create a new collection containing only the single object at the index in the base collection. The base collection remains unchanged.

#### **SYNTAX**

collection index\_collection
 collection1
 index

#### **Data Types**

collection1
index

collection
int

# **ARGUMENTS**

collection1

Specifies the collection to be searched.

index

Specifies the index into the collection. Allowed values are integers from 0 to sizeof\_collection - 1.

# **DESCRIPTION**

You can use the **index\_collection** command to extract a single object from a collection. The result is a new collection containing only that object. The index operation is done in constant time - it is independent of the number of elements in the collection, or the specific index.

The range of indices is from 0 to one less than the size of the collection. If the specified index is outside that range, an error message is generated.

Commands that create a collection of objects do not impose a specific order on the collection, but they do

index collection 114

generate the objects in the same, predictable order each time. Applications that support the sorting of collections allow you to impose a specific order on a collection.

You can use the empty string for the *collection1* argument. However, by definition, any index into the empty collection is invalid. Therefore, using the **index\_collection** command with the empty collection always generates the empty collection as a result and generates an error message.

Note that not all collections can be indexed.

## **EXAMPLES**

The following example from PrimeTime uses the **index\_collection** command to extract the first object of a collection.

```
pt_shell> set c1 [get_cells {u1 u2}]
{"u1", "u2"}
pt_shell> query_objects [index_collection $c1 0]
{"u1"}
```

# **SEE ALSO**

```
collections(2)
query_objects(2)
sizeof collection(2)
```

is\_false 115

# is\_false

Tests the value of a specified variable, and returns 1 if the value is 0 or the case-insensitive string **false**; returns 0 if the value is 1 or the case-insensitive string **true**.

#### **SYNTAX**

```
status is_false value
```

#### **Data Types**

```
value string
```

#### **ARGUMENTS**

value

Specifies the name of the variable whose value is to be tested.

## **DESCRIPTION**

This command tests the value of a specified variable, and returns 1 if the value is either 0 or the case-insensitive string **false**. The command returns 0 if the value is either 1 or the case-insensitive string **true**. Any value other than 1, 0, **true**, or **false** generates a Tcl error message.

The **is\_false** command is used in writing scripts that test Boolean variables that can be set to 1, 0, or the case-insensitive strings **true** or **false**. When such variables are set to **true** or **false**, they cannot be tested in the negative in an **if** statement by simple variable substitution, because they do not constitute a true or false condition. The following example is not legal Tcl:

```
set x FALSE
if { !$x } {
   set y TRUE
}
```

is false 116

This results in a Tcl error message, indicating that you cannot use a non-numeric string as the operand of "!". So, although you can test the positive condition, **is\_false** allows you to test both conditions safely.

# **EXAMPLES**

The following example shows the use of the **is\_false** command:

# **SEE ALSO**

```
expr(2)
if(2)
is_true(2)
```

is\_null\_object 117

# is\_null\_object

check whether one Tcl collection is null or not

#### **SYNTAX**

collection is\_null\_object
 collection1

#### **Data Types**

collection1

collection

# **ARGUMENTS**

collection1

Specifies one collection to be checked.

# **DESCRIPTION**

You can use the **is\_null\_object** command to check whether one Tcl collection is null or not. if it is null, return true; otherwise return false. Currently only command **align\_lib\_objects** returns null object.

# **EXAMPLES**

The following exmaple is to use is\_null\_object to check whether the object in the result from command align\_lib\_objects is null or not.

```
lc_shell>set cell1 test/BUF/*
test/BUF/*
```

is\_null\_object 118

```
lc shell>set cell2 test/CKGT/*
test/CKGT/*
lc_shell>set pinlist1 [get_lib_pins $cell1]
{"test/BUF/A", "test/BUF/X"}
lc_shell>set pinlist2 [get_lib_pins $cell2]
{"test/CKGT/CK", "test/CKGT/EN", "test/CKGT/Q", "test/CKGT/SE"}
lc_shell>set aligned_pinlist [align_lib_objects $pinlist1 $pinlist2]
_sel4 _sel5 _sel6 _sel7 _sel8 _sel
lc_shell> set i 0
lc_shell>foreach pair $aligned_pinlist {
set element1 [index collection $pair 0]
set element2 [index collection $pair 1]
set ret1 [is_null_object $element1]
set ret2 [is_null_object $element2]
if {$ret1 == "1"} {
 set name1 "null"
} else {
 set name1 [get_object_name $element1]
if {$ret2 == "1"} {
 set name2 "null"
} else {
 set name2 [get object name $element2]
echo "pair $i:($name1, $name2)"
incr i
}
pair 0: (null, EN)
pair 1: (null, CK)
pair 2: (null, SE)
pair 3: (A, null)
pair 4: (null, Q)
pair 5: (X, null)
```

# **SEE ALSO**

collections(2)

is\_true 119

# is\_true

Tests the value of a specified variable, and returns 1 if the value is 1 or the case-insensitive string **true**; returns 0 if the value is 0 or the case-insensitive string **false**.

#### **SYNTAX**

```
status is_true value
```

#### **Data Types**

```
value string
```

#### **ARGUMENTS**

value

Specifies the name of the variable whose value is to be tested.

## **DESCRIPTION**

This command tests the value of a specified variable, and returns 1 if the value is either 1 or the case-insensitive string **true**. The command returns 0 if the value is either 0 or the case-insensitive string **false**. Any value other than 1, 0, **true**, or **false** generates a Tcl error message.

The **is\_true** command is used in writing scripts that test Boolean variables that can be set to 1, 0, or the case-insensitive strings **true** or **false**. When such variables are set to **true** or **false**, they cannot be tested in the negative in an **if** statement by simple variable substitution, because they do not constitute a true or false condition. The following example is not legal Tcl:

```
set x TRUE
if { !$x } {
   set y FALSE
}
```

is true 120

This results in a Tcl error message, indicating that you cannot use a non-numeric string as the operand of "!". So, although you can test the positive condition, **is\_true** allows you to test both conditions safely.

# **EXAMPLES**

The following example shows the use of the **is\_true** command:

# **SEE ALSO**

```
expr(2)
if(2)
is_false(2)
```

lib2saif 121

# lib2saif

Creates a forward-annotation SAIF file for a specified technology library.

#### **SYNTAX**

```
status lib2saif
  [-output file_name]
  library
  [-lib pathname lib path name]
```

## **Data Types**

```
file_name string
library list
lib path name list
```

# **ARGUMENTS**

```
-output file name
```

Specifies the name of the library forward-annotation SAIF file created by **lib2saif**. The default file name is the value of the **power\_sdpd\_saif\_file** variable. By default, the value of the **power\_sdpd\_saif\_file** variable is *power\_sdpd.saif*.

#### library

Specifies the library name, or library file name for which the forward SAIF file is generated. If a library file name is specified then the library must be in .db format. The library must have state-dependent leakage power characterization and/or pin-level state-dependent and/or path-dependent internal power characterization for a library forward SAIF file to be generated.

```
-lib_pathname lib_path_name
```

Specifies the path name to the simulation library information. This is optional, and is only required if the library is not in the simulation tool's current path during simulation.

lib2saif 122

#### **DESCRIPTION**

This command creates a forward-annotation SAIF file that contains the state-dependent and path-dependent information for library cells. The library forward-annotation SAIF file is used in flows where a gate-level back-annotation SAIF file with state-dependent and/or path-dependent switching activity is generated.

For details on the SAIF format, see the SAIF specification.

For details on state-dependent and path-dependent power characterization, see the Library Compiler and Power Compiler documentation.

#### **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

# **EXAMPLES**

The following examples illustrate the use of this command:

```
prompt> lib2saif -out a130.saif asic130_typical
prompt> lib2saif -out a130.saif ../libs/asic130.db
```

## **SEE ALSO**

None

license\_users 123

# license\_users

Lists the current users of the Synopsys licensed features.

#### **SYNTAX**

status license\_users
 [feature\_list]

# **Data Types**

feature\_list list

## **ARGUMENTS**

#### feature list

Lists the licensed features for which to obtain the information. If more than one feature is specified, they must be enclosed in braces ({}). See the Synopsys \Installation Guide: UNIX-Based Platforms for a list of features supported by the current release, or determine from the key file all of the features that are licensed at your site.

# **DESCRIPTION**

This command displays information about all of the licenses, related users, and host names currently in use. If a feature list is specified, only information about those features is displayed.

The license\_users command is valid only when Network Licensing is enabled.

# **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

license users 124

#### **EXAMPLES**

In this example, all of the users of the Synopsys features are displayed:

#### prompt> license\_users

krig@nodel DC-Expert, Design-Compiler, Design-Vision,
Milkyway-Interface
doris@node2 Design-Compiler, HDL-Compiler, Power-Optimization
DC-Expert, DC-Ultra-Features, DC-Ultra-Opt,
Design-Compiler,
Wru@node4 DC-Expert, DC-Ultra-Features, DC-Ultra-Opt,
Design-Compiler, DesignWare,
Milkyway-Interface, Test-Compiler,
VHDL-Compiler

4 users listed.

This example shows the users of the "HDL-Compiler" or "VHDL-Compiler" features.

```
prompt> license users {HDL-Compiler VHDL-Compiler}
```

doris@node2 Design-Compiler, HDL-Compiler, Power-Optimization wru@node4 DC-Expert, DC-Ultra-Features, DC-Ultra-Opt, Design-Compiler, DesignWare, Milkyway-Interface, Test-Compiler, VHDL-Compiler

2 users listed.

# **SEE ALSO**

```
get_license(2)
remove license(2)
```

list attributes 125

# list\_attributes

Lists the currently-defined attributes.

## **SYNTAX**

```
.prod syn
status list_attributes
.prod icc
string list_attributes
.prod all
    [-application]
    [-class class_name]
    [-nosplit]
```

# **Data Types**

```
class name string
```

# **ARGUMENTS**

#### -application

Lists application attributes attributes.

```
-class class_name
```

Limits the listing to attributes of a single class. The valid values are those groups defined by Liberty syntax like library, cell, pin...

#### -nosplit

Prevents lines from being split when column fields overflow. Most of the attribute information is listed in fixed-width columns. If the information for a given field exceeds the column width, the next field begins on a new line in the correct column.

# **DESCRIPTION**

list attributes 126

The list\_attributes command displays an alphabetically-sorted list of application attributes.

Using the **-application** option adds all application attributes to the listing. Since there are many application attributes, you can limit the listing to a specific object class by using the **-class** option.

#### **EXAMPLES**

The following example adds application-defined attributes, but limits the listing to library attributes only:

```
prompt> list_attributes -application -class library
********
Report : List of Attribute Definitions
Version: K-2015.06-SP1-VAL-150625
Date : Thu Jun 25 19:31:47 2015
*******
Properties:
   A - Application-defined
   U - User-defined
                   Object Type Properties Constraints
Attribute Name
nom_process
                   library float A
nom_temperature
                   library float
library float
                                    A
nom_voltage
```

## **SEE ALSO**

```
get_attribute(2)
set_attribute(2)
```

list libs 127

# list\_libs

List libraries that are currently available in memory.

## **SYNTAX**

```
Status list_libs [lib_list]
```

#### **Data Types**

lib\_list list

# **ARGUMENTS**

lib\_list

Specifies the libraries to list. You can use the \* (asterisk) and ? (question mark) wildcard characters when specifying the libraries to list. For more information about using and escaping wildcards, see the **wildcards** man page.By default, the tool lists all libraries.

# **DESCRIPTION**

This comman displays all libraries that are currently available in memory.

# **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

# **EXAMPLES**

list libs 128

The following example list all loaded libraries.

prompt> list_libs		
Library	File	Path
z0 SHKA90_16384X8X4CM16_FF1P32VM40C	z0.db SHKA90_16384X8X4CM16_FF1P32VM40C.db	<pre>/remote/dtdata1/testdata/libra /remote/dtdata1/testdata/libra</pre>

# **SEE ALSO**

get\_libs(2)

Iminus 129

# **Iminus**

Removes one or more named elements from a list and returns a new list.

#### **SYNTAX**

```
list lminus
  [-exact]
  original_list
  elements
```

#### **Data Types**

```
original_list list
elements list
```

## **ARGUMENTS**

#### -exact

Specifies that the exact pattern is to be matched. By default, **Iminus** uses the default match mode of **Isearch**, the **-glob** mode.

```
original_list
```

Specifies the list to copy and modify.

#### elements

Specifies a list of elements to remove from original\_list.

#### **DESCRIPTION**

The **Iminus** command removes elements from a list by using the element itself, rather than the index of the element in the list (as in **Ireplace**). The **Iminus** command uses the **Isearch** and **Ireplace** commands to find the elements and replace them with nothing.

Iminus 130

If none of the elements are found, a copy of *original\_list* is returned.

The **Iminus** command is often used in the translation of Design Compiler scripts that use the subtraction operator (-) to remove elements from a list.

#### **EXAMPLES**

The following example shows the use of the **Iminus** command. Notice that no error message is issued if a specified element is not in the list.

```
prompt> set 11 {a b c}
a b c

prompt> set 12 [lminus $11 {a b d}]
c

prompt> set 13 [lminus $11 d]
a b c
```

The following example illustrates the use of **Iminus** with the **-exact** option:

```
prompt> set 11 {a a[1] a* b[1] b c}
a a[1] a* b[1] b c

prompt> set 12 [lminus $11 a*]
{b[1]} b c

prompt> set 13 [lminus -exact $11 a*]
a {a[1]} {b[1]} b c

prompt> set 14 [lminus -exact $11 {a[1] b[1]} ]
a a* b c
```

# **SEE ALSO**

```
lreplace(2)
lsearch(2)
```

lookup\_table 131

# lookup\_table

Provides lookup\_table manipulation commands to perform several operations on a variable of single lookup table object. The lookup table object can be operated solely by lookup table manipulation commands.

#### **SYNTAX**

# lookup\_table [option] lookup\_table object [arg arg ...]

## **Data Types**

```
option string
lookup_table object Tcl variable
```

# **ARGUMENTS**

#### option

Specifies a predefined operation on lookup\_table object. Following are the valid predefined option values.

```
template_name
variables
sizes
dimension
index
slice
bucket
fit
interpolate
index_output
```

#### lookup\_table object

Specifies a single lookup\_table object.

lookup\_table 132

#### DESCRIPTION

This command performs one of several operations on a single lookup table object variable given by \$lookupTableVariable. The option argument determines what action is carried out by the command. The legal options are:

```
lookup table template name $lookupTableVariable
Returns the name of the template used in the lookup table.
lookup table variables $lookupTableVariable
Returns a list of variables used by the lookup table.
The order of the list is the original order of variables.
lookup table sizes $lookupTableVariable
 Returns a list of sizes of the indices used in the lookup table.
The order of the list is the original order of variables.
The size of the returning list is the dimension of the table.
lookup table dimension $lookupTableVariable
Returns the dimension of the table. Returns 0 for scalar lookup table.
lookup table index $lookupTableVariable
Returns a list of lists where each element is a list storing the indices
of one variable. The order of the outer list is the original order of variable.
lookup_table slice $lookupTableVariable [-all] [-index {variable_name value}]
lookup table slice $lookupTableVariable [-data time] [-index {variable name value}]
lookup table slice $lookupTableVariable [-data values] [-index {variable_name value}]
lookup table slice $lookupTableVariable [-data ref] [-index {variable name value}]
Returns a list containing all or part of values of the lookup table.
The option -all indicates all values are returned. The option -all supports
 tables with arbitrary dimension including scalar/1D/2D/3D.
        The option -index indicates the returned list of values are fixed at the
        specified value of the variable name. The option -index supports scalar, 1D
 and 2D tables (CCS object is actually 2D table).
        For CCS objects, i.e., for output current rise|fall and pg current tables,
       the table values are time-current waveforms, for output voltage rise | fall
 tables, the table values are time-voltage waveforms:
        1. the 3rd index index 3 stores a list of time points, the [-data time] should
          be used to retrieve index 3(time);
 2. the values stores the corresponding current values, the [-data value] should
 3. the reference time attribute for specific index point can be retrieved by
          the [-data ref] option;
        The [-all] option does NOT support CCS object.
lookup table bucket $lookupTableVariable [-index
  {[variable name1 value1] [variable name2 value2] ... [variable nameN valueN]}}
        Support tables of arbitary dimensions.
 For 3-dimensional lookup table, the command returns collection of 8 triplets
 {index1, index2, index3, value} on the indices grid of the lookup table, where the given
 index point specified by option -index should fall on the region enclosed by the
 8 points. The order of the index in the triplets follows the order defined
 in the library by table template.
  If the given point is on the grid point, returns 8 identical points.
  If the given point is on the grid but not the grid point, returns 4 identical points on each end.
 For 2-dimensional lookup table, the command returns collection of 4 triplets
 {index1, index2, value} on the indices grid of the lookup table, where the given
```

lookup table 133

```
index point specified by option -index should fall on the region enclosed by the
 4 points. The order of the index in the triplets follows the order defined
 in the library by table template.
  If the given point is on the grid point, returns 4 identical points.
  If the given point is on the grid but not the grid point, returns 2 identical points on each end.
 For 1-dimensional lookup table, the command returns collection of 2 pairs
 {index, value} on the indices grid of the lookup table, where the given index
point specified by option -index should fall on the interval enclosed by the 2 points.
   If the given point is on the grid point, returns 2 identical points.
 For scalar lookup table, the command always returns the single table value.
lookup table fit $lookupTableVariable [-index
  {[variable name1 value1] [variable name2 value2] [variable name3 value3]}}]
        Support tables of arbitary dimensions.
Among the grid points returned from lookuptable bucket command, returns the
 one grid point that has the closest index to the given index.
 For scalar table, always return the single table value.
lookup table interpolate $lookupTableVariable [-index
  {[variable name1 value1] [variable name2 value2] [variable name3 value3]}]
        Support scalar/1D/2D/3D tables.
Returns value linear-interpolated from the lookup table based on given points.
The calculation is done on top of lookup table bucket.
 For scalar table, always returns the single table value.
-index option
Additional information about the -index option for lookup table bucket/fit/interpolate commands:
    1. All index defined in lookup table must be provided by -index option.
      For example, for 2D cell rise table, the input net transition and
       total output net capacitance values must be defined using index option.
    2. If there are extra index defined using index option, where the extra
      index is NOT defined in lookup table, the extra index is NOT to be considered
      in the manipulation commands. For example, if both input_net_transition and
      total output net capacitance values were provided using index option, for
       1-D cell rise table that is using input net transition as index, the
       total_output_net_capacitance is not be considered.
lookup table index output $lookupTableVariable
Returns the index output value of a pg current CCS object.
```

## **EXAMPLES**

The following example shows a list of lookup table operations:

```
lu_table_template ("tt_vio") {
  variable_1 : "related_pin_transition";
  index_1("1.000,17.000,27.000,97.000,217.000");
  variable_2 : "constrained_pin_transition";
  index_2("1.000,17.000,27.000,97.000,217.000");
}

timing () {
  timing_type : "setup_rising";
  related pin : "CP";
```

lookup table 134

```
rise constraint ("tt vio") {
 index 1("1, 17, 27, 97, 217");
 index_2("1, 17, 27, 97, 217");
 values("51.01, 82.01, 99.01, 94.01, 68.01", \
   "47.01, 54.01, 79.01, 67.01, 34.01", \
  "22.01, 57.01, 82.01, 64.01, 17.01", \
  "40.01, 61.01, 99.01, 81.01, 38.01", \
  "94.01, 129.01, 125.01, 121.01, 95.01");
 fall constraint ("tt vio") {
 index 1("1, 17, 27, 97, 217");
 index 2("1, 17, 27, 97, 217");
 values("108.01, 171.01, 222.01, 353.01, 503.01", \
  "102.01, 136.01, 194.01, 319.01, 488.01", \
  "63.01, 112.01, 191.01, 295.01, 485.01", \
  "81.01, 116.01, 208.01, 300.01, 505.01", \
  "94.01, 129.01, 222.01, 313.01, 519.01");
}
}
Assuming $a timing is the Tcl variable pointing to the timing group above.
lc_shell>set setup_table [get_lookup_table of_objects $a timing rise constraint]
sel8
lc shell>lookup table template name $setup table
tt vio
lc shell>lookup table variables $setup table
related pin transition constrained pin transition
1c shell>set table size [lookup table sizes $setup table]
5 5
lc shell> llength $table size
lc_shell>lookup_table dimension $setup_table
lc_shell>lookup_table index $setup_table
{1 17 27 97 217} {1 17 27 97 217}
lc shell>lookup table slice $setup table -all
51.01 82.01 99.01 94.01 68.01 47.01 54.01, 79.01 67.01 34.01 22.01 57.01 82.01 64.01 17.01 40.01 61
lc shell>lookup table slice $setup table -index {constrained pin transition 175}
lc_shell>lookup_table bucket $setup_table -index {related_pin_transition 12 constrained_pin_transit
{1 1 51.01} {1 17 82.01 } {17 1 47.01 54.01} {17 17 54.01}
lc_shell>lookup_table fit $setup_table index {related_pin_transition 12 constrained_pin_transition
{1 1 51.01}
lc shell>lookup table interpolate $setup table -index {related pin transition 12 constrained pin tr
63.01
```

lookup table 135

# **SEE ALSO**

collections(2)
filter\_collection(2)

ls 136

# Is

Lists the contents of a directory.

# **SYNTAX**

```
string ls [filename ...]
string filename
```

# **ARGUMENTS**

#### filename

Provides the name of a directory or filename, or a pattern which matches files or directories.

# **DESCRIPTION**

If no argument is specified, the contents of the current directory are listed. For each *filename* matching a directory, **Is** lists the contents of that directory. If *filename* matches a file name, the file name is listed.

# **EXAMPLES**

ls 137

# **SEE ALSO**

cd(2) pwd(2)

man 138

#### man

Displays reference manual pages.

#### **SYNTAX**

string man topic

#### **Data Types**

topic string

# **ARGUMENTS**

topic

Specifies the subject to display. Available topics include commands, variables, and error messages

# **DESCRIPTION**

The **man** command displays the online manual page for a command, variable, or error message. You can write man pages for your own Tcl procedures and access them with the **man** command by setting the **sh\_user\_man\_path** variable to an appropriate value. See the man page for the **sh\_user\_man\_path** variable for details.

## **EXAMPLES**

The following command displays the man page for the **echo** command:

prompt> man echo

man 139

The following command displays the man page for the error message CMD-025:

prompt> man CMD-025

# **SEE ALSO**

help(2)
sh\_user\_man\_path(3)

mem 140

## mem

Reports memory usage information.

#### **SYNTAX**

status mem
[-all]
[-verbose]

#### **ARGUMENTS**

-all

Reports the maximum of the peak memory usage among the main process and its child processes.

#### -verbose

Reports in detail the peak memory usage of the main process and each child process, including placement, extraction, and routing.

#### **DESCRIPTION**

This command reports the peak memory usage of processes. By default, it reports the peak memory usage of the main process in kilobytes. If you specify the **-all** option, it reports the maximum of the peak memory usage among the main process and its child processes. If you specify both the **-all** and **-verbose** options, it also prints out the peak memory usage in megabytes for the main process and each child process.

Memory peak is defined as the memory high-water mark of processes. When the tool reports a memory peak, it means the maximum memory allocated from the operating system. When child processes exist, the tool reports the maximum number among the main process and its child processes.

Note that the **mem** command reports the peak memory usage, not the swap space usage of the process. It actually reports how much memory was allocated from the operating system at the peak point. Some of the memory can be swapped out by the operating system based on the system status.

mem 141

# **EXAMPLES**

The following example shows the default command output:

```
prompt> mem 102400
```

The following example shows the output when using the **-all** and **-verbose** options:

```
prompt> mem -all -verbose
Main process mem-peak: 100 Mb
Child "placement" called 3 times, mem-peak: 60 Mb
Child "extraction" called 3 times, mem-peak: 50 Mb
102400
```

# **SEE ALSO**

cputime(2)

merge\_lib 142

# merge\_lib

Merges the base library and model file.

# **SYNTAX**

```
status set_lib_group
  [-lib_group group_name]
  [-base_lib base_db_filename]
  [-model_lib model_db_filename]
  [-merged_library_name merged_library_ename]
  [-resolve_conflict { use_base | use_model | error_out }]
  [-output merged_filename]
```

## **Data Types**

```
group_name string
base_db_filename string
model_db_filename string
merged_library_name string
merged_filename string
use base use model error out string
```

# **ARGUMENTS**

```
group_name
```

Specifies a library group name that is defined in set\_lib\_group command. The merge\_lib command will merge each base library with its associated model files in this group.

```
base_db_filename
```

Specifies one base library .db file name. This option and -model\_file should be specified together.

```
model db filename
```

Specifies one model .db file name. This option and -base\_lib should be specified together.

```
merged_library_name
```

Specifies a library name of the final merged library in a fixed string or a suffix starting with wild card(\*) in the form of \*\_suffix. Each merged library will use original base library\_name appended by the suffix.

merge lib 143

This is for multi sub-group merge in one merge\_lib command. If not specified, the library name of the base library will be used.

#### resolve conflict

Specifies one: use\_base to use data from base lib, use\_model to use data from model file or error\_out to quit merge. If not specified, the value in the base library will be used.

#### merged\_filename

Specifies an output .db file name or a suffix starting with wild card (\*) in the form of \*\_suffix. Each merged library will use original base library\_name appended by the suffix.db. This is for multi sub-group merge in one merge\_lib command. Alternatively, write\_lib can be used to write out a DB file. If not specified, it will use merged\_library\_name appended by extension .db similar to read\_lib.

#### **DESCRIPTION**

The **merge\_lib** command merges the base library and its associated model files. The base library and its associated model files are input by one of the followings listed in precedence:

- 1) merge\_lib -base\_lib and -model\_lib options. Both should be specified together.
- 2) merge\_lib -lib\_group option.
- 3) set\_lib\_group command which is defined before merge\_lib command.

#### **EXAMPLES**

In the following example, the base library pvt1.db and its model file upf.db are merged into a new library with library\_name merged\_pvt1.

```
prompt> merge lib -base lib pvt1.db -model lib upf.db -merged library name merged pvt1
```

# **SEE ALSO**

```
check_library(2)
set_lib_group(2)
```

parse proc arguments 144

# parse\_proc\_arguments

Parses the arguments passed into a Tcl procedure.

### **SYNTAX**

```
string parse_proc_arguments -args arg_list
result_array
list arg_list
string result array
```

## **ARGUMENTS**

```
-args arg list
```

Specified the list of arguments passed in to the Tcl procedure.

```
result_array
```

Specifies the name of the array into which the parsed arguments should be stored.

## **DESCRIPTION**

The **parse\_proc\_arguments** command is used within a Tcl procedure to enable use of the -help option, and to support argument validation. It should typically be the first command called within a procedure. Procedures that use **parse\_proc\_arguments** will validate the semantics of the procedure arguments and generate the same syntax and semantic error messages as any application command (see the examples that follow).

When a procedure that uses **parse\_proc\_arguments** is invoked with the -help option, **parse\_proc\_arguments** will print help information (in the same style as using **help -verbose**) and will then cause the calling procedure to return. Similarly, if there was any type of error with the arguments (missing required arguments, invalid value, and so on), **parse\_proc\_arguments** will return a Tcl error and the calling procedure will terminate and return.

parse\_proc\_arguments 145

If you didn't specify -help, and the specified arguments were valid, the array variable <code>result\_array</code> will contain each of the argument values, subscripted with the argument name. Note that the argument name here is NOT the names of the arguments in the procedure definition, but rather the names of the arguments as defined using the <code>define\_proc\_attributes</code> command.

The parse\_proc\_arguments command cannot be used outside of a procedure.

### **EXAMPLES**

The following procedure shows how **parse\_proc\_arguments** is typically used. The argHandler procedure parses the arguments it receives. If the parse is successful, argHandler prints the options or values actually received.

```
proc argHandler args {
   parse_proc_arguments -args $args results
   foreach argname [array names results] {
      echo " $argname = $results($argname)"
   }
}
define_proc_attributes argHandler -info "argument processor" \
   -define_args \
   {{-Oos "oos help" AnOos one_of_string {required value_help {values {a b}}}}}
   {-Int "int help" AnInt int optional}
   {-Float "float help" AFloat float optional}
   {-Bool "bool help" "" boolean optional}
   {-String "string help" AString string optional}
   {-List "list help" AList list optional}}
   {-IDup int dup AIDup int {optional merge duplicates}}}
```

Invoking argHandler with the -help option generates the following:

Invoking argHandler with an invalid option causes the following output (and a Tcl error):

```
prompt> argHandler -Int z
Error: value 'z' for option '-Int' not of type 'integer' (CMD-009)
Error: Required argument '-Oos' was not found (CMD-007)
```

Invoking argHandler with valid arguments generates the following:

```
prompt> argHandler -Int 6 -Oos a
  -Oos = a
  -Int = 6
```

parse proc arguments 146

# **SEE ALSO**

define\_proc\_attributes(2)
help(2)
proc(2)

preview 147

# preview

Evaluates its arg list without actually executing it, but option values are "stored through" if option valuetracking is enabled.

### **SYNTAX**

preview arg ...

### **ARGUMENTS**

arg

The arg list will be evaluated without being executed.

# **DESCRIPTION**

The preview command (like the built-in Tcl command eval) takes one or more arguments, which together comprise a Tcl script containing one or more commands. The preview command concatenates all its arguments together (like eval), and passes the concatenated string to the CCI/Tcl interpreter recursively.

The preview command passes its concatenated command string to the CCI/Tcl command evaluator as usual, but the special feature of the preview command is that the command will not actually be executed by preview. Instead only the early stages of CCI argument/option checking will happen for the command string. Specifically, standard CCI checking of option arguments is performed, as is "store through" of new current option values for options with current-value-tracking enabled (if option checking succeeded). The preview command thus provides a way to update current values of a command's options (which have current-value-tracking enabled) without actually executing the command.

Conceptually, the CCI preview command is in the same "family" as the Tcl built-in command eval - the difference is that eval executes its concatenated command string, while preview does not, but preview does implement CCI option checking and "store through" for current values of options (which have current-value-tracking enabled).

preview 148

The advantage of the preview command (compared with a command for turning on and off preview mode) is that a preview command is guaranteed to finish/exit (thus guaranteeing that the preview behavior in the CCI command evaluator will get turned off as soon as the preview command exits). If instead it was necessary to have matching commands for turning on and off "preview mode", bugs in Tcl script code might cause the "turn off preview mode" call to be skipped - then the interpreter would be stuck in "preview mode" indefinitely (and we do not want to take the risk of such a serious bug happening). By having preview as a command, we greatly reduce the risk that the interpreter could get "stuck in preview mode".

Note that the preview command itself does not implement any additional echoing to output of its concatenated command.

About preview and mutually exclusive options: preview performs all option checking for the previewed command as if it was to be executed (even though the command will not be executed). Thus the simultaneous presence of multiple mutually exclusive options will generate an error under preview (and "store through" of current option values will be aborted). This can be regarded as both a feature (it's consistent with normal command execution) and a limitation (it makes it impossible to set current values for mutually exclusive options of a command from a single run of preview). To workaround this limitation, we also provide the set\_command\_option\_value command (which does not do checks such as the mutual exclusion check) - see the man page for set\_command\_option\_value.

A possible power user application: power users could put preview commands in their home directory Tcl startup files for their favorite dialogs/commands to "seed" initial current values for these dialogs. This may lower the need for automatically saving replay scripts (of preview commands for each command/dialog) on exit from the application. Note: the set\_command\_option\_value command may be easier to use than preview for this purpose.

## **EXAMPLES**

Consider a command named foo with two integer options, -bar1 and -bar2, that have current-value-tracking enabled. In the following example, the "current values" being tracked for the -bar1 and -bar2 options are updated to 10 and 20 respectively:

```
prompt> preview foo -bar1 10 -bar2 20
prompt> get_command_option_values -current -command foo
-bar1 10 -bar2 20
Note that foo command is not actually executed in this example.
```

# **SEE ALSO**

```
get_command_option_values(2)
set command option value(2)
```

print message info 149

# print\_message\_info

Prints information about diagnostic messages that have occurred or have been limited.

### **SYNTAX**

```
string print_message_info
[-ids id_list]
[-summary]
```

## **Data Types**

```
id list list
```

# **ARGUMENTS**

```
-ids id list
```

Specifies a list of message identifiers to report. Each entry can be a specific message or a glob-style pattern that matches one or more messages. If this option is omitted and no other options are given, then all messages that have occurred or have been limited are reported.

#### -summary

Generates a summary of error, warning, and informational messages that have occurred so far.

## **DESCRIPTION**

The **print\_message\_info** command enables you to print summary information about error, warning, and informational messages that have occurred or have been limited with the **set\_message\_info** command. For example, if the following message is generated, information about it is recorded:

Error: unknown command 'wrong\_command' (CMD-005)

It is useful to be able to summarize all recorded information about generated diagnostic messages. Much

print message info 150

of this can be done using the **get\_message\_info** command, but you need to know a specific message ID. By default, **print\_message\_info** summarizes all of the information. It provides a single line for each message that has occurred or has been limited, and one summary line that shows the total number of errors, warnings, and informational messages that have occurred so far. If an *id\_list* is given, then only messages matching those patterns are displayed. If **-summary** is given, then a summary is displayed.

Using a pattern in the  $id\_list$  is intended to show a specific message prefix, for example, "CMD\*". Note that this does not show all messages with that prefix. It shows only the messages that have occurred or have been limited.

### **EXAMPLES**

The following example uses **print\_message\_info** to show a few specific messages:

```
        print_message_info -ids [list "CMD*" APP-99]

        Id
        Limit
        Occurrences
        Suppressed

        CMD-005
        0
        7
        2

        APP-99
        1
        0
        0
```

At the end of the session, you might want to generate some information about a set of interesting messages, such as how many times each occurred (which includes suppressions), how many times each was suppressed, and whether a limit was set for any of them. The following example uses **print\_message\_info** to get this information:

<pre>prompt&gt; print message</pre>	e info	•
-------------------------------------	--------	---

Id	Limit	Occurrences	Suppressed	
CMD-005	0	12	0	
APP-027	100	150	50	
APP-99	0	1	0	

Diagnostics summary: 12 errors, 150 warnings, 1 informational

Note that the suppressed count is not necessarily the difference between the limit and the occurrences, since the limit can be dynamically changed with the **set\_message\_info** command.

# **SEE ALSO**

```
get_message_info(2)
set_message_info(2)
suppress message(2)
```

print\_proc\_new\_vars 151

# print\_proc\_new\_vars

Checks for new variables created within a Tcl procedure.

### **SYNTAX**

string print\_proc\_new\_vars

## **ARGUMENTS**

The **print\_proc\_new\_vars** command has no arguments.

### DESCRIPTION

The **print\_proc\_new\_vars** command is used in a Tcl procedure to show new variables created up to that point in the procedure. If the **sh\_new\_variable\_message\_in\_proc** and **sh\_new\_variable\_message** variables are both set to **true**, this command is enabled. If either variable is **false**, the command does nothing. The result of the command is always an empty string.

When enabled, the command issues a CMD-041 message for each variable created in the scope of the procedure so far. Arguments to the procedure are excluded.

For procedures that are in a namespace (that is, not in the global scope), **print\_proc\_new\_vars** also requires that you have defined some aspect of the procedure using the **define\_proc\_attributes** command.

Important: This feature has a significant negative impact on CPU performance. This should be used only when developing scripts or in interactive use. When you turn on the feature, the application issues a message (CMD-042) to warn you about the usage of this feature.

print proc\_new\_vars 152

# **EXAMPLES**

Assuming that the appropriate control variables are set to **true**, the following commands show new variables created within procedures:

```
prompt> proc new_proc {a} {
             set x $a
             set y $x
             unset x
             print_proc_new_vars
prompt> new_proc 67
=New variable report for new_proc:
Information: Defining new variable 'y'. (CMD-041)
=END=
prompt>
prompt> proc ns::p2 {a} {
             set x $a
             print_proc_new_vars
prompt> define_proc_attributes ns::p2
prompt> ns::p2 67
=New variable report for ns::p2:
Information: Defining new variable 'x'. (CMD-041)
```

# **SEE ALSO**

```
define_proc_attributes(2)
sh_new_variable_message(3)
sh_new_variable_message_in_proc(3)
```

# print\_suppressed\_messages

Displays an alphabetical list of message IDs that are currently suppressed.

### **SYNTAX**

string print\_suppressed\_messages

### **ARGUMENTS**

The **print\_suppressed\_messages** command has no arguments.

### DESCRIPTION

The **print\_suppressed\_messages** command displays all messages that you suppressed using the **suppress\_message** command. The messages are listed in alphabetical order. You only can suppress informational and warning messages. The result of **print\_suppressed\_messages** is always the empty string.

### **EXAMPLES**

The following example shows the output from the **print\_suppressed\_messages** command:

```
prompt> print_suppressed_messages
No messages are suppressed
prompt> suppress_message {XYZ-001 CMD-029 UI-1}
prompt> print_suppressed_messages
The following 3 messages are suppressed:
```

CMD-029, UI-1, XYZ-001

# **SEE ALSO**

suppress\_message(2)
unsuppress\_message(2)

printenv 155

# printenv

Prints the value of environment variables.

### **SYNTAX**

string printenv
[variable name]

### **Data Types**

variable\_name

string

# **ARGUMENTS**

variable name

Specifies the name of a single environment variable to print.

# **DESCRIPTION**

The **printenv** command prints the values of the environment variables inherited from the parent process or set from within the application with the **setenv** command. When no arguments are specified, all environment variables are listed. When a single *variable\_name* is specified, if that variable exists, its value is printed. There is no useful return value from **printenv**.

To retrieve the value of a single environment variable, use the **getenv** command.

### **EXAMPLES**

The following examples show the output from the **printenv** command:

printenv 156

```
prompt> printenv SHELL
/bin/csh

prompt> printenv EDITOR
emacs
```

# **SEE ALSO**

getenv(2)
setenv(2)

printvar 157

# printvar

Prints the values of one or more variables.

## **SYNTAX**

```
string printvar
  [pattern]
  [-user defined | -application]
```

## **Data Types**

pattern string

# **ARGUMENTS**

#### pattern

Prints variable names that match *pattern*. The optional *pattern* argument can include the wildcard characters \* (asterisk) and ? (question mark). If not specified, all variables are printed.

#### -user\_defined

Shows only user-defined variables. This option is mutually exclusive with the **-application** option.

#### -application

Shows only application variables. This option is mutually exclusive with the **-user\_defined** option.

### **DESCRIPTION**

The **printvar** command prints the values of one or more variables. If the *pattern* argument is not specified, the command prints out the values of application and user-defined variables. The **- user\_defined** option limits the variables to those that you have defined. The **-application** option limits the variables to those created by the application. The two options are mutually exclusive and cannot be used together.

printvar 158

Some variables are suppressed from the output of **printvar**. For example, the Tcl environment variable array *env* is not shown. To see the environment variables, use the **printenv** command. Also, the Tcl variable **errorInfo** is not shown. To see the error stack, use the **error\_info** command.

# **EXAMPLES**

The following command prints the values of all of the variables:

```
prompt> printvar
```

The following command prints the values of all application variables that match the pattern sh\*a\*:

The following command prints the value of the **search\_path** variable:

The following command prints the values of the user-defined variables:

```
prompt> printvar -user_defined
a = "6"
designDir = "/u/designs"
```

# **SEE ALSO**

```
error_info(2)
printenv(2)
setenv(2)
```

proc\_args 159

# proc\_args

Displays the formal parameters of a procedure.

## **SYNTAX**

```
string proc_args
proc_name
```

### **Data Types**

proc\_name string

# **ARGUMENTS**

proc\_name

Specifies the name of the procedure.

# **DESCRIPTION**

The **proc\_args** command is used to display the names of the formal parameters of a user-defined procedure. This command is essentially a synonym for the TcI builtin command **info** with the *args* argument.

# **EXAMPLES**

This example shows the output of **proc\_args** for a simple procedure:

```
prompt> proc plus {a b} { return [expr $a + $b] }
```

proc\_args 160

```
prompt> proc_args plus
a b

prompt> info args plus
a b

prompt>
```

# **SEE ALSO**

```
info(2)
proc(2)
proc_body(2)
```

proc\_body 161

# proc\_body

Displays the body of a procedure.

# **SYNTAX**

```
string proc_body
   proc_name
```

### **Data Types**

proc\_name string

# **ARGUMENTS**

proc\_name

Specifies the name of the procedure.

# **DESCRIPTION**

The **proc\_body** command is used to display the body (contents) of a user-defined procedure. This command is essentially a synonym for the Tcl builtin command **info** with the *body* argument.

# **EXAMPLES**

This example shows the output of **proc\_body** for a simple procedure:

```
prompt> proc plus {a b} { return [expr $a + $b] }
prompt> proc_body plus
```

proc\_body 162

```
return [expr $a + $ b]
prompt> info body plus
return [expr $a + $ b]
prompt>
```

# **SEE ALSO**

```
info(2)
proc(2)
proc_args(2)
```

query\_objects 163

# query\_objects

Searches for and displays objects in the database.

## **SYNTAX**

```
string query_objects
[-verbose]
[-truncate elem_count]
[-class class_name]
object spec
```

### **Data Types**

class_name	string
elem_count	int
object spec	list

### **ARGUMENTS**

#### -verbose

Displays the class of each object found. By default, only the name of each object is listed. With this option, each object name is preceded by its class (see the EXAMPLES).

#### -truncate elem count

Truncates display to *elem\_count* elements. By default, up to 100 elements display. To see more or less elements, use this option. To see all elements, set the *elem\_count* value to 0.

#### -class class\_name

For elements in the *object\_spec* that are not collections, this is the class used when searching the database for objects which match the element. Valid classes are application-specific.

#### object\_spec

Provides a list of objects to find and display. Each element in the list is either a collection or a pattern which will match some objects in the database. Patterns are explicitly searched for in the database with class *class name*.

query\_objects 164

## **DESCRIPTION**

The **query\_objects** command finds and displays objects in the application's runtime database. The command does not have a meaningful return value; it displays the objects found and returns an empty string.

The *object\_spec* is a list containing collections and/or object names. For elements of the *object\_spec* that are collections, **query\_objects** simply displays the contents of the collection.

For elements of the *object\_spec* that are names (or contain wildcard patterns), the **query\_objects** command searches the database for objects of the class specified by the *class\_name* option. Note: The **query\_objects** command does not have a predefined implicit order of classes for which searches are initiated. If you do not specify the *class\_name* option, only those elements that are collections are displayed. Messages are displayed for the other elements (see EXAMPLES).

To control the number of elements displayed, use the *-truncate* option. If the display is truncated, you see the ellipsis (...) as the last element. Note that if the default truncation occurs, a message displays showing the total number of elements that would have displayed (see EXAMPLES).

The **query\_objects** command displays the output in either a Legacy format or in a Tcl compatible format. The default output format varies by tool but you can control the format yourself by setting the application variable query\_objects\_format. For example to force Tcl compatible output use this command:

```
pt_shell> set_app_var query_objects_format Tcl
Tcl
```

See below the differences between Legacy and Tcl formats.

NOTE: The output from the **query\_objects** command looks similar to the output from any command that creates a collection; however, the result of the **query\_objects** command is always an empty string.

### **EXAMPLES**

These following examples show the basic usage of the **query\_objects** command.

```
pt_shell> query_objects [get_cells o*]
{"or1", "or2", "or3"}
pt_shell> query_objects -class cell U*
{"U1", "U2"}
pt_shell> query_objects -verbose -class cell \
? \[list U* [get_nets n1]]
{"cell:U1", "cell:U2", "net:n1"}
```

If the output format is Tcl, then the output looks like this:

```
pt_shell> query_objects [get_cells o*]
{or1 or2 or3}
pt_shell> query_objects -class cell U*
{U1 U2}
```

query objects 165

When you omit the **-class** option, only those elements of the *object\_spec* that are collections generate output. The other elements generate error messages.

```
pt_shell> query_objects \[list U* [get_nets n1] n*]
Error: No such collection 'U*' (SEL-001)
Error: No such collection 'n*' (SEL-001)
{"n1"}
```

When the output is truncated, you get the ellipsis at the end of the display. For the following example, assume the default truncation is 5 (it is actually 100).

```
pt_shell> query_objects [get_cells o*] -truncate 2
{"or1", "or2", ...}
pt_shell> query_objects [get_cells *]
{"or1", "or2", "or3", "U1", "U2", ...}
Output truncated (total objects 126)
```

## **SEE ALSO**

```
collections(2)
get_cells(2)
get_clocks(2)
get_designs(2)
get_generated_clocks(2)
get_lib_cells(2)
get_lib_pins(2)
get_libs(2)
get_nets(2)
get_path_groups(2)
get_pins(2)
get_ports(2)
get_ports(2)
get_qtm_ports(2)
get_timing_paths(2)
```

quit 166

# quit

Exits the shell.

# **SYNTAX**

string quit

# **ARGUMENTS**

The **quit** command has no arguments.

# **DESCRIPTION**

The **quit** command exits from the application. It is basically a synonym for the **exit** command with no arguments.

# **EXAMPLES**

The following example exits the current session:

prompt> quit

# **SEE ALSO**

exit(2)

quit 167

read\_db

# read\_db

Reads in one or more design or library files in Synopsys database (.db) format.

### **SYNTAX**

```
string read_db
[-return_lib_collection]
  file names
```

## **Data Types**

file\_names list

# **ARGUMENTS**

file\_names

Specifies names of one or more files to be read.

```
-return_lib_collection
```

Specifies whether read\_db returns a library collection. If the db library is failed to be read, read\_db returns an empty collection.

# **DESCRIPTION**

The **read\_db** command reads design information from Synopsys database (.db) files into lc\_shell.

This command is derived from the **read\_file** command with the **-format db** option. For more information, see the man page for the **read\_file** command.

read db 169

# **SEE ALSO**

read\_lib(2)

read\_lib 170

# read\_lib

Reads a technology library into the shell.

# **SYNTAX**

```
status read_lib
  file_name
  [-test_model CTL_file_list]
  [-signoff_screening]
  [-model_type model_file_type]
  [-partial_model_check]
  [-html]
  [-return lib collection]
```

## **Data Types**

```
 \begin{array}{ll} \textit{file\_name} & \textit{string} \\ \textit{CTL\_file\_list} & \textit{list} \\ \textit{model\_file\_type} & \textit{string} \end{array}
```

# **ARGUMENTS**

#### file\_name

Specifies the name of the library file to be read. A technology must be in Synopsys Library Compiler format.

```
-test_model CTL_file_list
```

Specifies a set of one or more CTL files as test model of cells in the library. The format of the CTL\_file\_list is <cell\_name:>file\_name where cell\_name is optional and is to specify the particular cell a CTL file models. When the cell\_name is missing, the environment name in the CTL file is used as the cell name it is modeling. When specifying more than one CTL file, enclose them in braces ({}).

#### -signoff screening

Specifies that library Compiler is screening for sign-off tools.

```
-model_type model_file_type
```

Specifies that Library Compiler accepts one of these model types: [lvf|ccs\_power|power\_aware].

read lib 171

#### -partial\_model\_check

Specifies that Library Compiler run minimum set of screener checks on model file.

#### -html

Specifies that library screener results are reported in HTML.

#### -return lib collection

Specifies whether read\_lib returns a library collection. If the library file is failed to be compiled, read\_lib returns an empty collection.

### **DESCRIPTION**

The **read\_lib** command reads a library file into the shell (or GUI). The library file is automatically compiled by the Synopsys Library Compiler. The library specified in *file\_name* can have either a simple or complex file name. A simple file name has no directory specification, which means (in UNIX) that it does not contain a / (slash). Simple file names such as test.lib or library.db must be found in a directory listed in the **search\_path** variable. A complex file name has a directory specification in it, which means that it does contain a slash. Complex file names such as ./test.lib or ~synopsys/dc/test.lib are not searched for in **search\_path**.

You can read any number of libraries into the shell. Two libraries can have the same name in the system as long as they are read from different sources. The **list\_libs** command shows all libraries present in the system.

The **read\_lib** command will check the input model file library syntax against model syntax specified by **-model\_type** option. If any content of the input model file library does not belong to the specified model, syntax error will be reported.

For details on library file syntax, see the Library Compiler documentation. Function statements and state information are ignored when reading technology library files if you do not have a Library Compiler license.

## **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

# **EXAMPLES**

In the following example, the library file *tech\_lib.lib*, is read. This file contains technology information in Synopsys technology library entry format,

```
prompt> read lib ~synopsys/libraries/tech lib.lib
```

The following example reads a library file as well as a CTL file when the **-test\_model** option is used:

read lib 172

```
prompt> read_lib bar.lib -test_model {usr1.ctl usr2:usr2.ctl}
```

The following examples read in a lvf, ccs\_power or power\_aware model file respectively when the **- model\_type** option is used:

```
prompt> read_lib accv.lib -model_type lvf
prompt> read_lib accv.lib -model_type ccs_power
prompt> read_lib accv.lib -model_type power_aware
```

The following example reads a library file and report screener messages in HTML:

```
prompt> read_lib bar.lib -html
```

# **SEE ALSO**

```
write_lib(2)
search_path(3)
```

# redirect

Redirects the output of a command to a file.

## **SYNTAX**

```
string redirect
[-append] [-tee] [-file | -variable | -channel] [-compress]
target
{command_string}
string target
string command string
```

# **ARGUMENTS**

### -append

Appends the output to target.

#### -tee

Like the unix command of the same name, sends output to the current output channel as well as to the *target*.

#### -file

Indicates that *target* is a file name, and redirection is to that file. This is the default. It is exclusive of *-variable* and *-channel*.

#### -variable

Indicates that *target* is a variable name, and redirection is to that Tcl variable. It is exclusive of *-file* and *-channel*.

#### -channel

Indicates tha *target* is a Tcl channel, and redirection is to that channel. It is exclusive of *-variable* and *-file*.

#### -compress

Compress when writing to file. If redirecting to a file, then this option specifies that the output should be

compressed as it is written. The output file is in a format recognizable by "gzip -d". You cannot specify this option with *-append*.

#### target

Indicates the target of the output redirection. This is either a filename, Tcl variable, or Tcl channel depending on the command arguments.

#### command\_string

The command to execute. Intermediate output from this command, as well as the result of the command, will be redirected to *target*. The *command string* should be rigidly quoted with curly braces.

### DESCRIPTION

The **redirect** command performs the same function as the traditional unix-style redirection operators > and >>. The *command\_string* must be rigidly quoted (that is, enclosed in curly braces) in order for the operation to succeed.

Output is redirected to a file by default. Output can be redirected to a Tcl variable by using the *-variable* option, or to a Tcl channel by using the *-channel* option.

Output can be sent to the current output device as well as the redirect target by using the *-tee* option. See the examples section for an example.

The result of a **redirect** command which does not generate a Tcl error is the empty string. Screen output occurs only if errors occurred during execution of the *command\_string* (other than opening the redirect file). When errors occur, a summary message is printed. See the examples.

Although the result of a successful **redirect** command is the empty string, it is still possible to get and use the result of the command that you redirected. Construct a **set** command in which you set a variable to the result of your command. Then, redirect the **set** command. The variable holds the result of your command. See the examples.

The **redirect** command is much more flexible that traditional unix redirection operators. With **redirect**, you can redirect multiple commands or an entire script. See the examples for an example of how to construct such a command.

Note that the builtin Tcl command **puts** does not respond to output redirection of any kind. Use the builtin **echo** command instead.

#### **EXAMPLES**

In the following example, the output of the plus procedure is redirected. The echoed string and the result of the plus operation is in the output file. Notice that the result was not echoed to the screen.

```
prompt> proc plus {a b} {echo "In plus" ; return [expr $a + $b]}
```

```
prompt> redirect p.out {plus 12 13}
prompt> exec cat p.out
In plus
25
```

In this example, a typo in the command created an error condition. The error message indicates that you can use **error\_info** to trace the error, but you should first check the output file.

In this example, we explore the usage of results from redirected commands. Since the result of **redirect** for a command which does not generate a Tcl error is the empty string, use the **set** command to trap the result of the command. For example, assume that there is a command to read a file which has a result of "1" if it succeeds, and "0" if it fails. If you redirect only the command, there is no way to know if it succeeded.

```
redirect p.out { read_a_file "a.txt" }
# Now what? How can I redirect and use the result?
```

But if you set a variable to the result, then it is possible to use that result in a conditional expression, etc.

```
redirect p.out { set rres [read_a_file "a.txt"] }
if { $rres == 1 } {
   echo "Read ok!"
}
```

The **redirect** command is not limited to redirection of a single command. You can redirect entire blocks of a script with a single **redirect** command. This simple example with **echo** demonstrates this feature:

The **redirect** command allows you to tee output to the previous output device and also to redirect output to a variable. This simple example with **echo** demonstrates these features:

```
prompt> set y "This is "
This is
prompt> redirect -tee x.out {
         echo XXX
         redirect -variable y -append {
         echo YYY
         redirect -tee -variable z {
```

```
echo ZZZ

}

}

XXX

prompt> exec cat x.out

XXX

prompt> echo $y

This is YYY

ZZZ

prompt> echo $z

ZZZ
```

# **SEE ALSO**

echo(2) error\_info(2) set(2)

remove\_from\_collection 177

# remove\_from\_collection

Removes objects from a collection, resulting in a new collection. The base collection remains unchanged.

### **SYNTAX**

```
collection remove_from_collection
[-intersect]
collection1
object_spec
```

## **Data Types**

collection1 collection
object\_spec list

# **ARGUMENTS**

#### -intersect

Removes objects from collection1 not found in object\_spec. Without this option, removes objects from collection1 that are found in object\_spec.

#### collection1

Specifies the base collection to be copied to the result collection. Objects matching *object\_spec* are removed from the result collection.

#### object\_spec

Specifies a list of named objects or collections to remove. The object class of each element in this list must be the same as in the base collection. If the name matches an existing collection, the collection is used. Otherwise, the objects are searched for in the database using the object class of the base collection.

# **DESCRIPTION**

remove from collection 178

The **remove\_from\_collection** command removes elements from a collection, creating a new collection.

If the base collection is homogeneous, any element of the *object\_spec* that is not a collection is searched for in the database using the object class of the base collection. If the base collection is heterogeneous, any element of the *object\_spec* that is not a collection is ignored.

If the *-intersect* option is not specified, which is the default mode, and if nothing matches the *object\_spec*, the resulting collection is a copy of the base collection. If everything in the *collection1* option matches the *object\_spec*, the result is the empty collection. With the *-intersect* option the results are reversed.

For background on collections and querying of objects, see the **collections** man page.

### **EXAMPLES**

The following example from PrimeTime gets all input ports except "CLOCK".

```
pt_shell> set cPorts [remove_from_collection [all_inputs] CLOCK]
{"in1", "in2"}
```

### **SEE ALSO**

```
add_to_collection(2)
collections(2)
```

remove host options 179

# remove\_host\_options

.prod lc Removes -max\_cores specification set by the set\_host\_options command.

# **SYNTAX**

status remove\_host\_options

# **ARGUMENTS**

The **remove\_host\_options** command has no options.

# **DESCRIPTION**

The **remove\_host\_options** command unsets the -max\_cores option set by the **set\_host\_options** command. It is equivalent to

```
set_host_options -max_cores 1
```

Running the **remove\_host\_options** command disables parallel execution of the read\_lib command.

## **EXAMPLE**

lc\_shell> remove\_host\_options

remove\_host\_options 180

# **SEE ALSO**

set\_host\_options(2)
report\_host\_options(2)

remove\_lib 181

# remove\_lib

Removes a list of libraries from lc\_shell memory.

# **SYNTAX**

```
int
remove_lib [lib_list | -all]
list lib list
```

# **ARGUMENTS**

lib\_list

A list of libraries to remove.

-all

Causes the removal of all libraries in lc\_shell.

# **DESCRIPTION**

Removes a list of libraries from lc\_shell. If you don't specify any arguments, nothing is removed. When a library is removed, the memory it occupies is freed, so the object is no longer in lc\_shell.

#### Note:

Memory is freed to be reused by this same process. However, memory is not returned to the operating system until you exit the Library\_compiler or lc\_shell.

remove\_lib 182

# **EXAMPLES**

This example removes my\_lib:

```
lc_shell> remove_lib my_lib
Removing library 'my_lib'
```

This example removes all the library objects in lc\_shell.

```
lc_shell> remove_lib -all
Removing library 'test_libA'
Removing library 'test_libB'
Removing library 'test libC'
```

# **SEE ALSO**

None.

remove\_license 183

# remove\_license

Removes a licensed feature.

## **SYNTAX**

```
status remove_license
  feature_list
  [-keep num licenses]
```

# **Data Types**

```
feature_list list
num licenses integer
```

# **ARGUMENTS**

#### feature list

Specifies the list of features to remove. If you specify more than one feature, the list must be enclosed in braces ({}).

By looking at your key file, you can determine all of the features licensed at your site.

```
-keep num_licenses
```

Specifies the number of licenses to be retained for each feature after the command has completed. If this option is not specified, all of the features' licenses are checked in.

# **DESCRIPTION**

This command removes the specified licensed features from the features you are currently using.

For multicore runs, where multiple licenses might be required for certain features, you can use the **-keep** option to restrict the number of licenses that are checked in. This is analogous to the **get\_license - quantity** option.

remove license 184

The **list\_licenses** command provides a list of the features that you are currently using.

## **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

## **EXAMPLES**

The following example removes the multivoltage license:

```
prompt> remove_license Galaxy-MV
```

The following example removes some, but not all, of the licenses required for a multicore **compile\_ultra** run in Design Compiler:

# **SEE ALSO**

```
check_license(2)
license_users(2)
list_licenses(2)
get_license(2)
```

rename 185

## rename

Renames or deletes a command.

# **SYNTAX**

string rename
old\_name
new name

# **ARGUMENTS**

old name

Specifies the current name of the command.

new\_name

Specifies the new name of the command.

# **DESCRIPTION**

Renames the *old\_name* command so that it is now called *new\_name*. If *new\_name* is an empty string, then *old\_name* is deleted. The *old\_name* and *new\_name* arguments may include namespace qualifiers (names of containing namespaces). If a command is renamed into a different namespace, future invocations of it will execute in the new namespace. The **rename** command returns an empty string as result.

Note that the **rename** command cannot be used on permanent procedures. Depending on the application, it can be used on all basic builtin commands. In some cases, the application will allow all commands to be renamed.

WARNING: **rename** can have serious consequences if not used correctly. When using **rename** on anything other than a user-defined Tcl procedure, you will be warned. The **rename** command is intended as a means to wrap other commands: that is, the command is replaced by a Tcl procedure which calls the

rename 186

original. Parts of the application are written as Tcl procedures, and these procedures can use any command. Commands like **puts**, **echo**, **open**, **close**, **source** and many others are often used within the application. Use **rename** with extreme care and at your own risk. Consider using **alias**, Tcl procedures, or a private namespace before using **rename**.

## **EXAMPLES**

This example renames my\_proc to my\_proc2:

```
prompt> proc my_proc {} {echo "Hello"}
prompt> rename my_proc my_proc2
prompt> my_proc2
Hello
prompt> my_proc
Error: unknown command 'my_proc' (CMD-005).
```

# **SEE ALSO**

define\_proc\_attributes(2)

report\_app\_var 187

# report\_app\_var

Shows the application variables.

## **SYNTAX**

```
string report_app_var
[-verbose]
[-only_changed_vars]
[pattern]
```

## **Data Types**

pattern string

# **ARGUMENTS**

-verbose

Shows detailed information.

-only\_changed\_vars

Reports only changed variables.

pattern

Reports on variables matching the pattern. The default is "\*".

# **DESCRIPTION**

The **report\_app\_var** command prints information about application variables matching the supplied pattern. By default, all descriptive information for the variable is printed, except for the help text.

If no variables match the pattern, an error is returned. Otherwise, this command returns the empty string.

If the **-verbose** option is used, then the command also prints the help text for the variable. This text is

report\_app\_var 188

printed after the variable name and all lines of the help text are prefixed with " #".

The Constraints column can take the following forms:

```
{val1 ...}
```

The valid values must belong to the displayed list.

```
val \le a
```

The value must be less than or equal to "a".

$$val >= b$$

The value must be greater than or equal to "b".

The value must be greater than or equal to "b", and less than or equal to "a".

### **EXAMPLES**

The following are examples of the **report\_app\_var** command:

# **SEE ALSO**

```
get_app_var(2)
set_app_var(2)
write_app_var(2)
```

# report\_check\_library\_options

Reports the values or the status of the options set by the **set\_check\_library\_options** command.

## **SYNTAX**

```
status report_check_library_options
[-logic]
[-physical]
[-logic_vs_physical]
[-default]
```

## **ARGUMENTS**

#### -logic

Reports the values or the status of the options set by the **set\_check\_library\_options** command to check logical libraries.

See the **-logic** option in the **set\_check\_library\_options** man page for more information.

#### -physical

Reports the values or the status of the options set by the **set\_check\_library\_options** command to check physical libraries.

#### -logic vs physical

Reports the values or the status of the options set by the **set\_check\_library\_options** command to check cross logical and physical libraries.

See the **-logic\_vs\_physical** option in the **set\_check\_library\_options** man page for more information.

#### -default

Reports the default values of all library-checking options. If this option is not specified, the current values of the options are reported.

### DESCRIPTION

The **report\_check\_library\_options** command reports the values or the status of the options set by the **set\_check\_library\_options** command. The **report\_check\_library\_options** command provides information about options used for checking between logical libraries,

Use the report\_check\_library\_options command after running set\_check\_library\_options.

### **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

### **EXAMPLES**

In the following example, **report\_check\_library\_options** checks all data for the specified *test.db* library, and then reports the option values:

# **SEE ALSO**

```
check_library(2)
set_check_library_options(2)
```

report host options 191

# report\_host\_options

.prod lc Prints a report of multi-CPU processing options as defined by the **set\_host\_options** command.

# **SYNTAX**

status report\_host\_options

## **ARGUMENTS**

The **report\_host\_options** command has no arguments.

# **DESCRIPTION**

By default, the **report\_host\_options** command prints a report of the multi-CPU processing options defined by the **set\_host\_options** command used by IC Compiler.

### **EXAMPLES**

The following is an example of the **report\_host\_options** command:

lc\_shell> report\_host\_options

## **SEE ALSO**

report\_host\_options 192

remove\_host\_options(2)
set\_host\_options(2)

report\_lib 193

# report\_lib

Displays information about the specified logic library.

# **SYNTAX**

```
status report lib
   [-all]
   [-em]
   [-fpga]
   [-k factors]
   [-power]
   [-power label]
   [-table]
   [-full table]
   [-timing]
   [-timing_arcs]
   [-timing_label]
   [-noise]
   [-noise_arc]
   [-vhdl_name]
   [-yield]
   [-switch]
   [-pg_pin]
   [-char]
   [-operating_condition]
   [-op_cond_name op_cond_name]
   [-routing_rule]
   [-rwm]
   [-user_defined_data]
   library_name
   [cell_list]
```

# **Data Types**

```
op_cond_name string
library_name string
cell list string
```

# **ARGUMENTS**

-all

Lists all timing-related, power-related, electromigration-related, and FPGA-related information.

report\_lib 194

This option applies only to logic libraries.

#### -em

Lists all detailed electromigration-related information.

This option applies only to logic libraries.

#### -fpga

Lists all detailed FPGA-related information, such as parts and I/O cell attributes.

This option applies only to FPGA libraries.

#### -full table

Lists each cell's state-table description in tabular, expanded form.

This option applies only to logic libraries.

#### -k\_factors

Lists scaling information for library cells.

This option applies only to logic libraries.

#### -power

Lists all detailed power-related information.

This option applies only to logic libraries.

#### -power label

Lists the power labels for all power arcs, if specified, in a tabular form.

This option applies only to logic libraries.

#### -routing\_rule

Lists nondefault routing rule information from physical libraries.

This option applies only to physical libraries.

#### -rwm

Lists routing wire model information from physical libraries.

In a routing wire model report, the original routing wire model is printed out, which includes overlap wire ratio, adjacent wire ratio, wire ratio and wire length of both directions. Also reported is capacitance (in database units) per micron for each layer and for each direction (based on each layer's wire ratio), based on the default operating condition. The report shows resistance per square (in database units) for each direction based on the default operating condition. These derived numbers provide useful information before applying the routing wire-model using the **set\_routing\_wire\_model** command.

This option applies only to physical libraries.

#### -table

Lists each cell's state-table description in compact form.

This option applies only to logic libraries.

#### -timing

Lists all detailed timing-related information.

This option applies only to logic libraries.

#### -timing arcs

Lists all cell timing arcs.

This option applies only to logic libraries.

#### -timing\_label

Lists the timing labels for all timing arcs, if specified, in a tabular form.

This option applies only to logic libraries.

#### -user\_defined\_data

Lists detailed information about the user-defined groups and attributes.

This option applies to both logic libraries and physical libraries.

#### -vhdl name

Lists the cells and ports whose database (.db) names are different from their VHDL names.

This option applies only to logic libraries.

#### -yield

Lists failure rate information for library cells.

This option applies only to logic libraries.

#### -switch

Lists pin switch function information and cell-level steady state current information.

Use the **-pg\_pin** option to display the switch function of a power or ground pin.

This option applies only to logic libraries.

#### -pg\_pin

Lists power and ground pin information, such as the PG pin definition and the voltage name to which a signal pin has been linked and the PG type.

This option applies only to logic libraries.

#### -char

Lists cell characterization information, such as sensitization and pre-driver model.

This option applies only to logic libraries.

#### -operating\_condition

Lists all library operating condition information.

When this is the only option selected, the **report\_lib** command reports only operating condition information; no other information is reported.

#### -op\_cond\_name op\_cond\_name

Lists operating condition information by name.

When this is the only option selected, the **report\_lib** command reports only operating condition information, no other information is reported.

#### cell list

Specifies a list of cells about which information is to be reported. The default is to report information about all cells in the logic library or physical library.

This option applies to both logic libraries and physical libraries.

#### library\_name

Specifies the name of the library to report.

This argument is required.

#### -noise

Lists all detailed noise-related information in the specified library.

This option applies only to logic libraries.

#### -noise arcs

Lists all cell noise arcs.

This option applies only to logic libraries.

# **DESCRIPTION**

The **report\_lib** command displays information about the specified logic library, physical library, or symbol library.

By default, a logic library report displays a list of operating conditions, timing ranges, and wire load models, as well as a listing of all the cells in the library annotated with their attributes. You can restrict the set of cells by using the *cell\_list* argument.

Any library object added by using the **update\_lib** command is marked with an asterisk (\*) following its name, to identify those objects that have been added since the initial library was created with the **read\_lib** command.

The **-timing**, **-noise**, **-table**, **-full\_table**, **-timing\_label**, **-power\_label**, **-em**, **-power**, **-yield**, **-pg\_pin**, and **-switch** options can be used only with a logic library that was read in from a library source (.lib) file. If the library is read in from a database (.db) file, an error message is issued.

A physical library report displays a list of available layers, a list of vias, a list of sites and a list of cells. If a *cell\_list* is specified with **report\_lib**, the report includes only the specified cells; otherwise all cells in the given physical library are listed.

A symbol library report displays a list of the names of symbol definitions contained in the library *library\_name*. It also reports the route grid and meter scale for the library.

To generate a report, the specified library must be loaded into memory, unless it is found in the search path. The **list\_libs** command displays the libraries that are currently loaded.

## **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

### **EXAMPLES**

The following command generates a report for the *mylib* logic library. This type of report includes names of the library cells, wire load models, timing ranges, and operating conditions, the date the library was created, the date the library was generated, and CCS timing, CCS power, CCS Noise and LVF modeling information for the library cells.

```
prompt> report_lib mylib
********
Report : library
Library: mylib
Version: C-2009.06
********
Library Type
               : Technology
Tool Created
Date Created
                    : 2003.06
                    : 21-Jun-101 (INF CREATED ON 1-JUL-2001)
Library Version
                    : 1.000000
Time Unit
                    : 1ns
Capacitive Load Unit : 1.000000pf
Pulling Resistance Unit : 1kilo-ohm
Voltage Unit : 1V
Current Unit
                    : 1uA
Dynamic Energy Unit
Leakage Power Unit
                    : 1.000000pJ (derived from V,C units)
                    : 1pW
Bus Naming Style
                    : %s[%d] (default)
Operating Conditions:
   Operating Condition Name : mylib
   Library : mylib
   Process: 1.20
   Temperature: 125.00
   Voltage: 1.08
   Interconnect Model : worst case tree
Input Voltages:
   No input voltage groups specified.
```

```
Output Voltages:
```

No output\_voltage groups specified.

default\_wire\_load\_capacitance: 0.000096
default\_wire\_load\_resistance: 0.000380

default\_wire\_load\_area: 0.010000

Wire Loading Model:

Name : 05x05
Location : mylib
Resistance : 0.00038
Capacitance : 9.6e-05
Area : 0.01
Slope : 15.9634

Fanout Length Points Average Cap Std Deviation

\_\_\_\_\_\_

```
9.80
2 22.01
 3 35.15
 4 49.29
 5 64.54
 6 80.97
7
    98.68
8 117.77
9 138.32
10 160.41
11 184.15
12 209.61
13 236.90
14 266.09
15 297.29
16 330.57
17 366.04
18 403.77
19 443.86
20 486.41
```

. . .

Wire Loading Model Selection Group:

Name : a

	Selection		Wire load name
mi	n area	max area	
	0.00	5.00	05x05
	5.00	10.00	10x10
	10.00	20.00	20x20
	20.00	30.00	30x30

Wire Loading Model Mode: enclosed.

Wire Loading Model Selection Group: a.

Porosity information:

No porosity information specified.

Routing Layers:

```
"metal1" "metal2" "metal3" "metal4" "metal5"
              "metal6" "metal7" "metal8"
default_min_porosity: 0.000000
In_place optimization mode: match_footprint
Timing Ranges:
   No timing ranges specified.
Delay Threshold Trip-Points:
        input threshold pct rise:
        output_threshold_pct_rise:
        input threshold pct fall:
        output_threshold_pct_fall:
                                      50
Slew Threshold Trip-Points:
        slew lower threshold pct rise:
        slew upper threshold pct rise:
        slew lower threshold pct fall:
        slew upper threshold pct fall:
        slew derate from library:
                                       0.6
Components:
   Attributes:
      af - active falling
      ah - active high
      al - active low
      ar - active rising
       b - black box (function unknown)
      ce - clock enable
      cg - clock gating integrated cell
      ub - unbuffered
     pgt - pass gate
     ctl - has CTL test model
       d - dont touch
     iso - isolation cell
      ls - level shifter
      mo - map only
     1p0g - power only, no ground
     Op1g - ground only, no power
    0p0g - no power/ground
       p - preferred
      hp - hold_preferred
    pwrg - power gating cell
       r - removable
       s - statetable
     sa0 - dont_fault stuck-at-0
     sa1 - dont_fault stuck-at-1
     sa01 - dont fault both stuck-at-0 and stuck-at-1
      sz - use for size only
       t - test cell. t(scan type) as
         t(mux_ff) - muxed flip-flop
         t(mux_ld) - muxed latch
         t(clk_scan) - clocked scan
         t(clk scan ld) - clocked scan latch
         t(lssd_dld) - double latch LSSD
         t(lssd\_sld) - single latch LSSD
         t(lssd clk) - clocked LSSD
```

```
t(lssd auxclk) - auxiliary clock LSSD
       u - dont use
     udp - usable for datapath generators
     ufc - user_function_class. ufc(type) as
        ufc(u) - user-defined
         ufc(a) - automatically generated
     ccs - composite current source
   c ccs - compact ccs timing modeling
    ccsn - ccs noise data modeling
    ccsp - ccs power data modeling
    recv - receiver model
     lvf - lvf modeling
     imc - macro cell
switch cg - switch cell (coarse grain)
     ret - retention cell
      ao - always on cell
    gicg - generic integrated clock gating
      va - variation-aware ccs timing modeling
     val - variation-aware ccs leakage power modeling
     fil - filler cell
     tap - tap cell
   decap - decap cell
     pll - pll cell
Pin Attributes:
     ao - always on pin
     lse - level shifter enable pin
    isoe - isolation cell enable pin
    scmr - standard cell main rail
  Cell
                    Footprint Attributes
  _____
  AN2
  OR2
                                 ccs
```

The following command generates a report on library timing in the AND2 cell of the tech\_lib logic library:

```
prompt> report lib tech lib -timing AND2
**********
Report : library
Library: tech lib
Version: C-2009.06
********
Library Type : Technology
Tool Created
Date Created
                 : 2003.06
                 : 21-Jun-101 (INF CREATED ON 1-JUL-2001)
Library Version
                 : 1.000000
Delay Model
                 : table lookup
Time Unit
                  : 1ns
Timing Attributes Defaults:
                        Default
  Attribute
  ______
   max_transition
   max_fanout
   fanout_load
                        1
   max_capacitance
```

```
Lookup Table Template:
  Template_name
  _____
  del_0_5_7 w
      VARIABLE_1: input_net_transition
      VARIABLE_2: total_output_net_capacitance
     INDEX 1: 0.0150 0.2500 0.6500 1.4000 3.0000
      INDEX 2: 0.0000 0.0035 0.0070 0.0192 0.0402 0.0752 0.1750
CELL(AND2): 1.25;
 PIN(A): in, 0.0035, 1, 3, ,;
 END PIN A;
 PIN(B): in, 0.00375, 1, 3, ,;
 END PIN B;
 PIN(Z): out, 0, 18, 2, 0.175, ,;
   DELAY: A, Z, prop, pos unate, '', ( , ), ( , );
     cell rise (del 0 5 7 w):
                  0.0710 0.1000 0.1240 0.2050 0.3440 0.5750
        VALUES :
                  1.2330 0.1120 0.1410 0.1650 0.2470 0.3860
                  0.6170 1.2750 0.1520 0.1840 0.2100 0.2920
                  0.4320 0.6630 1.3210 0.1990 0.2360 0.2630
                  0.3470 0.4870 0.7190 1.3770 0.2630 0.3080
                  0.3400 0.4280 0.5700 0.8030 1.4630
     cell fall ( del 0 5 7 \text{ w} ):
        VALUES :
                 0.0620 0.0900 0.1160 0.2020 0.3500 0.5950
                  1.2940 0.1050 0.1360 0.1620 0.2480 0.3960
                  0.6420 1.3410 0.1440 0.1770 0.2040 0.2930
                  0.4410 0.6860 1.3860 0.1870 0.2240 0.2530
                  0.3430 0.4920 0.7390 1.4380 0.2410 0.2850
                  0.3180 0.4130 0.5650 0.8140 1.5150
     rise_transition ( del_0_5_7_w ) :
        VALUES: 0.0450 0.0960 0.1480 0.3400 0.6720 1.2270
                  2.8080 0.0490 0.0980 0.1500 0.3400 0.6720
                  1.2270 2.8080 0.0580 0.1060 0.1560 0.3440
                  0.6740 1.2270 2.8080 0.0720 0.1200 0.1660
                  0.3480 0.6770 1.2300 2.8080 0.0930 0.1460
                  0.1910 0.3630 0.6860 1.2370 2.8120
     fall transition ( del 0 5 7 w ):
                 0.0370 0.0900 0.1440 0.3380 0.6720 1.2300
        VALUES :
                  2.8190 0.0430 0.0930 0.1460 0.3380 0.6720
                  1.2300 2.8200 0.0510 0.1020 0.1530 0.3420
                  0.6740 1.2300 2.8190 0.0650 0.1150 0.1640
                  0.3480 0.6780 1.2330 2.8200 0.0870 0.1400
                  0.1870 0.3660 0.6920 1.2430 2.8250
   DELAY: B, Z, prop, pos_unate, '', ( , ), ( , );
      . . .
 END PIN Z;
END CELL AND2;
Number of library cells: 1
Number of reported cells: 1
1
```

The following command generates a report on library noise in the AND2 cell of the tech\_lib logic library:

```
prompt> report lib tech lib -noise AND2
CELL(AND2): 4, ;
 PIN(A): in, 2, , , ;
 END_PIN A;
 PIN(B): in, 2, , , ;
 END PIN B;
 PIN(Z): out, , , , , (, ), (, );
     noise_immunity_high ( noise5x5 ) :
        INDEX 2: 0.3620 0.7250 1.0870 1.4490 1.8120
        VALUES: 0.7330 1.0730 1.4120 1.7520 2.0920 0.8730
                  1.2140 1.5540 1.8940 2.2340 1.0950 1.4420
                   1.7870 2.1320 2.4770 1.2980 1.6480 1.9960
                   2.3430 2.6910 1.7030 2.0600 2.4140 2.7660
                   3.1190
 END PIN Z;
END CELL AND2;
```

For details about library timing report contents and syntax, see the Library Compiler Modeling Timing, Signal Integrity, and Power in Technology Libraries User Guide.

The following example generates a report on power information in the tech\_lib logic library:

```
prompt> report lib tech lib -power
Power Information:
  Attributes:
    a - average power specification
    i - internal power
    l - leakage power
    rf - rise and fall power specification
                     Power
          # Attr Toggling pin source of path When
    Cell
  _____
        0 1
  AN2
                  Z
Z
            1 i,a
                               Α
            2 i,a
  INV
            0 1
            1 i,a
                    Z
                               Α
  NO2
            0 1
            1 i,a
                    Z
                                Α
            2 i,a
                    Z
  flop1
            0 1
                   CP
            1
              i,a
                   Q
            2
              i,a
                               CP
            3
                    Q
              i,a
                   QN
                                СP
            4
              i,a
            5
              i,a
                    QN
  latch1
            0 1
            1
              i,a
                    G
                    Q
            2
              i,a
                                G
                   Q
            3 i,a
                                D
            4 i,a
                    QN
                                G
            5 i,a
                    QN
                                D
```

The following command generates a report on library electromigration in the *ad3* cell of the *tech\_lib* logic library:

```
prompt> report lib tech lib -em ad3
CELL(ad3): 2;
 PIN(y): out, 0, , , 1.812, , ;
   ELECTROMIGRATION: a;
     em_max_toggle_rate ( output_by_cap_and_trans ) :
         VALUES: 2.0000 1.0000 0.5000 1.5000 0.7500 0.3300 1.0000 0.5000 0.1500
   ELECTROMIGRATION: b;
      em max_toggle_rate ( output_by_cap_and_trans ) :
         VALUES: 2.0000 1.0000 0.5000 1.5000 0.7500 0.3300
                   1.0000 0.5000 0.1500
    ELECTROMIGRATION: c;
      em_max_toggle_rate ( output_by_cap_and_trans ) :
         VALUES: 2.0000 1.0000 0.5000 1.5000 0.7500 0.3300 1.0000 0.5000 0.1500
  END PIN y;
  PIN(a): in, 1, , ;
  END PIN a;
  PIN(b): in, 1, , ;
  END PIN b;
  PIN(c): in, 1, , ;
   ELECTROMIGRATION:
     em max toggle rate ( input by trans ) :
       VALUES: 1.5000 1.0000 0.5000
 END PIN c;
END CELL ad3;
Number of library cells: 1
Number of reported cells for em: 1
```

For details about library electromigration report contents and syntax, see the *Library Compiler Modeling Timing, Signal Integrity, and Power in Technology Libraries User Guide*.

The following command generates a report on timing arcs in the *tech\_lib* logic library. The *INV\_NEW* cell is identified as having been added using the **update\_lib** command:

If the **-timing\_arcs** option is not used, the last five columns do not appear.

The following command generates a report for a symbol library. The report includes the names of all symbol definitions, the route\_grid, and the meter\_scale:

```
prompt> report_lib sym_lib.sdb
```

The following command generates a report that displays timing arcs for the inverter cell from the *tech\_lib* logic library:

```
prompt> report_lib tech_lib -timing_arcs inverter
```

The following example generates a report that displays noise arcs for the inverter cell from the *tech\_lib* logic library:

```
prompt> report lib tech lib -noise arcs inverter
```

The following is an example of a compact report on state-table information in the tech\_lib logic library:

```
prompt> report_lib tech_lib -table

State table descriptions:

CELL(D_LATCH):

PIN(Q): CD, D, G
   TABLE: HNLNLLLL
   END_PIN Q;

PIN(QN):
   STATE_FUNCTION: Q'
   END_PIN QN;
END CELL D LATCH;
```

The following is an example of a tabular report on state-table information in the tech\_lib logic library:

```
prompt> report lib tech lib -full table
State table descriptions:
CELL (D LATCH):
 PIN(Q): CD, D, G
   TABLE:
   000
        L
   001 L
   010 L
   011
         L
        N
   100
   101
   110
   111
         Н
 END_PIN Q;
 PIN(QN):
   STATE FUNCTION: Q'
 END PIN QN;
END CELL D LATCH;
```

The following is an example of a pg\_pin report in the tech\_lib logic library:

```
prompt> report_lib tech_lib -pg_pin
...
CELL(LVLHLEHX2):

PG_PIN(VDDI):
    VOLTAGE_NAME: VDDH
    PG_TYPE: primary_power
```

```
END_PIN VDDI;

PG_PIN(VSS):
    VOLTAGE: VSS
    PG_TYPE: primary_ground
END_PIN VSS;

PIN(QN):
    RELATED_POWER_PIN : VDDI
    RELATED_GROUND_PIN : VSS
END_PIN QN;

END CELL LVLHLEHX2;
```

The following is an example of a characterization report in the tech\_lib logic library:

```
prompt> report_lib tech_lib -char
Report : library
Library: tech lib
Version: A-2007.12
: Technology
Library Type
Tool Created
Date Created
                     : A-2007.12
                     : Not Specified
                   : Not Specified
Library Version
Sensitization : 2IN 10UT
 pin names : (A, B, C)
 vector(0) : (0, 0, 0)
 vector(1) : (0, 0, 1)
 vector(2) : (0, 1, 0)
 vector(3) : (0, 1, 1)
 vector(4) : (1, 0, 0)
 vector(5) : (1, 0, 1)
 vector(6) : (1, 1, 0)
 vector(7) : (1, 1, 1)
 vector(8) : (1, 1, 1)
CELL(AN2): 2;
 SENSITIZATION MASTER: 2IN 10UT
 PIN NAME MAP : (A, B, Z)
 PIN(A): in, 1, , , ;
 END PIN A;
 PIN(B): in, 1, , , ;
 END PIN B;
 PIN(Z): out, 0, , , , ;
   DELAY: A, Z, prop, pos_unate, '', (1, 1), (0, 0), (0.1443, 0.0523);
     sensitization master: 2IN 10UT
     pin name map : (A, B, Z)
     wave_rise : (3, 4, 5)
     wave fall: (0, 3, 7)
     wave_rise_sampling_index: 2
     wave_fall_sampling_index: 2
     wave_rise_timing_interval : (0, 0.5)
     wave_fall_timing_interval : (0, 0.45)
   DELAY: B, Z, prop, pos_unate, '', (0.48, 0.77), (0, 0), (0.1443, 0.0523);
 END PIN Z;
END CELL AN2;
```

The following is an example of a switch-cell report in the *tech\_lib* logic library:

# **SEE ALSO**

```
read_lib(2)
system_variables(3)
update_lib(2)
write_lib(2)
```

set\_app\_var 207

# set\_app\_var

Sets the value of an application variable.

## **SYNTAX**

```
string set_app_var
-default
var
value
```

## **Data Types**

var string
value string

# **ARGUMENTS**

#### -default

Resets the variable to its default value.

var

Specifies the application variable to set.

value

Specifies the value to which the variable is to be set.

# **DESCRIPTION**

The **set\_app\_var** command sets the specified application variable. This command sets the variable to its default value or to a new value you specify.

This command returns the new value of the variable if setting the variable was successful. If the application variable could not be set, then an error is returned indicating the reason for the failure.

set\_app\_var 208

Reasons for failure include:

- The specified variable name is not an application variable, unless the application variable sh\_allow\_tcl\_with\_set\_app\_var is set to true See the sh\_allow\_tcl\_with\_set\_app\_var man page for details.
- The specified application variable is read only.
- The value specified is not a legal value for this application variable

## **EXAMPLES**

The following example attempts to set a read-only application variable:

In this example, the application variable name is entered incorrectly, which generates an error message:

This example shows the variable name entered correctly:

```
prompt> set_app_var sh_enable_page_mode 1
1
```

This example resets the variable to its default value:

```
prompt> set_app_var sh_enable_page_mode -default
```

# **SEE ALSO**

```
get_app_var(2)
report_app_var(2)
write_app_var(2)
```

# set\_check\_library\_options

Sets options for the **check\_library** command for various logic library and physical library checks.

## **SYNTAX**

```
status set check library options
   [-scaling {scaling types}]
   [-mcmm]
   [-upf]
   [-single mode]
   [-optimization {power}]
   [-compare {construct | attribute | value}]
   [-tolerance {type relative tolerance absolute tolerance}]
   [-validate {timing noise [value]}]
   [-analyze {nominal_vs_sigma | table_trend | table_bound | table_slope | table_index | sensitivity |
   [-criteria {criteria_spec}]
   [-group_attribute {groups_or_attributes}]
   [-report_format {format_spec}]
   [-leq]
   [-by_group_order]
   [-char integrity]
   [-significant digits]
   [-compensation]
   [-cell area]
   [-cell footprint]
   [-bus_delimiter]
   [-logic]
   [-routability]
   [-min_pin_layer layer_name]
   [-antenna]
   [-signal_em]
   [-same_name_cell]
   [-tech]
   [-placement]
   [-pattern must join pin]
   [-\texttt{pattern\_must\_join\_pin\_exclusion\_list} \ \textit{lib\_pin\_list}]
   [-physical]
   [-logic_vs_physical]
   [-all]
   [-reset]
   [-report all]
```

# **Data Types**

```
scaling_typeslisttypestringrelative_tolerancefloatabsolute tolerancefloat
```

criteria_spec	list
groups_or_attributes	list
format_spec	list
layer_name	string
lib pin list	list

## **ARGUMENTS**

### -scaling {scaling\_types}

Specifies a list of logic library consistency checks for various types of scaling. You can specify one or more of the following values:

- **timing** specifies logic library consistency checking for composite current source (CCS) timing scaling.
- **noise** specifies logic library consistency checking for CCS noise scaling.
- power specifies logic library consistency checking for CCS or nonlinear delay model (NLDM)
  power scaling and includes driver and receiver models, load indexes, base curve\_x, waveform,
  noise, and power models.

#### -mcmm

Specifies logic library consistency checking for multicorner-multimode, and includes the power\_down\_function attribute and power data.

#### -upf

Specifies logic library consistency checking for multivoltage and IEEE 1801, also known as Unified Power Format (UPF), and includes power special cells, the pg\_pin, voltage\_names, and power\_down\_function attributes, and power data.

#### -single mode

Specifies logic library consistency checking for single mode libraries such as etm. The libraries are generated at the same corner but with different modes and should be specified by set\_lib\_group command. If not specified so, the libraries specified in -logic\_library\_name option or runtime libraries will be used for the check. Those libraries should be consistent in cell/pin/pg\_pin groups/attributes.

#### -optimization {power}

Checks the libraries for various types of optimization. The **power** option checks for power optimization related issues in the libraries, namely, missing high threshold\_voltage\_group cells specified by the **target\_library** variable or **check\_library-logic\_library\_name** option (the latter having higher priority). When you use the **-optimization** option, use the **-criteria** option to specify the low threshold\_voltage\_group names. With optimization power checking, the tool checks for the presence of high-threshold-voltage library cells having the same logic functions as the low-threshold-voltage library cells.

#### -validate {timing noise value}

Specifies logic library consistency checking for library characterization between different models. The

**{timing}** option is for validation between different timing models (NLDM versus CCS). The optional **value** is for validation of the characterization value between models of different dimensions, such as a one-dimensional NLDM and a two-dimensional CCS model. The **{noise}** option is for validation of delay/slew between CCSN and NLDM.

```
-compare {construct | attribute | value}
```

Specifies the type or types of information compared between logic libraries, which can be one or more of the keywords **construct**, **attribute**, or **value**. For **attribute** or **value** comparison, only two libraries are compared; if more than two libraries are specified, only the first two are compared.

- -compare {construct} checks to see if constructs or attributes are missing.
- **-compare {attribute}** checks to see if constructs and attributes are missing and if the attribute values are inconsistent. This option checks all groups, subgroups, and attribute values except characterization values. It is a superset of the **-compare {construct}** option.
- -compare {value} compares values of each group and attribute between the libraries. This option is a superset of the -compare {attribute} option. In comparing characterization values, if the source is not from the .lib library files, the values are not reported, such as vector and capacitance values.

The comparison of the characterization values is controlled by the tolerances specified by the **-tolerance** option, or by the default values if the **-tolerance** option is not used. For minimum and maximum library checking and scaling group library checking, you should use the **-compare** {attribute} option to check all the library contents except for characterization values. When you specify this option, the following default checks are also performed: missing cells, missing and mismatched pins, and timing arcs.

```
-tolerance {type relative tolerance absolute tolerance}
```

Specifies a relative tolerance and an absolute tolerance for characterization value comparison, such as delay values. The format is

```
-tolerance {type rel_tol abs_tol}
```

The valid values for the *type* argument are delay, slew, delay\_ocv, slew\_ocv, delay\_ccsn, slew\_ccsn, delay\_sensitivity, slew\_sensitivity, delay\_interpolation, slew\_interpolation, constraint\_interpolation, voltage, constraint, slew\_index, load\_index, time, power, current, energy, energy\_ccsp, and capacitance. If the type is not specified, the values are for the output load capacitance. When you specify an absolute tolerance, do not include the unit. The units are fixed and can be reported by the **set\_check\_library\_options** command. For example, specify the tolerance values for delay and slew as shown below:

```
-tolerance {delay 0.1 0.2 slew 0.3 0.4}
```

If you do not specify tolerance values for a type, the default values are used. The default values that are set as follows, in compliance with PrimeTime and the Library Quality Assurance System:

```
Relative tolerance for load index : 0.01
Absolute tolerance for load index : 0.001pF
Relative tolerance for time : 0.04
Absolute tolerance for time : 0.015ns
Relative tolerance for power : 0.04
Absolute tolerance for power : 5pW
Relative tolerance for delay : 0.02
Absolute tolerance for delay : 0.002ns
Relative tolerance for slew : 0.03
```

```
: 0.003ns
Absolute tolerance for slew
Relative tolerance for ocv delay
                                  : 0.02
Absolute tolerance for ocv delay
                                  : 0.005ns
                                  : 0.03
Relative tolerance for ocv slew
Absolute tolerance for ocv slew
                                  : 0.0075ns
Relative tolerance for ccsn delay : 0.03
Absolute tolerance for ccsn delay : 0.003ns
                                  : 0.05
Relative tolerance for ccsn slew
Absolute tolerance for ccsn slew : 0.005ns
Relative tolerance for sensitivity delay: 0.1
Absolute tolerance for sensitivity delay: 0.01ns
Relative tolerance for sensitivity slew : 0.15
Absolute tolerance for sensitivity slew : 0.015ns
Relative tolerance for constraint : 0.04
Absolute tolerance for constraint : 0.015ns
Relative tolerance for capacitance : 0.01
Absolute tolerance for capacitance : 0.001pF
Relative tolerance for voltage : 0.05
Absolute tolerance for voltage : 0.02V
Relative tolerance for voltage index : 0.002
Absolute tolerance for voltage index : 0.002V
Relative tolerance for energy : 0.01
Absolute tolerance for energy
                                  : 0.1fJ
Please note that for 10nm (set lc enable 10nm mode true),
the default tolerances are as follows:
Relative tolerance for constraint : 0.01
Absolute tolerance for constraint : 0.001ns
Relative tolerance for voltage
                                  : 0.01
Absolute tolerance for voltage
                                  : 0.01V
-analyze {nominal_vs_sigma | table trend | table bound | table slope | table index |
sensitivity | voltage range | value range | interpolation | lvf | pg current |
ccsp time constant}
```

Specifies what is analyzed. You can specify one of the following values:

• **nominal\_vs\_sigma** analyzes multiple characterization tables. In the case of variation-aware models, analyze nominal, -sigma, and +sigma tables to see the trend and standard deviation for each slew and load index grid of a linear model. The linear model is modeled by the va\_parameters option.

Specify the va\_parameters in the **-group\_attribute** option. If you do not specify the va\_parameters, the variation-aware models for all va\_parameters are analyzed. Wildcards apply to va\_parameters.

- **table\_trend** analyzes a characterization table for trend. It analyzes the trend within the table to check if the values change monotonically in terms of slew or load indexes.
- **table\_bound** analyzes a characterization table for bounds. It analyzes the values of the table to check if the values exceed the upper or lower bound.
- table\_slope analyzes a characterization table for slope. It analyzes the slope formed by two
  adjacent grid points within the table to check if the slope value exceeds the maximum or
  minimum slope criteria. The slope calculation uses normalized values to eliminate the effect of the
  unit and table types.
- **table\_index** analyzes table index accuracy by calculating the ratio of each pair of adjacent indexes (next index to current index) and reports the index tables if at least one ratio meets the condition specified by the **-criteria {table\_type max\_index\_ratio = max\_ratio}** option.

- **sensitivity** analyzes a cell's sensitivity. It reports that the CCSN model response to the clamped waveform has an output delay or output slew that deviates from the CCSN model response to the original or normal non-clamped version of the waveform. Sensitivity analysis is a soft rule, meaning the failure in sensitivity does not affect cell pass rate.
- **voltage\_range** analyzes output waveform's voltage swing to see if it reaches 95% of VDD or within user specified tolerance.
- value\_range analyzes the range of a scalar attribute or table and reports those that are out of
  the specified range. It applies to all attributes that have values of floating point numbers. The
  attribute name is specified as the first parameter of the triplet in -criteria as follows:
  set\_check\_library\_options -analyze {value\_range} -criteria {[group/]attribute min\_value=val1
  max\_value=val2}
- **interpolation** analyzes the delay/slew/constraint table accuracy by fitting the rows and columns of the 2-D NLDM timing model with bicubic and bilinear models, and comparing the values at mid index points.
- **Ivf** analyzes 1) Ratio of sigma to nominal values and 2) Ratio of early (or late) sigma to later (or early) sigma values, and reports missing OCV/LVF models.
- **pg\_current** analyzes ratio of peak current in power/ground pg\_current when output is switching, and reports those smaller than min\_power\_to\_ground\_current\_ratio.
- ccsp\_time\_constant analyzes ratio of time constant value between CCSP vs. CCST/NLDM, and reports those larger than max\_ccsp\_to\_ccst\_time\_const\_ratio/max\_ccsp\_to\_nldm\_time\_const\_ratio.

#### -criteria criteria spec

Specifies analysis criteria for lvf, variation analysis (multiple tables), non-variation analysis (single table), or low threshold\_voltage\_group for power optimization. This option is used with the **-analyze**, or **-optimization** option. It is specified in the following format:

```
{std_error>m.m slope>n.n trend=trend_symbol |
  table_type upper_bound=upper_bound_value |
  lower_bound=lower_bound_val table_type[/table_sub_index] min_slope=min_value max_slope=max_valu
  table type max index ratio=max ratio clamping ratio=ratio val min power to ground current ratio
```

The std\_error and slope are used by the linear regression models. The **trend\_symbol** includes the following nine symbols:

```
/ monotonically increasing
\ monotonically decreasing
\ non-monotonically up

V non-monotonically down
- flat
M Multiple peaks
W Multiple troughs
N >=2 peaks with 2nd not turning low, i.e., increasing, decreasing and increasing
u >=2 peaks with 2nd not turning high, i.e., decreasing, increasing and decreasing
```

To specify the monotonically decreasing trend, use  $\{trend = '\'\}$ ,  $\{trend = \'\}$ , or "trend = \\". Do not use  $\{trend = \'\}$ . To specify the inequality trend, use  $\{trend! = \}$ . For the std\_error and slope expressions, you can also use the less-than sign (<).

The variation-aware analysis reports the results that meet any of the specified criteria.

This option is used with the -analyze option.

You can also set criteria for table bounds and slope analysis in this field.

```
{table type lower bound=lower value upper bound=upper value |
table type[/table sub index] min slope=min value max slope=max value}
The table type, table sub index, and associated group names are:
_____
Type Name Index Type
                           Related Group Names
          slew index
delav
          load index
                    rise_transition
fall_transition
transition slew_index
          load index
constraint constrained_index rise_constraint
          related index
                             fall constraint
                                 rise power
energy slew_index
         load index
                                 fall power
                           output current rise
                           output current fall
_____
capacitance slew_index receiver_capacitance1_rise load_index receiver_capacitance1_fall
                      receiver capacitance2 rise
                      receiver capacitance2 fall
______
dc_current input_voltage
         output voltage
_____
                           output voltage rise
                           output voltage fall
                          propagated noise low
                         propagated_noise high
______
pg current time
                                 pg current
ccsp time constant time
_____
```

{Ivth\_groups=Ivt\_name\_list} Specifies a list of low threshold\_voltage\_group strings for power optimization, such as {Ivth\_groups="Ivt svt"}. Ivth\_groups is equivalent to the **-Ivth\_groups** option of the **set\_multi\_vth\_constraint** command.

{clamping\_ratio=ratio\_value} Specifies a percentage for sensitivity analysis. By default clamping\_ratio=0.95. This is used with -analyze {sensitivity} option.

{max\_sigma\_to\_nominal\_ratio=r1 max\_sigma\_to\_sigma\_ratio=r2} Specifies two ratios: max\_sigma\_to\_nominal\_ratio and max\_sigma\_to\_sigma\_ratio. max\_sigma\_to\_nominal\_ratio is the maximum ratio of sigma value to nominal value, and max\_sigma\_to\_sigma\_ratio is the maximum ratio of early (or late) sigma value to late (early) sigma value. The calculated ratios that exceed the specified ratios will be reported. In the case of max\_sigma\_to\_sigma\_ratio, the condition can be either early/late or late/early exceeds max\_sigma\_to\_sigma\_ratio to be reported. The user specified values should meet max\_sigma\_to\_nominal\_ratio <= 1 and max\_sigma\_to\_sigma\_ratio > 1. Otherwise, the value will be ignored. By default, max\_sigma\_to\_nominal\_ratio=0.25 and max\_sigma\_to\_sigma\_ratio=3.

In the checking for the ratios, when the nominal or sigma slew (or delay) values at a grid point is <= the absolute slew (or delay) tolerance, the check will not be performed at such grid points. However, user can

set to a tighter tolerance using -tolerance option to report such points or report all points violating the max ratios using -report\_all.

This criteria is used with -analyze {lvf} option.

{min\_power\_to\_ground\_current\_ratio=ratio\_value} Specifies a ratio for pg\_current peak current analysis. By default min\_power\_to\_ground\_current\_ratio=10. This is used with -analyze {pg\_current} option.

{max\_ccsp\_to\_ccst\_time\_const\_ratio=ratio\_value} Specifies a ratio for CCSP vs. CCST time constant analysis. By default max\_ccsp\_to\_ccst\_time\_const\_ratio=10. This is used with -analyze {ccsp\_time\_constant} option. If either CCSP-time-constant/CCST-time-constant or reverse is larger than the ratio, it will be reported.

{max\_ccsp\_to\_nldm\_time\_const\_ratio=ratio\_value} Specifies a ratio for CCSP vs. NLDM time constant analysis. By default max\_ccsp\_to\_nldm\_time\_const\_ratio=10. This is used with -analyze {ccsp\_time\_constant} option. If either CCSP-time-constant/NLDM-time-constant or reverse is larger than the ratio, it will be reported.

{linear\_resistance min\_value=min\_val max\_value=max\_val} Specifies the min/max value for linear resistance calculated from dc\_current in switch cell. Recommended min\_value=10 Ohm and max\_value=1000 Ohm. This is used with -analyze {value\_range}.

#### -group\_attribute {groups\_or\_attributes}

Checks or compares specific groups and attributes only. These groups and attributes are either liberty syntax or user defined ones existing in the library. You can specify one or more groups or attributes. An item can be a group, an attribute, a group and an attribute together with a value, or a group and an attribute together without a value. Use a space to separate each item in the list.

Use a forward slash (/) to combine a group name and an attribute name that you are specifying together. For example, the **{pin/direction}** option combines the pin group and the direction attribute under the pin group. In this case, the command checks the direction only in the pin group.

Use curly braces ({}) or double quotation marks ("") to enclose an expression delimited by spaces. If the specified group/attribute is not in the library or not liberty syntax or user defined one, it will be ignored with warning.

You can also specify mega-attributes: timing, noise, power, ccs\_timing, ccs\_noise and ccs\_power that include all the associated groups in that type. ccs\_timing includes: output\_current\_rise output\_current\_fall compact\_ccs\_rise compact\_ccs\_fall va\_compact\_ccs\_rise va\_compact\_ccs\_fall base\_curve curve\_x curve\_y ccs\_noise includes: output\_voltage\_rise output\_voltage\_fall propagated\_noise\_low propagated\_noise\_high ccs\_power includes: dynamic\_current switching\_group intrinsic\_parasitic intrinsic\_resistance intrinsic\_capacitance leakage\_current pg\_current compact\_ccs\_power gate\_leakage timing includes both NLDM timing subgroups and ccs\_timing: \*cell\_rise, \*cell\_fall, \*rise\_transition, \*fall\_transition, \*rise\_constraint, \*fall\_constraint, output\_current\_rise, output\_current\_fall, compact\_ccs\_rise, compact\_ccs\_fall, \*receiver\_capacitance\* base\_curve, curve\_x, and curve\_y. noise includes: ccsn\_first\_stage, ccsn\_last\_stage, dc\_current, output\_voltage\_rise, output\_voltage\_fall, propagated\_noise\_low, and propagated\_noise\_high. power includes: leakage\_power, internal\_power, fall\_power, rise\_power, dynamic\_current, switching\_group, intrinsic\_parasitic, intrinsic\_resistance, intrinsic\_capacitance leakage\_current, pg\_current, compact\_ccs\_power and gate\_leakage

To specify specific group/tables, use -group\_attribute {[group[(modifier)]/][attribute]}. In the above format, group is a group name with optional modifier: group\_name(modifier), modifier is a logical expression in the form of attribute\_name=attribute\_value that serves as a constraint condition to

specify a specific group. e.g. timing(timing\_type=hold\_rising). Please note there is no space in specifying group\_name(attribute\_name=attribute\_value). attribute\_name is a scalar attribute name, e.g. timing\_type, and attribute\_value is a value of the attribute\_name. In the case of string type attribute\_value, regular expressions with wildcards can be used. If there is a space in the string value a double quote is required on the whole string, e.g. timing(when="A B"); otherwise, it is optional. Please note that it does not support complicated logical operations such as OR (||), AND (&&). Here is an example of specifying the timing arc with timing\_type=min\_pulse\_width: -group\_attribute {timing(timing\_type=min\_pulse\_width)}

The following example checks only the pin group whose name is A:

```
-group_attribute {"pin = A"}
```

The following wildcard characters are available for pattern matching:

- An asterisk (\*) matches any string, including a null string.
- A question mark (?) matches any single character.

#### For example:

- -group\_attribute {pin} checks the pin group only.
- -group\_attribute {direction} checks the direction attribute only.
- -group\_attribute {pin/direction} checks the pin's direction only.
- -group\_attribute {pin/direction=input} checks the pin direction only when it is input.
- -group\_attribute {cell\_rise cell\_fall output\_current\_\*} checks and validates the NLDM and CCS timing models only.
- -group\_attribute {va\_\* compact\_ccs\_\*} checks and validates the variation-aware timing models only.

If you do not specify the **-group\_attribute** option, the **check\_library** command checks all groups and attributes that apply to the specified mode.

```
-report format {format spec}
```

Specifies the format for the generated report. The syntax of the specification is as follows:

```
[csv[=csv dir]] [sql=sql filename] [nosplit] [html] [display] [sort by cell | sort by group type
```

You must specify at least one of the following values in the specification:

#### • **csv**[=*csv dir*]

Selects comma-separated values (CSV) as the report format, which is compatible with spreadsheet programs. By default, the CSV files are stored in the current working directory. Specify the directory to store the CSV files by using the *csv\_dir* argument.

The file names are constructed by concatenating library names with "\_vs\_" appended by check type and .csv, e.g. ff\_1.2v\_-30c\_vs\_ss\_1.3v\_80c\_timing\_mismatched.csv. When the names are longer than the

system limit (255 chars), only the first library name with library count is used.

If you perform multiple runs with the same settings, the directory for the previous run is saved to a directory named csv\_dir\_bak.

If you do not specify this value, the **check\_library** command generates a plain ASCII report.

#### • **sql**=*sql\_filename*

Specifies sqlite database filename, e.g. test.db3 to store the check\_library results in.

#### • nosplit

Prevents line-splitting, and facilitates writing scripts to extract information from the report output. Most of the information is listed in fixed-width columns. If the information in a given field exceeds the column width, the next field begins on a new line, starting in the correct column.

#### html

Selects HTML as the report format. Optionally specify the directory in which to store the HTML files by using the *html\_dir* argument. By default, it is the current directory.

### display

Launches a browser to view the check results in HTML. This should be used only with the **html** report format.

#### sort\_by\_cell | sort\_by\_group\_type

Specifies the sorting method. Use **sort\_by\_cell** to sort the validation and analysis tables by cell names. Use **sort\_by\_group\_type** to sort the validation and analysis tables by group types, such as delay, slew, constraints, and receiver capacitance.

By default, the validation and analysis tables are sorted by the group type.

If you do not specify this option, the **check\_library** command generates an ASCII report that is sorted by the group type.

#### -leq

Checks the logical equivalence for *when* conditions. For example, if you set the **-leq** option, the following expressions are reported as identical:

```
when : A+B when : B+A
```

By default, logical equivalence is disabled and string comparisons are used.

#### -by\_group\_order

Compares or checks libraries by the order of library groups for non-unique groups and groups without name, such as leakage\_power. This is for concurrent checking of multiple libraries.

#### -logic

Checks the following options for the logic library:

```
-scaling
-mcmm
-upf
-optimization {power}
```

#### -logic\_vs\_physical

Checks the following options for the logic vs. physical libraries:

```
-cell_area
-cell_footprint
-bus_delimiter
```

#### -all

Checks the following options for the library:

```
-logic
-logic_vs_physical
-physical
```

#### -char\_integrity

Checks the following options for accuracy:

```
-validate { timing noise }
-analyze { sensitivity voltage_range }
When lc_enable_10nm_mode is set to true, -analyze { interpolation }
and -analyze { table_trend } -criteria {trend!=/ trend!=\} for constraint table monotonicity
are also included.
```

#### -report all

Check/reports all grid points. In the case of 7x7 tables, it will report 49 grid points even when the value difference is 0. This is equivalent to 0 tolerances.

#### -significant\_digits digits

Specifies the number of significant digits displayed for floating-point numbers. Allowed values are from 0 through 13. The default value is 6.

#### -compensation

Waives bad CCSN issues in -validate {noise} mode that can be tolerated in PT with slight loss of accuracy.

#### -cell area

Compares the cell area defined by the area attribute in the logic library with the area determined by the cell PR boundary in the physical library. In a FRAM view, the rectangular area covered by the place-and-route boundary for a standard cell, or the area enclosed by the cell boundary of a macro in a polygon, is compared with the cell area in the .db file. This comparison determines an area ratio for each cell. If the ratio is found to be the same for all the cells in the logic library, the cell areas are considered consistent. However, if the ratio for a cell deviates from the normal or average ratio for this library by a margin of 5 percent or more, the cell areas are considered inconsistent. There is no area check for the pad cells because they are special cells located at the chip boundary, and are not used as internal gates. They are considered to have zero area, and are therefore not checked for area.

#### -cell\_footprint

Checks that the cell PR boundaries in the physical library is consistent among a set of cells when the **cell\_footprint** attribute is specified in the logic library. This consistency check is done only when cell\_footprint attribute is specified in the cell group. This option reports cell\_footprint's and the cell names and their PR boundaries.

#### -bus delimiter

Reports bus delimiters or bus naming styles in the logic and physical libraries. If the library does not define a bus delimiter, it reports it as Undefined.

#### -routability

Checks pin routability

```
-min pin layer layer name
```

Specifies the minimum layer name. Pins on layers lower than this layer are checked for existence. This option goes with **-routability**.

#### -antenna

Checks missing antenna property

```
-signal em
```

Checks missing signal EM rules

```
-same name cell
```

Checks same name cells in the physical libraries

#### -tech

Checks technology data in the library

#### -placement

**Checks** cell placement constraint, layers, sites

```
-pattern_must_join_pin
```

Checks pattern must-join related items

```
-pattern_must_join_pin_exclusion_list lib_pin_list
```

Specifies a collection of lib\_pins that don't need the pattern must-join check. This option goes with **- pattern\_must\_join\_pin** 

#### -physical

Checks the following options for the physical library:

```
-routability
-antenna
-signal_em
-same_name_cell
-tech
-placement
-pattern_must_join_pin
-pattern_must_join_pin_exclusion_list
-min_pin_layer
```

#### -reset

Resets the options of the command to their default, missing cells, missing or mismatched pins are checked between logic libraries. All other options are ignored if used with the **-reset** option.

### DESCRIPTION

The **set\_check\_library\_options** command sets specific options for the **check\_library** command for logic library checking.

Run the **set\_check\_library\_options** command before you run the **check\_library** command. If you do not specify any option with the **set\_check\_library\_options** command, by default the command checks missing cells, missing and mismatched pins, including pg\_pins versus power and ground pins.

A status indicating success or failure is returned.

### **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

### **EXAMPLES**

In the following example, the **-upf** options are set, the lib1.db logic library is checked for upf:

```
prompt> set check library options -upf
prompt> check_library -logic_library_name lib1.db
#BEGIN XCHECK LIBRARY
Logic Library #1:
                           lib1
   Library name
   File name
                           /home/goose/tmp/lib1.db
   Library type
                           pg_pin based db
                           1.000000
   Library Version
                           J-2014.09
   Tool Created
   Data Created
                           Thu Mar 9 14:21:29 2006
   Time unit
                            1ns
                           1000ff
   Capacitance unit
                            1mW
   Leakage power unit
   Current unit
                            1mA
check library options
                            -upf
Version
                            J-2014.09-ALPHA5
Check date and time
                            Thu Jul 10 03:01:46 2014
#BEGIN LIBSCREEN UPF
Library#1 (lib1):
Warning: Cell 'isolation_cell' is missing 'backup_power' pg_pin, so it will become a black-box cell
Warning: Cell 'ls_1', pin 'A', The pin 'A' is missing the attribute 'input_voltage_range'. (LBDB-
Warning: Cell 'ls_1', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
                                                                                         (LBDB
Warning: Cell 'ls_2', pin 'A', The pin 'A' is missing the attribute 'input_voltage_range'.
Warning: Cell 'ls_2', pin 'Y', The pin 'Y' is missing the attribute 'output_voltage_range'.
Warning: Cell 'LVLLHX2M', pin 'A', The pin 'A' is missing the attribute 'input voltage range'.
```

```
Warning: Cell 'LVLLHX2M', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
Warning: Cell 'LVLLHX8M', pin 'A', The pin 'A' is missing the attribute 'input voltage range'.
Warning: Cell 'LVLLHX8M', pin 'Y', The pin 'Y' is missing the attribute 'output_voltage_range'.
Warning: Cell 'LVLLHEHX2M', pin 'A', The pin 'A' is missing the attribute 'input_voltage_range'.
Warning: Cell 'LVLLHEHX2M', pin 'Y', The pin 'Y' is missing the attribute 'output_voltage_range'.
Warning: Cell 'LVLLHEHX8M', pin 'A', The pin 'A' is missing the attribute 'input_voltage_range'.
Warning: Cell 'LVLLHEHX8M', pin 'Y', The pin 'Y' is missing the attribute 'output voltage range'.
Power management cell checking passed.
#END LIBSCREEN UPF
Information: List of cell classification (LIBCHK-312)
Librarv name
                          lib1(lib#1)
Total number
Inverter
Buffer
Level shifter
Differential level shifter 0
Isolation cell
Clock Isolation cell
Retention cell
Switch cell
Always on cell
______
#BEGIN XCHECK LOGICCELLS
#END XCHECK LOGICCELLS
#BEGIN XCHECK LOGICPINS
#END XCHECK LOGICPINS
#BEGIN XCHECK LOGICPGPINS
Number of cells missing pg pins in library 1: 0 (out of 7)
#END XCHECK LOGICPGPINS
#BEGIN XCHECK ARCS
#END XCHECK ARCS
Logic vs. logic library check summary:
Logic library consistency check PASSED for UPF.
#END XCHECK LIBRARY
```

In the following example, the **-logic\_vs\_physical** option is set, the logic library test.db vs. physical library test.ndm are checked for consistency:

```
prompt> set_check_library_options -logic_vs_physical
prompt> check_library -logic_library_name "test.db" -physical_library_name test.ndm
#BEGIN_XCHECK_LIBRARY
```

```
check_library options -logic_vs_physical
              O-2018.06-DEV
Version
Check date and time Mon Feb 5 17:56:11 2018
#BEGIN XCHECK CELLS
Number of cells missing in logic library: 0 out of 747
Number of cells missing in physical library: 0 out of 747
#END XCHECK CELLS
#BEGIN XCHECK PINS
Warning: List of pins missing in logic library (LIBCHK-212)
Physical library
                   Cell name
                                Pin name
                                               direction
______
tcbn90ghvt
                   AN2HVTD0
tcbn90ghvt
                   AN2HVTD0
                                 VSS
______
Number of cells missing pins in logic library: 1
Number of cells missing pins in physical library: 0
Error: List of pins mismatched in logic and physical libraries (LIBCHK-213)
______
                          Pin direction/type
            Pin name tcbn90ghvtbc tcbn90ghvt
______
ANTENNAHVT
            I
                   signal
                                 diode
______
Number of cells with mismatched pins: 1
#END XCHECK PINS
#BEGIN XCHECK FOOTPRINT
Warning: List of cells with cell footprint attribute (LIBCHK-215)
______
Logic library name cell_footprint Cell name
                                        PR boundary Compatibility
______
               TIEHHVT TIEHHVT
tcbn90ghvtbc
                                        {0 0} {0.64 2.52}
                         TIELHVT
                                        {0 0} {0.64 2.52}
tcbn90ghvtbc
               TIELHVT
                         AN2HVTD0
                                       {0 0} {1.6 2.52} Incompatible
tcbn90ghvtbc
               an2d1
                                  {0 0} {1.6 2.52}
               an2d1 AN2HVTD1
tcbn90ghvtbc
                                                      Incompatible
                          AN2HVTD2
tcbn90ghvtbc
               an2d1
                                        {0 0} {1.92 2.52} Incompatible
Number of incompatible cell footprints in the libraries: 1 out of 3
#END XCHECK FOOTPRINT
#BEGIN XCHECK CELLAREA
Number of cells with inconsistent areas: 0
Average cell area ratio physical/logic in the libraries: 1
#END XCHECK CELLAREA
```

#BEGIN XCHECK BUS DELIMITER

```
Information: List of bus naming styles (LIBCHK-214)
  ______
                                   Library type
                                                Bus naming style
  Library name
  ______
  tcbn90ghvtbc
                                   Logic library
                                                Undefined
  tcbn90ahvt
                                   Physical library []
  ______
  Inconsistent bus delimiters found in the libraries.
  #END XCHECK BUS DELIMITER
  Information: Logic library is INCONSISTENT with physical library (LIBCHK-220)
  #END XCHECK LIBRARY
In the following example, the -physical option is set, the physical library test.ndm are checked
  prompt> set check library options -physical
  prompt> check_library -physical_library_name { test.ndm }
  #BEGIN CHECK PHYSICAL LIBRARY
  #BEGIN CHECK ROUTABILITY
  Target Library: test
  ______
  Report of missing pin access:
  Total number of cells without optimal routability: 0 (out of 3)
  Report of irregular cut shapes or routing blockages:
  Total number of cells with irregular cut layer shapes or routing blockages: 0
  (out of 3)
  Summary of cell objects:
  ______
  Cell Name # Terminals # Real Shapes # Regular # Zero-spacing # Design-rule
  Routing Blockages Routing Blockages Routing Blockages
  ______
  AND2X1 LVT 5 0 22 0 0
  ZZY 3 0 0 0 0
  TXL 2 0 0 0 0
  ______
  Report of terminal overlapped:
  Total number of cells with terminal overlapped: 0 (out of 3)
  Report of blocked terminals:
  Total number of cells with blocked terminals: 0 (out of 3)
  Report of improper routing blockages:
  Total number of cells with improper routing blockages: 0 (out of 3)
  Report of routing ports without geometry:
  Total number of cells with routing ports without geometry: 0 (out of 3)
  Report of ports with inconsistent routing attributes:
  Total number of cells with ports with inconsistent routing attributes: 0 (out
  of 3)
```

```
Report of improper internal port settings:
Total number of cells with improper internal port settings: 0 (out of 3)
Report of via regions on wire tracks:
Warning: List of pins with off-track or missing via regions. (FRAM-018)
______
Target Library : test
Technology Library: test
Routing Direction: M1 H M2 unknown M3 unknown M4 unknown (skip upper metal
Pitch: M1 0.320 M2 0.320 M3 0.320 M4 0.320 (skip upper metal layers)
Offset : M1 0.000 M2 0.000 M3 0.000 M4 0.000 (skip upper metal layers)
 -----
Cell Name Pin Name Pin Layer Off-track
(lower/upper metal layers)
AND2X1 LVT Q M1 Horizontal / No tracks info
ZZY P1 M2 No tracks info & No tracks info
ZZY P2 M2 No tracks info & No tracks info
ZZY P3 M2 No tracks info & No tracks info
TXL T1 M3 No tracks info & amp; No tracks info
TXL T2 M3 No tracks info & No tracks info
______
Warning: The routing direction of layer M2 is not defined for wire tracks
calculation. (FRAM-020)
Warning: The routing direction of layer M3 is not defined for wire tracks
calculation. (FRAM-020)
Warning: The routing direction of layer M4 is not defined for wire tracks
calculation. (FRAM-020)
Total number of cells with off-track or missing via regions: 3 (out of 3)
Detail list of wire track check for via regions:
______
Cell Name Pin Terminal Terminal Contact Code Access Track Access Track BBox /
Points
Name Name Layer (Lower Metal) (Upper Metal)
______
AND2X1 LVT IN1 IN1 M1 VIA12C (15) Horizontal No tracks info (0.7199,
0.9299) (1.0201, 0.9951)
AND2X1 LVT IN1 IN1 M1 VIA12C (15) rotated Horizontal No tracks info (0.7599,
0.8899) (0.9801, 1.0351)
______
Report of pins on color wire tracks:
______
Target Library: test
Technology Library: test
Site : unit
Routing Direction: M1 H M2 unknown M3 unknown (skip upper metal layers)
Pitch : M1 0.320 M2 0.320 M3 0.320 (skip upper metal layers)
Offset : M1 0.000 M2 0.000 M3 0.000 (skip upper metal layers)
Track color : M1 N/A M2 N/A M3 N/A (skip upper metal layers)
______
Cell Object Object Object Track Color Center line aligned Fat
Name Type Name Layer Color Color Matched with Track Shape
_____
AND2X1 LVT Terminal IN1 M1 no mask N/A N/A No Yes
\verb|AND2X1_LVT| Regular blockage RB_3 M1 no_mask N/A N/A No Yes |
-----
Warning: The routing direction of layer M2 is not defined for wire tracks
calculation. (FRAM-020)
```

```
Warning: The routing direction of layer M3 is not defined for wire tracks
calculation. (FRAM-020)
Warning: The track color information of layer M1 is not defined for color wire
tracks calculation. (FRAM-056)
Warning: The track color information of layer M2 is not defined for color wire
tracks calculation. (FRAM-056)
Warning: The track color information of layer M3 is not defined for color wire
tracks calculation. (FRAM-056)
Color track info of all 3 cells with 11 terminals are reported.
#END CHECK ROUTABILITY
Report placement checking for library: test
#BEGIN CHECK PLACEMENT
Target Library: test
Report of improper placement constraints:
Total number of cells without placement layers and constraints: 0 (out of 3)
Report of improper site definition:
Total number of cells with improper site definition: 0 (out of 3)
#END CHECK PLACEMENT
Report drc checking for library: test
Report antenna for library: test
#BEGIN CHECK ANTENNA
Warning: The library is missing antenna rules. (LIBCHK-116)
Total number of cells missing gate area and diode protection antenna
properties: 2 (out of 3)
______
Cell name Cell type Missing property Pin name(s)
______
TXL lib cell gate area T1 (Total 1)
TXL lib_cell diff_area T2 (Total 1)
ZZY lib_cell gate_area P1 P2 (Total 2)
ZZY lib cell diff area P3 (Total 1)
#END CHECK ANTENNA
#BEGIN CHECK SIGNALEM
Warning: The library is missing signal EM data. (LIBCHK-114)
#END CHECK SIGNALEM
#BEGIN CHECK SAMENAMECELL
#END CHECK SAMENAMECELL
#BEGIN CHECK TECH
Warning: Cut layer 'CO' has a non-cross primary default ContactCode 'POLYCON'.
(line 1659) (TECH-083w)
```

```
#END_CHECK_TECH
#END_CHECK_PHYSICAL_LIBRARY
Physical library checks done.
```

In the following example, the **-same\_name\_cell** option is set, the physical libraries phys1.ndm phys2.ndm are checked.

```
prompt> set_check_library_options -same_name_cell
prompt> check_library -physical_library_name { phys1.ndm phys2.ndm }

#BEGIN_CHECK_PHYSICAL_LIBRARY

#BEGIN_CHECK_SAMENAMECELL

Information: List of cells with same names (LIBCHK-112)

Cell name Library list

AND2X1_LVT phys1 phys2

#END_CHECK_SAMENAMECELL

#END_CHECK_PHYSICAL_LIBRARY
```

# **SEE ALSO**

```
check_library(2)
report_check_library_options(2)
```

# set\_command\_option\_value

Set a command option default or current value.

# **SYNTAX**

```
string set_command_option_value
  -default | -current

-command command_name

-option option_name | -position positional_option_position
-value value | -undefined
```

# **ARGUMENTS**

-default

Set the default option value.

-current

Set the current option value.

-command\_name

Set the option value for an option of this command.

-option option\_name

Set the option value for this option of the command.

-position positional\_option\_position

Set the option value for this positional option of the command.

-value value

Set the option value to this value.

#### -undefined

Set the option value to the "undefined value".

### **DESCRIPTION**

Sets the current or default value of a command option.

Either -default must be specified (to specify setting the default value of the option), or -current must be specified (to specify setting the current value of the option). Unlike for get\_command\_option\_values, one of -current or -default must be specified for set\_command\_option\_value.

An option of a command must be specified (for value setting) by passing a command name via -command and either an option name (for an option of the command) via -option, or the position of a positional option via -position. The *option\_name* passed via -option (for a dash option) must not have its leading dash character omitted. An option name passed via -option may be either the name of a dash option or the name of a positional option. A positional option may be specified either via -option or via -position. Positional option positions of a command are numbered 0, 1, 2, ... (N-1), where N is the number of positional options of the command.

To set the (current or default) value of the option, a string value should be passed via -value. Alternatively, you can pass -undefined to reset the option to have the "undefined value". (CAVEAT: For some "set value implementations" for numeric options, -undefined does not really "undefine" the value - instead the value is set to 0.)

Processing of the -value value does not include any CCI option checking of the value (such as checking whether the option value has correct syntax for its type).

The command "throws" a Tcl error for various conditions:

- \* the command does not exist
- \* the command exists but no such option of the command exists
- \* the set operation failed (could be due to a failed conversion for one of the "set value" implementations which does a conversion from string to one of integer, double, etc.)

The -undefined option is a mutually exclusive alternative to the -value option. -undefined has the effect of resetting the option value to the "undefined value".

A possible power user application: power users could put set\_command\_option\_value commands in their home directory Tcl startup files for their favorite dialogs/commands to "seed" initial current values for these dialogs. This may lower the need for automatically saving replay scripts (of set\_command\_option\_value commands for each command/dialog option/field) on exit from the application.

# **EXAMPLES**

The following example sets the current value for the -bar option of the foo command to a value of abc.

```
prompt> set_command_option_value -current -command foo \
    -option "-bar" -value abc
```

The following example sets the current value for the first positional argument of the foo command to a value of xyz.

```
prompt> set_command_option_value -current -command foo \
    -position 1 -value xyz
```

# **SEE ALSO**

```
get_command_option_values(2)
preview(2)
```

# set\_current\_command\_mode

### **SYNTAX**

```
string set_current_command_mode

-mode command_mode | -command command
string command_mode
string command
```

### **ARGUMENTS**

#### -mode command mode

Specifies the name of the new command mode to be made current. **-mode** and **-command** are mutually exclusive; you must specify one, but not both.

#### -command command

Specifies the name of the command whose associated command mode is to be made current. **-mode** and **-command** are mutually exclusive; you must specify one, but not both.

## **DESCRIPTION**

The **set\_current\_command\_mode** sets the current command mode. If there is a current mode in effect, the current mode is first canceled, causing the associated clean up to be executed. The initialization for the new command mode is then executed as it is made current.

If the name of the given command mode is empty, the current command mode is cancelled and no new command mode is made current.

A current command mode stays in effect until it is displaced by a new command mode or until it is cleared by an empty command mode.

If the command completes successfully, the new current command mode name is returned. On failure,

the command returns the previous command mode name which will remain current and prints an error message unless error messages are suppressed.

### **EXAMPLES**

The following example sets the current command mode to a mode called "mode\_1"

```
shell> set_current_command_mode -mode mode_1
```

The following example clears the current command mode without setting a new mode.

```
shell> set_current_command_mode -mode ""
```

The following example sets the current command mode to the mode associated with the command "modal\_command"

```
shell> set_current_command_mode -command modal_command
```

set\_host\_options 232

# set\_host\_options

.prod lc Controls the maximum number of CPU cores that can be used for read\_lib command.

### **SYNTAX**

```
status set_host_options
-max cores number of cores
```

### **Data Types**

number\_of\_cores

integer

# **ARGUMENTS**

```
-max_cores number_of_cores
```

Specifies the maximum number of CPU cores that are allowed for parallel execution.

# **DESCRIPTION**

The **set\_host\_options** command is used to specify the maximum number of CPU cores that the read\_lib command can use for parallel execution. The default is 1, which indicates that parallel execution is not enabled. The maximum number of cores that can be specified is 16.

To disable parallel execution, set the **-max\_cores** option to 1.

### **EXAMPLES**

The following example tells the tool that it can use up to eight cores for parallel execution:

set host options 233

lc\_shell> set\_host\_options -max\_cores 8

# **SEE ALSO**

remove\_host\_options(2)
report\_host\_options(2)

set\_lib\_attribute 234

# set\_lib\_attribute

Sets an existing attribute to a specified value on the specified list of objects.

### **SYNTAX**

```
collection set_lib_attribute
  objects
  attribute_name
  attribute value
```

### **Data Types**

```
objects collection
attribute_name string
attribute_value string
```

### **ARGUMENTS**

#### objects

Specifies the objects on which the attribute is to be set.

#### attribute name

Specifies the name of the attribute to be set.

```
attribute value
```

Specifies the value of the attribute. The data type must be the same as that of the attribute.

### **DESCRIPTION**

This command sets the value of an attribute on an object. For a complete list of attributes, This command returns a collection of objects that have the specified attribute value set. If the attribute is not set on any objects, the command returns an empty string.

set lib\_attribute 235

# **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information if there is no scenario dependency for the attributes. However, for attributes such as **max\_leakage\_power**, which are scenario dependent, this command uses information from the current scenario only.

# **EXAMPLES**

The following example sets attribute this area to 7.291200 on lib/testCell. hierarchy:

prompt> set\_lib\_attribute lib/testCell area 7.291200

### **SEE ALSO**

collections(2)
get\_attribute(2)

set\_lib\_group 236

# set\_lib\_group

Specifies a library (sub)group to qualify by check\_library or merge by merge\_lib. The (sub)group has base libraries and their associated model files or a list of ETM libraries of the same PVT, depending on the options.

# **SYNTAX**

```
status set_lib_group
group_name
[-corner corner_name]
[-base_lib base_library_list]
[-model_lib model_library_list]
[-single_mode_lib single_mode_library_list]
[-reset]
```

### **Data Types**

```
base_library_list list
model_library_list list
single mode library list list
```

# **ARGUMENTS**

#### group\_name

Specifies a group name. This is used especially when multiple groups are defined. All the libraries in the same group name should be of the same cell set.

#### -corner

Specifies a corner name for the single mode etm libs. Those are typically of the same PVT(corner). This is optional.

#### -base lib

Specifies one or multiple base library .db file names. It should be specified if -model lib is specified.

#### -model\_lib

Specifies one or multiple model .db file names in the type of lvf ccs\_power or power\_aware.

set\_lib\_group 237

#### -single\_mode\_lib

Specifies a list of single mode etm db file name and associated mode pairs in {} or double quote. The mode is optional for single\_mode checking, in which case the etms in this option are taken as different modes at the same corner.

#### -reset

Remove/resets this group group\_name. Specify group name. The other options should not be specified and will be ignored if specified so.

### **DESCRIPTION**

The set\_lib\_group command specifies

- 1) base library and model file association as a subgroup and different corner libraries as a group if -base\_lib and -model\_lib are specified.
- 2) a list of ETM library db files of the same PVT and associated modes if -single\_mode\_lib is specified. This (sub)group will be used in successing check\_library or merge\_lib commands. It does not load the libraries at this point.

# **EXAMPLES**

In the following example, a library group consisting of 3 base libraries and 1 model file is specified in the group name of grp1:

```
prompt> set_lib_group grp1 -base_lib "1.db 2.db 3.db" -model_lib "upf.db"
```

In the following example, a library group consisting of 2 etm libraries with different modes is specified in the group name of grp2 at corner c1:

```
prompt> set_lib_group grp2 -corner c1 -single_mode_lib "{etm1.db m1} {etm2.db m2}"
```

### **SEE ALSO**

```
check_library(2)
merge_lib(2)
write lib group(2)
```

# set\_lib\_mismatch\_fix\_options

Specifies options for check\_library command to generate a tcl script to be used for library mismatch fixes.

### **SYNTAX**

```
status set_lib_mismatch_fix_options
[-output lib_mismatch_fix_tcl_filename]
[-resolve_by_db db_attribute_list]
[-resolve_by_frame frame_attribute_list]
[-remove missing {cell pin pg pin}]
```

### **Data Types**

```
lib_mismatch_fix_tcl_filename string
db_attribute_list list
frame attribute list list
```

### **ARGUMENTS**

#### -output

Specifies an output tcl filename. If not specified, lib\_mismatch\_fix.tcl will be used by default.

```
-resolve_by_db
```

Specifies to resolve conflicts to the attributes with db as golden. The attributes are bus\_naming\_style, antenna\_diode\_type, cell\_type, pin\_type, pg\_type and direction.

#### -resolve by frame

Specifies to resolve conflicts to the attributes with frame as golden. The attributes are bus\_naming\_style, pg\_type and pg\_pin/direction for pg\_pin fixes from frame.

```
-remove_missing {cell pin pg_pin}
```

Specifies to remove the cells missing in the other library by remove\_lib\_cell. e.g. -remove\_missing {cell} removes the cells existing in either logic or physical libraries but not both when sourcing the mismatch fix script. -remove\_missing {pin pg\_pin} will remove the cells that are missing pin/pg\_pins as there is no remove\_lib\_pin command available in the tools that will source the script.

All the options are optional.

### **DESCRIPTION**

The **set\_lib\_mismatch\_fix\_options** command specifies options for check\_library command to generate a tcl script to be used for library mismatch fixes. The tools that source the script should be those that accept the commands (e.g. set\_attribute) and app options. This command should be issued before check\_library.

### **EXAMPLES**

In the following example, mismatches in bus\_naming\_style, antenna\_diode\_type(is\_diode) and signal pin direction will be resolved by using defined DB attribute values to update FRAME attributes while the mismatches in PG types and directions will be resolved by using defined FRAME attribute values to update corresponding DB attributes. These actions are recorded in the tcl script lib\_auto\_fix.tcl.

```
prompt> set_lib_mismatch_fix_options -output lib_auto_fix.tcl
    -resolve_by_db {bus_naming_style antenna_diode_type direction}
    -resolve by frame {pg type pg pin/direction}
```

### **SEE ALSO**

check library(2)

set message info 240

# set\_message\_info

Set some information about diagnostic messages.

### **SYNTAX**

```
string set_message_info -id message_id [-limit max_limit|-stop_on|-stop_ff]
string message_id
integer max limit
```

### **ARGUMENTS**

-id message id

Information is to be set for the given *message\_id*. The message must exist. Although different constraints allow different message types, no constraint allows severe or fatal messages.

```
-limit max limit
```

Set the maximum number of occurrences for *message\_id*. This is an integer greater than or equal to zero. If you set it to zero, that means the number of occurrences of the message is unlimited. Messages which occur after a limit is reached are automatically suppressed.

```
-stop_on
```

Force Tcl error if message is emitted.

```
-stop_off
```

Turn off a previous -stop\_on directive

### **DESCRIPTION**

The **set\_message\_info** command sets constraints on diagnostic messages (typically error, warning, and informational messages).

set message info 241

Currently, you can set a upper limit for the number of occurrences of a message. You can set this to zero to indicate that there is no limit. You can retrieve the current limit for a message using the get\_message\_info command. When the limit is exceeded, all future occurrences of the message are automatically suppressed. A count of total occurrences (including those suppressed) can be retrieved using get\_message\_info.

### **EXAMPLES**

The following example uses **set\_message\_info** to set a limit on the number of APP-027 messages to 100. When the 101st APP-027 message is about to be issued, you will be warned that the limit has been exceeded, and that all future occurrences will be suppressed.

```
prompt> set_message_info -id APP-027 -limit 100
prompt> do_command
Warning: can't find node U27.1 (APP-027)
Warning: can't find node U27.2 (APP-027)
Warning: can't find node U27.3 (APP-027)
...
Warning: can't find node U27.100 (APP-027)
Note - message 'APP-027' limit (100) exceeded. Remainder will be suppressed.
```

# **SEE ALSO**

```
get_message_info(2)
print_message_info(2)
suppress_message(2)
```

set process label 242

# set\_process\_label

Sets the process label for one or more libraries.

### **SYNTAX**

```
string set_process_label
    label
    -libraries libraries
```

### **Data Types**

```
label string
libraries list
```

# **ARGUMENTS**

#### label

The process label to be used for specified libraries.

```
-libraries libraries
```

A list of libraries in memory to which to apply new process label.

# **DESCRIPTION**

The **set\_process\_label** command is used to modify **process\_label** attribute under default operating\_conditions group. This command can only take effect after read\_lib/read\_db. Following is the corresponding liberty syntax:

```
library (lib_name) {
operating_conditions ( opc_name ) {
   ...
   process_label : "name";
}
```

set process label 243

}

The updated "process\_label" attribute can be queried by **get\_lib\_attribute** and **report\_lib**. **write\_lib** can be used to save the updated process\_label in disk.

## **Multicorner-Multimode Support**

This command should be used after read\_lib or read\_db

# **EXAMPLES**

This example shows how to change/query the process label for a library.

```
prompt> set_process_label -libraries { wc_v0p99_t0 wc_v0p81_t0 } test_label
prompt> get_lib_attribute [get_lib_objects -class_type operating_conditions -of_objects [get_libs]]
prompt> report_lib -operating_condition wc_v0p99_t0
```

### **SEE ALSO**

```
read_db(2)
read_lib(2)
report_lib(2)
check_library(2)
get_lib_attribute(2)
```

set\_unix\_variable 244

# set\_unix\_variable

This is a synonym for the **setenv** command.

# **SEE ALSO**

gettenv(2) printenv(2) printvar(2) set(2) setenv(2) sh(2) unset(2)

setenv 245

# setenv

Sets the value of a system environment variable.

### **SYNTAX**

```
string setenv variable_name new_value
string variable_name
string new value
```

# **ARGUMENTS**

```
variable name
```

Names of the system environment variable to set.

new\_value

Specifies the new value for the system environment variable.

# **DESCRIPTION**

The **setenv** command sets the specified system environment *variable\_name* to the *new\_value* within the application. If the variable is not defined in the environment, the environment variable is created. The **setenv** command returns the new value of *variable\_name*. To develop scripts that interact with the invoking shell, use **getenv** and **setenv**.

Environment variables are stored in the Tcl array variable **env**. The environment commands **getenv**, **setenv**, and **printenv** are convenience functions to interact with this array.

The **setenv** command sets the value of a variable only within the process of your current application. Child processes initiated from the application using the **exec** command after a usage of **setenv** inherit the new variable value. However, these new values are not exported to the parent process. Further, if you set

setenv 246

an environment variable using the appropriate system command in a shell you invoke using the **exec** command, that value is not reflected in the current application.

# **EXAMPLES**

The following example changes the default printer.

```
shell> getenv PRINTER
laser1
shell> setenv PRINTER "laser3"
laser3
shell> getenv PRINTER
laser3
```

# **SEE ALSO**

```
exec(2)
getenv(2)
unsettenv(2)
printenv(2)
printvar(2)
set(2)
sh(2)
unset(2)
```

sh 247

# sh

Executes a command in a child process.

### **SYNTAX**

```
string sh [args] string args
```

# **ARGUMENTS**

args

Command and arguments that you want to execute in the child process.

### **DESCRIPTION**

This is very similar to the **exec** command. However, file name expansion is performed on the arguments. Remember that quoting and grouping is in terms of Tcl. Arguments which contain spaces will need to be grouped with double quotes or curly braces. Tcl special characters which are being passed to system commands will need to be quoted and/or escaped for Tcl. See the examples below.

# **EXAMPLES**

This example shows how you can remove files with a wildcard.

```
prompt> 1s aaa*
aaa1          aaa2          aaa3
prompt> sh rm aaa*
prompt> 1s aaa*
```

sh 248

```
Error: aaa*: No such file or directory
     Use error_info for more info. (CMD-013)
```

This example shows how to grep some files for a regular expression which contains spaces and Tcl special characters:

```
prompt> exec cat test3.out
blah blah blah c
blah blah c blah
input [1:0] A;
output [2:0] B;
prompt>
prompt> sh egrep -v {[]+c[]+} test3.out
blah blah blah
prompt>
prompt> sh egrep {t[]+\[] test3.out
input [1:0] A;
output [2:0] B;
```

# **SEE ALSO**

exec(2)

sizeof\_collection 249

# sizeof\_collection

Returns the number of objects in a collection.

### **SYNTAX**

int sizeof\_collection
 collection1

### **Data Types**

collection1

collection

# **ARGUMENTS**

collection1

Specifies the collection for which to get the number of objects. If the empty collection (empty string) is used for the *collection1* argument, the command returns 0.

# **DESCRIPTION**

The **sizeof\_collection** command is an efficient mechanism for determining the number of objects in a collection.

### **EXAMPLES**

The following example from PrimeTime shows a simple way to find out how many objects matched a particular pattern and filter in the **get\_cells** command.

```
pt_shell> echo "Number of hierarchical cells: \
```

sizeof collection 250

The following example from PrimeTime shows what happens when the argument for the **sizeof\_collection** command results in an empty collection.

```
pt_shell> set s1 [get_cells *]
{"u1", "u2", "u3"}
pt_shell> set ssize [filter_collection $s1 "area < 0"]
pt_shell> echo "Cells with area < 0: [sizeof_collection $ssize]"
Cells with area < 0: 0
pt_shell> unset s1
```

# **SEE ALSO**

```
collections(2)
filter collection(2)
```

sort collection 251

# sort\_collection

Sorts a collection based on one or more attributes, resulting in a new, sorted collection. The sort is ascending by default.

# **SYNTAX**

```
collection sort_collection
[-descending]
[-dictionary]
collection
criteria
```

### **Data Types**

collection criteria

collection list

# **ARGUMENTS**

#### -descending

Indicates that the collection is to be sorted in reverse order. By default, the sort proceeds in ascending order.

#### -dictionary

Sort strings dictionary order. For example "a30" would come after "a4".

#### collection

Specifies the collection to be sorted.

#### criteria

Specifies a list of one or more application or user-defined attributes to use as sort keys.

sort collection 252

#### **DESCRIPTION**

You can use the **sort\_collection** command to order the objects in a collection based on one or more attributes. For example, to get a collection of leaf cells increasing alphabetically, followed by hierarchical cells increasing alphabetically, sort the collection of cells using the *is\_hierarchical* and *full\_name* attributes as *criteria*.

The *criteria* can specify an attribute on another object. The other object must be available as an attribute on this object. For example, if you had a collection of net shapes, you can sort the objects by net using *owner\_net.name* for instance.

In an ascending sort, Boolean attributes are sorted with those objects first that have the attribute set to *false*, followed by the objects that have the attribute set to *true*. In the case of a sparse attribute, objects that have the attribute come first, followed by the objects that do not have the attribute.

Sorts are ascending by default. The -descending option reverses the order of the objects.

#### **EXAMPLES**

The following example from PrimeTime sorts a collection of cells based on hierarchy, and adds a second key to list them alphabetically. In this example, cells i1, i2 and i10 are hierarchical, and o1 and o2 are leaf cells. Because the *is\_hierarchical* attribute is a Boolean attribute, those objects with the attribute set to *false* are listed first in the sorted collection.

```
pt_shell> set zc [get_cells {o2 i2 o1 i1 i10}]
{"o1", "i2", "o1", "i1", "i10"}
pt_shell> set zsort [sort_collection $zc {is_hierarchical full_name}]
{"o1", "o2", "i1", "i10", "i2"}
pt_shell> set zsort [sort_collection -dictionary $zc {is_hierarchical full_name}]
{"o1", "o2", "i1", "i2", "i10"}
```

### **SEE ALSO**

collections(2)

sort lib objects 253

# sort\_lib\_objects

sort objects in Tcl collections based on one or more attributes.

#### **SYNTAX**

collection sort\_lib\_objects
 [-by attribute\_list]
 collection1

#### **Data Types**

collection1
attribute\_list

collection list

### **ARGUMENTS**

collection1

specifies Tcl collection to be sort.

-by attribute list

Specifies a list of one or more application or user-defined attributes to use as sort keys. Most of time, the option should be specified. the option can be omitted when there is name for the object in the collection and the name is used as key to sort. If the option is not specified and there is no name for the object in the collection, the command does nothing and returns empty collection.

## **DESCRIPTION**

You can use the **sort\_lib\_objects** command to sort objects in collection based on one or more attributes.

sort\_lib\_objects 254

## **EXAMPLES**

The following exmaple sort a collection of pins and use pin name as key.

```
lc_shell>set cell_list [get_lib_cells test/*]
{"test/BUF", "test/CKGT", "test/FSB2"}
lc_shell>set sort_cell [sort_lib_objects $cell_list]
{"test/BUF", "test/CKGT", "test/FSB2"}
lc_shell>sizeof_collection $sort_cell
3
lc_shell>foreach_in_collection element $cell_sort {
   echo "cell: " [get_object_name $element]
}
cell: BUF
cell: CKGT
cell: FSB2
```

## **SEE ALSO**

collections(2)

source 255

#### source

Read a file and evaluate it as a Tcl script.

#### **SYNTAX**

```
string source [-echo] [-verbose] [-continue_on_error] file
string file
```

#### **ARGUMENTS**

#### -echo

Echoes each command as it is executed. Note that this option is a non-standard extension to Tcl.

#### -verbose

Displays the result of each command executed. Note that error messages are displayed regardless. Also note that this option is a non-standard extension to Tcl.

#### -continue\_on\_error

Don't stop script on errors. Similar to setting the shell variable sh\_continue\_on\_error to true, but only applies to this particular script.

#### file

Script file to read.

#### **DESCRIPTION**

The **source** command takes the contents of the specified *file* and passes it to the command interpreter as a text script. The result of the source command is the result of the last command executed from the file. If an error occurs in evaluating the contents of the script, then the **source** command returns that error. If a return command is invoked from within the file, the remainder of the file is skipped and the source command returns normally with the result from the return command.

source 256

By default, source works quietly, like UNIX. It is possible to get various other intermediate information from the source command using the **-echo** and **-verbose** options. The **-echo** option echoes each command as it appears in the script. The **-verbose** option echoes the result of each command after execution.

NOTE: To emulate the behavior of the dc\_shell **include** command, use both of these options.

The file name can be a fully expanded file name and can begin with a tilde. Under normal circumstances, the file is searched for based only on what you typed. However, if the system variable sh\_source\_uses\_search\_path is set to "true", the file is searched for based on the path established with the search\_path variable.

The **source** command supports several file formats. The *file* can be a simple ascii script file, an ascii script file compressed with gzip, or a Tcl bytecode script, created by TclPro Compiler. The **-echo** and **-verbose** options are ignored for gzip formatted files.

#### **EXAMPLES**

This example reads in a script of aliases:

```
prompt> source -echo aliases.tcl
alias q quit
alias hv {help -verbose}
alias include {source -echo -verbose}
prompt>
```

### **SEE ALSO**

```
search_path(3)
sh_source_uses_search_path(3)
sh_continue_on_error(3)
```

suppress\_message 257

## suppress\_message

Disables printing of one or more informational or warning messages.

#### **SYNTAX**

```
string suppress_message [message_list]
list message list
```

#### **ARGUMENTS**

message\_list

A list of messages to suppress.

#### **DESCRIPTION**

The **suppress\_message** command provides a mechanism to disable the printing of messages. You can suppress only informational and warning messages. The result of **suppress\_message** is always the empty string.

A given message can be suppressed more than once. So, a message must be unsuppressed (using **unsuppress\_message**) as many times as it was suppressed in order for it to be enabled. The **print\_suppressed\_messages** command displays the currently suppressed messages.

#### **EXAMPLES**

When the argument to the **unalias** command does not match any existing aliases, the CMD-029 warning message displays. This example shows how to suppress the CMD-029 message:

suppress\_message 258

```
prompt> unalias q*
Warning: no aliases matched 'q*' (CMD-029)
prompt> suppress_message CMD-029
prompt> unalias q*
prompt>
```

## **SEE ALSO**

unsuppress\_message(2)
set\_message\_info(2)

unalias 259

# unalias

Removes one or more aliases.

#### **SYNTAX**

string **unalias** patterns

## **ARGUMENTS**

#### patterns

Specifies the patterns to be matched. This argument can contain more than one pattern. Each pattern can be the name of a specific alias to be removed or a pattern containing the wildcard characters \* and %, which match one or more aliases to be removed.

#### **DESCRIPTION**

The **unalias** command removes aliases created by the **alias** command.

## **EXAMPLES**

The following command removes all aliases.

```
prompt> unalias *
```

The following command removes all aliases beginning with f, and the alias rt100.

```
prompt> unalias f* rt100
```

unalias 260

# **SEE ALSO**

alias(2)

unsetenv 261

## unsetenv

Removes a system environment variable.

#### **SYNTAX**

string **getenv**variable name

#### **Data Types**

variable\_name

string

#### **ARGUMENTS**

variable name

Specifies the name of the environment variable to be unset.

#### **DESCRIPTION**

The **unsetenv** command searches the system environment for the specified *variable\_name* and removes variable from the environment. If the variable is not defined in the environment, the command returns a Tcl error. The command is catchable.

Environment variables are stored in the **env** Tcl array variable. The **unsetenv**, commands is a convenience function to interact with this array. It is equivalent to 'unset ::env(variable\_name)'

The application you are running inherited the initial values for environment variables from its parent process (that is, the shell from which you invoked the application). If you unset the variable using the **unsetenv** command, you remove the variable value in the application and in any new child processes you initiate from the application using the **exec** command. However, the variable is still set in the parent process.

See the **set** and **unset** commands for information about working with non-environment variables.

unsetenv 262

## **EXAMPLES**

In the following example, **unsetenv** remove the DISPLAY varible from the environment:

## **SEE ALSO**

```
catch(2)
exec(2)
printenv(2)
set(2)
unset(2)
setenv(2)
getenv(2)
```

unsuppress\_message 263

## unsuppress\_message

Enables printing of one or more suppressed informational or suppressed warning messages.

#### **SYNTAX**

string unsuppress message [messages]

list messages

#### **ARGUMENTS**

messages

A list of messages to enable.

#### **DESCRIPTION**

The **unsuppress\_message** command provides a mechanism to re-enable the printing of messages which have been suppressed using **suppress\_message**. You can suppress only informational and warning messages, so the **unsuppress\_message** command is only useful for informational and warning messages. The result of **unsuppress\_message** is always the empty string.

You can suppress a given message more than once. So, you must unsuppress a message as many times as it was suppressed in order to enable it. The **print\_suppressed\_messages** command displays currently suppressed messages.

#### **EXAMPLES**

When the argument to the **unalias** command does not match any existing aliases, the CMD-029 warning message displays. This example shows how to re-enable the suppressed CMD-029 message. Assume that

unsuppress message 264

there are no aliases beginning with 'q'.

```
prompt> unalias q*
prompt> unsuppress_message CMD-029
prompt> unalias q*
Warning: no aliases matched 'q*' (CMD-029)
```

## **SEE ALSO**

print\_message\_info(2)
suppress\_message(2)

which 265

# which

Locates a file and displays its pathname.

#### **SYNTAX**

string which filename\_list
list filename list

#### **ARGUMENTS**

filename\_list

List of files to locate.

## **DESCRIPTION**

Displays the location of the specified files. This command uses the search\_path to find the location of the files. This command can be a useful prelude to read\_db or link\_design, because it shows how these commands expand filenames. The **which** command can be used to verify that a file exists in the system.

If an absolute pathname is given, the command searches for the file in the given path and returns the full pathname of the file.

## **EXAMPLES**

The following examples are based on the following search\_path.

prompt> set search\_path "/u/foo /u/foo/test"

which 266

The following command searches for the file name foo1 in the search\_path.

```
prompt> which fool
/u/foo/fool
```

The following command searches for files foo2, foo3.

```
prompt> which {foo2 foo3}
/u/foo/test/foo2 /u/foo/test/foo3
```

The following command returns the full pathname.

```
prompt> which ~/test/designs/sub_design.db
/u/foo/test/designs/sub_design.db
```

## **SEE ALSO**

link\_design(2)
read\_db(2)
search\_path(3)

write\_app\_var 267

# write\_app\_var

Writes a script to set the current variable values.

#### **SYNTAX**

```
string write_app_var
  -output file
  [-all | -only_changed_vars]
  [pattern]
```

#### **Data Types**

```
file string
pattern string
```

## **ARGUMENTS**

```
-output file
```

Specifies the file to which to write the script.

-all

Writes the default values in addition to the current values of the variables.

```
-only_changed_vars
```

Writes only the changed variables. This is the default when no options are specified.

#### pattern

Writes the variables that match the specified pattern. The default is "\*".

#### DESCRIPTION

The write\_app\_var command generates a Tcl script to set all application variables to their current

write\_app\_var 268

values. By default, variables set to their default values are not included in the script. You can force the default values to be included by specifying the **-all** option.

## **EXAMPLES**

The following is an example of the **write\_app\_var** command:

```
prompt> write_app_var -output sh_settings.tcl sh*
```

## **SEE ALSO**

```
get_app_var(2)
report_app_var(2)
set_app_var(2)
```

write\_lib 269

# write\_lib

Writes a compiled library to disk in the Synopsys .db file,

#### **SYNTAX**

```
int write_lib
    library_name
    [-output file name]
```

### **Data Types**

## **ARGUMENTS**

#### library\_name

In the Synopsys .db file format, the *library\_name* argument specifies the name of the technology library to be written.

```
-output file_name
```

Specifies an output file name or path name for the library.

#### -format db

Specifies the external format of the specified library. Only supports the .db file format.

## **DESCRIPTION**

The write\_lib command saves a compiled technology library to the disk.

If you specify the **-output** option, the files are written in the specified format with the appropriate file name extensions. If you use the **-output** option to specify a file name in the Synopsys .db file format, the file is saved with the specified name. If you do not use the **-output** option, the library is saved in the

write\_lib 270

current directory with the name, *library\_name*.db.

**Note:** This command overwrites files without issuing a warning.

## **Multicorner-Multimode Support**

This command has no dependency on scenario-specific information.

## **EXAMPLES**

The following example shows how to read and write a technology library.

```
prompt> read_lib my_lib.lib
```

```
prompt> write_lib my_lib
```

The following example shows how to write a technology library to a specified file.

```
prompt> write_lib my_lib -output ~synopsys/test/test.db
```

## **SEE ALSO**

read\_lib(2)

write\_lib\_group 271

# write\_lib\_group

Writes out a tcl script containing the library groups defined by set\_lib\_group command and link\_library.

#### **SYNTAX**

status write\_lib\_group
 [-output filename]

#### **Data Types**

filename

string

### **ARGUMENTS**

-output filename

Specifies a tcl file name for the output. If not specified, it will output to screen.

### **DESCRIPTION**

The **write\_lib\_group** command writes out a tcl script containing the library groups defined by set\_lib\_group command with base library and model file association. If there are multiple set\_lib\_group command lines, they will be sorted by lib\_group name and each base library and all of its associated model files will have one command line. This command can also be used to dump out intermediate library groups for debug use. The output script will have comments if there are issues found in library group qualification with error code.

#### **EXAMPLES**

write\_lib\_group 272

In the following example, the filename libgrps\_out.tcl is written out after the library group is qualified by check\_library.

```
prompt> write_lib_group -output libgrps_out.tcl
libgrps_out.tcl file has the following contents:
set link_library "liberty_FF_1p19_m40.db liberty_FF_1p23_m40.db "
set_lib_group grp1 -base_lib " liberty_FF_1p19_m40.db liberty_FF_1p23_m40.db " -model_lib upf.db
```

## **SEE ALSO**

```
check_library(2)
set_lib_group(2)
```

write\_scaling\_lib\_group 273

# write\_scaling\_lib\_group

Writes out a tcl script containing the scaling library groups and link\_library after running check\_library.

#### **SYNTAX**

```
status write_scaling_lib_group
[-output filename]
[-auto_adjust]
[-no link library]
```

#### **Data Types**

filename string

## **ARGUMENTS**

#### -output filename

Specifies a file name for the output.

#### -auto adjust

Outputs a subset group that is the best possible with valid formation by removing off-grid corners. In the case of multiple subsets of groups, it outputs one of the best groups with maximum number of libraries and scaling dimensions which is the first in the group name in LIBCHK-304 table.

```
-no_link_library
```

Does not write out link\_library in the output script as a valid variable setting but as comments.

#### DESCRIPTION

The **write\_scaling\_lib\_group** command writes out a tcl script containing the scaling library groups that meet the library formation after qualified by check\_library. This command should be issued after check\_library command. This command can also be used to dump out intermediate scaling library groups

write\_scaling\_lib\_group 274

for debug use when the libraries are not completely qualified. This way users can fix library issues reported by check\_library and re-qualify. The output script will have comments if there are issues found in library data and/or formation with error code.

### **EXAMPLES**

In the following example, the slg\_out.tcl is written out after the library group is qualified by check\_library.

```
prompt> write_scaling_lib_group -output slg_out.tcl
slg_out.tcl file has the following contents:
set link_library "liberty_FF_1p19_m40.db liberty_FF_1p23_m40.db "
create_scaling_lib_group -name grp1 " liberty_FF_1p19_m40.db liberty_FF_1p23_m40.db "
```

## **SEE ALSO**

```
check_library(2)
create_scaling_lib_group(2)
```

write\_scaling\_lib\_group 275