

LEGEND:-	DESCRIPTION	
1	6A SWITCH BOARD	1000mm ABOVE FFL
o 	6A TWO WAY SWITCH BOARD	1000mm ABOVE FFL
1	15A SWITCH BOARD (FOR GEYSER POINT)	
4	,	1000mm ABOVE FFL
	SINGLE POLE SWITCH FOR A/C	150mm ABOVE FFL
	FAN REGULATOR	1000mm ABOVE FFL
	1200mm DIA CEILING FAN	CEILING
\bigcirc	450mm DIA CEILING FAN	CEILING
\bigoplus	CHANDELIER	CEILING
<u> </u>	1x28W FL. LIGHT FIXTURE	CEILING
	1x9W MIRROR LIGHT FIXTURE	1200mm ABOVE FFL
9	1x18W WALL LIGHT FIXTURE	2100mm ABOVE FFL
\oplus	1x18W CEILING LIGHT	CEILING
\boxtimes	2x11W CEILING LIGHT	CEILING
Ą	5A SWITCH WITH SOCKET	150mm ABOVE FFL
<u>A</u>	5A SWITCH WITH SOCKET FOR SHAVING	1200mm ABOVE FFL
\triangle	5A SWITCH WITH SOCKET IN SWITCH BOARD	1200mm ABOVE FFL
<u>~</u>	15A SWITCH WITH SOCKET	150mm ABOVE FFL/ AS PER LIFT VENDOR
<u>~</u>	15A SWITCH WITH SOCKET(FOR COOKING RANGE)	1200mm ABOVE FFL
	15A SWITCH WITH SOCKET(FOR MICRO WAVE OVEN)	1200mm ABOVE FFL
Č	15A SOCKET OUTLET (FOR GEYSER)	2100mm ABOVE FFL
	A/C POINT	2100mm ABOVE FFL
×J-«J-«⊱-«J	5A SWITCH WITH SOCKET (FOR WASHING MACHINE)	915 mm ABOVE FFL
- •(j	5A SWITCH WITH SOCKET (FOR RO)	1200mm ABOVE FFL
≪	5A SWITCH WITH SOCKET (FOR REFRIGERATOR)	1200mm ABOVE FFL
-₫	5A SWITCH WITH SOCKET (FOR CHIMNEY)	1850mm ABOVE FFL
- ⊶	5A SWITCH WITH SOCKET (FOR MIXER)	1200mm ABOVE FFL
Å	TELEPHONE POINT	150mm ABOVE FFL
8	T.V. POINT	200mm ABOVE FFL
	DISTRIBUTION BOARD	1200mm ABOVE FFL
\Box	BUZZAR	2100mm ABOVE FFL
<u> </u>	BELL PUSH	1200mm ABOVE FFL
⊕	EXHAUST FAN	2100mm ABOVE FFL
	6A SOCKET FOR EXHAUST FAN	2100mm ABOVE FFL
LVJB	LOW VOLTAGE JUNCTION BOX	1200mm ABOVE FFL