SPECIALIST APPLICATION OVERVIEW

Scour and water-level monitoring

Measurement and telemetry concepts to support engineering assessment of hydraulic structures.

Monitoring purpose

Monitoring can provide observations of water level, bed movement and other selected parameters near bridges or hydraulic structures. Measurements support an engineering assessment; they do not guarantee structural safety or predict every failure.

A site-specific measurement design

Select suitable measurement technology and sensor locations after a hydraulic and structural assessment. Scour/bed-level measurement and water-level measurement are different tasks; a general water-level radar should not be assumed to measure submerged bed scour.

Integration scope

A proposal may include suitable sensors, a control/data-logging panel, power arrangements, telemetry, visualisation and agreed alerts. Data availability depends on sensor suitability, calibration, power, communications and maintenance.

Alert limits and the actions taken in response must be defined by competent engineers and the structure operator. Monitoring supplements inspection and maintenance procedures.

PREPARE AN ENQUIRY

Measure the right parameters.

Discuss monitoring objectives, site constraints and the response process before equipment selection.

Information to share

Structure and river drawings; monitoring objectives; hydraulic/bed conditions; expected ranges and accuracy; mounting access; power/connectivity; logging intervals; alert recipients and responsibility; maintenance and data-retention requirements.

Information to confirm in the proposal

Sensor principle/model and environmental limits; installation design; calibration and validation; communications and logging; alert configuration; commissioning/acceptance criteria; inspection and maintenance scope.

Confirm before ordering

This brochure is introductory information for business enquiries. Confirm the manufacturer, model, configuration, performance, suitability, availability and applicable certificates with our team. Pricing, taxes, delivery, warranty, installation, cancellation and refund terms are set out in the accepted quotation/contract, subject to applicable law. No universal product warranty or performance guarantee is made here. Names of third-party products identify their owners and do not by themselves establish endorsement or authorised dealership.

Discuss your requirements

Email: info@orbitengineerings.com
Telephone: +91 70241 28029
Website: orbitengineerings.com/contact

Operator: Vijay Kumar Tiwari, trading as Orbit Engineering Solutions (proprietorship).
Business address: GF, E-45, Pride City, Katara Hills, Bhopal, Madhya Pradesh 462043, India.

Grievance Officer: Vijay Kumar Tiwari (Proprietor), +91 70241 28029, info@orbitengineerings.com.
Privacy notice: orbitengineerings.com/privacy-policy