[PI5008K] Pixel Plus GUI Design Guideline





Contents

BOOT LIVE VIEW MAIN MENU CALIBRATION MANUAL CALIBRATION VEHICLE SETTING FUNCTION SETTING TRIGGER SETTING **VIDEO SETTING UPDATE SYSTEM INFO DIALOG BOX** PROGRESS BAR POP-UP LAYER ORGANIZATION



Background (0, 0, 1280, 720)





••• Live View


Outline_mode_xxx.bmp (0, 0, 528, 720)

Outline_view_xxx.bmp (255, 528, 752, 720)





Main Menu





Background.bmp (0, 0, 1280, 720)

Pgl_Sel.bmp (48, 122, 230, 64)

Db_Sel.bmp (48, 193, 230, 64)

Back Sel.bmp (48, 278, 230, 60)







Trigger Menu.bmp (35, 35, 256, 581)

Background.bmp (0, 0, 1280, 720)

ReverseSignal_Sel.bmp (48, 122, 230, 64)

ReverseViewMode_Sel.bmp (48, 193, 230, 64)

TurnSignal_Sel.bmp (48, 264, 230, 64)

TurnViewMode_Sel.bmp (48, 335, 230, 64)

EmergencySignal_Sel.bmp (48, 406, 230, 64)

nergencyViewMode Sel.bmp (48, 477, 230, 64)

Back_Sel.bmp (48, 553, 230, 60)



TriggerSignal xx.bmp

- TriggerSignal_Off.bmp
- TriggerSignal_Off_Sel.bmp
- TriggerSignal On.bmp
- TriggerSignal_On.bmp

TriggerView xx.bmp

- TriggerView t3db.bmp
- TriggerView_t3db_Sel.bmp
- TriggerView t3df.bmp
- TriggerView_t3df_Sel.bmp
- TriggerView t3dlf.bmp
- TriggerView t3dlf Sel.bmp
- TriggerView t3dl.bmp
- TriggerView_t3dl_Sel.bmp
- TriggerView t3drf.bmp
- TriggerView t3drf Sel.bmp
- TriggerView t3dr.bmp
- TriggerView t3dr Sel.bmp
- TriggerView tb.bmp
- TriggerView_tb_Sel.bmp
- TriggerView tf.bmp
- TriggerView tf Sel.bmp





Background.bmp (0, 0, 1280, 720)

ScreenX_Sel.bmp (48, 122, 230, 64)

ScreenY_Sel.bmp (48, 193, 230, 64)

Brightness_Sel.bmp (48, 264, 230, 64)

Contrast_Sel.bmp (48, 335, 230, 64)

Saturation_Sel.bmp (48, 406, 230, 64)

Back_Sel.bmp (48, 482, 230, 60)



Step_n.bmp

- Step_0.bmp
- Step_1.bmp
- Step_2.bmp
- Step_3.bmp
- Step_4.bmp
- Step_5.bmp
- Step_6.bmp
- Step_7.bmp
- Step_8.bmp
- Step_9.bmp
- Step_10.bmp
- Step Sel 0.bmp
- Step_Sel_1.bmp
- Step_Sel_2.bmp
- Step_Sel_3.bmp
- Step_Sel_4.bmp
- Step_Sel_5.bmp
- Step_Sel_6.bmp
- Step_Sel_7.bmp
- Step_Sel_8.bmp
- Step Sel 9.bmp
- Step_Sel_10.bmp





Background (0, 0, 1280, 720)

Front_Sel.bmp (48, 122, 230, 64)

Right_Sel.bmp (48, 193, 230, 64)

Left_Sel.bmp (48, 264, 230, 64)

Rear_Sel.bmp (48, 335, 230, 64)

Quad_Sel.bmp (48, 406, 230, 64)

Capture_Sel.bmp (48, 477, 230, 64)

Back_Sel.bmp (48, 550, 230, 60)








Background (0, 0, 1280, 720)

CalibAuto_Sel.bmp (48, 122, 230, 64)

CalibManual_Sel.bmp (48, 193, 230, 64)

CalibBack_Sel.bmp (48, 269, 230, 60)





Manual Calibration

Background (0, 0, 1280, 720)

Mirror.bmp (1112, 34, 139, 44) Normal.bmp (1112, 34, 139, 44)

ManFront_Sel.bmp (48, 122, 230, 64)

ManRight_Sel.bmp (48, 193, 230, 64)

ManLeft_Sel.bmp (48, 264, 230, 64)

ManRear_Sel.bmp (48, 335, 230, 64)


ManViewGen_Sel.bmp (48, 406, 230, 64)

ManBack_Sel.bmp (48, 481, 230, 60)





Move Point (Manual Calibration)







Background.bmp (0, 0, 1280, 720)

FactoryReset_Sel.bmp (48, 122, 230, 64)
FwUpdate_Sel.bmp (48, 193, 230, 64)

Back_Sel.bmp (48, 269, 230, 60)





••• System Info

Background.bmp (0, 0, 1280, 720)



Back Sel.bmp (48, 411, 230, 60)





Dialog_xxxxxx.bmp (492, 288, 296, 143)



Btn_Ok_Sel.bmp (501, 382, 135, 40)

Btn_Cancel_Sel.bmp (644, 382, 135, 40)


Dialog_xxxxxx.bmp

- Dialog_CalibFailRetry.bmp
- Dialog_RunMenu.bmp
- Dialog CalibManual.bmp
- Dialog SaveView.bmp
- Dialog_Update.bmp





PopUp_xxxxxx.bmp (492, 307, 296, 105)



PopUp xxxxxx.bmp


- PopUp_Calibration.bmp
- PopUp_Done.bmp
- PopUp_DoNotTurnOff.bmp
- PopUp_NoCameraInput.bmp
- PopUp_NoSaved.bmp
- PopUp_NoSDCard.bmp
- PopUp_Saved.bmp
- PopUp_Shutdown.bmp
- PopUp_ViewGen.bmp
- PopUp_TBD.bmp



•••• Progress Bar

Progress n.bmp

- Progress_0.bmp
- Progress_10.bmp
- Progress_20.bmp
- Progress 30.bmp
- Progress_40.bmp
- Progress_50.bmp
- Progress 60.bmp
- Progress_70.bmp
- Progress_80.bmp
- Progress 90.bmp
- Progress 100.bmp
- Progress1_10.bmp
- Progress1_20.bmp
- Progress1_30.bmp
- Progress1_40.bmp
- Progress1 50.bmp
- Progress1_60.bmp
- Progress1_70.bmp
- Progress1_80.bmp
- Progress1 90.bmp
- Progress1 100.bmp



Progress_n.bmp (452, 156, 376, 47)



Layer Organization (1/3)

Scene	API	OSD list	sub menu list	Format	Layer	Area	Layer order		
Booting	PPAPI_DISPLAY_BOOTING_CI	BootingCI		RLE	Layer 1	Area 0	vedio_43210		
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0	*Culo_43210		
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area0	video_32140		
	PPAPI_DISPLAY_VIEW_Car_On	2D Car & Shadow & Door		RLE	Layer 2	Area 0			
		3D Car & Shadow & Wheel		RLE	Layer 2	Area 1			
tion of any	TBD.	Rec Icon		RLE					
Live view	PPAPP_View_SetSectionPgI	2D TopView PGL	fw dynamic / bw dynamic	RLE	Layer 3	Area 0			
		RearCam PGL	bw dynamic	RLE	Layer 3	Area 1			
	PPAPI DISPLAY VIEW Outline On	Outline & 2d/3d Mode & 3d point		RLE	Layer 4	Area 0			
	FFAFI_DISFLAT_VIEW_OUTINE_ON	Outline with warning & view		RLE	Layer 4	Area 1			
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	vedio_43210		
Main Manu	PPAPI_DISPLAY_MenuItem	Select List Item	vehicle / trigger / video / camera / calibration / update / system info	RLE	Layer 1	Area 0			
Main Menu	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0			
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0			
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	vedio_43210		
	PPAPI_DISPLAY_MenuItem	Select List Item	PGL / Dynamic Blending	RLE	Layer 1	Area 0			
Vahicla Satting	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu1 : pgl	Off / Rear / Always	RLE	Layer 1	Area 1			
Vehicle Setting	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu2 : dynamic blending	Off / On	RLE	Layer 1	Area 2			
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0			
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0			
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0			
	PPAPI_DISPLAY_MenuItem	Select List Item	reverse signal / reverse view / turn signal / turn view / emergency signal / emergency view / back	RLE	Layer 1	Area 0			
Trigger Setting	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu1 : reverse signal	on / off	RLE	Layer 1	Area 1			
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu2 : reverse view	top+3D rear / top+rear	RLE	Layer 1	Area 2			
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu3 : turn signal	on / off	RLE	Layer 1	Area 3	vedio_43210		
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu4 : turn view	top+3D left front / top+3D right front / top+3D left / top+3D right	RLE	Layer 2	Area 0			
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu5 : emergency signal	on / off	RLE	Layer 2	Area 1			
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu6 : emergency view	top+3D front / top+front / top+3D left front / top+3D right front	RLE	Layer 2	Area 2			
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0			
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0			



Layer Organization (2/3)

Scene	API	OSD list	sub menu list	Format	Layer	Area	Layer order
Video Setting	PPAPI DISPLAY POPUP On	Popup		RLE		Area 0	,
	PPAPI_DISPLAY_MenuItem	Select List Item	screen x / screen y / brightness / contrast / saturation / back	RLE	Layer 1	Area 0	
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu1 : screen x	0/1/2/3/4/5/6/7/8/9/10	RLE	Layer 1	Area 1	vedio_43210
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu2 : screen y	0/1/2/3/4/5/6/7/8/9/10	RLE	Layer 1	Area 2	
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu3 : brightness	0/1/2/3/4/5/6/7/8/9/10	RLE	Layer 1	Area 3	
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu4 : contrast	0/1/2/3/4/5/6/7/8/9/10	RLE	Layer 2	Area 0	
	PPAPI_DISPLAY_SubMenuList	[select / no select] Sub menu5 : saturation	0/1/2/3/4/5/6/7/8/9/10	RLE	Layer 2	Area 1	
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0	
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0	
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	
	PPAPI_DISPLAY_PROGRESSBAR_On	Progress Bar		RLE	Layer 0	Area 1	
Camera Setting	PPAPI_DISPLAY_MenuItem	Select List Item	front / right / left / rear / quad / capture / back	RLE	Layer 1	Area 0	vedio_43210
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0	
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0	
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	vedio_43210
	PPAPI_DISPLAY_PROGRESSBAR_On	Progress Bar		RLE	Layer 0	Area 1	
Calibration	PPAPI_DISPLAY_DIALOG_On	Dialog button	ok / cancel	RLE	Layer 0	Area 2	
&	PPAPI_DISPLAY_MenuItem	Select List Item	auto calibration / manual calibraton / back	RLE	Layer 1	Area 0	
Auto Calibration	PPAPI_DISPLAY_DIALOG_On	Dialog Box		RLE	Layer 1	Area 1	
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0	
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0	
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	
	PPAPI_DISPLAY_PROGRESSBAR_On	Progress Bar		RLE	Layer 0	Area 1	
	PPAPI_DISPLAY_DIALOG_On	Dialog button	ok / cancel	RLE	Layer 0	Area 2	
	PPAPI_DISPLAY_MenuItem	Select List Item	front / rear / left / right / view generation / back	RLE	Layer 1	Area 0	
	PPAPI_DISPLAY_DIALOG_On	Dialog Box		RLE	Layer 1	Area 1	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 1		RLE	Layer 2	Area 0	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 2		RLE		Area 1	vedio_43210
Manual Calibration	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 3		RLE	Layer 2	Area 2	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 4		RLE	Layer 2		
	PPAPI_DISPLAY_MenuList	Menu List		RLE		Area 0	
	PPAPI_DISPLAY_SubMenuList	[no select] Sub Menu List	mirror/normal	RLE	Layer 3	Area 1	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 5		RLE	Layer 4	Area 0	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 6		RLE	Layer 4	Area 1	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 7		RLE	Layer 4	Area 2	
	PPAPI_DISPLAY_CALIB_Point	[select / no select] Position 8		RLE	Layer 4	Area 3	



Layer Organization (3/3)

Scene	API	OSD list	sub menu list	Format	Layer	Area	Layer order
View Generation	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	video_12340
	PPAPI_DISPLAY_PROGRESSBAR_On	Progress Bar		RLE	Layer 0	Area 1	
	PPAPI_DISPLAY_DIALOG_On	Dialog button	ok / cancel	RLE	Layer 0	Area 2	
	PPAPI_DISPLAY_VIEW_ViewMode	ViewMode	front / rear / 3d front / 3d rear / 3d left / 3d left front / 3d right / 3d right front	RLE	Layer 0	Area 3	
	PPAPI_DISPLAY_DIALOG_On	Dialog Box		RLE	Layer 1	Area 1	
	PPAPI_DISPLAY_VIEW_2DCarImage	2D Car		RLE/16bit	Layer 3	Area 0	
	PPAPI_DISPLAY_VIEW_3DCarImage	3D Car	3d front / 3d rear / 3d left / 3d left front / 3d right / 3d right front	RLE/16bit	Layer 3	Area 1	
	PPAPI_DISPLAY_Background_On	Outline with warning		RLE	Layer 4	Area 0	
	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	
	PPAPI_DISPLAY_PROGRESSBAR_On	Progress Bar		RLE	Layer 0	Area 1	
	PPAPI_DISPLAY_DIALOG_On	Dialog button	ok / cancel	RLE	Layer 0	Area 2	
Update Setting	PPAPI_DISPLAY_MenuItem	Select List Item	factory reset / fw update / back	RLE	Layer 1	Area 0	
	PPAPI_DISPLAY_DIALOG_On	Dialog Box		RLE	Layer 1	Area 1	
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Arear 0	
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0	
System Info	PPAPI_DISPLAY_POPUP_On	Popup		RLE	Layer 0	Area 0	vedio_43210
	PPAPI_DISPLAY_MenuItem	Select List Item	back	RLE	Layer 1	Area 0	
	PPAPI_DISPLAY_SubMenuList	[no select] Sub menu1 : FW version		RLE	Layer 1	Area 1	
	PPAPI_DISPLAY_SubMenuList	[no select] Sub menu2 : Lib version		RLE	Layer 1	Area 2	
	PPAPI_DISPLAY_SubMenuList	[no select] Sub menu3 : ISP version		RLE	Layer 1	Area 3	
	PPAPI_DISPLAY_SubMenuList	[no select] Sub menu4 : Sensor ID		RLE	Layer 2	Area 0	
	PPAPI_DISPLAY_MenuList	Menu List		RLE	Layer 3	Area 0	
	PPAPI_DISPLAY_Background_On	Background		RLE	Layer 4	Area 0	

