
#### SDO SOP:

- 1. 下載 SDO
- 2. SDO download link:

https://www.supermicro.com/zh\_tw/support/resources/downloadcenter/smsdownload



3. 下載檔案後,將 X86 內檔案 COPY 至 USB DISK 根目錄下



4. 插上有含 SDO 的 USB 後,系統開機,看到如下畫面按 F11



## 5. 選擇 UEFI Built-in EFI Shell

```
Please select boot device:

Generic Flash Disk 8.07
IBA GE Slot 0500 v1404
UEFI: Generic Flash Disk 8.07, Partition 1
UEFI: Built—in EFI Shell
Enter Setup

† and ↓ to move selection
ENTER to select boot device
ESC to boot using defaults
```

## 6. ESC → fs0: (進入 USB DISK)

```
UEFI Interactive Shell v2.2

EDK II

UEFI v2.70 (American Megatrends, 0x0005000E)

Mapping table

FSO: Alias(s):HD010b:;BLK1:

PciRoot(0x0)/Pci(0x14,0x0)/USB(0xB,0x0)/HD(1,MBR,0x3BC6CD65,0x800,0xEFF7E0)

BLK0: Alias(s):

PciRoot(0x0)/Pci(0x14,0x0)/USB(0xB,0x0)

Press ESC in 4 seconds to skip startup.nsh or any other key to continue.

Shelly fso:

FSO:\>
```

### 7. 指令: SuperDiag.efi /full

```
Directory of: FSO:∖
                              4,096 LOCAL
07/16/2025 08:50 <DIR>
07/16/2025 08:50
                                 96 AUTOEXEC.BAT
07/16/2025 08:50 <DIR>
                              4,096
07/25/2025 09:17
                               21 startup.nsh
07/25/2025 09:17
                          1,970,464 SuperDiag.efi
07/25/2025
           09:17
                             18,732 Supermicro Super Diagnostics Offline readme.txt
                          2,657,531 Supermicro Super Diagnostics Offline User Guide V1.10.1.pdf
07/25/2025
          09:17
07/25/2025 09:17 <DIR>
                              4,096
07/25/2025 09:17 <DIR>
                              4,096
         5 File(s) 4,646,844 bytes
         4 Dir(s)
SO:\> SuperDiag.efi /full_
```

Parameter	Description	
/help	Displays all supported parameters and their instructions.	
/quick	Performs all actions, including collecting, detecting, and diagnosing, except 16-	
	bit/32-bit/64-bit memory diagnostics	
/full	Performs all actions, including collecting, detecting, and diagnosing.	

# 8. 測試中

- 9. 此工具會在 USB 磁碟中建立一個資料夾,其中包含電路板名稱、序號和時間標籤,用於儲存結果。您可以在該資料夾中找到超文本 (.html) 格式的摘要日誌。
- 10. 測試完畢後,如下範例

```
[Component Detection]
Start Time: 2021–08–04 10:38:10
Result: Passed
Total Type Count: 14, Passed Count: 9, Aborted Count: 5, Warning Count: 0, Failed Count: 0

[Component Diagnostics]
Start Time: 2021–08–04 10:38:10
Result: Warning
Total Type Count: 11, Passed Count: 8, Aborted Count: 3, Warning Count: 0, Failed Count: 0

Overall Result: Passed

Generating diagnostics result. Please wait.

Successful to save result to SuperDiag_X11SPA-TF_WM193S004074_20210804103810\SuperDiag_X11SPA-TF_WM193S004074_Summary_20210804105444.html.
```

#### 11. 請提供此檔案

