Multiplexing


CSC 343-643



Fall 2013

Multiplexing


- Often two machines can not utilize the full capacity of a link
- Need to share the channel among multiple users (multiplexing)



- Types of multiplexing
 - Frequency-division multiplexing
 - Time-division multiplexing
 - Code-division multiplexing
 - Statistical time-division multiplexing


Frequency Division Multiplexing

- Given a medium with bandwidth larger than a single signal
- Divide bandwidth to allow multiple carrier signals
 - Carrier frequencies may *not* overlap (analog signaling)
 - Signal raised in frequency to particular carrier



- Multiple signals can be sent simultaneously

E. W. Fulp CSC 343-643 Fall 2013 2



- Telephone system
 - Consider backbone links carrying multiple connections
 - Twelve 4 kHz channels multiplexed together
 - Multiplexed into the 60 to 108 kHz band, called a group

What are other examples of FDM?


Digital Subscriber Line

Using the existing telephony network for high-speed data and voice

- Local loop twisted pair has a 1.1 MHz bandwidth potential
 - However only a fraction is actually used
 - Voice requires 300 Hz to 3400 Hz
 - Remove (filter) anything below 300 Hz and above 3400 Hz
- Asymmetric Digital Subscriber Line (ASDL) has larger bandwidth
 - Asymmetric since higher bit rates downstream than upstream
 - Line is not filtered, 1.1 MHz is available

E. W. Fulp CSC 343-643 Fall 2013 4

- Divides 1.1 MHz bandwidth into 256 channels (three bands)
 - 1. 0 to 4 kHz telephone service (POTS) (1 channel)
 - 2. 25 kHz to 200 kHz upstream (5 channels)
 - 3. 250 kHz to 1000 kHz for downstream (remaining channels)




- Each channel modulation is similar to V.34
 - QAM used, 15 bits/baud, 4000 baud
 - Actual rate also depends on line length and quality

What is the bit rate if 224 channels are available?

Cable TV Networks

- Uses FDM to transmit multiple channels concurrently
 - Each channel is allocated 6 Mhz (8 MHz in Europe)



Note: Normally, the band of frequencies from 88 – 110MHz are used for radio broadcasts.


- Upstream is 5 42 MHz and downstream is above 550 Hz
 - Use QAM-64 per channel

What is the maximum data rate per channel?

E. W. Fulp CSC 343-643 Fall 2013 6


Time Division Multiplexing

- FDM requires analog circuits (not amenable to computers)
- Time Division Multiplexing (TDM) is used by digital electronics
 - However, local loops are analog
- TDM works by interleaving multiple signals over time



Generic TDM Description

- A n signals $m_i(t), i = 1...n$ are to be multiplexed
- Input data may be briefly buffered
- Buffers scanned to produce a composite digital stream



• Data rate of the composite stream

$$r_c \ge \sum_{i=1}^n r_i$$


E. W. Fulp CSC 343-643 Fall 2013 8

Digital Carrier Systems

- TDM is used in telephone networks, voice is 4 kHz
- 8000 PCM samples are taken per second at 8 bits/sample therefore a voice channel is 64 kbps


What is the time per sample?

• 24 voice channels are multiplexed together (T1)



• T1 frame consists of $24 \times 8 = 192$ bits plus 1 extra bit for framing, total of 193 bits every 125 μ sec What is the bit rate of a T1?

- If a T1 is used for data (non-voice), then only 23 channels are used, 24th is for synchronization
- T1 can be multiplexed into higher carriers



E. W. Fulp CSC 343·643 Fall 2013 10

TDM Link Control

The T1 description does not have headers, trailers, CRCs, etc...

- Control mechanisms (data-link) are not needed
- Flow control
 - Multiplexed data rate is fixed
 - Multiplexer and demultiplexer operate at same rate
 - Therefore flow control is not needed What if a "user" transmits more or less than subscribed?
- Error control
 - Why retransmit an entire T1 frame?
- Flow and error control are handled on a per channel basis

Code Division Multiplexing

- Code Division Multiplexing (CDM) is a form of spread spectrum
 - A narrow band signal is spread over a larger frequency band
 - Users can share simultaneously, and more tolerant of interference
 - Also called Code Division Multiple Access (CDMA)
- Lounge analogy, assume multiple conversations between paris of people
 - TDM pairs take turns talking, only one pair at a time
 - FDM pairs use different pitches, multiple pairs at once
 - CDM pairs use different languages, multiple pairs at once
- Given CDM uses different "codes" per conversation, important that the codes can be separated once received

E. W. Fulp CSC 343·643 Fall 2013 12

CDM Chips

- ullet Each bit time is divided into m short intervals called **chips**
 - Typically 64 or 128 chips per bit (let's use 8 as an example)
- Each station is assigned a unique m-chip code called a chip squence
 - Assume a bipolar encoding is used for the sequences (-1 and +1)
- Consider the chip sequence (-1 -1 -1 +1 +1 -1 +1)
 - To transmit a 1, then transmit the sequence, to transmit a 0 then send the inverted sequence

Example CDM Sequences

ullet Assume 4 stations A, B, C, and D with the following sequences

$$A: (-1 -1 -1 +1 +1 -1 +1 +1)$$
 $B: (-1 -1 +1 -1 +1 +1 +1 -1)$
 $C: (-1 +1 -1 +1 +1 +1 -1 -1)$
 $D: (-1 +1 -1 -1 -1 -1 +1 -1)$

- All the chip sequences are pairwise orthogonal (a requirement)
 - Normalized inner product of any 2 sequences S and T is zero

$$S \cdot T = \frac{1}{m} \sum_{i=1}^{m} S_i T_i = 0$$

E. W. Fulp CSC 343·643 Fall 2013 14

- For example,

$$A \cdot C = (-1 \cdot -1) + (-1 \cdot +1) + (-1 \cdot -1) + (+1 \cdot +1) + (+1 \cdot +1) + (-1 \cdot +1) + (+1 \cdot -1) + (+1 \cdot -1)$$

$$= 0$$

- Sequences with this property can be found using Walsh codes
- A few interesting properties

$$-S \cdot \overline{T} = 0$$

$$-S \cdot S = 1$$

$$-S \cdot \overline{S} = -1$$

CDM Transmission Example

- Assume all stations are synchronized in time
 - Each can send a 1 (transmitting their sequence), a 0 (negated sequence), or nothing
- If two or more stations transmit simultaneously, then add the signals
 - Assume the chip sequences for A, B, C, and D

Who transmits	Resulting signal S_i would be
C	$S_1 = (-1 +1 -1 +1 +1 +1 -1 -1)$
B+C	$S_2 = (-2 0 0 0 + 2 + 2 0 -2)$
$A + \overline{B}$	$S_3 = (0 0 -2 +2 0 -2 0 +2)$
$A + \overline{B} + C$	$S_4 = (-1 +1 -3 +3 +1 -1 -1 +1)$
A+B+C+D	$S_5 = \begin{pmatrix} -4 & 0 & -2 & 0 & +2 & 0 & +2 & -2 \end{pmatrix}$
$A + B + \overline{C} + D$	$S_6 = (-2 -2 0 -2 0 -2 +4 0)$

- Remember this is only transmitting a single bit

E. W. Fulp CSC 343·643 Fall 2013 16

Recovering the Bit from C

- Receiving station must know the sequence of the source
 - Computer the normalized inner product of the received signal and the source's chip sequence
- Assume you want to recover C (transmitted a 1)

Who transmits	Resulting signal would be	$C \cdot S_i$
C	(-1 +1 -1 +1 +1 +1 -1 -1)	(1+1-1+1+1+1-1-1)/8 = 1
B+C	(-2 0 0 0 +2 +2 0 -2)	(2+0+0+0+2+2+0+2)/8 = 1
$A + \overline{B} + C$	(-1 +1 -3 +3 +1 -1 -1 +1)	(1+1+3+3+1-1+1-1)/8 = 1
A + B + C + D	(-4 0 -2 0 +2 0 +2 -2)	(4+0+2+0+3+0-2+2)/8 = 1

- Note, an important assumption is synchronization of senders
 - Not possible for all types of applications (mobile phones)

Mobile Phones, a brief (one slide, US-oriented) history

- First Generation (1G), analog communications
 - Advanced Mobile Phone System (AMPS) divides geography into cells, each with a set of frequencies
 - Phones used Frequency Division Duplex (FDD) to share bandwidth
- Second Generation (2G), digital communications (voice and slow data)
 - Digital AMPS (DAMPS) uses TDM to host multiple phones within a frequency, popular in the US, but most have moved to GSM
 - Global System for Mobile communications (GSM) uses FDM and TDM like DAMPS, is the most widely used
 - CDMA was introduced, but became widely accepted in 3G
- Third Generation (3G), digital voice and data
 - Wideband CDMA (WCDMA) and CDMA2000 use code division multiplexing

E. W. Fulp CSC 343-643 Fall 2013 18

Multiplexing Analogy

3-lane highway used by employees of 3 companies (IBM, Cisco, EMC)

- FDM
 - Assign a lane to each company
 - Employees must use lane assigned to their company
 - Can use assigned lane at any time
- TDM
 - Assign specific times for highway use
 - 1. IBM employees 5:00am 6:00am
 - 2. Cisco employees 6:01am 7:00am
 - 3. EMC employees 7:01am 8:00am
 - Employees use entire highway, but only during assigned time

Any problems with FDM or TDM?


STDM

- Any employee can use any lane at any time
- Works only if there is no peak time, based on averages
- If all employees use highway at 8:00am ...

E. W. Fulp CSC 343·643 Fall 2013 20

Statistical Time Division Multiplexing

- Computer traffic (data) is often bursty, not a constant bit stream
 - On/off oriented (consider telephone conversations)




- Using TDM, if a station is idle transmit what?
- Statistical TDM exploits the fact that digital data is often bursty
 - Dynamically allocate time-slots (channels) on demand

What is the disadvantage?

Generic STDM Description

• Slots are not assigned to a particular source



- Assume arriving frames join a queue
 - Frames will be buffered until transmitted
 - Addresses are required ⇒ more overhead


Why are addresses required?

E. W. Fulp CSC 343·643 Fall 2013 22

STDM Performance

- Sum of the average input rates is less than the multiplexed line
 - However, the sum of the input *peaks* is greater
 - If all inputs transmit at the peak...
- Typically buffering is done on the input side
 - This temporarily stores the data until it is served
 - Smoothes the data stream by removing burstiness
 - Buffering does add possible transmission delays
- Analysis is based on queueing theory
 - Interested in the average packet delay
 - Delay is based on the arrivals and the server

A Simple Model



- Packets arrive at the system according to arrival pattern
 - Packets can be from one or multiple sources (multiplexer)
- If the buffer is finite and full, the packet is dropped
- Packets are serviced in a FIFO order
- We are interested in a relationship between the following
 - N(t) the number of packets in the system at time t
 - $\alpha(t)$ the number of arrivals in interval 0 to t
 - T_i the time spent in the system by packet i

E. W. Fulp CSC 343-643 Fall 2013 24


Little's Theorem

• An intuitive notion of the typical number of packets in the system

$$N_t = \frac{1}{t} \int_0^t N(\tau) d\tau$$

the time average of $N(\tau)$ up to time t

ullet N_t will change over time, but it will approach a steady state




• Similarly, we can make the same claim about the arrivals

$$\lambda_t = \frac{\alpha(t)}{t}$$

the average arrival rate up to time t

• The steady state arrival rate is

$$\lambda = \lim_{t \to \infty} \lambda_t$$



E. W. Fulp CSC 343-643 Fall 2013 26

ullet The time average of the packet delay up to time t is

$$T_t = \frac{\sum_{i=1}^{\alpha(t)} T_i}{\alpha(t)}$$

the average time spent in the system per packet up to time t

• The steady state time average packet delay is

$$T = \lim_{t \to \infty} T_t$$


• These quantities $(N, \lambda, \text{ and } T)$ are related by a simple formula, also known as **Little's Theorem**

$$N = \lambda T$$

- It expresses the *natural* idea that crowded systems (large N) are associated with long delays (large T)
- Valid for different types of queueing systems...

Graphical Proof

• Little's Theorem is really an accounting identity



- ullet Suppose the system is initially empty N(0)=0
- ullet Let lpha(t) be the number of arrivals and eta(t) be the number of departures at time t
 - The number in the system at time t is $N(t)=\alpha(t)-\beta(t)$

E. W. Fulp CSC 343·643 Fall 2013 28

• The area between the graphs of $\alpha(t)$ and $\beta(t)$ is

$$\int_0^t N(\tau) \tag{1}$$

ullet Let t be any time at which the system is empty N(t)=0, then the same area is equal to

$$\sum_{i=1}^{\alpha(t)} T_i \tag{2}$$

ullet Setting equation (1) equal to equation (2) and dividing by t

$$\frac{1}{t} \int_{0}^{t} N(\tau) = \frac{1}{t} \sum_{i=1}^{\alpha(t)} T_{i} = \frac{\alpha(t)}{t} \frac{\sum_{i=1}^{\alpha(t)} T_{i}}{\alpha(t)}$$

• This equals


$$N_t = \lambda_t T_t$$

Applications

- The significance of Little's Theorem is its generality
 - Holds for almost any queueing system that reaches steady state
 - However, it may require information we don't know
- Given the statistics about the arrivals and departures, we can derive the wait time as well as the queue length
 - Given a certain arrival and departure process, we want the average delay...

E. W. Fulp CSC 343·643 Fall 2013 30

M/M/1 Queue




- Consider a single buffer and server, assume
 - Interarrival times are exponential with rate $\lambda > 0$
 - Processing times are exponential with rate $\mu>0$
 - Buffer space is infinite
- Average delay is


$$T = \frac{1}{\mu - \lambda}$$

Can determine the delay given the average arrival and processing

M/M/1 Performance

- As the utilization approaches 1, performance decreases (unstable)
- System is stable when $\rho < 1$ (underload)






Why does queueing increase dramatically when $\lambda = \mu$?

Why does queueing exist when $\lambda < \mu$ (underload) condition?

E. W. Fulp CSC 343-643 Fall 2013 32

Average Rate

- The arrival pattern of packets (customers) is important
 - We need to also describe the variation



So what? Request CSC 790 High-Speed Networks and find out more...

Back to TDM and STDM Performance

Results for the M/M/1 queue can be applied multiplexing systems

- ullet TDM consists of dividing the capacity into n channels
 - Each channel has rate $\frac{r}{n}$
 - Each stream can be modeled as an M/M/1 queue with
 - * Arrival rate λ
 - * Transmission rate μ
 - Using Little's Theorem, delay per packet is

$$T_{TDM} = \frac{1}{\mu - \lambda}$$

CSC 343·643 Fall 2013 34 E. W. Fulp

- ullet STDM buffers packets from n streams
 - Assume multiplexed in one FIFO buffer
 - Total arrival rate is $n \cdot \lambda$
 - System is an M/M/1 queue with transmission rate $n \cdot \mu$
 - Average delay is

$$T_{STDM} = \frac{1}{n \cdot \mu - n \cdot \lambda} = \frac{T_{TDM}}{n}$$

therefore the STDM system delay is a fraction $(\frac{1}{n})$ of TDM


- Example, channel with 128kbps data rate
 - 10 users that transmit packets with independent exponentially distributed lengths of 1000 bits.
 - Each packet is transmitted according to a Poisson process with average rate 10 packets per second.
 - TDM, each user gets a 12.8kbps channel

$$T_{TDM} = \frac{1}{12.8 - 10} = 360 \text{msec}$$

- STDM all users share the link

$$T_{STDM} = \frac{T_{TDM}}{10} = 36 \text{msec}$$

E. W. Fulp CSC 343·643 Fall 2013 36



Multiplexing Results

- Preceding example indicates
 - TDM (separate channel) multiplexing results in poor delay
 - Performance is even worse if channels are not assigned proportionally to arrival rate
 - Arrival rates tend to change over time...
- However, models presented here rely on assumptions that may not be applicable to actual traffic
- TDM/FDM is still used in telephony since voice traffic *tends* to be *regular* rather than Poisson