






## EEPROM




## SPI FLASH




## DHT11/DS18B20




## REMOTE




## LED




## VOLTAGE







## TPAD




## ADC




## LED DIGITAL TUBE



## BEEP




## KEY




|                   |               |                               |
|-------------------|---------------|-------------------------------|
| Title:            |               | Cannot open file<br>E:\protel |
| STM32 EDU DEVICES |               |                               |
| Author:           | Size:         |                               |
| ATOM@ALIENTEK     | SheetSize     |                               |
| Date:             | File:         |                               |
| 2021/8/4          | DEVICE.SchDoc |                               |
| Revision:         | Version:      |                               |
| V1.0              | Version       |                               |


## DAP




## DAP STA LED




## DAP SWD




## DAP USB




## ON BOARD POWER SOURCE



## POWER



## USB



|                                |                            |                               |
|--------------------------------|----------------------------|-------------------------------|
| Title:<br>STM32 EDU JTAG&POWER |                            | Cannot open file<br>E:\protel |
| Author:<br>ATOM@ALIENTEK       | Size:<br>SheetSize         |                               |
| Date:<br>2021/8/4              | File:<br>JTAG&POWER.SchDoc |                               |
| Revision:<br>v1.0              | Version:<br>Version        |                               |
|                                |                            |                               |

