

38. Answer: D

For n-type semiconductors, the impurity energy level is just below the conduction band. The electrons in the energy band need little energy to reach the conduction band. Since this energy band supplies electrons to the conduction band, it is called the donor band.

39. Answer: A