

DAY-1:

Tasks


1.

Create a table listing 3 types of printers, 2 types of scanners, and 2 types of webcams, and for each, write one real-life use case (for example: 'Inkjet printer – printing college assignments').

Device	Type	Real-life Use Case
Printer	Inkjet Printer	Printing college assignments and colorful photos
Printer	Laser Printer	Printing a large number of documents quickly
Printer	Dot Matrix Printer	Printing bills, invoices, and multi-part forms
Scanner	Flatbed Scanner	Scanning documents, ID cards, and photos
Scanner	Sheet-fed Scanner	Scanning multiple pages quickly
Webcam	Built-in Webcam	Attending online classes and video meetings
Webcam	External USB Webcam	Online classes, video calls, and streaming

2.

Draw a labeled diagram showing how a typical home printer connects to a laptop or PC, including the connection interface used (USB, Wi-Fi, or Bluetooth).



3.

List three different connection interfaces (such as USB, Wi-Fi, Bluetooth) used by peripherals like printers, scanners, and webcams, and for each, name one advantage and one disadvantage.

Hint: Think about speed, convenience, and compatibility.

Connection Interface	Advantage	Disadvantage
USB	Fast and reliable connection	Requires a physical cable
Wi-Fi	Wireless and convenient; no cable is needed	Depends on network stability
Bluetooth	Wireless and easy to pair	Shorter range and can be slower than USB

4.

Pick any one device you use at home or college (printer, scanner, or webcam). Write step-by-step instructions for how you would connect it to your computer, including what cable or wireless method you would use and any setup steps required.

Steps followed:

1. **Check the printer:** Make sure the printer is properly assembled, has paper, and has enough ink or toner.

2. **Connect the printer:** Connect the printer to the computer using a **USB cable**.
3. **Switch on the printer:** Turn on the printer and wait for it to initialize.
4. **Install the driver:** Windows will usually detect the printer and automatically install the required driver. If it does not, download the correct driver from the printer manufacturer's official website.
5. **Open printer settings:** Go to **Settings → Devices → Printers & scanners**.
6. **Add the printer:** Click **Add a printer or scanner** and select the connected printer when it appears.
7. **Set as default printer:** Select the printer and choose **Manage → Set as default**, if required.
8. **Print a test page:** Open the printer settings and select **Print a test page**.
9. **Check the result:** Make sure the test page prints correctly without errors.