
HDI - Density Improvements

- Smaller pads mean more routing space
- Blind vias free up space on other layers that thru-holes occupy
- Rout channel increases:



		0.8 mm	1.0 mm	1.27 mm
	Conventional PCB .005" (.13mm) trace and space	\mathbf{v}	00	
	.025" (.64mm) pads .014" (.35mm) drill	Λ		
	High Density PCB .004" (.10mm) trace and space			
	.019" (.48mm) pads .010" (.25mm) drill		0 0	
		•		•••
	Microvia .004" (.10mm) trace and space		ollo	o o
	.012" (.30mm) pads .004" (.10mm) microvia		٥	
-	.004 (.1011111) IIIICIOVIA			