



**Finite Element Simulation For Mechanical Design** 

## Plasticity in FE modelling

Prof. A. Bernasconi

Plasticity: deformations that are not fully recovered once loads are removed

Here we treat time-independent plasticity:

- No creep
- No effect of the strain rate

We refer to isotropic materials and small strain formulation

### Uniaxial stress ( $\sigma$ – $\epsilon$ relationship assumed bilinear for the sake of simplicity): loading

 $d\sigma$  $\sigma_Y$ 

F, yield function Yielding is defined by F = 0

For uniaxial loading

$$F = |\sigma| - \sigma_Y$$

For 
$$\epsilon \geq \epsilon_Y$$

$$d\epsilon = d\epsilon^e + d\epsilon^p$$

$$d\sigma = E d\varepsilon^e$$
  $d\sigma = E(d\varepsilon - d\varepsilon^p)$   $d\sigma = E_t d\varepsilon$   $d\sigma = H_D d\varepsilon^p$ 

$$d\sigma = E_t d\epsilon$$

$$d\sigma = H_p \ d\varepsilon^p$$


Strain hardening parameter

# H<sub>p</sub>, strain hardening parameter, or plastic modulus


 $H_p = \frac{E_t}{1 - (E_t/E)}$  or  $E_t = E\left(1 - \frac{E}{E + H_p}\right)$ 

If  $H_p = 0$  (for which  $E_t = 0$ ), the material is said **elastic-perfectly plastic** 

If the material has not yet yielded or is unloading  $E_t = E$ 








Hardening rules:


ISOTROPIC (no Bauschinger effect)

- Unloading takes place elastically
- Conditions remain elastic until the limit of the elastic range is reached
- The span of the elastic range is defined by the hardening rule



KYNEMATIC (no increase of the elastic range)

The two rules can be used in combination



- Unloading takes place elastically
- Conditions remain elastic until the limit of the elastic range is reached
- The span of the elastic range is defined by the hardening rule

Largest magnitude of the stress reached previously,  $\sigma_0 = \sigma_Y + \alpha$ 


$$F = |\sigma| - \sigma_0$$

• KYNEMATIC (no increase of the elastic range)  $F = |\sigma - \alpha| - \sigma_Y$ 

$$F = |\sigma - \alpha| - \sigma_Y$$

The two rules can be used in combination

Kynematic shift



Prior to yielding,  $\alpha$  = 0 and  $\sigma_0$  =  $\sigma_Y$ 


Elastic conditions: when  $\alpha$  and  $\sigma$  are such that F < 0

Yielding: when F = 0

F > 0 is not physically possible

Continued or renewed plastic straining with strain hardening alters  $\alpha$ 


Let's start from point A, which lies in the linear elastic range. We know  $\sigma_A$ ,  $\epsilon_A$  and  $\epsilon_B$   $\sigma_B$  must be calculated



In order to resemble the calculations in a multiaxial stress state, we cannot "read the curve"

This document is distributed by Andrea Bernasconi to the students of the course Finite Element Simulation for Mechanical Design for personal use only, as teaching/learning materials. Any other use is forbidden without the written consent of the author.


Let's start from point A, which lies in the linear elastic range. We seek for point C, at the limit of the elastic range



$$F_C = |\sigma_A + \beta \Delta \sigma_{\text{trial}}| - \sigma_Y = 0$$
  
where  $\Delta \sigma_{\text{trial}} = \sigma_D - \sigma_A$   $\beta = \frac{\sigma_Y - \sigma_A}{\sigma_{\text{trial}}}$ 

### Post yield calculations in uniaxial stress by two-step integration

#### Starting from point C



method

The error can be reduced by reducing the step size

1st step 
$$(\Delta \sigma)_1 = (E_t)_C (\varepsilon_B - \varepsilon_C) = \sigma_D - \sigma_C$$
 and  $\sigma_{B1} \approx \sigma_C + (\Delta \sigma)_1 = \sigma_D$   
2nd step  $(\Delta \sigma)_2 = (E_t)_D (\varepsilon_B - \varepsilon_C)$  and  $\sigma_{B2} \approx \sigma_C + (\Delta \sigma)_2$   
 $\sigma_{B3} = \sigma_C + \frac{1}{2} \left[ (\Delta \sigma)_1 + (\Delta \sigma)_2 \right]$  or  $\sigma_{B3} = \sigma_C + \frac{1}{2} \left[ (E_t)_C + (E_t)_D \right] \Delta \varepsilon_{CB}$   
 $y_{n+1} = y_n + \left[ (1 - \gamma)(dy/dx)_n + \gamma(dy/dx)_{n+1} \right] \Delta x$  Generalized trapezoidal rule We used  $\gamma = 0.5$ , i.e. Runge-Kutta second

POLITECNICO DI MILANO

We used  $\gamma$ =0.5, i.e. Runge-Kutta second order



# General formulation: incremental plasticity relations

In a 3D stress state, results are history-dependent

Therefore we have to establish relationships between increment of stresses and increment of strains.

$$\{d\boldsymbol{\varepsilon}\} = \{d\boldsymbol{\varepsilon}^e\} + \{d\boldsymbol{\varepsilon}^p\}$$

$$\{d\boldsymbol{\sigma}\} = [\mathbf{E}]\{d\boldsymbol{\varepsilon}^e\} \quad \text{or} \quad \{d\boldsymbol{\sigma}\} = [\mathbf{E}]\Big(\{d\boldsymbol{\varepsilon}\} - \{d\boldsymbol{\varepsilon}^p\}\Big)$$

$$\{d\boldsymbol{\sigma}\} = [d\sigma_x \ d\sigma_y \ d\sigma_z \ d\tau_{xy} \ d\tau_{yz} \ d\tau_{zx}]^T$$


We need three ingredients:

- Yield criterion (relates the state of stress to the onset of yielding)
- Flow rule (relates the state of stress to increments of plastic strain)
- Hardening rule (describes how the yield criterion is modified by straining beyond initial yield)

$$F = F(\{\sigma\}, \{\alpha\}, W_p)$$

 $\alpha$  and W<sub>p</sub> describe how the yield surface (equation F=0) changes in response to plastic strains

F = 0 at yield and during plastic flow



#### During plastic flow:

- lpha and/or  $W_p$  change
- stresses remain on the yield surface (dF = 0)

During unloading dF < 0

F > 0 is not physically possible

This document is distributed by Andrea Bernasconi to the students of the course Finite Element Simulation for Mechanical Design for personal use only, as teaching/learning materials. Any other use is forbidden without the written consent of the author.

The flow rule is stated in terms of a function Q called plastic potential

$$\{d\boldsymbol{\varepsilon}^p\} = \left\{\frac{\partial Q}{\partial \boldsymbol{\sigma}}\right\} d\lambda$$

i.e. 
$$d\varepsilon_x^p = (\partial Q/\partial \sigma_x) d\lambda$$
 and so on


 $d\lambda$  is called a **plastic multiplier** 

If Q = F, the flow rule is called **associated** 

Flow rules for ductile metals are usually associated



### Hardening can be modelled as isotropic or kinematic, either separately or in combination



Kinematic hardening:

$$\{\alpha\} = \int \!\! \lceil \mathbf{C} \rfloor \{d\boldsymbol{\varepsilon}^p\}$$

Translation of the yield surface

Isotropic hardening:

$$W_p = \int \{\boldsymbol{\sigma}\}^T \{d\boldsymbol{\varepsilon}^p\}$$

Plastic work per unit volume, describes growth of the yield surface

In general, H<sub>p</sub> is not constant

$$\{d\alpha\} = \lceil \mathbf{C} \rfloor \{d\varepsilon^p\}$$
 in which

Subsequent yield surface, isotropic hardening

$$\lceil \mathbf{C} \rfloor = \frac{2}{3} H_p \left[ 1 \quad 1 \quad 1 \quad \frac{1}{2} \quad \frac{1}{2} \quad \frac{1}{2} \right]$$

Plastic flow takes place at constant volume

$$d\varepsilon_x^p + d\varepsilon_y^p + d\varepsilon_z^p = 0$$

hence

$$[1 \ 1 \ 1 \ 0 \ 0 \ 0] \{\alpha\} = \alpha_x + \alpha_y + \alpha_z = 0$$

o the students or aterials. Any oth



During an increment of plastic straining, dF = 0, thus from  $F = F(\{\sigma\}, \{\alpha\}, W_p)$ 

$$\left\{\frac{\partial F}{\partial \boldsymbol{\sigma}}\right\}^{T} \left\{d\boldsymbol{\sigma}\right\} + \left\{\frac{\partial F}{\partial \boldsymbol{\alpha}}\right\}^{T} \left\{d\boldsymbol{\alpha}\right\} + \frac{\partial F}{\partial W_{P}} dW_{P} = 0$$

$$\{d\mathbf{\sigma}\} = [\mathbf{E}] \left( \{d\boldsymbol{\varepsilon}\} - \{d\boldsymbol{\varepsilon}^p\} \right) \qquad \Longrightarrow \qquad \{d\mathbf{\sigma}\} = [\mathbf{E}] \left( \{d\boldsymbol{\varepsilon}\} - \left\{ \frac{\partial Q}{\partial \mathbf{\sigma}} \right\} d\lambda \right),$$

$$\{d\mathbf{\sigma}\} = [\mathbf{E}] \left\{ \{d\mathbf{\varepsilon}\} - \left\{ \frac{\partial Q}{\partial \mathbf{\sigma}} \right\} d\lambda \right\}$$

$$\{d\boldsymbol{\varepsilon}^p\} = \left\{\frac{\partial \mathcal{Q}}{\partial \boldsymbol{\sigma}}\right\} d\lambda \qquad \Longrightarrow \qquad dW_p = \{\boldsymbol{\sigma}\}^T \left\{\frac{\partial \mathcal{Q}}{\partial \boldsymbol{\sigma}}\right\} d\lambda,$$

$$dW_p = \{\boldsymbol{\sigma}\}^T \left\{ \frac{\partial Q}{\partial \boldsymbol{\sigma}} \right\} d\lambda$$

$$\{\alpha\} = \int \left[\mathbf{C}\right] \{d\boldsymbol{\varepsilon}^p\}$$

$$\{d\boldsymbol{\varepsilon}^p\} = \left\{\frac{\partial Q}{\partial \boldsymbol{\sigma}}\right\} d\lambda$$

$$\{d\mathbf{\alpha}\} = \left\lceil \mathbf{C} \right\rfloor \left\{ \frac{\partial Q}{\partial \mathbf{\alpha}} \right\} d\lambda$$



This document is distributed by Andrea Bernasconi to the students of the course Finite Element Simulation for Mechanical Design for personal use only, as teaching/learning materials. Any other use is forbidden without the written consent of the author.

Substituting and solving for the plastic multiplier

$$d\lambda = \lfloor \mathbf{P}_{\lambda} \rfloor \{ d\boldsymbol{\varepsilon} \}$$

$$[\mathbf{E}_{ep}] = [\mathbf{E}] \left[ \begin{bmatrix} \mathbf{I} \end{bmatrix} - \left\{ \frac{\partial Q}{\partial \boldsymbol{\sigma}} \right\} \begin{bmatrix} \mathbf{P}_{\lambda} \end{bmatrix} \right]$$

 $[E_{ep}]$  can be regarded as a generalized form of tangent modulus  $E_{t}$ 

It is symmetric for Q = F

$$[E_{ep}] = [E]$$
:

- for unloading from a plastic state (F = 0 and dF < 0) or</li>
- when yielding has yet to appear (F < 0)</li>

This document is distributed by Andrea Bernasconi to the students of the course Finite Element Simulation for Mechanical Design for personal use only, as teaching/learning materials. Any other use is forbidden without the written consent of the author.

Use of [E<sub>ep</sub>] in element formulation provides the tangent stiffness

$$[\mathbf{k}_t] = \int_{V} [\mathbf{B}]^T [\mathbf{E}_{ep}] [\mathbf{B}] dV$$

By assembling the equations for a FE structure, one obtains the relationship between displacement increments and load increments when there is plastic straining

$$[\mathbf{K}_t]\{d\mathbf{D}\} = \{d\mathbf{R}\}$$



# **Associative plasticity (metals): von Mises** theory

It postulates that yielding takes place when the effective stress reaches a limiting value

$$\sigma_e = \frac{1}{\sqrt{2}} \left[ (\sigma_x - \sigma_y)^2 + (\sigma_y - \sigma_z)^2 + (\sigma_z - \sigma_x)^2 + 6 \left( \tau_{xy}^2 + \tau_{yz}^2 + \tau_{xy}^2 \right) \right]^{1/2}$$

In this context, deviatoric stresses play an important role

$$\{\mathbf{s}_{\sigma}\} = \begin{cases} s_{x} \\ s_{y} \\ s_{z} \end{cases} = \begin{cases} \sigma_{x} - \sigma_{m} \\ \sigma_{y} - \sigma_{m} \\ \sigma_{z} - \sigma_{m} \end{cases} = \frac{1}{3} \begin{cases} 2\sigma_{x} - \sigma_{y} - \sigma_{z} \\ 2\sigma_{y} - \sigma_{z} - \sigma_{x} \\ 2\sigma_{z} - \sigma_{x} - \sigma_{y} \end{cases} \qquad \{\mathbf{s}_{\tau}\} = \begin{cases} s_{xy} \\ s_{yz} \\ s_{zx} \end{cases} = \begin{cases} \tau_{xy} \\ \tau_{yz} \\ \tau_{zx} \end{cases}$$

$$s_x + s_y + s_z = 0$$

$$\sigma_m = \frac{\sigma_x + \sigma_y + \sigma_z}{3}$$

$$\sigma_e = \sqrt{\frac{3}{2}} \left[ s_x^2 + s_y^2 + s_z^2 + 2 \left( s_{xy}^2 + s_{yz}^2 + s_{zx}^2 \right) \right]^{1/2}$$

This document is distributed by Andrea Bernasconi to the students of the course Finite Element Simulation for Mechanical Design for personal use only, as teaching/learning materials. Any other use is forbidden without the written consent of the


Being Q = F,

$$d\boldsymbol{\varepsilon}_p = \frac{\partial F}{\partial \boldsymbol{\sigma}} \, d\lambda \ .$$

It implies that  $d\epsilon_p$  is normal to the surface of equation F = 0 in the stress space

It can be demonstrated that the plastic multiplier is the same as the effective plastic strain corresponding to  $\sigma_e$ , which is expressed by

$$d\lambda = d\varepsilon_e^p = \sqrt{\frac{2}{3}} \left[ \left( d\varepsilon_x^p \right)^2 + \left( d\varepsilon_y^p \right)^2 + \left( d\varepsilon_z^p \right)^2 + \left( d\varepsilon_z^p \right)^2 + \left( d\gamma_{xy}^p \right)^2 + \left( d\gamma_{yz}^p \right)^2 + \left( d\gamma_{zx}^p \right)^2 \right]^{1/2}$$



$$F = \sigma_e - \sigma_0$$

Isotropic hardening can be described by a strain hardening expressions (instead of work hardening) , where  $\sigma_0$  is the largest value of  $\sigma_e$  reached in previous plastic straining



$$F = \left[ \frac{3}{2} \left\langle (s_x - \eta \alpha_x)^2 + (s_y - \eta \alpha_y)^2 + (s_z - \eta \alpha_z)^2 \right\rangle + 3 \left\langle (s_{xy} - \eta \alpha_{xy})^2 + (s_{yz} - \eta \alpha_{yz})^2 \right.$$

$$\left. + (s_{zx} - \eta \alpha_{zx})^2 \right\rangle \right]^{1/2} - \eta \sigma_Y - (1 - \eta) \sigma_0$$

$$\frac{\partial F}{\partial \alpha} = -\eta \frac{\partial F}{\partial \sigma}$$

 $\eta = 0$ , purely isotropic

 $\eta = 1$  purely kynematic

In 
$$\left\{\frac{\partial F}{\partial \sigma}\right\}^T \{d\sigma\} + \left\{\frac{\partial F}{\partial \alpha}\right\}^T \{d\alpha\} + \frac{\partial F}{\partial W_p} dW_p = 0$$
  $\frac{\partial F}{\partial W_p} dW_p$  is replaced by

$$\frac{\partial F}{\partial \sigma_0} d\sigma_0 \qquad \text{where} \qquad \frac{\partial F}{\partial \sigma_0} = -(1 - \eta) \quad \text{and} \quad d\sigma_0 = H_p d\lambda$$

$$\frac{\partial F}{\partial \alpha} = -\eta \frac{\partial F}{\partial \sigma}$$

 $\left\{\frac{\partial F}{\partial \boldsymbol{\sigma}}\right\}^{t} [\mathbf{E}]$  $\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} [\mathbf{E}] \left\{ \frac{\partial Q}{\partial \boldsymbol{\sigma}} \right\} - \left\{ \frac{\partial F}{\partial \boldsymbol{\alpha}} \right\}^{T} [\mathbf{C}] \left\{ \frac{\partial Q}{\partial \boldsymbol{\alpha}} \right\} - \frac{\partial F}{\partial W_{p}} {\{\boldsymbol{\sigma}\}}^{T} \left\{ \frac{\partial Q}{\partial \boldsymbol{\sigma}} \right\}$  $\frac{\partial Q}{\partial \boldsymbol{\sigma}} = \frac{\partial F}{\partial \boldsymbol{\sigma}} \qquad \frac{\partial F}{\partial \boldsymbol{\alpha}} = -\eta \frac{\partial F}{\partial \boldsymbol{\sigma}}$  $d\sigma_0 = H_p d\lambda$   $\frac{\partial F}{\partial \sigma_0} = -(1 - \eta)$  $\frac{\partial Q}{\partial \boldsymbol{\alpha}} = \frac{\partial F}{\partial \boldsymbol{\alpha}}$ 

$$\begin{bmatrix} \mathbf{P}_{\lambda} \end{bmatrix} = \frac{\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} [\mathbf{E}]}{\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} \left( [\mathbf{E}] + \boldsymbol{\eta} [\mathbf{C}] \right) \left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\} + (1 - \boldsymbol{\eta}) H_{p}}$$

$$\left\{\frac{\partial F}{\partial \boldsymbol{\sigma}}\right\} = \frac{1}{2[\cdots]^{1/2}} \left\{\frac{\partial}{\partial \boldsymbol{\sigma}}[\cdots]\right\}$$



$$\left[\frac{3}{2}\left\langle (s_{x} - \eta\alpha_{x})^{2} + (s_{y} - \eta\alpha_{y})^{2} + (s_{z} - \eta\alpha_{z})^{2}\right\rangle + 3\left\langle (s_{xy} - \eta\alpha_{xy})^{2} + (s_{yz} - \eta\alpha_{yz})^{2} + (s_{zx} - \eta\alpha_{zx})^{2}\right\rangle \right]^{1/2} + (s_{zx} - \eta\alpha_{zx})^{2}\right\}$$

$$\begin{bmatrix} \mathbf{P}_{\lambda} \end{bmatrix} = \frac{\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} [\mathbf{E}]}{\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} \left( [\mathbf{E}] + \boldsymbol{\eta} [\mathbf{C}] \right) \left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\} + (1 - \boldsymbol{\eta}) H_{p}}$$

$$\left\{\frac{\partial F}{\partial \sigma}\right\} = \frac{1}{2[\cdots]^{1/2}} \left\{\frac{\partial}{\partial \sigma}[\cdots]\right\} = \frac{1}{2[\eta \sigma_{\gamma} + (1-\eta)\sigma_{0}]} \left\{\frac{\partial}{\partial \sigma}[\cdots]\right\}$$

During yielding F = 0

$$F = \left[ \frac{3}{2} \left\langle (s_x - \eta \alpha_x)^2 + (s_y - \eta \alpha_y)^2 + (s_z - \eta \alpha_z)^2 \right\rangle + 3 \left\langle (s_{xy} - \eta \alpha_{xy})^2 + (s_{yz} - \eta \alpha_{yz})^2 + (s_{yz} - \eta \alpha_{yz})^2 + (s_{yz} - \eta \alpha_{yz})^2 \right\rangle \right]^{1/2} - \eta \sigma_Y - (1 - \eta) \sigma_0$$

$$\begin{bmatrix} \mathbf{P}_{\lambda} \end{bmatrix} = \frac{\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} [\mathbf{E}]}{\left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\}^{T} \left( [\mathbf{E}] + \boldsymbol{\eta} [\mathbf{C}] \right) \left\{ \frac{\partial F}{\partial \boldsymbol{\sigma}} \right\} + (1 - \boldsymbol{\eta}) H_{p}}$$

$$\left\{\frac{\partial F}{\partial \sigma}\right\} = \frac{1}{2[\cdots]^{1/2}} \left\{\frac{\partial}{\partial \sigma}[\cdots]\right\} = \frac{1}{2[\eta \sigma_{\gamma} + (1-\eta)\sigma_{0}]} \left\{\frac{\partial}{\partial \sigma}[\cdots]\right\}$$

$$F = 0$$

$$\frac{\partial}{\partial \sigma_x} [\cdots] = 3 \left[ (s_x - \eta \alpha_x) \frac{\partial s_x}{\partial \sigma_x} + (s_y - \eta \alpha_y) \frac{\partial s_y}{\partial \sigma_x} + (s_z - \eta \alpha_z) \frac{\partial s_z}{\partial \sigma_x} \right]$$

$$\frac{\partial}{\partial \sigma_x} \left[ \cdots \right] = 3 \left[ (s_x - \eta \alpha_x) \frac{2}{3} - (s_y - \eta \alpha_y) \frac{1}{3} - (s_z - \eta \alpha_z) \frac{1}{3} \right]$$

Differentiation with respect to  $\sigma_v$  and  $\sigma_z$  is performed similarly

Remembering that 2 s<sub>x</sub> - s<sub>y</sub> - s<sub>z</sub> = 3 s<sub>x</sub>, same for  $\alpha_x$ , and all other deviatoric and shift components

$$\left\{ \frac{\partial F}{\partial \sigma} \right\} = \frac{3}{\eta \sigma_Y + (1 - \eta) \sigma_0} \left( \frac{1}{2} \begin{Bmatrix} \mathbf{s}_{\sigma} - \eta \mathbf{\alpha}_{\sigma} \\ \mathbf{0} \end{Bmatrix} + \begin{Bmatrix} \mathbf{0} \\ \mathbf{s}_{\tau} - \eta \mathbf{\alpha}_{\tau} \end{Bmatrix} \right)$$
where
$$\left\{ \mathbf{\alpha} \right\} = \begin{Bmatrix} \mathbf{\alpha}_{\sigma} \\ \mathbf{\alpha}_{-} \end{Bmatrix}$$

With F = Q and isotropic hardening ( $\eta$ =0), we have the **Prandtl-Reuss relations** 

$$\frac{d\varepsilon_x^p}{s_x} \ = \ \frac{d\varepsilon_y^p}{s_y} \ = \ \frac{d\varepsilon_z^p}{s_z} \ = \ \frac{d\varepsilon_{xy}^p}{s_{xy}} \ = \ \frac{d\varepsilon_{yz}^p}{s_{yz}} \ = \ \frac{d\varepsilon_{zx}^p}{s_{zx}} \ = \ \frac{3}{2\sigma_0} \, d\lambda$$

Each plastic strain increment is proportional to its corresponding deviatoric stress (principal axes of strain increments coincide with those of stresses)



# Computational procedures for time independent plastic analysis: given R, find D

Required material's data: E,  $\sigma_{\rm Y}$  and values of H<sub>p</sub> for any given value of  $\sigma_{\rm e}$  First step: find state A, where the structure is at the verge of yield. Then, we apply a load increment  $\{\Delta R\}$  and seek for state B First, we generate  $[K_t]_A$ , and calculate

$$[\mathbf{K}_t]_A \{\Delta \mathbf{D}\}_{AB} = \{\Delta \mathbf{R}\}$$

After this first iteration, a load imbalance between the applied loads R and the nodal forces generated by the stresses in the elements, will be generated. In facts, the problem is non-linear, therefore more iterations are needed to find  $\{\Delta D\}_{AB}$ .

- This document is distributed by Andrea Bernasconi to the students of the course Finite Element Simulation for Mechanical Design for personal use only, as teaching/learning materials. Any other use is forbidden without the written consent of the author.
- {<del>o</del>}
- $\{\alpha\}$
- $W_p$  (or  $\sigma_0$ ) are updated.
- A new element tangent stiffness is evaluated
- A new structure tangent stiffness  $[K_t]_B$  is evaluated
- A new load increment is applied

$$[\mathbf{K}_t]_B \{\Delta \mathbf{D}\}_{BC} = \{\Delta \mathbf{R}\}$$