Use J-Flash to program DCP

1. Download and install J-Link software

You can download form the below site

https://www.segger.com/downloads/jlink/

The version you downloaded should be v6.10 or later

- 2. Unzip MM32_JLINK_pack.zip
- 2.1 Copy \MM32_JLINK_pack\PackagesFiles\Devices\MindMotion to your JLink install folder Default path is C:\Program Files (x86)\SEGGER\JLink_V644g\Devices
- 2.2 Copy \MM32_JLINK_pack\PackagesFiles\JLinkDevices.xml, and replace this file in your JLink install folder

File path is C:\Program Files (x86)\SEGGER\JLink_V644g\JLinkDevices.xml

3. Connect DCP to J-Link

To download program use 5 wires

J-LINK DCP VTref **VDD** <-> GND **GND** <-> SWDCLK **SWDCLK** <-> SWDIO <-> **SWDIO RESET** nRST <->

Photo1 shows wires connect to J-Link






Photo2

SWDCLK – Green wire SWDIO – Red wire GND – Blue wire VDD – Black wire

nRST - Yellow wire

4. Program DCP

1) open JFlash.exe




- 2) Choose Create a new project, then Start J-Flash
- 3) Select Target Device "MindMotion MM32F0133C7P", then click OK




4) File -> Open data file...


Select the hex file you want to update to the device




5) Target -> Connect, please make sure DCP is power on



6) Target -> Manual Programming -> Erase Sectors



7) Target -> Manual Programming -> Program



After that, the DCP should be updated.