SIM-TRHEPD-RHEED 1.0 documentation

SIM-TRHEPD-RHEED Developper Team

Contents:

1	Introduction					
	1.1 Overview	1				
	1.2 License	1				
2.	Installation	7				
_	2.1 Download and installation	?				
	2.2 Switching between TRHEPD and RHEED modes	4				
3	sage					
	Brief explanation	5				
	List of the two-dimensional space groups	5				
4	ample 1: Si(111)-($\sqrt{3} \times \sqrt{3}$)R30 $^{\circ}$ surface with a T4-site Al add atom					
	First stage: bulk part calculation	7				
	Second stage: surface part calculation	11				
	Third stage: convolution procedure	13				
5	Example 2: $Ge(001)$ - $c(4 \times 2)$ surface					
	5.1 Utility xyz.exe	15				
	Utility potcalc.exe	16				
6	Utility to_dft.py	17				
	5.1 Prerequisites	17				
	5.2 Input files	17				
	5.3 Execution	20				

Introduction

1.1 Overview

The software package SIM-TRHEPD-RHEED (STR) is a simulator for total-reflection high-energy positron diffraction (TRHEPD) and reflection high-energy electron diffraction (RHEED). Please cite Ref. [1] and [2], if you use the software in a research paper.

The software was written originally by Takashi Hanada [1] and is based on the theory written in Ref.[3]. The present package, STR v. 1.0 [2], was developed with the support of "Project for advancement of software usability in materials science" of The Institute for Solid State Physics, The University of Tokyo.

The package contains Fortran codes and Python3 scripts. A standard Linux environment is assumed throughout the present document.

- [1] T. Hanada, H. Daimon, and S. Ino, Rocking-curve analysis of reflection high-energy electron diffraction from the Si(111)- $(\sqrt{3} \times \sqrt{3})$ R30°-Al, -Ga, and -In surfaces, Phys. Rev. B 51, 13320–13325 (1995).
- [2] T. Hanada, Y. Motoyama, K. Yoshimi and T. Hoshi, submitted to Computer Physics Communications.
- [3] A. Ichimiya, Many-beam calculation of reflection high energy electron diffraction (RHEED) intensities by the multislice method, Jpn. J. Appl. Phys. 22, 176-180 (1983).

1.2 License

This package is distributed under GNU General Public License version 3 (GPL v3).

Installation

2.1 Download and installation

Here, a standard linux OS with a Fortran90 and Python3 environment is assumed.

One can download the source code with git command in a working directory

```
$ git clone http://github.com/sim-trhepd-rheed/sim-trhepd-rheed
```

and the following directory will be generated

```
sim-trhepd-rheed
```

In the sim-trhepd-rheed directory, execute the command below in order

```
$ cd src/
$ make
```

and the following executable files will be generated.

```
bulk.exe
surf.exe
xyz.exe
potcalc.exe
```

Note: The source codes of the numerical calculation library LAPACK (zgeev.f, zgeevb.f) are stored in the src/ directory and are also compiled. If LAPACK is preinstalled in your computer, you can use preinstalled LAPACK by editing the src/Makefile file properly.

In addition, Python3 scripts

```
script/make_convolution.py
tool/todft/to_dft.py
```

are also used. The required Python modules for the scripts will be explained later.

Set the environmental variables properly so that you can run the binary files and the srcipts.

2.2 Switching between TRHEPD and RHEED modes

The default source code of STR is written for TRHEPD experiment. If one would like to use STR for RHEED experiment, one should modify the line $\frac{1}{2}$



in bulkm.f90, surfm.f90, U0.f90, before the compilation. Hereafter we explain the TRHEPD case.

Usage

3.1 Brief explanation

In STR, the partial differential equation (PDE) of dynamical quantum diffraction theory is solved numerically. The procedure is decomposed into three stages as explained in Ref.[2]. At the first stage, the application bulk.exe is executed so as to solve the PDE in the bulk region. The required input file is bulk.txt so as to set the atom positions in the bulk region. The output file is bulk.s, which is required in the next stage. At the second stage, the application surf.exe is executed so as to solve the PDE in the surface region. The required input file is bulk.txt so as to set the atom positions in the surface region. The output file is surf-bulkP.s that contains the rocking curve data. At the third stage, the convolution procedure is executed by make_convolution.py.

3.2 List of the two-dimensional space groups

In the input file bulk.txt, one can specify the surface structure with a two-dimensional space group. The index NSG specifies the two-dimensional space group and are shown in the following table

NSG	symmetry		
1	p1		
2	p211		
3	p1m1		
4	p1g1		
5	c1m1		
6	p2mm		
7	p2mg		
8	p2gg		
9	c2mm		
10	p4		
11	p4mm		
12	p4gm		
13	p3		
14	p3m1		
15	p31m		
16	p6		
17	p6mm		

Example 1: Si(111)-($\sqrt{3} \times \sqrt{3}$)R30 $^{\circ}$ surface with a T4-site Al add atom

The present package contains two examples in the sample/ directory for tutorial. In the code, the z-axis is assumed to be perpendicular to the surface and the region $z \to \infty$ is the vaccum region. The vectors a and b are defined as the bulk 1 x 1 unit-cell vectors perpendicular to the z-axis.

The first example is the TRHEPD data for Si(111)- $(\sqrt{3} \times \sqrt{3})R$ 30° surface with a T4-site Al add atom under the many-beam condition. The present section details the typical usage of STR. The input data files, bulk.txt and surf.txt, are stored in the sample/T4Al_on_Si_111/output/ directory.

4.1 First stage: bulk part calculation

The bulk part is the crystalline silicon and the input file bulk.txt is as follows

bulk.txt

```
01: 3,3,1
              ,NH,NK,NDOM,
                           ---- Si(111) bulk
02: 13
              .NB
03: 0
             , RDOM
04: -6, -6, -5, -5, -4, -4, -3, -3, -2, -2, -1, -1, 0, 0,
     1,1,2,2,3,3,4,4,5,5,6,6 , (IH(I),IK(I))
05: 15,-30,-30,0,0.5,7,0.1 ,BE,AZI,AZF,DAZ,GI,GF,DG
06: 0.1,100 ,DZ,ML
07: 1
           , NELM
08: 14,1.0, 0.1
                     ,Si Z,da1,sap
09: 0.4,0.4,0.4
                     ,BH(I),BK(I),BZ(I)
10: 14, 3.83966, 3.83966, 120, 3.13507, -0.333333, 0.333333,
                                                                  NSG, AA, BB, GAM, CC, DX, DY
           , NATM
12: 1, 1, 0, 0, 1.17565
                             , IELM(I), ocr(I), X(I), Y(I), Z(I)
13: 1, 1, -0.333333, 0.333333, 1.95942
                                           , IELM(I), ocr(I) , X(I), Y(I), Z(I)
```

Hereafter, the line number of the text file is indicated at the head of each line. For example, the real fourth line is $^{\prime}$ -6,-6,-5,-5,-4,-4,-3,-3,-2,-2,-1,-1,0,0, 1,1,2,2,3,3,4,4,5,5,6,6, (IH(I),IK(I)) $^{\prime}$.

The parameters are explained below

NH, NK, NDOM

• NH, NK

The parameters specify the beam indices used in the calculation. With a set of integer parameters, IH and IK, the beam component (IH / NH, IK / NK) is included in the calculation, where the unit is bulk 1×1 reciprocal lattice. The unit cell of the reconstructed surface structure is described in the input data for surf.exe (surf.txt)

NDOM

The number of domains and is 1, unless a multi-domain system is calculated. The possible maximum number of domains is six. (NDOM \leq 6). Multiple-domain systems (NDOM > 1) are supported within the cases in which the domains form the same reconstructed surface with different orientations and their intensities must be summed. Moreover a multiple-domain system is supported, only if the two lattice vectors have the same length (a=b) and the angle between them (γ) satisfies $\gamma = 90^{\circ}$ or $\gamma = 120^{\circ}$.

NB(I)

The parameter NB(I) is the number of beams in domain I for I = 1, ..., NDOM.

RDOM(I)

The parameter RDOM(I) is an azimuth shift angle in domain I and should be written for I = 1 to NDOM in degree unit. All the azimuth angles in domain I are shifted by RDOM(I) from the default values. In the case of $\gamma = 90^{\circ}$, RDOM(I) is allowed as (integer) x 90° . In the case of $\gamma = 120^{\circ}$, RDOM(I) is allowed as (integer) x 60° .

IH(J, I), IK(J, I)

```
—- Repeat the following line inside the curly bracket for I = 1, ..., NDOM —- 
{ The indices IH (J, I) and IK (J, I) of the beam indices for J = 1, ..., NB(I) in domain I }
```

BE, AZI, AZF, DAZ, GI, GF, DG

• BE

Beam energy (unit: KeV)

• AZI

Initial (minimum) azimuthal angle (unit: degree)

• AZF

Final (maximum) azimuthal angle (unit: degree)

• DAZ

Azimuth angle interval (unit: degree)

Note: The azimuth angle is zero, if the direction is along the a-axis direction of the bulk. The azimuth angle is positive, if it rotates counterclockwise from the viewpoint of the vacuum side.

• G

Initial (minimum) glancing angle (unit: degree)

• GF

Final (maximum) glancing angle (unit: degree)

• DG

Glancing angle interval (unit: degree)

DZ, ML

DZ

Slice thickness or the mesh interval in the z-direction (unit: Å). Typically, DZ is 0.1~0.01.

ML

The maximum number of the bulk layers that contribute to the reflection effect. Here the layer unit length is CC defined below. Typically, ML is \sim 100.

NELM

The number of atom species in the bulk region. In the present context, one 'atom species' indicates the parameter set of the scattering properties and may be not identical to chemical species.

Repeat the following line inside the curly bracket for I = 1, ..., NELM

ι

iz, da1, sap

• iz

Atomic number

• da1

The parameter in the real part of the atomic scattering factor, a(1). Typically, da1 is ~ 1.0. See P.A. Doyle and P.S. Turner: Acta Cryst. A24 (1968) 390, L. -M. Peng, Micron 30 (1999) 625 and so on.

• sap

The scale parameter in the imaginary part of atomic scattering factor. The imaginary part is sap times larger than the real part. Typically, sap is 0.15 for BE = 10 KeV and 0.10 for BE = 15 KeV.

BH(I), BK(I), BZ(I)

The components of B = 8 π < u^2 > (\mathring{A}^2), where < u^2 > is the root mean square of vibration displacements).

- BH(I)//a* Surface component in the direction of a^* , the reciprocal lattice vector of a
- BK(I)//b* Surface component in the direction of b^* , the reciprocal lattice vector of b
- BZ(I) The z-axis component.

}

NSG, AA, BB, GAM, CC, DX, DY

• NSG

The index of the two-dimensional space groups of bulk 1×1 structure. NSG = 1, 2, ..., 16 or 17. See Sec. 'List of the two-Dimensional space Groups'.

AA

The length of the bulk cell vector a (\mathring{A})

• BB

The length of the bulk cell vector b (\mathring{A})

• GAM

The angle γ between the two vectors a and b (deg)

• CC

The unit length on the z-axis or the unit layer thickness perpendicular to the surface (\mathring{A}). Note that the unit layer may be not that for the periodic cell but that for a stacking structure. For example, the periodic cell of zinc-blend (111) surface is the stacked three-layer (\mathring{A} BC \mathring{A}) structure and the unit layer can be set to be one layer of the three.

• DX, DY

For atoms which are placed in the layer on the distance CC, atoms move parallelly to DX (unit length is AA) in the direction of unit cell a and DY (unit length is BB) in the direction of unit cell b. For example, in the case of the zinc-blende (111) plane, instead of giving the atomic coordinates of three layers of ABC, give the atomic coordinates of one layer (unit thickness is CC), and you can shift them 1/3 by using DX and DY.

NATM

The number of the atoms in the 1 x 1 unit cell, according to the symmetry corresponding to NSG.

```
—- Repeat the following line inside the curly bracket for I = 1, ..., NATM —-{
```

IELM(I), ocr(I), X(I), Y(I), Z(I)

• IELM(I)

The atom-species index IELM(I) = 1, 2, ... or NELM.

ocr(I)

The occupation ratio of atom I.

• X(I)

The coordinate of atom I in the direction of a (unit: AA),

Y(I)

The coordinate of atom I in the direction of b (unit: BB),

In order to correctly perform symmetry operations in a 2D plane, X- and Y-coordinates of atoms on the rotational symmetry axis perpendicular to the surface or on the reflection surface perpendicular to the surface should have an accuracy of 4 digits or more after the decimal point (the error should be 0.0001 or less). If it deviates more than that, it is determined that the position has low symmetry, and the number of expansions to the symmetric position in the plane becomes excessive. Also, since the X- and Y-coordinates of atoms on the mirror surface cannot move independently, take care to optimize the positions.

• Z(I)

The z-axis coordinate of atom I (unit: Å). The values should satisfy $0 \le z(i)$ <CC. Note that the scattering potential for $0 \le z < CC$ is calculated with the contribution from the atoms in the regions $-CC \le z < 0$ and $CC \le z < 2 * CC$.

The bulk part calculation is carried out by

\$ bulk.exe

and the output file surf-bulkP.s, a binary file, appears. The output file is required in the surface part calculation explained in the next subsubsection.

4.2 Second stage: surface part calculation

The surface part is described in the input file surf.txt as follows:

surf.txt

```
01: 3
           ,NELMS, ----- Si(111)-root3 x root3-R30-Al T4
02: 13,1.0,0.1
                   , Al Z,da1,sap
03: 0.6,0.6,0.6
                   ,BH(I),BK(I),BZ(I)
04: 14,1.0,0.1
                   , Si Z,da1,sap
05: 0.6,0.6,0.6
                   ,BH(I),BK(I),BZ(I)
                 , Si Z,da1,sap
06: 14,1.0,0.1
07: 0.4,0.4,0.4
                   ,BH(I),BK(I),BZ(I)
08: 15,2,1,-1,1, 1.7, 0.33333,-0.33333
     ,NSGS,msa,msb,nsa,nsb,dthick,DXS,DYS
           ,NATM
09: 7
10: 1,1
         0.00000
                   0.00000
                             6.55449
11: 2,1
         0.63960
                   0.31980
                             5.13449
12: 3,1
         0.00000
                   0.00000
                             4.08072
13: 3.1
         1.00000
                  1.00000
                             4.51072
14: 3.1
         0.00000
                   0.00000
                             1.77942
15: 3,1
         1.00000
                   1.00000
                             2.08942
16: 3,1
         0.33333
                   0.66667
                             1.17565
17: 1
           , WDOM
```

The parameters are explained below

NELMS

The number of atom species in the surf region.

```
—- Repeat the following line inside the curly bracket for I = 1, ..., NELM —- \{
```

iz, da1, sap

See the explanation of these parameters in bulk.txt

BH(I), BK(I), BZ(I)

See the explanation of these parameters in bulk.txt

NSGS, msa, msb, nsa, nsb, dthick, DXS, DYS

NSGS

The index of the two-dimensional space group of the reconstructed surface structure. NSGS = 1, 2, ..., 16 or 17. See Sec. 'List of the two-Dimensional space Groups'.

· msa, msb, nsa, nsb

Primitive lattice vectors for the reconstructed surface structure a_s and b_s are determined, according to the primitive lattice vector a and b of 1 x 1 bulk structure, as $a_s = \max x \ a + \max b x \ b$ and $b_s = \max x \ a + \max b x \ b$. Examples are written below; Si(111)-(7 × 7) surface is described by msa = nsb = 7, msb = nsa =0, NSGS=14. Si(111) $\sqrt{3} \times \sqrt{3}$ surface is described by msa = 2, msb = 1, nsa = -1, nsb = 1, NSGS=15. Si(001)-c(4 × 2) surface is described by msa = 4, nsb = 2, msb = nsa =0, NSGS=9. Si(001)-p(2 × 2) surface is described by msa = 2, nsb = nsa = 0, NSGS=7. Si(001)-(2 × 1) surface is described by msa = 2, nsb = 1, msb = nsa = 0, NSGS=6.

• dthick

The thickness of the vaccuum region (\mathring{A}). The vacuum region is included for z < (z-coordinate of the top surface-layer atom) + dthick in the surface part calculation. Typically, dthick is 2.0.

• DXS, DYS

In order to overlap the surface layer in accordance with the top layer of the bulk (coordinates described in the input data of BULK.EXE), all the atoms on the surface layer move DXS (unit is bulk AA) in the direction of the unit vector a., and move DYS (unit is bulk BB) in the direction of b.

NATMS

The number of the atoms in the reconstructed surface cell, according to the symmetry corresponding to NSGs.

Repeat the following line inside the curly bracket for I=1,...,NATM

```
IELM(I), ocr(I), X(I), Y(I), Z(I)
```

• IELM(I)

The atom-species index IELM(I) = 1, 2, ... or NELM.

• ocr(I)

The occupation ratio of atom I.

• X(I)

The coordinate of atom I in the direction of a (unit: AA)

• Y(I)

The coordinate of atom I in the direction of b (unit: BB).

• Z(I)

The z-axis coordinate of atom I (unit: $\mbox{\normalfont\AA}$).

WDOM(I)

The weight of the intensity for domain I for $I=1,\dots,NDOM$. For example, a system of three domains (NDOM=3) with the same weights is described as '1,1,1'.

The surface part calculation is carried out by

}

\$ surf.exe

and the output file surf-bulkP.s appears.

4.3 Third stage: convolution procedure

After the surface-part calculation, the convolution procedure should be carried out by

\$ python3 make_convolution.py --filename surf-bulkP.s --omega 0.5

Here the full width at half maximum is chosen to be $\omega=0.5^\circ$. The output file convolution.txt appears and contains the rocking curve data.

The first column of convolution.txt is the glancing angle in the degree. The NB=13 rocking curves appear in the second, third, ..., fourteenth column.

Example 2: Ge(001)-c(4 × 2) surface

The second example is the TRHEPD data for Ge(001)- $c(4 \times 2)$ surface structure in the one-beam condition. The present section details the usage of the two optional utilities, xyz.exe and potcalc.exe.

5.1 Utility xyz.exe

The utility xyz.exe generates the atom position data into the xyz-format file and is used, for example, when one would like to visualize the atomic structure. The utility is carried out by

```
$ xyz.exe
```

in the directory that contains bulk.txt and surf.txt. When one executes xyz.exe, the message

```
# of a-units, b-units & bulk layers ? :
```

appears and requires the three integer parameters (u_a, u_b, u_c) , so as to determine the region of the generated structure file. For example, one types

```
1 1 2
```

for the case of $(u_a, u_b, u_c) = (1, 1, 2)$. The two-dimensional lattice vectors of the generated structure file are $a_{\rm file} \equiv u_a a_{\rm s}$ and $b_{\rm file} \equiv u_b b_{\rm s}$. The thickness of the bulk region in the generated structure file is set to be $u_c \times {\rm CC}$.

The generated structure file is sample/Ge_001_c4x2/output/surf-bulk.txt. The last two lines of the file

```
16.00267 0.00000
0.00000 8.00134
```

indicate the two-dimensional periodic cell vectors, $a_{\rm file} = (16.00267\text{\AA}, 0)$ and $b_{\rm file} = (0, 8.00134\text{\AA})$.

5.2 Utility potcalc.exe

After the surface part calculations, the utility potcalc.exe plots the complex potential $V_{00}(z) = \hbar^2 U_{00}(z)/2m$ where m is the mass of positron and electron. The utility is valid only in the one-beam condition. When one executes xyz.exe, the message

```
# of bulk-unit repetition ?
```

appears and requires one integer parameter, so as to define the lower limit of z in the generated numerical data of the potential. For example, one types

3

for the surface region and the bulk region, where the bulk region consists of three bulk-unit repetitions.

Utility to_dft.py

The present section details the Python3 utility to_dft.py, which enables us a DFT calculation by Quantum Espresso (QE) for the files in STR.

The utility generates the input file of QE from the xyz-formatted structure file. The utility can also run QE, if QE is installed. As an optional function, the utility supports the generation of hydrogen-terminated structure in limited types of surface structures.

This section gives a tutorial of to_dft.py with the Si(001)-(2x1) surface. The input and output files are available on the tool/todft/sample/Si001 directory.

6.1 Prerequisites

The utility requires

• Python3 >= 3.6

The following packages are also required:

- Atomic Simulation Environment(ASE) (>= 3.21.1)
- Numpy
- Scipy
- Matplotlib
- Tomli

6.2 Input files

One should prepare an xyz-formatted structure file. An example is surf_Si001.xyz in the tool/todft/sample/Si001/directory.

surf_Si001.xyz

```
12
Si(001) surface test
Si 1.219476 0.000000 9.264930
```

(continues on next page)

(continued from previous page)

```
Si
     6.459844
                 0.000000
                             9.987850
     1.800417
Si
                 1.919830
                             8.404650
Si
     5.878903
                 1.919830
                             8.404650
Si
     3.839660
                 1.919830
                             7.155740
Si
     0.000000
                 1.919830
                             6.900440
Si
     3.839660
                 0.000000
                             5.743910
Si
     0.000000
                 0.000000
                             5.597210
Si
     1.919830
                 0.000000
                             4.321250
Si
     5.759490
                 0.000000
                             4.321250
Si
                             2.963750
     1.919830
                 1.919830
Si
      5.759490
                 1.919830
                             2.963750
```

One should prepare also a controlling file in Tom's Obvious, Minimal Language (TOML). An example is input.toml in the tool/todft/sample/Si001 directory.

input.toml

```
[Main]
input_xyz_file = "surf_Si001.xyz"
output_file_head = "surf_Si001_output"
[Main.param]
z_{margin} = 0.001
slab_margin = 10.0
[Main.lattice]
unit_vec = [[7.67932, 0.00000, 0.00000], [0.00000, 3.83966, 0.00000]]
[H_term]
r_SiH = 1.48 \# angstrom
theta = 109.5 #H-Si-H angle in degree
[ASE]
solver_name = "qe"
kpts = [3,3,1] # sampling k points (Monkhorst-Pack grid)
command = "mpirun -np 4 ./pw.x -in espresso.pwi > espresso.pwo"
[Solver]
[Solver.control]
calculation='bands' # 'scf', 'realx', 'bands',...
pseudo_dir='./'
                  # Pseudopotential directory
[Solver.system]
ecutwfc = 20.0
                      # Cut-off energy in Ry
nbands=33
                    # # of bands (only used in band structure calc
[Solver.pseudo]
Si = 'Si.pbe-n-kjpaw_psl.1.0.0.UPF'
H = 'H.pbe-kjpaw_psl.1.0.0.UPF'
```

The input file consists of four sections: Main, H_term, ASE, and Solver. Below is a brief description of the variables for each section. The section H_term is required, only if one would like to generate the hydrogen-terminated structure. If not, the section H_term should not appear.

6.2.1 Main section

This section contains settings related to the parameters required for hydrogen termination.

• input_xyz_file

Format: string

Description: Name of the xyz file to input

• output_file_head

Format: string

Description: Header for output files (xyz and cif files)

6.2.2 Main.Param section

• z_margin

Format: float

Description: Margin used to extract the lowest and second-to-last atoms. For example, if the z-coordinate of the atom in the bottom layer is z_min , the atoms in $z_min - z_margin \ll z \ll z_min + z_margin will be extracted.$

• slab_margin

Format: float

Description: Margin for tuning the size of the slab. If the z-coordinates of the atoms in the bottom and top layers are z_min, z_max, then the slab size is given by z_max-z_min+slab_margin.

6.2.3 Main.lattice section

• unit_vec

Format: list

Description: Specify the lattice vectors (ex. unit_vec = [[7.67932, 0.00000, 0.00000], [0.00000], 3.83966, 0.00000]]).

6.2.4 H_term section

This section enables us to generate the hydrogen-terminated structure. At the present code supports the hydrogen-terminated structures only for the (001)-type and (111)-type slab of the silicon diamond structure. The hydrogen-terminated models are generated in the following manner: The bottom layer atoms are removed, and H atoms are placed at the corresponding positions to create a model with the distance to the next layer atoms adjusted to a tetrahedral structure (for example, the distance to a silane molecule in the case of Si).

• r_SiH

Format: float

Description: The distance (in Å) between a vertex (e.g. Si) and H of a tetrahedral structure.

6.2. Input files

• theta

Format: float

Description: The angle between the vertex and H of the tetrahedral structure (e.g. Si-H-Si).

6.2.5 ASE section

This section specifies parameters related to ASE.

• solver_name

Format: string

Description: The name of the solver. Currently, only qe is given.

• kpts

Format: list

Description: Specify the k-points to be sampled (Monkhorst-Pack grid).

command

Format: string

Description: Set the command used to run the solver.

6.2.6 Solver section

In this section, parameters related to Solver are specified. You will need to specify this if you want to perform first-principles calculations directly using ASE. Basically, the configuration is the same as the one specified in the input file of each solver. For example, in the case of QE, Solver.control contains the parameters to be set in the control section of QE. The required pseudopotential files written in Solver.pseudo section should be downloaded, for example, by the wget command:

```
wget https://www.quantum-espresso.org/upf_files/Si.pbe-n-kjpaw_psl.1.0.0.UPF wget https://www.quantum-espresso.org/upf_files/H.pbe-kjpaw_psl.1.0.0.UPF
```

6.3 Execution

The script to_dft.py is carried out by

```
$ python3 to_dft.py input.toml
```

and the following files are generated:

- surf_Si001_output.xyz
- surf_Si001_output.cif
- espresso.pwi
- espresso.pwo

The three files surf_Si001_output.xyz, surf_Si001_output.cif and espresso.pwi are those in the xyz format, the Crystallographic Information File (CIF) format and the input file of QE, respectively. The files in the xyz and CIF formats are useful for visualization and are not required for QE. If QE works properly, the output file of QE, the output file espresso.pwo appears. If QE is does not work properly, the output file espresso.pwo contains error messages.

Here, the calculated structure is the hydrogen-terminated structure;

surf_Si001_output.xyz

```
14
Lattice= "7.67932 0.0 0.0 0.0 3.83966 0.0 0.0 0.0 17.0241"
→Properties=species:S:1:pos:R:3 pbc="T T T"
Si
         1.21947600
                           0.00000000
                                             9.26493000
Si
         6.45984400
                           0.00000000
                                             9.98785000
Si
         1.80041700
                           1.91983000
                                             8.40465000
Si
         5.87890300
                           1.91983000
                                             8.40465000
Si
         3.83966000
                           1.91983000
                                             7.15574000
Si
         0.00000000
                           1.91983000
                                             6.90044000
Si
         3.83966000
                           0.00000000
                                             5.74391000
Si
         0.00000000
                           0.00000000
                                             5.59721000
Si
                                             4.32125000
         1.91983000
                           0.00000000
                                             4.32125000
Si
                           0.00000000
         5.75949000
Η
         1.91983000
                          -1.20862950
                                             3.46707512
Н
         1.91983000
                           1.20862950
                                             3.46707512
Η
                          -1.20862950
                                             3.46707512
         5.75949000
Н
         5.75949000
                           1.20862950
                                             3.46707512
```

6.3. Execution 21