

Eye Spy

A privacy alarm that changes color when something is watching.

WHAT IT DOES

It watches for devices that may be recording or tracking you — body cameras, security cameras, license-plate readers, smart glasses, drones and trackers. One light tells you what it found.

It only listens. It never sends anything, never connects to the internet, and never records anyone.

WHAT IT FINDS

- Body cameras, security cameras and license-plate readers
 - Smart glasses, drones and Bluetooth trackers
 - Card skimmers, and unknown devices that follow you
- Trackers alert only after 30 minutes of following you.

WHAT IT CANNOT DO

- Find a camera or tracker that is switched off
- See through walls, or tell you who owns a device
- Block, jam or switch anything off

TURN IT ON

1. Plug the cable into the device and into power.
2. The light glows blue for a few seconds while it starts.
3. Then it settles on a color: green, yellow or red.

WHAT THE COLORS MEAN

- | | |
|-----------------|---|
| ● Blue | Starting up. Wait a moment |
| ● Green | Nothing found nearby |
| ● Yellow | Something worth noticing is near |
| ● Red | A surveillance or tracking device is near |

HOW TO USE IT

1. **Carry it with power.** Battery pack, then a bag, desk or pocket.
2. **Glance at the color.** Green: carry on. Yellow: be aware.
3. **Red:** something is watching or tracking. Look around, and move on if you would rather not stay near it.
4. **Press the button** to clear the reading and take a fresh look.

GOOD TO KNOW

- It only notices devices that are close by — usually the same room.
- It checks three ways in turn, so give it up to half a minute to notice something new.
- Yellow and red fade on their own a few minutes after you walk away.
- Green means nothing found yet, not that nothing is there.
- Red is not proof of anything illegal — just that equipment used for watching or tracking is nearby.
- A model with a small screen shows the same reading as a word: CLEAR, CAUTION or ALERT.

IF SOMETHING SEEMS WRONG

- **Light stays dark** Try another USB cable and another socket.
- **Stuck on yellow** Press the button once, or just wait a few minutes.
- **Always green** Check it has power. Some devices only announce themselves now and then.

USE IT RESPONSIBLY

- It only listens to radio signals already in the air. It never transmits, never joins a network, and never records anyone.
- Never interfere with any camera or equipment.
- Follow local laws, stay on public ground, and do not trespass.