IQRF-UDP

UDP implementation in IQRF devices

Technical Guide





Throughout this document, GW stands for a general device (typically the IQRF GW Daemon).

Application protocol for UDP channel

The communication is realized with the application protocol described below. It uses the transport protocol UDP according the OSI reference model. For establishing a connection it is necessary to know the UDP port where the GW is listening and its IP address or the NetBIOS name (Host Name).

GW responses to commands to any asking device. Asynchronous messages are sent to broadcast address until the communication is established. After communication establishing the messages are sent to address of the last communicating host. Thus, more hosts (e.g. servicing programs on more PCs) can communicate with the GW.

If the IP address or NetBIOS of the GW and the port number are known it is just possible to establish the connection. Otherwise the request for a GW identification can be sent to broadcast address (in a single LAN segment only – routers filter packets with broadcast addresses.) All GWs receiving this request will answer which allows to get actual IP address of given GW.

Packet description

The packet structure is the same for both communication directions:

HEADER (H = 9 B) DATA (D = 0 – 497 B) CRC (2 B)

For receiving, the GW checks:

- GW_ADR validity see the packet header
- Packet length must not be lower than HEADER + CRC
- Packet length must not be higher than HEADER + DATA MAX + CRC
- CRC

Header

Packet header has a fixed length:

0	1	2	3	4	5	6	7	8
GW_ADR	CMD	SUBCMD	RES	RES	PACID_H	PACID_L	DLEN_H	DLEN_L

GW_ADR Identification address of the equipment:

0x22 IQRF device (e.g.IQD-GW-01, GW-WIFI-01 or GW-ETH-02A)

0x20 3rd party or user specific device, e.g. based on the IQRF GW Daemon

CMD Command of the packet (values: 0x01 ... 0x7F)

Answer to given command: CMD = CMD | 0x80 (bit 7 of given CMD set)

SUBCMD Auxiliary information of the command (values: see description below)

RES Reserved

PACID_H Packet identification – upper byte (values: 0x00 ... 0xFF)
PACID_L Packet identification – lower byte (values: 0x00 ... 0xFF)

DLEN_H Data length – upper byte (values: 0x00, 0x01)

DLEN_L Data length – lower byte (values: 0x00 ... 0xFF)

The packet identification (PACID) can be any number 0x0000 – 0xFFFF according to the host specification. The GW always copies this number to the answer to given packet. It means that the host can use any 2B value for PACID_x and the GW returns it without any change. So, the usage is up to the host application. The host can use it e.g. for an identification of received response to given request. IQRF IDE as a host uses it exactly in this way: IDE increments PACID_x with every packet sent to the GW and expects the same PACID_x value in the response from GW.



CRC

The check part has a fixed length:

H+D	H+D+1
CRC_H	CRC_L

CRC type CRC-16-CCITT

Polynomial $0x1021 (x^16 + x^12 + x^5 + 1)$

Initial value 0x0000

CRC is calculated from the HEADER and DATA parts.

Communication initiated by the host

Get GW identification

Getting a GW identification. It is intended to identification of the GW which the connection is established with.

Host → GW direction

CMD 0x01 Returns the GW identification

SUBCMD 0x00 No information

DLEN 0x0000 No data

 $GW \rightarrow Host direction$

CMD 0x81 Answer to the 0x01 command

SUBCMD 0x00 No information

0x10 Bootloader

DATA Text with GW identification. See Data identification.

Get GW status

The GW returns the information about its state.

Host → GW direction

CMD 0x02 Returns the GW status

SUBCMD 0x00 No information

DLEN 0x0000 No data

 $\textbf{GW} \rightarrow \textbf{Host direction}$

CMD 0x82 Answer to the 0x02 command

SUBCMD 0x00 No information
DATA See Status data



Write data to TR module

Data according the IQRF SPI protocol is written to the TR module. The answer is an acknowledge of writting to the module. If the answer is requested from the module it is sent with the actual command – see Communication initiated by the GW. According to GW configuration either just actual data or the whole packet is written.

Host → GW direction

CMD 0x03 Write data to the TR module

SUBCMD 0x00 No information

DATA Data for the TR module

GW → Host direction

CMD 0x83 Answer to the 0x03 command

SUBCMD 0x50 Write OK

0x60 Write Error (number of data = 0 or more than TR buffer COM length)

0x61 Write Error (SPI bus busy)

0x62 Write Error (IQRF - CRCM Error)

0x63 Write Error (GW is not in service mode)

DLEN 0x0000 No data

Write to RTCC in GW

Writing of time and date to the RTCC in GW

Host → GW direction

CMD 0x08 Write to RTCC SUBCMD 0x00 No information

DB1 GW time – seconds (values see Time and data coding)

DB2 GW time – minutes
DB3 GW time – hours

DB4 GW data – day of week

DB5 GW data – day
DB6 GW data – month
DB7 GW data – year

GW → Host direction

CMD 0x88 Answer to the 0x08 command

SUBCMD 0x50 Write OK

0x60 Write Error (invalid values)

DLEN 0x0000 No data



Change autentization

Changing of username and password for access to GW via www.

 $Host \rightarrow GW$ direction

CMD 0x09 Change autentization

SUBCMD 0x00 No information
DB1 Username: text

to (max. 15 characters, not used ones replace with zeroes)

DB15

DB16 Old password: text

to (max. 15 characters, not used ones replace with zeroes)

DB30

DB31 New password: text

to (max. 15 characters, not used ones replace with zeroes)

DB45

 $\textbf{GW} \rightarrow \textbf{Host direction}$

CMD 0x89 Answer to the 0x09 command

SUBCMD 0x50 Write OK

0x60 Write Error (invalid old password)

DLEN 0x0000 No data

Read TR Module Info in GW

Getting information about the module in the GW

 $\textbf{Host} \rightarrow \textbf{GW direction}$

CMD 0x11 Read the TR Module Info from the GW

SUBCMD 0x00 No information

DLEN 0x0000 No data

 $\textbf{GW} \rightarrow \textbf{Host direction}$

CMD 0x91 Answer to the 0x11 command

SUBCMD 0x00 No information
DATA See Module Info



Reset GW (GW as well as the bootloader)

Remote GW reset (initialization).

 $Host \rightarrow GW$ direction

CMD 0x12 GW reset
SUBCMD 0x00 No information

DLEN 0x0000 No data

GW → Host direction

See Communication initiated by the GW – Sending the GW status message.

TR module reset

Remote reset of the TR module.

 $\textbf{Host} \rightarrow \textbf{GW direction}$

CMD 0x13 TR module reset
SUBCMD 0x00 No information
DLEN 0x0000 No data

GW → Host direction

CMD 0x93 Answer to the 0x13 command

SUBCMD 0x50 OK command

0x60 Error command

DLEN 0x0000 No data

Sending a command not implemented in GW

Host → GW direction

CMD ? Unknown command SUBCMD ? Arbitrary information

DATA Arbitrary data

 $GW \rightarrow Host direction$

CMD ? | 0x80 Answer to an unknown command

SUBCMD 0x60 Packet error DLEN 0x0000 No data



Communication initiated by the GW (asynchronous message)

Send data from TR module

Sends data from the TR module according to the IQRF SPI protocol. According to the settings either just actual data or the whole packet is send.

GW → Host direction

CMD 0x04 Send data from TR module

SUBCMD 0x00 No information

DATA Data from TR module

Send GW status message

It is a message from the GW about its state. The information is indicated by the SUBCMD byte.

GW → Host direction

CMD 0x05 GW status message

SUBCMD 0x01 GW reset, sent after switching on

0x02 Change its own IP address (only if the DHCP is active)

DATA Text with GW identification. See Identification data.

Identification data

Identification data consists of several texts separated by 0x0D 0x0A.

1. GW type e.g.: "IQRF-GW-Daemon" or "GW-ETH-02A"

2. FW version e.g.: "2.50"

3. MAC address e.g.: "00 11 22 33 44 55"

4. TCP/IP Stack version e.g.: "5.42"

5. IP address of GW e.g.: "192.168.2.100"

6. Net BIOS Name e.g.: "iqrf xxxx "15 characters

7. IQRF module OS version e.g.: "3.06D"

8. Public IP address e.g.: "213.214.215.120"



Status data

GW status data for the Get GW status command.

DB1		TR module status (see the IQRF SPI protocol)
DB2		Not used
DB3	0x01	Supplied from external source
DB4 DB5 DB6 DB7 DB8 DB9		GW time – seconds (see Time and date coding) GW time – minutes GW time – hours GW date – day of the week GW date – day GW date – month GW date – year
DB1	1	Not used
DB1	2	Not used

Time zone coding

0x00	(GMT-12:00)	0x0B	(GMT-02:00)	0x16	(GMT+05:45)
0x01	(GMT-11:00)	0x0C	(GMT-01:00)	0x17	(GMT+06:00)
0x02	(GMT-10:00)	0x0D	(GMT)	0x18	(GMT+06:30)
0x03	(GMT-09:00)	0x0E	(GMT+01:00)	0x19	(GMT+07:00)
0x04	(GMT-08:00)	0x0F	(GMT+02:00)	0x1A	(GMT+08:00)
0x05	(GMT-07:00)	0x10	(GMT+03:00)	0x1B	(GMT+09:00)
0x06	(GMT-06:00)	0x11	(GMT+03:30)	0x1C	(GMT+09:30)
0x07	(GMT-05:00)	0x12	(GMT+04:00)	0x1D	(GMT+10:00)
80x0	(GMT-04:00)	0x13	(GMT+04:30)	0x1E	(GMT+11:00)
0x09	(GMT-03:30)	0x14	(GMT+05:00)	0x1F	(GMT+12:00)
0x0A	(GMT-03:00)	0x15	(GMT+05:30)	0x20	(GMT+13:00)

Time and date coding

For individual values the BCD code is used. The upper nibble (UN) means tens and the lower nibble (LN) means units.

Example (seconds):

DB = 0x53 means 53 s

Legal ranges:

Seconds	UN = 0 - 5	LN = 0 - 9	min. 0 max. 59
Minutes	UN = 0 - 5	LN = 0 - 9	min. 0 max. 59
Hours	UN = 0 - 2	LN = 0 - 9	min. 0 max. 23
Day	UN = 0 - 3	LN = 0 - 9	min. 1 max. 31
Month	UN = 0 - 1	LN = 0 - 9	min. 1 max. 12
Year	UN = 0 - 9	LN = 0 - 9	min. 8 max. 99 (2008 - 2099)
Day of week	UN = 0	LN = 0 - 6	min. 0 max. 6 (0 – Sunday, 1 – Monday,)

These ranges are checked during writing to the GW. If out of range the packet with SUBCMD = write Error is returned.





Module Info data

Information about the TR module in the GW. See IQRF OS Reference guide, function moduleInfo() for description.

DB1	bufferInfo[3]
DB2	bufferInfo[2]
DB3	bufferInfo[1]
DB4	bufferInfo[0]
DB5	bufferInfo[4]
DB6	bufferInfo[5]
DB7	bufferInfo[6]
DB8	bufferInfo[7]





Product information

Document history

190425 GW_ADR parameters in packet header slightly updated.

180511 First release as a separate document. Write Error 0x63 added to Write data to TR module.

Till May 2018 UDP protocol description was included in User's guides of respective IQRF gateways (GW-ETH-0xx

and GW-WIFI-01).



Sales and Service

Corporate office

IQRF Tech s.r.o., Prumyslova 1275, 506 01 Jicin, Czech Republic, EU Tel: +420 493 538 125, Fax: +420 493 538 126, www.iqrf.tech

E-mail (commercial matters): sales@iqrf.org

Technology and development

www.iqrf.org

E-mail (technical matters): support@iqrf.org

Partners and distribution

www.iqrf.org/partners

Quality management

ISO 9001: 2009 certified

Trademarks

The IQRF name and logo are registered trademarks of IQRF Tech s.r.o. PIC, SPI, Microchip and all other trademarks mentioned herein are property of their respective owners.

Legal

All information contained in this publication is intended through suggestion only and may be superseded by updates without prior notice. No representation or warranty is given and no liability is assumed by IQRF Tech s.r.o. with respect to the accuracy or use of such information.

Without written permission, it is not allowed to copy or reproduce this information, even partially.

No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

The IQRF® products utilize several patents (CZ, EU, US).

On-line support: support@iqrf.org

