		GND	TP1-1 RF TP1-2 GND TP1-3 FOCS. RTN TP1-4 TRKG Err A+C TP1-5 FOCS Err IN TP1-6 FOCS Err OUT TP1-7 TRKG Err In TP1-8 TILT Err
https://www.domesday86.com			