P		P8		
GND	GND		GND	GND
3.3V	3.3V	1		
5V raw	5V raw	1		
5V	5V		P8_7	P8_8
PWR	RESET		P8_9	P8_10
P9_11 RX4	P9_12		P8_11	P8_12
P9_13 TX4	P9_14 pwm	1	P8_13 pwm	P8_14
P9_15	P9_16 pwm	1	P8_15	P8_16
P9_17	P9_18	1	P8_17	P8_18
P9_19 SCL	P9_20 SDA	1	P8_19 pwm	P8_20
P9_21 TX2	P9_22 RX2		P8_21	P8_22
P9_23	P9_24 TX1		P8_23	P8_24
P9_25	P9_26 RX1	1	P8_25	P8_26
P9_27	P9_28	1	P8_27	P8_28
P9_29	P9_30	1	P8_29	P8_30
P9_31	1.8V ADC	1	P8_31	P8_32
P9_33 AIN4	GND ADC		P8_33	P8_34
P9_35 AIN6	P9_36 AIN5		P8_35	P8_36
P9_37 AIN2	P9_38 AIN3	1	P8_37 TX5	P8_38 RX5
P9_39 AIN0	P9_40 AIN1	1	P8_39	P8_40
P9_41	P9_42	1	P8_41	P8_42
GND	GND	1	P8_43	P8_44
GND	GND		P8_45	P8_46