Arduino PRO MINI Atmega328P pinout

Kód produktu 1472415090

RST	29	PC6	RESET/PCINT14
DTR			
TX0	31	PD1	TXD/PCINT17
RX1	30	PD2	RXD/PCINT16
VCC			+5 VDC
GND			
GND			
VIN			

TX0	31	PD1	TXD/PCINT17
RX1	30	PD0	RXD/PCINT16
2	32	PD2	INTO/PCINT18
3	1	PD3	PCINT19/OC2B/INT1
4	2	PD4	PCINT20/XCK/T0
5	9	PD5	PCINT21/OC0B/T1
6	10	PD6	PCINT22/OC0A/AIN0
7	11	PD7	PCINT23/AIN1
8	12	PB0	PCINTO/CLKO/ICP1
9	13	PB1	PCINT1/OC1A
10	14	PB2	PCINT2/SS/OC1B

	1
	41
	1
-}	1
	1
	1
	1
- }	1
	1
RESET E SE	

A7	22	ADC7	
A6	19	ADC6	
A5	27	PC4	ADC4/SDA/PCINT12
A4	28	PC5	ADC5/SCL/PCINT13
А3	26	PC3	ADC3/PCINT11
A2	25	PC2	ADC2/PCINT10
A1	24	PC1	ADC1/PCINT9
A0	23	PC0	ADCO/PCINT8
13	17	PB5	SCK/PCINT5
12	16	PB4	PCINT4/MISO
11	15	PB3	PCINT3/OC2A/MOSI