

Evolution of Multilevel Machines

To provide perspective on multilevel machines, we examine their historical development – how the number and nature of levels has evolved over the years

Hardware vs Software

Hardware consists of tangible objects:


- integrated circuits, printed circuit boards
- cables, power supplies, memories, printers

Software consists of algorithms and their computer representations:


- detailed instructions telling how to do something
- the essence is the *instructions*, not the physical media

Hardware vs Software

In the very first computers, the boundary was **crystal clear**



Over time it has **blurred** considerably due to the addition, removal, and *merging* of levels as computers *evolved*



Hardware and Software are Logically Equivalent

Any operation performed by software can also be built directly into the hardware

And vice versa: any instruction executed by hardware can also be simulated in software

As Karen Panetta put it

Hardware is just petrified software

Hardware and Software are Logically Equivalent


And the decision to put functions in hardware *or* software is based on:

- **cost** - which is cheaper to build or implement
- **speed** - hardware is faster, software is more flexible
- **reliability** - fewer components means fewer failure points
- **frequency of expected changes** - software is easier to modify

There are few hard-and-fast rules

These decisions *shift* with technology economics, demand, and computer usage

Hardware and Software are Logically Equivalent



ISA programming

ISA programming is simply *no longer done today*, completely replaced by using assembly which is a symbolic representation of it

But the earliest programmable computer, like the *ENIAC* only had the *digital logic level* and the *instruction set architecture*

And *critically* no memory

In order to program it, the steps would include

1. Writing, solving, and breaking down complex math into basic arithmetic steps
2. Creating a schematic map on how data should physically flow through the units
3. Plugging cables
4. Setting switches

Invention of Microprogramming (Wilkes, 1951)

In **1951**, Maurice Wilkes suggested designing a *three-level computer* to


- drastically simplify hardware and
- reduce the number of unreliable vacuum tubes

The machine was to have a built-in, *unchangeable* interpreter (**microprogram**), whose function was to execute ISA-level programs by **interpretation**


Since the hardware would only execute *microprograms* instead of *ISA-level* programs

1. Fewer electronic circuits were needed
2. fewer tubes
3. **enhanced reliability**

After — Wilkes (3 levels)



Before (2 levels)



The Rise of Microprogramming

A few three-level machines were constructed during the **1950s**


More were constructed during the **1960s**

By **1970**, the idea of having the ISA level interpreted by a microprogram (instead of directly by the electronics) was **dominant**


All major machines of the day used it

Open Shop - Running a FORTRAN Program

Compilation Phase



Execution Phase



The First Operating System – FMS

Around **1960**, people tried to *reduce* wasted time by automating the operator's job

A program called an *operating system* was kept in the computer at all times

One of the first widespread OSes was **FMS (FORTRAN Monitor System)** on the IBM 709

Card	Function
*JOB	Accounting info
*FORTRAN	Load FORTRAN compiler from tape
*DATA	Execute translated program
*END	End of job

The asterisk identified control cards so they would not be confused with program and data cards


A New Virtual Machine is Born

The operating system was designed to automate the operator's job - but it was also the *first step* in the development of a **new virtual machine level**

The ***FORTRAN** card could be viewed as a virtual "*compile program*" instruction

The ***DATA** card could be regarded as a virtual "*execute program*" instruction

A level with only **two instructions** was not much of a level



These eventually evolved into

- **operating system macros / supervisor calls**

(modern term: **system call**)

Some instructions were identical to ISA, but others (especially I/O) were completely different



Batch Systems -> Timesharing

Batch systems (early 1960s):

- Read card decks, printed output on line printer
- Wait of **several hours** between submission and results
- Developing software was *very* difficult

Timesharing systems (Dartmouth, MIT, early 1960s):

- Multiple programmers communicate *directly* with the computer
- *Remote terminals* connected via telephone lines
- Computer **shared** among many users
- Immediate results, type in a program, get output back almost immediately



Migration of Functionality to Microcode

Once microprogramming was common (by **1970**), designers realized they could *add new instructions* by just **extending the microprogram**


They could add "hardware" (new machine instructions) by *programming*

This led to an **explosion in instruction sets** as designers competed to produce bigger and better instruction sets

Many instructions were *not essential* but they were slightly *faster*

Example:

- **INC** (add 1) was not necessary (machines already had **ADD**), but it was a little faster



Additional Microcode Features

Once designers saw how easy it was to add new instructions, they began looking for *other features* to add to their microprograms:

- **Indexing and indirect addressing**
- **Relocation facilities**
- **Interrupt systems**
- **Process switching**
- **Audio, image, and multimedia** processing instructions

Numerous other features and facilities were added, usually for speeding up some particular activity

The Elimination of Microprogramming

Microprograms grew **fat** during the golden years (1960s-1970s)



They also tended to get *slower and slower* as they acquired more bulk

Researchers realized:

- *Eliminate* the microprogram
- *Vastly reduce* the instruction set
- Have remaining instructions be **directly executed**

Result: machines could be **sped up**

Computer design had come *full circle*, back to the way it was before Wilkes invented microprogramming



*this only works because memory now exists

The Wheel Keeps Turning

Modern processors still rely on *microprogramming* to translate complex instructions to internal **microcode** that can be executed directly on streamlined hardware

The boundary between hardware and software is *arbitrary and constantly changing*

- Today's software may be *tomorrow's hardware*, and vice versa
- Boundaries between levels are also *fluid*
- One person's hardware is *another person's software*

From the programmer's point of view, how an instruction is actually implemented is *unimportant* (except perhaps for its speed)