

Cheat Sheet — Alpha1 (Updated)

Encoder

- Rotate: navigate UI lines / change values in edit mode
- Press: enter / exit edit mode on selected line
- ``*` indicates active edit mode

BPM Edit

- Available ****only in STOP mode****
- Rotate encoder to BPM line
- Press encoder → enter BPM edit (`\*` appears)
- Rotate encoder → set BPM
- SHIFT (Button 8) → Tap Tempo
- Press encoder again → apply BPM (`\*` disappears)

Transport Buttons

- ****PLAY/STOP**** (Button 1): toggle play / stop
- ****REC**** (Button 3):
- STOP mode → arm recording
- RECORDING:
- Linear mode → destructive overwrite
- Loop mode → overdub
- Press REC again → immediate clean current track

Navigation Buttons

- ****REW**** (Button 4): reserved (future)
- ****FF**** (Button 5): reserved (future)
- ****REW + FF****: MIDI Panic (All Notes Off)

Shift / Tap

- ****SHIFT**** (Button 8):
- Tap tempo in BPM edit mode
- Modifier for future features

Notes

- No long presses used (reserved for future)
- No scrub / FF / REW yet (planned)
- Encoder is primary control surface