



WORK TIME

Time to Complete System

User Manual -- v1.1

Powered by **SRSSupport** | Hosted by **SRSCloud**

VERSION 1.1

ANDROID TABLET

ALL ROLES

CYBER ESSENTIALS 2FA



Philtronics
Limited



What is Work Time?

Work Time is a shopfloor timing system built for Philtronics Ltd. Operators press START when beginning an assembly job and STOP when finished. The system records the duration, workstation, and work order. Supervisors and managers see all active jobs in real time, can message operators directly, and monitor performance against target times.

■ No technical knowledge needed.

If you can use a smartphone, you can use Work Time.

User Roles

Every account has a role controlling what it can see and do.

■ OPERATOR Start/stop own timers View own history Cancel within 60s	■ SUPERVISOR All Operator actions Home dashboard Wall Board (both) Message operators View all history Adjust timers
■ MANAGER All Supervisor actions Dashboard Target Times CSV export Requires 2FA	■ ADMINISTRATOR All Manager actions User management Reset passwords and 2FA Delete timers Requires 2FA

■■ Manager and Administrator accounts require 2FA.

This satisfies Cyber Essentials compliance. Operators and Supervisors use standard password login.

Signing In

Open Chrome on your tablet and go to the Work Time web address your supervisor gave you.

1 Enter your username

Not case-sensitive, e.g. operator1.

2 Enter your password

Characters appear as dots.

3 Tap Sign In

Operators go to the Timer screen. Supervisors and above go to the Home dashboard. Managers and Administrators also complete a 2FA step if configured.

■■ 10 failed attempts locks the device for 15 minutes.

Two-Factor Authentication (2FA)

Setting up 2FA for the first time

A setup screen appears automatically after your first login as a Manager or Administrator.



- 1 Download an authenticator app**
Google Authenticator or Microsoft Authenticator -- free from the App Store or Google Play.
- 2 Scan the QR code shown on screen**
Open the authenticator app, tap +, and scan the code.
- 3 Enter the 6-digit code and tap Enable 2FA**
Once confirmed, 2FA is active on your account.

Logging in with 2FA

After entering your username and password correctly, a Two-Factor Verification step appears. Open your authenticator app, find the Work Time entry, and type the 6-digit code. Tap Verify.

■■ Lost your phone?

Contact your administrator -- they can reset your 2FA so you can set it up on a new device.

Starting a Job Timer

Operators land directly on the Timer screen after login. Fill in the job details and tap the green START button.

- 1 Item Number (required)**
Type or scan the part number. Letters, numbers, hyphens and underscores only, max 40 characters.
- 2 Workstation (optional)**
Type or scan your workstation identifier e.g. WS-01.
- 3 W/O Number (optional)**
Type or scan the Work Order number.
- 4 Time Check (optional)**
Tick for a formally measured timing. Leave unticked for a simple time task.
- 5 Tap the green START button**
The timer starts immediately.

■■ One timer at a time.

Stop your current job before starting a new one. If your session crashed and you try to start a new job, a Resume button appears to restore your previous timer.

Form Fields Explained

Field	Required?	What to enter
Item Number	Required	The part or assembly number. Can be scanned from a barcode or QR code. Letters, numbers, hyphens and underscores only, max 40 characters.
Workstation	Optional	Your workstation or bench e.g. WS-01. Can be scanned. Appears in all history views, exports, and the Wall Board.



W/O Number	Optional	The Work Order number e.g. WO-10042. Can be scanned. Appears in history and CSV exports for traceability.
Time Check	Optional	Marks this as a formally measured timing. Shows as a blue Time Check badge in all history views.

Scanning a Barcode or QR Code

Every field with a Scan button can be filled using the tablet camera.

- 1 Tap the Scan button next to the field you want to fill**
- 2 Allow camera access (first time only)**
Tap Allow when Chrome asks. You will not be asked again on this device.
- 3 Point the camera at the barcode or QR code**
The system reads it automatically within a second or two. Good lighting helps.
- 4 The field fills automatically**
The camera closes. Check the value then continue.

■ Torch button.

In low light a Torch button appears at the bottom of the camera screen.

Stopping a Job Timer

Once started the screen shows a large running clock. Tap STOP as soon as you finish the job. The Workstation and W/O Number are shown beneath the clock as a reminder.

■■■ Timer restores automatically.

If you close the browser or switch devices, your active timer restores when you log back in. The elapsed time is calculated from the server so it is always accurate.

Target Time on the Timer Screen

If a manager has set a target time for the item you are working on, a progress bar appears beneath the running clock showing how much of the target time has elapsed.

Green bar	Under 80% of target time elapsed -- on track
Amber bar	Between 80% and 100% of target -- approaching
Red bar	Target exceeded

The label shows the target time and either the time remaining or how long overdue, updating live every second. If no target is set for this item, the progress bar is not shown.

Cancelling a Timer

Within 60 seconds: Tap Cancel next to STOP. Confirm to cancel or tap Keep Running to go back.

After 60 seconds: Only a Supervisor or above can cancel. They must enter a reason, permanently recorded in the audit trail.

■ **All cancellations are permanently recorded.**

Who cancelled, when, and the reason are stored and cannot be deleted.

Viewing Your History

Tap the menu (three lines) then History to see your completed jobs. The default view shows the last 7 days. Each entry shows the item number, workstation, W/O number, start and end times, duration, and any Time Check or target time badges.

Supervisor: Home Dashboard

Supervisors, Managers, and Administrators land on the Home dashboard after login. It provides an at-a-glance view of the entire shopfloor.

The Home page shows:

Active Jobs	All currently running timers, sorted with overdue jobs first. Each row shows a colour-coded dot, operator name, and duration.
Today at a Glance	Quick stat tiles: Active Now, Completed Today, This Week, Item Types.
Quick Actions	Large buttons linking to Wall Board, Compact Board, Dashboard, Target Times, History, and User Management.
Performance (Manager+)	Today's jobs by item with average time, target, and delta column.
User Status (Admin)	Active accounts, disabled accounts, and managers/admins who have not configured 2FA.

Supervisor: Wall Board

Tap the menu then Wall Board for the full interactive wall board. Each tile shows item number, operator, elapsed time (live), workstation, W/O number, target progress bar, and a Message button.

Green border	Job running normally, under 80% of target elapsed (or under 2 hours if no target)
Amber border	Between 80-100% of target (or 2-4 hours if no target)
Red border	Target exceeded (or over 4 hours if no target)

The board refreshes every 5 minutes. Tap the Refresh button for an instant update.

Supervisor: Wall Board Compact



Tap the menu then Wall Board Compact for the TV display mode. Designed for a large shopfloor monitor -- shows as many tiles as possible with just operator name, item number, and elapsed time. The same colour logic applies. No message buttons -- this view is for display only.

Supervisor: Messaging Operators

Supervisors can send a real-time message to any operator who is currently logged in. The message appears instantly as a popup on the operator screen.

1

Tap the Message button

On the Wall Board tile or the Home dashboard Active Jobs list.

2

Type your message

Up to 500 characters. Press Ctrl+Enter or tap Send Message.

3

Message delivered instantly

A popup appears on the operator screen showing your name, the message, and the time. It stays until dismissed or after 60 seconds.

■■ Operator not logged in?

A confirmation will tell you the message was not delivered. Ask them to log in and try again.

Supervisor: Viewing All History

The History screen has additional filters for Supervisors -- search by Operator ID, Item Number, and Status. Leave fields blank to see all records.

■ Finding stuck timers.

In the Status dropdown select Active (stuck timers) and tap Search. This removes the date filter so any stuck timer appears regardless of when it was started.

Manager: Dashboard

Tap the menu then Dashboard for production statistics across all operators. Use the date range and other filters then tap Search.

The performance table columns:

Avg Actual	The average real time taken for completed jobs in the selected period
Target	The set target time for this item (blank if no target)
Avg Delta	Difference between average actual and target. Green if under, red if over. Blank if no target is set.

Manager: Target Times



Tap the menu then Target Times to manage completion targets per item number. Targets appear on the Wall Board tiles, operator timer screen, and history entries.

1 Tap + Add Target Time

2 Enter or scan the Item Number

The Scan button lets you scan the same barcode the operator uses, eliminating typing errors.

3 Set the target hours and minutes

For example 1 hour 30 minutes.

4 Tap Add Target Time

Saved immediately and visible on all active tiles for that item.

To edit an existing target, tap Edit next to the item. To remove a target, tap the delete button.

Manager: CSV Export

On the Dashboard, set your filters and tap Export CSV. The file downloads to your device and opens in Excel or Google Sheets. The export includes Item Number, Operator, Workstation, W/O Number, Start and End times (UTC and London), Duration, Time Check flag, and Status.

Administrator: Managing Users

Adding a user: Tap Admin, then + New User. Fill in Username, Full Name, Password (8+ characters) and Role. Tap Create User.

Resetting a password: Find the user in the list and tap Reset PW. Enter a new password and tap Reset Password.

Disabling an account: Tap Edit next to the user, untick Account Active, tap Save Changes. The user cannot log in but history records are kept.

Resetting 2FA: Find the user in the list and tap Reset 2FA. Confirm. They are prompted to set up 2FA again on their next login.

■ **Only reset 2FA when you are certain of the user identity.**

Resetting 2FA temporarily reduces account security until the user completes setup again.

Deleting a timer record: Go to History, find the record, and tap the delete button. A confirmation box appears before anything is deleted.

■■ **Deletion is permanent and cannot be undone.**

The timer record and its full audit log are removed from the database permanently.

Troubleshooting



I cannot sign in

Check username and password. Passwords are case-sensitive. After 10 failed attempts wait 15 minutes. If your account may be disabled, contact your administrator.

I am not being asked for my 2FA code

2FA is required for Manager and Administrator accounts only. If you have not set up 2FA yet you will see a setup prompt after login. If you dismissed it with Remind Me Later you will be prompted again at your next login.

The Scan button is not working

Make sure you are using Google Chrome version 83 or later. If camera permission was denied, tap the padlock icon in the address bar, change Camera to Allow, then refresh.

My active timer is not showing after a refresh or on a different device

Tap the menu then Timer. The system restores your active timer automatically. If you see the error but no STOP button, sign out and back in.

I sent a message but the operator did not receive it

The operator must be currently logged in to receive messages. If not connected you will see a notification that the message was not delivered.

The page is not loading

Check the tablet is connected to Wi-Fi. Pull down to refresh. If the problem continues wait 30 seconds and try again.



WORK TIME

Time to Complete System -- User Manual v1.1

Powered by **SRSSupport** | Hosted by **SRSCloud**



Philtronics Ltd