

Work Time

Shopfloor Time-Tracking System

Philtronics Ltd · Version 3.0 · 4 June 2026

Contents

- | | |
|---------------------|------------------------------|
| 1. Introduction | 6. Supervisor Guide |
| 2. Getting Around | 7. Manager Guide |
| 3. Roles and Access | 8. Administrator Guide |
| 4. Operator Guide | 9. Two-Factor Authentication |
| 5. Messages | 10. Tips and Troubleshooting |

1 Introduction

Work Time is the shopfloor time-tracking system used at Philtronics. Operators clock on and off assembly jobs, and supervisors and managers monitor progress, quality and productivity in real time. This manual covers everything the system does, organised by what you need to do in it. If you only operate timers on the shopfloor, the Operator Guide is all you need. Supervisors, managers and administrators have additional sections covering the wallboards, dashboards, reporting and administration.

Who this is for

The system has five levels of access, each building on the one below: Operator, Supervisor, Manager, Administrator and Superuser. What you can see and do depends on your level. The Roles and Access section explains exactly who can do what.

Signing in

- 1 Open the Work Time address in your browser. On a shared shopfloor device this is usually already open.
- 2 Enter your username and password and select **Sign In**.
- 3 Managers and administrators with two-factor authentication enabled will be asked for a 6-digit code from their authenticator app (see Two-Factor Authentication).

Your session stays signed in for the working day. Use **Sign Out** in the menu when you finish on a shared device.

2 Getting Around

The menu button (top-left) opens the navigation drawer. The pages you see depend on your access level. The table below shows where each page lives and who can reach it.

Page	What it is for	Lowest level that sees it
Home	At-a-glance overview of active jobs, today's figures and items needing attention	Supervisor
Timer	Start, run, pause and stop jobs (the operator's main screen)	Operator
History	Look back over completed jobs	Operator
Wall Boards	Live department displays of every active job	Supervisor
Dashboard	Live management overview	Manager
Target Times	Set and adjust target times per item	Manager
Reports	Productivity, quality and build-time reporting and CSV export	Manager
Charts	Visual trends and breakdowns	Manager
Admin	Manage user accounts, items and configuration	Administrator

The **user manual** is always available from the bottom of the navigation drawer.

3 Roles and Access

Access is layered. Each level can do everything the level below it can, plus more. Your level is set by an administrator when your account is created.

Level	Can do
Operator	Run their own timers (start, pause, stop, raise a hand, cancel within the first minute), and view their own history.
Supervisor	Everything an operator can, plus the Home overview and the wall board for their own department, see and respond to raised hands, message operators, and cancel or adjust any timer.
Manager	Everything a supervisor can, plus all departments' wall boards, the Dashboard, Target Times, Reports and Charts, and the Time Check review workflow.
Administrator	Everything a manager can, plus user management, item management and system configuration.
Superuser	Full access, including managing administrator and superuser accounts.

Department scope

Supervisors only see the wall board and raised hands for their own department. Managers and above see every department.

4 Operator Guide

The Timer page is where the day's work is tracked. You can only run one job at a time.

Starting a job

- 1 On the **Timer** page, enter the **Item Number**. You can type it or tap the scan button to read a QR code or barcode with the device camera.
- 2 Optionally add a **Workstation**, **W/O Number** and **Route Card No**. Each can also be scanned.
- 3 Tick **Time Check** only if this run is a measured timing (see the note below). Leave it unticked for an ordinary job.
- 4 Select **Start**. The stopwatch begins and, if a target time is set for the item, you will see it shown beneath the clock.

What is a Time Check?

A Time Check marks the run as a deliberate, measured timing rather than ordinary work. When you complete a Time Check job, it is sent to managers who may use your measured time to set the official target time for that item. Only tick it when you have been asked to perform a timed run.

While a job is running

- **Stop** finishes the job and records the time.
- **Pause** holds the clock (for example for a break) and lets you record a reason; paused time is not counted in the job's total.
- **Raise Hand** signals a supervisor that you need help. Your job jumps to the top of the wall board and supervisors are alerted.
- **Cancel** abandons the job. You can cancel within the first minute yourself; after that, a supervisor must do it.

Working outside normal hours

Outside working hours the system automatically pauses active timers. If you are genuinely working overtime, select the amber **Override — Working Overtime** button that appears, and your timer will keep running and will not be auto-paused again that day.

Today's jobs and history

Completed jobs for the day appear beneath the timer. The **History** page lets you look back over earlier work.

5 Messages

Supervisors and managers can start a short chat with an operator, for example in response to a raised hand. A message slides in on the operator's screen, and either side can reply until the supervisor closes the conversation.

Conversations are live only

Chats are not stored. If either person reloads the page the conversation clears. It is intended for quick, in-the-moment communication, not a record.

6 Supervisor Guide

Supervisors gain the Home overview and their department's wall board, and can respond to operators in real time.

The Home overview

Home gives a live picture of the floor. The **Today at a Glance** card shows active jobs and completed counts, and two attention tiles sit beneath:

- **Raised Hands** — how many operators currently need help. Tap the tile to see who, message them, or lower a hand once they have been helped. The count updates live.
- **Time Checks to Review** **MANAGER** — measured runs waiting to be reviewed (covered in the Manager guide).

Wall Boards

The wall board is a live display of every active job in a department, designed to be shown on a large screen. Jobs are ordered by priority, with anything needing attention floated to the top:

1. Hands raised
2. Active rework
3. Overdue jobs
4. Jobs approaching their target (warning)
5. Jobs on track
6. Paused jobs

A **Compact** version of each board is available for smaller screens. Supervisors see their own department; managers see all departments.

Responding to a raised hand

- 1 When an operator raises a hand, an alert appears and the Raised Hands count rises.
- 2 Open the tile to see the operator, item and workstation.
- 3 Select **Message** to chat, or go to the operator in person.
- 4 Select **Lower** once the operator has been helped (the operator, or "Lower All", can also clear it).

Cancelling or adjusting a job

Supervisors and above can cancel any job (not just within the first minute) and can adjust a job's start or finish time when a correction is needed. Both actions ask for a reason and are recorded.

7 Manager Guide

Managers add full visibility across departments, target-time control, reporting, and the Time Check review workflow.

Dashboard

A live management overview of activity across all departments.

Target Times

Each item can have a target time (hours and minutes). Targets drive the on-track, warning and overdue states on the wall boards and the productivity figures in reporting. On the **Target Times** page you can add or change a target for any item.

The Time Check review workflow

This turns a measured run into a target time. When an operator completes a job with **Time Check** ticked, it becomes a review for managers.

- 1 A live prompt appears for any manager online, and the **Time Checks to Review** tile on Home shows the waiting count, so a review is never missed even if no manager was online at the time.
- 2 Open the tile to see each measured run with the operator, the measured time and the item's current target.
- 3 Adjust the time if you want to add an allowance, then select **Set as Target** to make it the item's new target, or **Dismiss** to leave the target unchanged.

One decision per item

Setting a target from one measured run clears any other pending reviews for the same item, since the target is now decided. Dismissing only clears the run you dismissed.

Reports

The Reports page provides management reporting, each available on screen and as a CSV download:

- **Productivity** — active time against available time per working day, compared with the configurable target percentage.
- **Quality (Right First Time)** — RFT rate and a breakdown of rework by item and operator.
- **Assembly build times** — combined and elapsed build time per item, work order and route card, accounting for multiple operators on one build.
- **Job timings** — the underlying completed-job data.

Charts

The Charts page presents the same kinds of information visually, including productivity, quality and build-time trends.

8 Administrator Guide

Administrators manage the people and reference data the system runs on.

User management

- Create, edit and deactivate user accounts and set each person's access level and department.
- Add users individually, or several at once with a bulk upload.
- Administrators can create accounts up to Manager level; only a Superuser can create Administrator or Superuser accounts, and Superuser accounts are visible only to other Superusers.

Items and configuration

- Maintain the item list used for autocomplete when operators start a job.
- Adjust system configuration, such as the productivity target percentage used in reporting.

Change default passwords

Any seeded default accounts should have their passwords changed before real use.

9 Two-Factor Authentication

Manager, Administrator and Superuser accounts can be protected with two-factor authentication (2FA) using an authenticator app.

Setting it up

- 1 From your account settings, choose to enable two-factor authentication.
- 2 Scan the QR code shown with an authenticator app (such as Google Authenticator or Microsoft Authenticator).
- 3 Enter the 6-digit code the app generates to confirm and switch it on.

After this, signing in asks for a fresh 6-digit code each time, in addition to your password.

10 Tips and Troubleshooting

Situation	What to do
My timer paused on its own	This happens automatically outside working hours. If you are working overtime, use the amber Override button to keep it running.
I can't cancel my job	Operators can only cancel within the first minute. After that, ask a supervisor.
The item won't scan	Type the item number instead; scanning is always optional.
A message didn't reach the operator	The operator must be signed in with the app open for live messages to arrive. If their device was asleep, message again once they are active.
I can't see a page in the menu	Pages are shown by access level. If you need a page you cannot see, ask an administrator about your access level.
A target looks wrong	A manager can correct it on the Target Times page. If it came from a Time Check, the change is recorded with who set it.