Philip Sisa M. sisaphilip@gmail.com

For AM signal;

Average sideband amplitude = (0.05 +0.02)/2 = 0.035V

modulation index = (0.035 * 2)/0.1= 0.7

For FM signal modulation index can not be estimated since the parameters available are suited for AM signal analysis.