


1. FLASHING OF LED USING AT89C51 MICROCONTROLLER USING PROTEUS



The source code for the LED flashing program is as follows:

```
1 ORG 0000H
2 UP: SETB P2.0
3 ACALL DELAY
4 CLR P2.0
5 ACALL DELAY
6 SJMP UP
7 DELAY: MOV R4, #35
8 H1: MOV R3, #255
9 H2: DJNZ R3, H2
10 DJNZ R4, H1
11 RET
12 END
13
```

