


CO1-AT3

Name: K.Naga Venkata Siva


[Reg.no:](#) 192425345

Course : CSA1208


1)




2)



3)



4)



5) i)

GNUSim8085 - 8085 Microprocessor Simulator

File Reset Assembler Debug Help

Registers

Register	Value
A	35
BC	15 25
DE	00 00
HL	30 0F
PSW	00 00
PC	42 16
SP	FF FF
Int-Reg	00

Flag

Flag	Value
S	0
Z	0
AC	0
P	1
C	0

Load me at

```
1 mvi a, 15h
2 sta 2500h
3 mvi a, 20h
4 sta 2501h
5
6 lda 2500h
7 mov b, a
8 lda 2501h
9 add b
10 sta 2502h
11
12 hlt
```

Decimal - Hex Conversion

Decimal: 0 Hex: 0

To Hex To Dec

I/O Ports

0 - + 00

Update Port Value

Memory

0 - + 00

Update Memory

Memory

Address (Hex)	Address	Data
2500	9472	21
2501	9473	32
2502	9474	53
2503	9475	0
2504	9476	0
2505	9477	0
2506	9478	0
2507	9479	0
2508	9480	0
2509	9481	0
250A	9482	0
250B	9483	0
250C	9484	0
250D	9485	0

Line No Assembler Message

0 Program assembled successfully

ii)

GNUSim8085 - 8085 Microprocessor Simulator

File Reset Assembler Debug Help

Registers

Register	Value
A	35
BC	15 25
DE	00 00
HL	30 0F
PSW	00 00
PC	42 16
SP	FF FF
Int-Reg	00

Flag

Flag	Value
S	0
Z	0
AC	0
P	1
C	0

Load me at

```
1 mvi a, 15h
2 sta 2500h
3 mvi a, 20h
4 sta 2501h
5
6 lda 2500h
7 mov b, a
8 lda 2501h
9 add b
10 sta 2502h
11
12 hlt
```

Decimal - Hex Conversion

Decimal: 0 Hex: 0

To Hex To Dec

I/O Ports

0 - + 00

Update Port Value

Memory

0 - + 00

Update Memory

Memory

Address (Hex)	Address	Data
2500	9472	21
2501	9473	32
2502	9474	53
2503	9475	0
2504	9476	0
2505	9477	0
2506	9478	0
2507	9479	0
2508	9480	0
2509	9481	0
250A	9482	0
250B	9483	0
250C	9484	0
250D	9485	0

Line No Assembler Message

0 Program assembled successfully

6)

GNUSim8085 - 8085 Microprocessor Simulator

File Reset Assembler Debug Help

Registers

Register	Value
A	33
BC	45 12
DE	00 00
HL	00 00
PSW	00 00
PC	42 13
SP	FF FF
Int-Reg	00

Flag

Flag	Value
S	0
Z	0
AC	0
P	1
C	0

Load me at

```
1 jmp start
2
3 num1: db 45h
4 num2: db 12h
5
6 start: lda num1
7 mov b, a
8 lda num2
9 mov c, a
10
11 mov a, b
12 sub c
13 sta 2502h
14
15 hlt
```

Decimal - Hex Conversion

Decimal	Hex
0	0

I/O Ports

Port	Value
0	00

Memory

Address	Value
0	00

Start 2502h

Address (Hex)	Address	Data
2502	9474	33
2503	9475	0
2504	9476	0
2505	9477	0
2506	9478	0
2507	9479	0
2508	9480	0
2509	9481	0
250A	9482	0
250B	9483	0
250C	9484	0
250D	9485	0
250E	9486	0
250F	9487	0

Line No Assembler Message

```
0 Program assembled successfully
```