

ActiveFit Elite Pro Smartwatch Documentation

Table of Contents

1. Introduction
 2. Product Overview
 3. Setup Instructions
 4. Using the ActiveFit Elite Pro
 5. Troubleshooting Guide
 6. Maintenance and Care
 7. Safety Information
 8. Warranty and Support
-

1. Introduction

Welcome to the ActiveFit Elite Pro experience, where cutting-edge technology meets uncompromised style. Designed for fitness enthusiasts and tech aficionados alike, this smartwatch offers a seamless blend of functionality and innovation.

2. Product Overview

Key Features:

- **Built-in GPS:** Track your outdoor activities without the need to carry your phone.
- **Heart Rate Monitor:** Real-time monitoring for optimized health tracking.
- **Water Resistance:** Safe for swimming, with resistance up to 50 meters.

- **Bluetooth Connectivity:** Easily pair with your smartphone to receive notifications and sync data.
- **Long Battery Life:** Enjoy up to 10 days of use on a single charge.
- **Fast Charging:** 50% charge in just 30 minutes.
- **Compatibility:** Works with iOS and Android devices.

3. Setup Instructions

Step 1: Charging Your Device

- Connect the magnetic charging cable to a power source.
- Align the charger with the back of your watch until it clicks into place.

Step 2: Device Pairing

- Download the “ActiveFit” app from the App Store or Google Play.
- Turn on Bluetooth on your phone and smartwatch.
- Open the app and select ‘Pair New Device.’
- Follow on-screen instructions to complete the pairing process.

4. Using the ActiveFit Elite Pro

Navigating the Interface

- Swipe up to view notifications.
- Swipe down for quick settings.
- Swipe left or right to access apps and widgets.

Tracking Your Activity

- Select the Activity app for options like running, cycling, or swimming.
- Start an activity to monitor metrics such as distance, pace, and heart rate.

Customizing Your Watch Face

- Long press on the current watch face.
- Swipe through options and tap to select.

5. Troubleshooting Guide

Problem: App Keeps Crashing

- Ensure the app is updated to the latest version.
- Restart your phone and try opening the app again.
- Clear app cache from phone settings.

Problem: Bluetooth Connectivity Issues

- Make sure Bluetooth is enabled on both devices.
- Forget the device in Bluetooth settings and re-pair.
- Restart both devices if issues persist.

Problem: Stuck on Software Update

- Restart the watch by holding the power button for 10 seconds.
- If stuck, perform a factory reset by holding power and volume up buttons.

6. Maintenance and Care

- **Battery Care:** Avoid extreme temperatures and overcharging.
- **Cleaning:** Use a damp cloth to clean the watch regularly.
- **Software Updates:** Regularly check the app for firmware updates.

7. Safety Information

- Avoid exposure to high-velocity water.
- Use only the provided charger to minimize risks of damage.

8. Warranty and Support

Warranty Coverage

- The ActiveFit Elite Pro comes with a 1-year limited warranty covering manufacturing defects.

Customer Support

- Reach out via email at support@activefit.com or call our hotline at 1-800-555-0199.

Thank you for choosing the ActiveFit Elite Pro. Elevate your lifestyle with every step!