

BrewMaster Pro 12-Cup Drip Coffee Maker

Introduction

The BrewMaster Pro 12-Cup Drip Coffee Maker is designed to offer the ultimate in brewing convenience and versatility. With features such as a programmable timer, built-in grinder, and adjustable brew strength, this coffee maker caters to all your coffee cravings.

Key Features

- **12-Cup Capacity:** Ideal for households and small offices.
- **Programmable Timer:** Wake up to a freshly brewed pot with the automatic timer setting.
- **Built-in Grinder:** Freshly grind your beans to enhance flavor.
- **Auto-Shutoff:** Safety feature that turns off the machine after brewing.
- **Adjustable Brew Strength:** Customize your coffee strength for a perfect cup.
- **Warming Plate:** Keeps your coffee warm for up to 2 hours.
- **Removable Water Reservoir:** Easy to fill and clean.

Safety Information

Please read all safety instructions before using your coffee maker:

- Ensure the voltage indicated on the appliance corresponds to your local electrical voltage.
- Always place the coffee maker on a flat, stable surface.
- Do not immerse in water or any other liquid.
- Keep away from children to avoid burns or other injuries.

Setup Instructions

1. **Unpack the Coffee Maker:** Remove all packaging materials and ensure you have all components – the main unit, carafe, filter basket, and user manual.
2. **Assemble the Parts:** Insert the filter basket into its holder.
3. **Add Water:** Remove the water reservoir, fill it to the desired level, and reattach.
4. **Add Coffee Grounds:** If using pre-ground coffee, place it in the filter basket. For whole beans, use the built-in grinder.
5. **Plug In and Turn On the Machine:** Insert the power plug into an outlet and turn the coffee maker on using the power button.

Using the Coffee Maker

1. **Set the Timer:** Use the control panel to program the brewing time.
2. **Select Brew Strength:** Choose between regular and strong settings.
3. **Start Brewing:** Press the 'Brew' button. The machine will alert you when the coffee is ready.

Maintenance and Cleaning

- **Daily Cleaning:** Empty the carafe and filter basket after each use.
- **Weekly Cleaning:** Rinse the water reservoir and clean the exterior with a damp cloth.
- **Descaling:** Descale the machine monthly using a descaling solution to remove mineral build-up.

Troubleshooting

- **Coffee Maker Doesn't Start:** Check the power connection and ensure the water reservoir is filled.

- **Leaking Water:** Ensure the carafe is properly positioned on the warming plate.
- **Coffee Not Hot Enough:** Verify the warming plate is turned on.

FAQ

- **How do I set the programmable timer?** Follow the setup instructions in the manual, or contact customer support if you need further assistance.
- **Is the grinder adjustable?** Yes, you can adjust the grind size by referring to the manual.

Warranty and Support

The BrewMaster Pro comes with a one-year limited warranty covering manufacturing defects. For any issues or inquiries, contact our support team at support@brewmastercoffee.com or call 1-800-COFFEE-HELP.