

Introduction

Welcome to the CleanSweep EcoVac Ultra X, the next generation in advanced vacuum cleaning technology. Designed for efficiency and ease of use, this vacuum provides powerful suction along with eco-friendly operation to meet the needs of modern homes.

Key Features

- **Powerful Suction:** The EcoVac Ultra X boasts a 1300W motor designed to pick up debris and protect delicate floor surfaces.
- **HEPA Filtration System:** Equipped with a HEPA filter, it ensures capture of 99.97% of particles, perfect for allergy sufferers.
- **Dual-Floor Capability:** Seamlessly switches from carpets to hardwood floors with specialized attachments.
- **Extended Battery Life:** Provides up to 70 minutes of uninterrupted cleaning on a single charge.

Specifications

- **Motor Power:** 1300W
- **Battery:** Rechargeable Lithium-Ion
- **Weight:** 6.5 kg
- **Dust Capacity:** 1.5 liters
- **Dimensions:** 45x30x25 cm

Getting Started

1. **Unboxing:** Carefully remove the EcoVac Ultra X and its components from the packaging.
2. **Assembly:** Connect the main unit to the handle with a gentle push until you hear a click.

3. **Charging:** Plug the charger into the port and fully charge the vacuum before first use (about 3 hours).
4. **Storage:** Utilize the wall-mounted dock for convenient storage and charging between uses.

Using the Vacuum

1. **Power On:** Press the power button located on the handle.
2. **Select Mode:** Choose between 'Eco' and 'Max' modes using the toggle switch based on your cleaning needs.
3. **Changing Attachments:** Connect different attachments by sliding them into the nozzle until secure.
4. **Emptying the Dust Bin:** Press the release button to detach the dust bin, open the lid, and dispose of the waste.

Maintenance

- **Filter Cleaning:** Check and clean the HEPA filter every month by rinsing it under water and letting it dry completely.
- **Brush Roll:** Inspect for tangled hair or debris, and remove blockages as needed.
- **Battery Care:** Ensure the vacuum is stored with a moderate charge to maintain battery health.

Troubleshooting

- **Won't Turn On:** Check that the vacuum is charged and ensure all parts are correctly assembled.
- **Loss of Suction:** Examine the dust bin for fullness, and clean or replace the filter if necessary.
- **Charging Issues:** Verify the charger is plugged in properly, or try a different power outlet.

Warranty and Support

The CleanSweep EcoVac Ultra X comes with a 2-year warranty covering parts and labor for manufacturing defects. For warranty claims, please contact our support team with your purchase receipt and product serial number.

Customer Support

- **Phone:** 1-800-CLEANSWEEP
- **Email:** support@cleansweep.com
- **Website:** www.cleansweep.com/support

Your satisfaction is our priority. For additional support, visit our website for FAQs, live chat, and instructional videos.

Conclusion

Thank you for choosing the CleanSweep EcoVac Ultra X. Designed with versatility and performance in mind, it's an ideal choice for maintaining the cleanliness of your home with ease and efficiency.