

CoolSmart 3000 User Manual

Product Overview

Welcome to the future of refrigeration with the CoolSmart 3000. This cutting-edge smart refrigerator connects seamlessly with your smart home system, offering unparalleled convenience and advanced features. With Wi-Fi and Bluetooth connectivity, along with an intuitive mobile app, manage your fridge settings from anywhere.

Key Features

- **Wi-Fi & Bluetooth Connectivity:** Easily connect to your home network for remote access.
- **Smart App Compatibility:** Use with our app for remote monitoring and control.
- **Voice Command Integration:** Compatible with Alexa and Google Assistant.
- **Temperature Control & Monitoring:** Customize temperature zones for optimal food preservation.
- **Energy Efficient:** Boasts an A+++ energy rating.
- **Inventory Management:** Keeps track of what's inside and alerts you when supplies run low.

Setup Guide

1. **Unboxing and Installation**
2. Carefully remove the packaging and transport bolts.
3. Place the refrigerator on a level surface.
4. Plug into a dedicated wall outlet.
5. **Connecting to Wi-Fi**
6. Access the control panel and navigate to 'Network Settings.'
7. Select your Wi-Fi network and enter the password.
8. Confirm the connection within the app.
9. **App Setup**
10. Download the CoolSmart app from the App Store or Google Play.

11. Create an account and link your refrigerator by entering the Model ID found inside the fridge.

Using Your Smart Features

- **Temperature Management:** Adjust using the app or voice commands. The fridge will suggest settings based on contents.
- **Modes:** Enable 'Vacation Mode' or 'Quick Cool' with ease.
- **Inventory:** Scan barcodes with the app to keep track of expiration dates and quantities.

Maintenance and Care

- **Cleaning:** Use a soft cloth and mild detergent. Avoid abrasive cleaners.
- **Filter Replacement:** Replace the water filter every six months. Follow instructions in the app for more information.
- **Software Updates:** Ensure your refrigerator is connected to Wi-Fi to automatically receive updates.

Troubleshooting

1. **Wi-Fi Connection Issues**
2. Ensure the fridge is within range of your router.
3. Check your network password.
4. Reset network settings if needed.
5. **App Not Responding**
6. Restart your smartphone and ensure the app is updated.
7. Uninstall and reinstall the app if freezes occur.
8. **Firmware Update Problems**
9. Confirm stable internet connection.
10. Retry the update manually through Settings > Software Update.

Safety Information

- Use caution around electrical connections and water supply.
- Keep the area around the refrigerator clear of debris and obstructions.

Warranty & Support

All CoolSmart models are backed by a 2-year warranty covering parts and labor. For support, contact us at support@coolsmart.com or call (555) 123-4567. Our agents are ready to assist you 24/7.

For further details, please refer to the included documentation or visit our website.