

EchoWave SB-5000 Soundbar Documentation

Overview

The EchoWave SB-5000 is a state-of-the-art soundbar designed to deliver an exceptional audio experience. With support for the latest sound technologies such as Dolby Atmos, it ensures immersive surround sound from a sleek and compact design. Compatible with the majority of modern TVs, the SB-5000 is perfect for upgrading your home entertainment setup.

Product Components

- EchoWave SB-5000 Soundbar
- Remote Control with Batteries
- HDMI Cable
- Optical Cable
- Power Cord
- Wall Mount Kit
- User Manual

Setup Instructions

1. **Position the Soundbar:** Place the soundbar in front of your TV or mount it on the wall using the provided kit. Ensure it's centered for optimal sound distribution.
2. **Connect via HDMI ARC:**
3. Locate the HDMI ARC port on your TV and connect it to the corresponding port on the soundbar.
4. On your TV settings, select HDMI ARC as the audio output.
5. **Connect via Optical Cable (Alternative):**
6. Use the optical cable to connect from the TV's optical out port to the soundbar.
7. Select 'Optical' from the soundbar's input options.
8. **Power On:** Connect the power cord to an outlet and turn on the soundbar using the remote control.

9. **Audio Settings:** Adjust the TV audio settings if necessary to ensure the soundbar is the selected audio output.

Advanced Features

- **Bluetooth Connectivity:**
 - Pair your smartphone or tablet by navigating to the Bluetooth menu in the soundbar settings and selecting 'EchoWave SB-5000'.
 - Play music wirelessly from your device.
- **Dolby Atmos Support:**
 - Experience three-dimensional sound effects by selecting compatible media sources.
 - Adjust settings via the remote to enhance the surround sound experience.

Troubleshooting Guide

- **No Sound Output:**
 - Verify all cables are securely connected.
 - Ensure the correct input is selected on the soundbar.
 - Check TV settings to confirm the soundbar is selected as the output device.
- **Bluetooth Connection Issues:**
 - Make sure Bluetooth is enabled on your device.
 - Restart the soundbar and attempt pairing again.
- **Remote Control Not Working:**
 - Check and replace remote batteries if needed.
 - Point the remote directly at the soundbar.

Maintenance Tips

- Dust the soundbar regularly with a soft, dry cloth.
- Avoid using harsh chemicals for cleaning.
- Ensure the soundbar is in a well-ventilated space to prevent overheating.

FAQs

- **Is the SB-5000 compatible with all TV models?** Yes, it supports HDMI ARC and optical connections for wide compatibility.
- **Do I need additional cables for setup?** No, the necessary cables are included in the package.

Warranty and Support

The EchoWave SB-5000 comes with a one-year limited warranty. For support, contact us at support@echowaveaudio.com or call 1-800-ECHOWAVE. Our customer service team is available 24/7 to assist you with any inquiries or issues.