

EchoWave Smart Speaker Documentation

Introduction

Welcome to the EchoWave Smart Speaker, your personal assistant for smart living. Featuring crisp sound quality, seamless integration with smart home devices, and intuitive voice control, EchoWave is designed to transform your living space into an interactive environment.

Product Features

- **Wi-Fi Connectivity:** Supports both 2.4GHz and 5GHz networks.
- **Voice Assistance:** Compatible with Alexa and Google Assistant for seamless voice commands.
- **High-Fidelity Sound:** Delivers booming bass and crystal-clear trebles.
- **Smart Home Integration:** Connects with lights, thermostats, and more.
- **Compact Design:** Sleek and portable for any room.

Getting Started

1. Unboxing:

2. Open the packaging and verify all components: EchoWave unit, power adapter, quick start guide.

3. Physical Setup:

4. Place the EchoWave on a stable, flat surface.
5. Connect the power adapter to the EchoWave and plug it into an electrical outlet.

6. Initial Configuration:

7. Download the 'EchoWave Connect' app from your app store.
8. Open the app and create or log into your account.

9. Follow the app instructions to pair your device with the app.

Wi-Fi and Network Configuration

- **Connecting to Wi-Fi:**

- Within the app, go to 'Device Settings'.
- Select 'Wi-Fi Setup'.
- Choose your network and enter the Wi-Fi password.
- Confirm and wait for the connection.

- **Troubleshooting Wi-Fi Issues:**

- Ensure the router is within range.
- Restart the router and speaker if connection fails.
- Check for firmware updates in the app.
- Switch between 2.4GHz and 5GHz if the network is not visible.

Using the EchoWave

- **Voice Commands:**

- Activate by saying 'Hey EchoWave'.
- Examples: 'Hey EchoWave, play my music playlist.'

- **Touch Controls:**

- Adjust volume, play/pause with easy access buttons on the device.

- **Smart Integrations:**

- Connect to smart devices through the 'Smart Home' tab in the app.

Troubleshooting Guide

- **Device Not Turning On:**

- Check power connection and try another outlet.
- Perform a reset by holding the power button for 15 seconds.

- **Firmware Updates:**

- Use the app or visit the support site for downloading updates via USB.

Maintenance and Care

- **Cleaning:**

- Use a dry cloth to clean the exterior.

- **Handling:**

- Avoid exposure to water and store in a cool, dry place.

Warranty and Customer Support

- **Warranty Information:**

- EchoWave comes with a one-year limited warranty.

- **Contact Support:**

- Visit our website or call our toll-free number for assistance.

- **Community Forums:**

- Join our community online for tips and support from other EchoWave users.

Thank you for choosing EchoWave. We hope this smart speaker exceeds your expectations in creating a connected lifestyle.