

# EcoChef Stainless Steel Collection

---

## Product Overview

The EcoChef Stainless Steel Collection is a premium cookware set designed to meet the culinary needs of both amateur cooks and professional chefs. This set includes a variety of essential kitchen pieces: a 1.5-quart saucepan with lid, a 3-quart sauté pan with lid, an 8-quart stockpot with lid, and a 10-inch frying pan. Each piece is crafted from high-quality stainless steel, ensuring durability, superior heat distribution, and a radiant shine that enhances any kitchen decor.

Designed with health and efficiency in mind, the EcoChef Collection features a non-stick, PFOA-free interior coating, providing a healthier cooking surface and effortless food release. The ergonomic handles remain cool to the touch, offering comfort and safety during use.

## Specifications

- **Material:** Premium Stainless Steel with Non-stick Ceramic Coating
- **Compatibility:** Suitable for all stovetops, including induction
- **Oven-Safe:** Up to 550°F (handles excluded)
- **Dishwasher Safe:** Yes
- **Weight:** Approximately 15 lbs total
- **Manufacturer Warranty:** 5 years

# Usage Instructions

## Initial Use

1. Wash all pieces with warm, soapy water to remove any manufacturing residues. Rinse thoroughly and dry.
2. Pre-condition the non-stick surface by applying a light layer of cooking oil. Heat gently for a minute, then cool and wipe with a paper towel.

## Everyday Cooking

- **Saucepan:** Ideal for simmering sauces, prepping grains, and boiling liquids.
- **Sauté Pan:** Use for searing meats, cooking stews, and stir-frying.
- **Stockpot:** Perfect for soups, broths, and boiling pasta.
- **Frying Pan:** Great for pancakes, eggs, and sautéed vegetables.

**Note:** Start cooking on a medium heat setting; the efficient heat distribution will handle the rest. Avoid using metal utensils to preserve the non-stick surface.

## Care and Maintenance

- Always allow cookware to cool before washing.
- Hand wash with gentle dish soap using a soft sponge or cloth. For stubborn stains, soak in warm water before cleaning.
- Avoid abrasive pads or harsh detergents.
- Dry thoroughly after washing to prevent water spots.

## Warranty and Support

The EcoChef Stainless Steel Collection comes with a 5-year warranty against manufacturing defects. To activate your warranty, please register your product on our website within 30 days of purchase. For support, contact us at [support@ecochef.com](mailto:support@ecochef.com) or call 1-800-123-4567.

# Common Issues and Troubleshooting

## Uneven Heating

- Ensure the cookware has a good contact with the flat stovetop surface.
- Verify that you are using the compatible stovetop as mentioned above.

## Non-Stick Surface Wears Over Time

- Avoid high heat settings and metal utensils.
- Recondition the surface as in the Initial Use instructions.

## FAQs

**Q: Can I use these pots and pans on an induction cooktop? A:**

Yes, the EcoChef Collection is designed to be compatible with all stovetops including induction.

**Q: Is the non-stick coating safe at high temperatures? A:** The non-stick coating is safe up to 550°F when used correctly.

**Q: What should I do if there is a manufacturing defect? A:**

Contact our customer support with your purchase details for a warranty claim.

By following these guidelines, your EcoChef Stainless Steel Collection will provide years of high-quality cooking performance.