

Elegance Pro Chrono - User Manual

Introduction

Welcome to the Elegance Pro Chrono. This watch combines timeless elegance with modern technology, offering features that suit both casual and professional settings. Equipped with a durable stainless steel body, it offers precision timekeeping and sophisticated design.

Product Features

- **Water Resistance:** Rated up to 100 meters, suitable for swimming and water sports.
- **Chronograph Functionality:** Includes stopwatch capabilities, ideal for athletes and fitness enthusiasts.
- **Luminous Hands:** Enhanced visibility in low-light conditions.
- **Scratch-resistant Sapphire Crystal:** Ensures clarity and durability.

Specifications

- **Case Diameter:** 42 mm
- **Case Thickness:** 12 mm
- **Strap Width:** 20 mm, adjustable stainless steel
- **Battery Life:** Up to 3 years
- **Movement:** Quartz

How to Use

1. **Setting the Time:** Pull the crown out to position 2, rotate to adjust the time, then push the crown back in.
2. **Using the Chronograph:**
3. Press the top button to start/stop the timer.
4. Press the bottom button to reset.
5. **Adjusting the Strap:** Use the adjusting tool provided to remove links for a perfect fit.

Maintenance and Care

- Regularly clean with a soft, damp cloth.
- Avoid exposing to extreme temperatures and shocks.
- Check seals every two years to maintain water resistance.

Troubleshooting

- **Watch Not Running:** Check the battery; replace if necessary.
- **Condensation Under the Glass:** Have the seals checked and replaced by a professional.
- **Chronograph Not Resetting to Zero:** Follow the manual reset procedure.

Warranty and Support

The Elegance Pro Chrono comes with a 2-year warranty. For support, contact our customer service via email or phone.

FAQs

- **Can the watch be worn while swimming?** Yes, it's water-resistant up to 100 meters.
- **What materials are used for the strap?** High-quality stainless steel.
- **How can I return or exchange the watch?** Follow the return policy on our website or contact support.
- **Payment Issues on Website:** Ensure card details are correct; try using a different device or browser.

Thank you for choosing the Elegance Pro Chrono. Enjoy precision and luxury at your wrist!