

ErgoFlex Pro 3000 - Office Chair

Documentation

Product Overview

The ErgoFlex Pro 3000 is designed for optimal comfort and productivity in the modern workplace. With key ergonomic features tailored to various user needs, this chair combines style, durability, and flexibility.

Specifications

- **Dimensions:**
 - Seat Height: Adjustable from 18 to 22 inches
 - Width: 26 inches
 - Depth: 24 inches
- **Weight Capacity:** 300 lbs
- **Materials:**
 - Base: Reinforced nylon plastic
 - Backrest: Breathable mesh
 - Seat Cushion: High-density foam
- **Colors Available:** Black, Gray, Blue

Key Features

- **Ergonomic Design:**
 - Adjustable lumbar support
 - Synchro-tilt mechanism
 - Multifunctional armrests (height and depth adjustable)
- **Ease of Use:**
 - Smooth-rolling casters suitable for all floor types

Assembly Instructions

1. **Unpack the Chair Components:**
2. Ensure all parts listed in the manual are present.

3. **Attach the Casters:**

4. Insert each caster into the base until it clicks.

5. **Install the Gas Lift:**

6. Place the gas lift into the center of the base.

7. **Attach the Seat Mechanism:**

8. Use the provided Allen wrench to secure the seat mechanism to the seat cushion.

9. **Assemble the Backrest:**

10. Align the backrest with the seat bracket and secure with screws.

Usage Guide

• **Adjusting Seat Height:**

- Pull up the lever under the seat to raise or lower the chair.

• **Adjusting Armrests:**

- Press the button on the armrest to adjust height or slide forward/backward.

• **Lumbar Support Adjustment:**

- Slide the lumbar support up or down to the desired position.

Troubleshooting

• **Chair Does Not Recline:**

- Ensure the recline lock is disengaged.

• **Height Adjustment Not Working:**

- Check if the gas lift is correctly seated and try applying slight pressure to reactivate.

• **Excessive Squeaking:**

- Use a silicone-based spray at swivel points.

Warranty and Support

• **Warranty:**

- 5-year coverage for structural repairs
- 2-year coverage for upholstery

• **Returns and Exchanges:**

- Return eligible within 30 days of purchase. To initiate a return, contact support with your order number.

Customer Support

For further assistance, contact our support team at support@ergoflex.com or call us at 1-800-555-3300. Additional resources and FAQs are available on our website at www.ergoflex.com/support.

Thank you for choosing the ErgoFlex Pro 3000. Your comfort and satisfaction are our top priorities.