

ErgoMax Deluxe Chair - User Documentation

Product Overview

The ErgoMax Deluxe Chair is designed to offer exceptional comfort and support. Featuring a modern ergonomic design, this chair is perfect for extended hours at the desk, whether working from home or in an office environment.

Key Features

- **Ergonomic Design:** Supports natural body posture.
- **Adjustable Lumbar Support:** Customizes back support.
- **Height Adjustment:** Easily adjustable pneumatic height.
- **Breathable Mesh Back:** Enhances airflow and comfort.
- **360-Degree Swivel:** Allows free movement.
- **Sturdy Frame:** Supports weights up to 300 lbs.

Assembly Instructions

1. **Unpack Components:** Carefully remove all components from the packaging.
2. **Assemble Base:** Attach wheels to the base, ensuring they click into place.
3. **Attach Gas Cylinder:** Place the gas cylinder firmly into the center of the base.
4. **Seat Assembly:** Secure the seat onto the gas cylinder, ensuring the seat is level.
5. **Install Armrests:** Align and secure armrests to the sides of the seat using the provided bolts.
6. **Attach Backrest:** Align the backrest with the brackets on the seat, and secure them using the long screws.

Refer to diagram 1 for assembly visuals.

Usage Guidelines

- **Adjusting Height:** Pull the lever under the seat to adjust height.
- **Adjusting Lumbar Support:** Turn the knob on the side of the backrest.
- **Swivel & Recline:** Use the tilt tension knob to adjust recline strength.

Maintenance and Care

- **Cleaning:** Use a damp cloth to clean the surfaces.
- **Maintenance:** Regularly check for loose bolts and tighten as needed.

Troubleshooting

- **Squeaky Wheel:** Lubricate with silicone spray.
- **Height Won't Adjust:** Ensure the pneumatic lever is fully engaged.
- **Backrest Looseness:** Tighten screws on backrest brackets.

Warranty and Returns

Your ErgoMax Deluxe Chair is covered by a 2-year warranty. If any issues occur due to manufacturing defects, contact our customer support for assistance. Ensure you have your order number for quicker service.

Customer Support

For further assistance, contact us at support@homefurnish.com or call 1-800-555-CHAIR.

We hope you enjoy your ErgoMax Deluxe Chair!