

FitMaster Pro 2024 User Manual

Introduction

Welcome to the FitMaster Pro 2024, your ultimate companion for tracking your fitness journey! Packed with cutting-edge technology and versatile features, the FitMaster Pro 2024 helps you monitor your health metrics with precision and ease. Whether you're a seasoned athlete or someone just beginning to explore the benefits of a healthier lifestyle, this device is designed to support your goals.

Getting Started

Unboxing Your FitMaster Pro 2024

- **Inside the box:**
- FitMaster Pro 2024 device
- Magnetic charging cable
- Quick start guide
- Warranty card

Charging the FitMaster Pro 2024

1. Connect the magnetic charging cable to the device.
2. Plug the USB end into a computer or a USB power adapter.
3. A battery icon will appear, indicating charging status.
4. Charge for at least 2 hours before first use.

Pairing with Your Smartphone

- **Compatible with:**
- Android 8.0 or above

- iOS 13 or later
- **Pairing Steps:**
- Download the 'FitCompanion' app from Google Play Store or Apple App Store.
- Open the app and create an account.
- Turn on Bluetooth on your phone.
- Select 'Pair New Device' in the app and follow the on-screen instructions.

Using Features

Heart Rate Monitoring

- Continuous monitoring with real-time updates on your heart rate.
- To view your heart rate data, open the FitCompanion app and navigate to 'Health Metrics'.

Step Counting

- Tracks your steps throughout the day and gives detailed insights into your activity levels.
- View daily, weekly, and monthly step counts via the app.

Sleep Analysis

- Automatically detects when you fall asleep and provides analysis of your sleep patterns.
- Check sleep duration, quality, and suggestions for improvement through the app.

Smart Notifications

- Receive calls, texts, and app notifications on your FitMaster Pro 2024.
- Customize notification settings in the app under 'Preferences'.

Water Resistance

- Water-resistant up to 50 meters, suitable for swimming and showering.

Maintenance and Care

- Regularly clean the device with a soft, damp cloth.
- Avoid exposure to extreme heat or cold.
- Update the software regularly via the app to ensure optimal performance.

Troubleshooting Guide

Syncing Issues

- Ensure Bluetooth is enabled on your phone.
- Restart both the device and the phone.
- Re-pair the device by following the pairing instructions.

App Crashes

- Clear the app cache from your phone's settings.
- Uninstall and reinstall the app if the problem persists.

Battery Performance

- For optimal battery life, fully charge the device regularly and avoid using while charging.

FAQs

Q: How do I update the device firmware? A: Go to the FitCompanion app, select 'Device Settings', and follow the instructions for firmware updates.

Q: Is the strap replaceable? A: Yes, compatible accessory straps are available on our website.

Q: How do I activate the extended warranty? A: Register your device on our website under 'My Account' within 30 days of purchase.

Contact Support

For further assistance, reach out to our customer support team: -

Phone: 1-800-FIT-MSTR - **Email:** support@fitmaster.com - **Live**

Chat: Available on our website from 8 AM to 8 PM EST.

Thank you for choosing FitMaster Pro 2024. Happy tracking!