

Harmony 4-Piece Patio Set

Documentation

Introduction

Welcome to your new outdoor living experience with the Harmony 4-Piece Patio Set, designed to bring style and comfort to your patio. Featuring a sleek modern design, this set includes a sofa, two chairs, and a coffee table, perfect for relaxing or entertaining under the open sky.

Product Features

- **Materials:** Made from rust-resistant aluminum and weather-resistant fabric, ensuring durability and longevity.
- **Design:** Contemporary aesthetics with a minimalist approach to maximize space and comfort.
- **Color Options:** Available in three colors: Ocean Blue, Garden Green, and Classic Gray.
- **Dimensions:**
 - Sofa: 78" W x 32" D x 34" H
 - Chairs: 32" W x 32" D x 34" H
 - Table: 48" L x 24" W x 18" H
- **Weight Capacity:** Each piece can hold up to 250 lbs.

Assembly Instructions

1. **Unpacking:** Carefully remove all components from packaging. Check against the provided parts list.
2. **Sofa Assembly:**
3. Attach sofa arms using the labeled screws and an Allen wrench (included).

4. Secure the backrest to the arms.
5. **Chair Assembly:**
6. Attach chair legs to the seat frame, ensuring they are firmly screwed in.
7. Attach backrest and adjust for stability.
8. **Table Assembly:**
9. Connect table legs to the tabletop.
10. Tighten screws and check for stability.
11. **Final Check:** Make sure all screws are tightened securely, and components are stable.

Maintenance Tips

- **Cleaning:** Clean metal surfaces with a mild detergent and water. Avoid abrasive cleaners.
- **Fabric Care:** Removable cushion covers are machine washable. Use cold water and air dry.
- **Storage:** Store furniture in a dry area during extreme weather conditions to prevent damage.

Warranty Information

The Harmony 4-Piece Patio Set comes with a 3-year limited warranty covering manufacturer defects. For a warranty claim, contact our support with proof of purchase and photographs of the issue.

Troubleshooting

- **Delayed Shipping:** If tracking shows delays, contact our support with your order number. We'll expedite communication with the carrier.
- **Missing Parts:** Refer to the parts list and contact support if parts are missing.
- **Assembly Issues:** Ensure all parts are aligned correctly. If problems persist, see our online video guide or contact support.

Customer Support

For further assistance, reach out to our customer care team at support@brownbox.com or call 1-800-555-0199. Our representatives are available Monday through Friday, 8 a.m. to 6 p.m. EST.

Thank you for choosing the Harmony 4-Piece Patio Set. We hope it brings joy and relaxation to your outdoor space.