

HomeSync Hub 3000 Documentation

Product Overview

The HomeSync Hub 3000 is a cutting-edge smart home device designed to bring convenience and efficiency to your household. Featuring seamless automation capabilities, it integrates with various smart home ecosystems, offering control over lights, thermostats, and security systems.

- **Key Features:**

- Wi-Fi and Bluetooth connectivity
- Voice control compatibility with virtual assistants like Alexa and Google Assistant
- User-friendly mobile app for remote control
- Energy-efficient design

Technical Specifications

- **Model Number:** HSH3000
- **Connectivity:** 802.11 a/b/g/n/ac Wi-Fi, Bluetooth 5.0
- **Power Supply:** AC 100-240V, 50/60 Hz
- **Dimensions:** 6 x 4 x 1.5 inches
- **Weight:** 0.75 lbs

Setup Guide

1. **Unbox the Device:** Carefully remove the HomeSync Hub 3000 from the packaging, ensuring all components are included.
2. **Power Up:** Connect the device to a power outlet using the included adapter.
3. **Connect to Wi-Fi:**
4. Open the HomeSync app on your smartphone.
5. Follow the onscreen instructions to enter your Wi-Fi credentials.
6. Press the Wi-Fi setup button on the device until the LED indicator blinks.
7. Confirm connection within the app.

8. **Pair with Smartphone:**

9. Ensure Bluetooth is enabled on your phone.
10. In the app, select 'Pair New Device' and follow pairing prompts.

11. **Integration with Voice Assistants:**

12. Follow in-app guides to link with Alexa or Google Assistant.

Troubleshooting

• **Wi-Fi Connectivity Issues:**

- Ensure the device is within range of the router.
- Restart your router and attempt reconnection.
- Check for firmware updates in the app.
- Reset network settings by holding the reset button for 10 seconds.

• **Device Unresponsive:**

- Verify power supply at the outlet.
- Try a different power cable if unresponsive.
- If issues persist, contact support for a replacement if under warranty.

Maintenance

- Regularly update firmware via the HomeSync app.
- Clean the device with a soft, dry cloth to prevent dust accumulation.
- Avoid placing the device in areas with extreme temperature variations.

Warranty and Support

- **Warranty Period:** 2-year limited warranty for defects
- **Customer Support:** Available via phone, email, or chat at our website brownsupport.com
- **Replacement:** Eligible devices under warranty can be replaced with proof of purchase.

For further assistance, visit our FAQ section in the HomeSync app or contact customer support at any time.

End of Documentation