

NetCom FastWave AC1900 Wi-Fi Router User Manual

Table of Contents:

1. Introduction
 2. Key Features
 3. Hardware Overview
 4. Setup Instructions
 5. Troubleshooting Guide
 6. Technical Specifications
 7. Maintenance Tips
 8. Safety and Warranty Information
-

1. Introduction

Welcome to your new NetCom FastWave AC1900 Wi-Fi Router. This high-speed, dual-band router is designed to enhance your internet experience with reliable connectivity and easy setup.

2. Key Features

- **High-Speed Connectivity:** Supports speeds up to 1900 Mbps to seamlessly stream, game, and browse without interruptions.
- **Dual-Band Support:** Offers both 2.4GHz and 5GHz bands to minimize interference and optimize speed.
- **Advanced Security:** Built-in firewall and WPA3 encryption to protect your network.
- **User-Friendly Interface:** Easy setup with an intuitive web-based configuration page.

3. Hardware Overview

- **Ports:** 4x Gigabit Ethernet LAN ports, 1x Gigabit WAN port.
- **Buttons:** Power, WPS, Reset.
- **LED Indicators:** Power, Internet, LAN, Wi-Fi status indicators.

4. Setup Instructions

Unboxing

1. Remove the router, power adapter, Ethernet cable, and manual from the packaging.

Connecting Your Hardware

1. Connect the provided Ethernet cable to your modem and the router's WAN port.
2. Plug in the router to a power source and turn it on using the Power button.

Configuration

1. Connect a device to the default Wi-Fi network or use a LAN cable.
2. Open a web browser and enter `http://192.168.1.1`.
3. Log in with the default credentials provided in the manual.
4. Follow the on-screen instructions to configure your Wi-Fi name and password.

5. Troubleshooting Guide

Common Issues and Solutions

- **Intermittent Connectivity:** Try repositioning the router to reduce interference. Update the firmware via the settings page if issues persist.
- **Slow Internet Speeds:** Disconnect unused devices. Change the Wi-Fi channel in the settings to reduce overlap with other networks.
- **Setup Difficulties:** Ensure all cables are not damaged. Restart the router and follow the setup process again.

6. Technical Specifications

- **Wi-Fi Standards:** IEEE 802.11ac/n/g/b/a

- **Frequency Bands:** 2.4GHz and 5GHz
- **Speed:** Up to 1300 Mbps on 5GHz, 600 Mbps on 2.4GHz
- **Dimensions:** 9.8 x 6.8 x 1.6 inches
- **Weight:** 0.9 lbs

7. Maintenance Tips

- **Firmware Updates:** Regularly check the settings page for firmware updates to ensure optimal performance and security.
- **Network Security:** Change passwords periodically and enable guest networks for visitor access.
- **Router Placement:** Keep the router elevated and central to get the best range and performance.

8. Safety and Warranty Information

- **Safety Precautions:** Avoid exposure to high heat and moisture. Ensure ventilation is not obstructed.
- **Warranty:** Comes with a 2-year warranty covering manufacturing defects. Refer to our website for warranty claims and service centers.

For further assistance, please visit our website or contact customer support. Thank you for choosing NetCom for your networking needs.