

# NetConnect Pro 7500 User Guide

## Product Overview

The NetConnect Pro 7500 is a state-of-the-art dual-band router designed to deliver seamless internet connectivity across your home or office. With enhanced security features and robust performance, it is perfect for streaming, gaming, and buffering-free browsing.

- **Wi-Fi Technology:** 802.11ac
- **Frequency Bands:** Dual-band 2.4GHz and 5GHz
- **Maximum Speed:** Up to 1900Mbps
- **Ports:** 4 x LAN, 1 x WAN, USB 3.0
- **Security:** WPA/WPA2 encryption

## Setup Instructions

1. **Unboxing and Placement:**
2. Remove the NetConnect Pro 7500 and components from the box.
3. Place the router in a central location to maximize coverage.
4. **Connecting to the Modem:**
5. Connect the WAN port of the router to the modem using the Ethernet cable provided.
6. Plug the power adapter into the router and a power outlet.
7. **Initial Configuration:**
8. Use a computer or mobile device to connect to the default Wi-Fi network (SSID and password on the router's label).
9. Open a web browser and enter `192.168.1.1` to access the setup page.
10. Follow the on-screen instructions to complete the setup.

## Troubleshooting Connectivity Issues

1. **Wi-Fi Disconnection:**
2. **Restart the Router:** Unplug for 20 seconds before reconnecting.
3. **Check Positions:** Ensure there are no obstructions.
4. **Update Firmware:** Go to the settings page and navigate to `Firmware Update`.
5. **Interference:**
6. Move the router away from electronic devices like microwaves or wireless phones.
7. Change the Wi-Fi channel to reduce congestion.
8. **Device Not Connecting:**
9. Perform a factory reset by holding the reset button for 10 seconds.
10. Reconfigure the settings using the initial setup guide.

## Advanced Settings

- **Parental Controls:**

- Access `Advanced Settings` > `Parental Controls` to restrict content and time usage.

- **Guest Network:**

- Enable a guest network under `Wireless Settings` to keep your main network secure.

- **Security Settings:**

- Change default username and password.
- Activate `WPA2` in the `Security Settings` for higher protection.

## **Maintenance Tips**

- Regularly check for firmware updates to ensure optimal performance.
- Keep the router in an open area to decrease overheating risk.

## **Customer Support**

For additional assistance, contact NetConnect Support: - **Phone:** 1-800-555-0199 - **Email:** [support@netconnect.com](mailto:support@netconnect.com) - **Live Chat:** Available on our website weekdays 9 AM to 7 PM EST

Keep this guide handy for future reference and enjoy your seamless networking experience with the NetConnect Pro 7500!