

Rustic Oak Dining Table Documentation

Product Overview

The Rustic Oak Dining Table is a finely-crafted piece of furniture designed to add a touch of elegance and warmth to any dining area. Constructed from high-quality solid oak, this table measures 72 inches long, 36 inches wide, and 30 inches high, providing ample space for family gatherings and dinner parties.

Key Features

- **Premium Solid Oak Wood:** Known for its strength and durability, the oak surface is both scratch-resistant and appealingly grainy.
- **Expandable Leaf:** Extend the table to accommodate additional guests with a simple pull-out leaf mechanism.
- **Rustic Finish:** A weathered finish gives the table a charming rustic appeal, enhancing any room's decor.
- **Easy Assembly:** Designed for quick and simple assembly with minimal tools required.

Assembly Instructions

Required Tools

- Phillips screwdriver (not included)
- Allen wrench (included)

Step-by-Step Guide

1. **Unpack All Components:** Carefully open the packaging, ensuring all parts are accounted for per the included parts list.
2. **Attach Legs:** Using the provided screws and Allen wrench, attach the four legs to the underside of the table. Each leg should be securely fitted into its corresponding corner bracket.

3. **Install the Leaf Mechanism:** Align the extendable leaf with the table's internal grooves, and gently slide into position until secure.
4. **Check Stability:** Ensure all screws are tight and the table stands level without rocking.
5. **Final Inspection:** Inspect for any loose parts or misalignments before placing in the desired location.

Care and Maintenance

- **Regular Dusting:** Use a soft, dry cloth to dust regularly, keeping the oak surface free from debris.
- **Cleaning:** For spills, use a damp cloth to wipe clean, avoiding harsh chemicals that may damage the wood.
- **Polishing:** Use a quality furniture polish occasionally to maintain the luster of the rustic finish.

Troubleshooting

- **Damaged Surface:** Contact customer service immediately with your order number to arrange for a replacement or repair.
- **Misaligned Leaf:** If the extension leaf isn't aligning correctly, ensure the grooves are clear of debris and re-seat the leaf properly.
- **Loose Legs:** Regularly check and tighten leg screws to prevent wobbling.

Warranty and Support

The Rustic Oak Dining Table comes with a 2-year warranty covering defects in materials and workmanship. To activate your warranty, register your purchase on our website using your order number.

For support, contact our customer service team at any time for guidance on assembly, care, or troubleshooting. We are dedicated to ensuring your complete satisfaction with our product.

Contact Information

- **Customer Service:** 1-800-123-4567
- **Email Support:** support@furnitureco.com
- **Website:** www.furnitureco.com

By following this documentation, you can ensure a smooth setup and long-lasting enjoyment of your Rustic Oak Dining Table. Thank you for choosing our product.