

Welcome to the TechPro X200 Laptop User Guide. This document aims to provide comprehensive information to help you set up and use your TechPro X200 laptop efficiently.

Product Overview The TechPro X200 is a high-performance laptop designed for both professional and personal use. With advanced features such as a 15.6-inch Full HD display, Intel i7 processor, and 16GB RAM, it ensures seamless multitasking and powerful computing capabilities.

Features - 15.6-inch Full HD LED Display - Intel Core i7 Processor - 16GB DDR4 RAM - 512GB SSD Storage - Built-in Fingerprint Reader - Backlit Keyboard

Initial Setup 1. Unbox your TechPro X200 and place it on a stable surface. 2. Connect the power adapter to the laptop and plug it into a power source. 3. Press the power button to turn on the device. 4. Follow the on-screen instructions to complete the initial setup process, including language settings, Wi-Fi connectivity, and user account creation.

Software Installation 1. Your TechPro X200 comes pre-installed with basic software. To install additional applications, access the supplied software via the laptop's app store. 2. If you encounter an 'Installation package incomplete' error, download the software directly from our website: www.techpro.com/downloads. 3. Follow the prompts to successfully install your desired applications.

Updating Applications Keeping your applications up-to-date is vital for optimal performance. 1. Go to 'Settings' > 'Updates & Security'. 2. Select 'Check for updates' to allow the system to fully update applications and drivers.

Warranty Information Your TechPro X200 is covered under a one-year limited warranty, which includes accidental screen damages. To query your warranty status, visit: www.techpro.com/warranty-status and enter your order information.

Troubleshooting Guide - Application Crashes: If an application crashes, ensure it's updated to the latest version. Restart your laptop and try reopening the application. - **Internet Connectivity Issues:** Check Wi-Fi settings to confirm that you're connected to the correct network. Restarting your modem might also help. - **Screen Display Problems:** Adjust brightness settings or update graphic drivers via 'Device Manager'.

Customer Support For further assistance, contact our support team via chat or phone. Visit www.techpro.com/support for more details.

Thank you for choosing TechPro X200 as your computing partner. We are committed to providing you with best-in-class service and support.