

Product Overview

Welcome to the future of outerwear with the ThermoTech Smart Heated Jacket—a revolutionary garment designed for ultimate comfort and convenience. Employing advanced heating technology and smart functionality, this jacket ensures warmth and style in any weather.

Key Features

- **Smart Heating System:** Three customizable heat settings to tailor warmth levels.
- **Water-Resistant Fabric:** Keeps you dry and comfortable in wet conditions.
- **Long-Lasting Battery:** Enjoy up to 10 hours of warmth on a single charge.
- **USB Charging:** Easily recharge the battery via USB.
- **App Connectivity:** Control heat settings and monitor battery life via the ThermoTech app.

Getting Started

Initial Setup

1. **Unpack the Jacket:** Carefully remove the jacket from packaging.
2. **Charge the Battery:** Connect the power bank to a charger using the provided USB cable. Charge until the indicator turns green.
3. **Install the App:** Download the ThermoTech app from your device's app store.
4. **Connect via Bluetooth:** Turn on Bluetooth, open the app, and follow the on-screen prompts to sync your jacket.

Wearing the Jacket

- **Adjust Fit:** Use the adjustable straps for a comfortable fit.
- **Activate Heating:** Press the power button on the jacket or control via the app. Select high, medium, or low heat.

Daily Use

- **Temperature Adjustment:** Use the app or jacket controls to adjust heat levels as needed.
- **Weather Adaptability:** Utilize the jacket's water-resistant properties in light rain or snow.
- **Charging:** Plug in the USB cable through the discreet power port for easy charging.

Maintenance and Care

Cleaning

- **Machine Washable:** Use a gentle cycle with cold water. Remove the battery before washing.
- **Drying:** Hang to dry; do not tumble dry.

Storage

- Store in a cool, dry place.
- Ensure the jacket is fully dry before storage.

Warranty and Support

- **Warranty:** The jacket comes with a 2-year warranty covering manufacturing defects.
- **Support:** Contact us at support@thermotech.com or call 1-800-555-0199 for assistance.

Troubleshooting Guide

- **Not Heating:** Ensure the battery is charged. Check connections within the app.
- **Connectivity Issues:** Reset Bluetooth and reconnect through the app.
- **Battery Issues:** If the battery doesn't hold a charge, contact support for replacement.

FAQs

- **Q:** How do I return my jacket? **A:** Contact customer service within 30 days for return instructions.
- **Q:** Can I wear it in the rain? **A:** Yes, the jacket is water-resistant but should not be submerged.
- **Q:** What if the size is incorrect? **A:** We offer easy exchanges. Contact customer service for assistance.

Enjoy warmth and innovation with the ThermoTech Smart Heated Jacket. Thank you for choosing us!