

VistaCapture Pro 4K Camera

Documentation

Introduction

Welcome to the user guide for the VistaCapture Pro 4K, an advanced camera designed for capturing stunning visuals with crystal-clear quality. This camera is ideal for both professional photographers and enthusiastic hobbyists who desire seamless and high-resolution video and photo capture.

Features & Specifications

- **Resolution:** 4K UHD Video – 3840 x 2160 pixels, Full HD 1080p, HD 720p
- **Frame Rate:** 4K at 30fps, Full HD at 60fps, HD at 120fps for slow motion
- **Sensor:** 24MP APS-C CMOS Sensor
- **Lens Mount:** Interchangeable lenses with 18-55mm kit lens included
- **Connectivity:** Built-in Wi-Fi and Bluetooth for file transfer and remote control
- **Display:** 3-inch articulating touchscreen LCD
- **Battery Life:** Approximately 400 shots per charge
- **Storage:** Dual SD card slots
- **Weight:** 560 grams (body only)

Unboxing & Setup

1. **Unboxing:** Carefully remove all components from the box. The package includes:
2. VistaCapture Pro 4K Camera Body
3. 18-55mm Lens
4. Battery and Charger
5. USB Cable
6. Lens Cap

7. Shoulder Strap

8. User Manual

9. **Battery Installation:**

10. Open the battery compartment on the bottom of the camera.

11. Insert the battery and secure the compartment.

12. **Lens Attachment:**

13. Align the lens with the mounting mark on the camera body.

14. Twist the lens clockwise until it clicks into place.

15. **Power On:**

16. Press the power button located on the top right of the camera.

Operating Your Camera

- **Taking Photos:** Switch to photo mode via the mode dial. Use autofocus by half-pressing the shutter button.
- **Recording Video:** Select video mode. Ensure desired resolution and frame rate settings, then press the record button.
- **Using Wi-Fi:** Enable Wi-Fi in the settings menu. Connect your smartphone using the VistaCapture app.

Maintenance & Care

- **Cleaning:** Use a microfiber cloth for the lens and body. Avoid using solvents.
- **Storage:** Store the camera in a dry, cool place. Use a camera bag for protection.

Troubleshooting & FAQs

- **Issue: Payment Errors during Purchase**
 - Ensure accurate billing information and try a different browser.
- **Issue: No Wi-Fi Connection**
 - Restart the camera and confirm network settings.

Contact & Support Information

- **Customer Support:** Available 24/7 at support@vistacapture.com or call 1-800-555-0199.

Appendices

- **Warranty:** One-year limited warranty covering manufacturing defects.
- **Glossary:**
- **4K:** High-definition video standard.
- **APS-C:** A sensor size standard in cameras.

Thank you for choosing VistaCapture Pro 4K. We hope you enjoy capturing life's moments with unparalleled clarity.