

WindGuard Pro Smart Windbreaker User Manual

Product Overview

The WindGuard Pro Smart Windbreaker combines sleek design with cutting-edge technology to deliver ultimate weather protection and smart functionalities. Manufactured with a hybrid of lightweight polyester and a durable nylon shell, this jacket is both water-resistant and windproof. Available in sizes XS through XXL and in colors black, navy, and olive, it adapts to both casual and outdoor environments.

Key Features:

- Integrated heating elements for adjustable warmth
- Bluetooth connectivity for app control
- Hidden pockets with space for a battery pack
- Reflective strips for night-time safety

Usage Instructions

Wearing the Jacket

1. Slip the jacket on and ensure a comfortable fit by adjusting the drawstrings at the hood and hem.
2. Use the adjustable velcro cuffs to keep the wind out.

Connecting to Smart Features

1. Charge the included battery pack and insert it into the designated pocket.
2. Power on the jacket by pressing the button located inside the left pocket.

3. Pair the jacket with the WindGuard app on your smartphone by enabling Bluetooth and following on-screen instructions.
4. Use the app to adjust heat settings, monitor battery life, and check environmental conditions.

Care Instructions

- Wash the jacket on a cold, gentle cycle to avoid damaging the heating elements.
- Disconnect the battery pack before washing.
- Air dry the jacket or tumble dry on low heat.

Troubleshooting

Connectivity Issues

- **Problem:** Unable to connect to the jacket via Bluetooth.
- **Solution:** Ensure the battery pack is charged and correctly connected. Restart both the jacket and smartphone. If issues persist, reinstall the WindGuard app.

Heating Elements Malfunction

- **Problem:** Heating elements do not warm up.
- **Solution:** Check that the battery pack is charged and connected. If the problem continues, contact WindGuard support for assistance.

Warranty and Support

Your WindGuard Pro is covered by a two-year warranty including all manufacturing defects. For support, call our helpline at 1-800-WG-PRO or email support@windguardpro.com.

Frequently Asked Questions (FAQs)

Can I return the jacket if it doesn't fit?

Yes, you can return the jacket within 30 days of purchase if it is in original condition.

What happens if I'm overcharged?

Contact customer support with your order number for a swift resolution and refund.

How do I track my jacket's shipment?

You will receive a tracking number via email once your order is dispatched.

For all other inquiries, refer to the contact page on our website or reach out to our support team.