

WorkPro Flexi Desk Documentation

Introduction

Welcome to the comprehensive guide for your new WorkPro Flexi Desk. Designed with flexibility and functionality in mind, the WorkPro Flexi Desk is perfect for home offices and corporate workspaces alike. This desk offers a sleek design with modern features that cater to a variety of work styles and environments.

Product Specifications

- **Dimensions:**

- Length: 60 inches
- Width: 30 inches
- Height: 29 inches (adjustable range from 27 to 32 inches)

- **Materials:**

- Desktop: Premium oak veneer
- Frame: Powder-coated steel

- **Weight:** 90 pounds

- **Color Options:**

- Natural Oak
- Espresso Brown

- **Features:**

- Adjustable height with easy-access levers
- Built-in cable management system
- Three spacious drawers including a lockable central drawer
- Scratch-resistant surface

Assembly Instructions

1. **Unpack All Components:** Lay out all parts, ensuring you have the desktop, frame, legs, screws, and assembly tools included.
2. **Attach the Legs:** Use the provided screws to attach the legs to the corners of the underside of the desktop.

3. **Install the Frame:** Align the frame with the leg attachments and secure with screws using the provided hex key.
4. **Adjust Height Settings:** Stand the desk upright and adjust the height by releasing the side levers and moving to the desired level before locking them.
5. **Cable Management Setup:** Utilize the slots and clips underneath the desktop to organize cables.

Usage Tips

- **Adjusting Height:** Pull and hold the side levers to smoothly raise or lower the desk to your preferred height. Ensure levers are securely locked once adjusted.
- **Organizing Cables:** Feed cables through the management slots to keep your workspace tidy and efficient.
- **Drawer Maintenance:** Keep the lockable central drawer key in a safe place and use gentle cleansers on the surfaces to maintain the finish.

Troubleshooting

- **Desk Wobbles:** Ensure all screws are tightly secured and the desk is on an even surface.
- **Damage on Delivery:** Photograph any damage and contact customer support with images to process a replacement or refund.
- **Missing Parts:** Verify against the inventory list in the manual and contact support for any missing components.

Customer Support

For additional help, reach out to our 24/7 customer support team at support@workprodesks.com or call 1-800-555-0199.

Order Issues: - To amend or cancel orders, contact us within 24 hours. - For refunds and replacements, submit a claim with relevant photographs if damage occurred.

Warranty

Your WorkPro Flexi Desk comes with a 2-year warranty covering defects in materials and workmanship. For further details, refer to the warranty section of this manual or visit our website.

Thank you for choosing the WorkPro Flexi Desk. We hope it makes your workspace more productive and enjoyable!