

Zephyr Breeze 3000 Hair Dryer User Manual

Table of Contents

1. Introduction
2. Key Features
3. Specifications
4. Safety Instructions
5. Setup and Usage
6. Care and Maintenance
7. Troubleshooting
8. Warranty and Support Information
9. Compliance

1. Introduction

Thank you for purchasing the Zephyr Breeze 3000 Hair Dryer. This advanced hair styling tool is designed to provide you with salon-quality results in the comfort of your own home. With state-of-the-art technology and innovative design, achieving the perfect style has never been easier.

2. Key Features

- **2000W Professional Motor:** Ensures fast drying and a long lifespan.
- **3 Heat Settings & 2 Speed Settings:** Customize your drying experience to suit your hair type.
- **Ionic Conditioning:** Reduces frizz and enhances shine for a smooth finish.
- **Cool Shot Button:** Locks your style in place.
- **Removable Air Filter:** Easy cleaning to maintain optimal performance.

- **Ergonomic Design:** Lightweight and balanced for comfortable handling.
-

3. Specifications

- **Power:** 2000 watts
 - **Weight:** 1.5 lbs (0.68 kg)
 - **Cord Length:** 9 feet (2.74 meters)
 - **Attachments:** Concentrator nozzle, diffuser
 - **Warranty:** 2-year limited warranty
-

4. Safety Instructions

- Do not use the hair dryer near water or with wet hands.
 - Ensure the voltage of the device matches the local power supply.
 - Unplug after use and before cleaning.
 - Do not block the air vents.
 - Always keep the device out of reach of children.
-

5. Setup and Usage

Step 1: Attach the desired nozzle or diffuser to the mouth of the dryer.

Step 2: Plug into a standard power outlet. Do not use extension cords with this device.

Step 3: Select your preferred speed and heat setting using the switches located on the handle.

Step 4: Activate the Cool Shot button for a blast of cool air to set your style.

Step 5: Once finished, switch off the device and unplug it.

6. Care and Maintenance

- Clean the air filter regularly by removing it and washing it with warm soapy water.
 - Wipe the exterior with a damp cloth and dry immediately.
 - Store in a cool, dry place when not in use.
-

7. Troubleshooting

Problem: Hair dryer does not turn on. - **Solution:** Ensure the device is plugged in and the power outlet is functional. Try resetting by unplugging and pressing the power button for 10 seconds.

Problem: Low airflow or overheating. - **Solution:** Clean the air filter and ensure the vents are not blocked.

Problem: Unusual noise or vibration. - **Solution:** Check attachments are secured correctly. If problem persists, contact customer support.

8. Warranty and Support Information

This product includes a 2-year limited warranty covering defects in materials and workmanship. For support, please contact us at support@zephyrco.com or call 1-800-555-0199.

9. Compliance

The Zephyr Breeze 3000 complies with all applicable safety standards and regulations. Please refer to the compliance section for detailed information.

Thank you for choosing the Zephyr Breeze 3000 Hair Dryer. We hope you enjoy a wonderful styling experience!